




KONGSBERG

INSTALLATION MANUAL

HMS 300

Helideck Monitoring System





KONGSBERG

HMS 300 Helideck Monitoring System

Installation Manual

M450-70/7.0

July 2023 © Kongsberg Maritime AS

Document history

Document number: M450-70 / Revision 7.0		
Rev. 1.0	October 2021	First version.
Rev. 2.0	December 2021	Updated repeater light control unit enclosure drawing. Updated HMI Unit dimensions and drawing. GSN router dimensions included.
Rev. 3.0	January 2022	Updated GSN router interface schematics.
Rev. 4.0	February 2022	Updated with survey of helideck and wind sensor. HMS 300 wiring diagram updated.
Rev. 5.0	May 2022	Updated procedure and text in chapter 12. Updated check list in Appendix A. CAP 437 requirement on 4 Hz wind data output rate is described in chapter 8.1.
Rev. 6.0	October 2022	Configuration of Helimet output included. Updated with survey of Gill wind sensor. Updated with latest HMI hardware. Appendix with description of how to connect helideck status light included.
Rev. 7.0	July 2023	Corrected description of wave and water lever system with IP range for RangeFinder sensor. The Gill wind sensor is added to the list of meteorology sensor interfaces.

Copyright

©Kongsberg Maritime AS

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or otherwise copied without prior permission from Kongsberg Maritime AS.

Note

The information contained in this document remains the sole property of Kongsberg Maritime AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Maritime AS.

Kongsberg Maritime AS endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.

Warning

The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. The user must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.

Kongsberg Maritime disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.

Comments

To assist us in making improvements to the product and to this manual, we welcome comments and constructive criticism.

e-mail: km.seatex@km.kongsberg.com

Table of contents

Glossary	10
ABOUT THIS MANUAL	13
HMS 300	14
System description	14
System diagram	15
Scope of supply	16
Basic items	16
Additional required items	17
Additional items	17
Main system units	19
Processing Unit description	19
EGDE/HMI Unit description	19
MRU description	20
MGC description	20
Repeater lights description	20
Repeater lights control unit/module description	21
Meteorological sensors	21
Wave and water level system	21
Product restrictions	21
Restrictions in export	21
Restrictions in guarantee	22
Restrictions in use	22
General safety rules	22
Network security	23
Support information	23
PREPARATIONS	25
Installation drawings	25
Necessary tools and equipment	25
IMU transportation box	26
Worker skills	26
Determining the location of system parts	26
Processing Unit and HMI Unit location	26
IMU location	27
IMU Junction Box location	28
Monitor location	28
Repeater lights location	28
Repeater lights Control Unit location	29
Meteorological sensors location	30

Wave and water level system	31
Cabinet requirements	31
INSTALLING THE PROCESSING AND HMI UNITS	32
System units pre-installed in a rack	32
Installing the delivered rack	32
Mounting the Processing and HMI Units in a rack	33
Cables HMS Processing Unit	34
Processing Unit cable installation procedure	36
Cables EDGE/HMI Unit	37
HMI Unit cable installation procedure	38
INSTALLING THE MRU AND JUNCTION BOX	39
Installing the MRU with wall mounting bracket	39
Installing the MRU with protected mounting bracket	41
Installing the MRU junction box	45
Cables	46
Cable from Processing Unit to junction box	46
Cable specification	46
MRU to Processing Unit cable wiring	46
Junction box to Processing Unit cable installation procedure	47
INSTALLING THE MGC AND JUNCTION BOX	49
Installing the MGC and Junction Box	49
Cables	49
Cable from Processing Unit to MGC JB7 junction box	50
Cable specification	50
MGC to Processing Unit cable wiring	50
Junction box to Processing Unit cable installation procedure	51
INSTALLING THE REPEATER LIGHTS AND CONTROL UNIT	52
Installing the repeater lights	52
Installing the repeater light control unit	56
INSTALLING THE METEOROLOGICAL SENSORS	58
Wind sensor	58
Multi-weather sensor	60
Dual-pressure sensor	61
Cloud height sensor	63
Visibility sensor	64
Connection box for meteorology sensors	64
Wiring of meteorology sensors	65
Wind sensor	65
Multi-weather sensor	66

Dual-pressure sensor	68
Cloud height sensor	69
Visibility sensor	70
Sea water temperature sensor	72
INSTALLING THE WAVE AND WATER LEVEL SYSTEM	73
About the RangeFinder sensor	73
Sensor location and orientation	73
MET sensor power rail	75
SURVEY OF SENSORS ON VESSELS.....	76
Vessel reference system definition	76
Surveying the MRU.....	77
Surveying the MGC.....	79
Alignment surfaces	81
Surveying the helideck	82
Surveying the wind sensor	83
Survey accuracy	85
CABLE LAYOUT AND INTERCONNECTIONS	86
Cable plan.....	86
Interconnections	88
SETTING TO WORK	89
Setting to work summary	89
Verifying that the HMS is ready for operational use.....	90
LED indicators Processing Unit	90
LED indications.....	90
LED indicator on EDGE/HMI Units.....	90
Configuration management description.....	91
Entering HMS 300 VMS Core configuration.....	91
Required system configuration.....	91
Vessel configuration	91
Configuring the MRU	98
Helimet output configuration.....	100
COMMISSIONING.....	103
DRAWINGS	104
Processing Unit dimensions	105
HMI Unit dimension	106
MRU dimensions.....	107
MRU wall mounting bracket dimensions.....	108
MRU protected mounting bracket dimensions.....	109
MRU junction box dimensions.....	110
MRU Ex enclosure dimensions.....	111

Meteorology sensor connection box dimensions	112
Multi-weather sensor dimensions.....	113
Cloud height sensor dimensions.....	114
Shock absorber dimensions	115
Visibility sensor dimensions.....	116
RangeFinder sensor dimensions.....	117
RangeFinder hand rail mounting bracket dimensions.....	118
Multi power serial DIN rail dimensions.....	119
Phoenix contact DIP switch settings	120
System components and schematics.....	121
Power diagram.....	122
Wiring diagram.....	123
Repeater light dimensions	124
Repeater light schematics.....	125
Repeater light control unit enclosure dimensions	126
Repeater light control unit enclosure wiring diagram	127
Repeater light control unit enclosure arrangement.....	128
TECHNICAL SPECIFICATIONS	129
Performance specifications.....	129
MRU	129
Wind sensor, optional.....	129
Multi-weather sensor, optional.....	130
Dual-pressure sensor, optional	130
Cloud height sensor, optional.....	130
Visibility sensor, optional	131
RangeFinder Motion sensor, optional	131
Weights and outline dimensions.....	131
Processing Unit	131
HMI Unit (dual).....	131
MRU Unit.....	131
MRU wall mounting bracket.....	132
MRU protected mounting bracket	132
MRU junction box	132
Wind sensor, optional.....	133
Multi-weather sensor, optional.....	133
Dual-pressure sensor, optional	133
Cloud height sensor without damper, optional.....	133
Visibility sensor, optional	133
RangeFinder Motion sensor, optional	134
RangeFinder sensor hand rail mounting bracket, optional	134
Repeater light	134

Repeater light control unit enclosure	134
GSN router	134
Connection box for meteorology sensors	135
Power specifications	135
Processing Unit	135
HMI Unit (dual).....	135
MRU Unit.....	135
Wind sensor, optional.....	135
Multi-weather sensor, optional.....	136
Dual-pressure sensor, optional	136
Cloud height sensor, optional.....	136
Visibility sensor, optional	136
RangeFinder Motion sensor, optional	136
Repeater light	136
Repeater control unit.....	137
GSN router.....	137
Environmental specifications	137
Processing Unit	137
HMI Unit	137
MRU Unit.....	138
MRU junction box	138
Wind sensor, optional.....	138
Multi-weather sensor, optional.....	139
Dual-pressure sensor, optional	139
Cloud height sensor, optional.....	139
Visibility sensor, optional	139
RangeFinder Motion sensor, optional	139
Repeater light	140
Repeater light control unit enclosure	140
Connection box for meteorology sensors	140
External interface specifications.....	140
Processing Unit	140
HMI Unit	141
MRU Unit.....	141
Product safety specifications	141
Processing Unit	141
Data output specifications	141
Processing Unit	141
Data input specifications	141
Processing Unit	141
Cable specifications.....	142
MRU cable.....	142
Cable from Processing Unit to MRU/MGC junction box	142

Data cable	142
Repeater light cable	143
Repeater light control unit cable.....	143
INTERFACE DESCRIPTIONS	144
Processing Unit interfaces	144
Front interfaces Processing Unit	144
Rear interfaces Processing Unit	144
RS-422 A and B signal definition.....	145
COM 1 and COM 2	146
Connector board	146
Ethernet connection	149
HMI Unit interfaces.....	150
Front interface HMI Unit.....	150
Rear interface HMI Unit.....	151
Ethernet connection	151
Meteorology sensor interface	152
GSN router interfaces.....	153
EQUIPMENT HANDLING	155
Taking delivery.....	155
Unpacking and handling.....	155
Storage.....	155
Health and safety	156
Disposal	156
Virus protection	156
REFERENCES.....	157
A CHECK LIST	158
B STATUS LIGHT	159
Alarm signal	159
External light relay box	160
Status light control panel.....	161
Installation.....	161
C NMEA PROTOCOLS	163
Wind speed and direction data.....	163
MWD message	163
MWV message.....	163
Pressure, temperature and humidity data	164
XDR message.....	164
Sea water temperature	165
Heading data.....	165
HDT message.....	165

HDG message.....	165
Position and speed data	166
GGA messages	166
GLL messages	167
VTG messages	167
RMC messages	168
Time sync data.....	168
ZDA message	168
D FREE AND OPEN SOURCE SOFTWARE	170
BSD license	170
Curl license	171
f2c license	171
GCC license.....	172
GNU general public license, version 2.....	173
GNU general public license, version 3.....	177
GNU lesser general public license, version 2.1.....	185
GNU lesser general public license, version 3.....	192
GNU C library license	194
ISC license.....	196
OpenSSL license	197
OpenSSH license	200
TinyLogin license	203
X11 license	205
Mosquitto license	205
Google Protobuf license	205
Libmodbus license.....	206

Glossary

Abbreviations

CG	Centre of Gravity. The mass centre of a vessel. This is normally the location with least linear acceleration, and hence the best location for measurements of roll and pitch.
CGND	Communication ground.
CL	Centre line. Is the longitudinal axis along the centre of the ship.
GGND	The MRU and MGC ground.
GPS	Global positioning system
GUI	Graphical user interface
HMI	Human machine interface
LED	Light emitting diode
LGND	Logic ground
MP	Monitoring Point
MRC	Special software delivered with all MRU units. Running on a PC under Windows XP, Vista and 7. With this software the user can set up the MRU according to his application by use of the delivered configuration cable. The MRC software is used to change the configuration parameters, to check the internal status, etc.
MRU	Motion Reference Unit. This is the inertial sensor within the HMS measuring dynamic linear motion and attitude.
MSL	Mean Sea Level. In the HMS software this means the design water line of the vessel on which the HMS system is installed.
NMEA	National marine electronics association. NMEA 0183 (reference IEC 61162) is a standard for interchange of information between navigation equipment.
PGND	Power ground
RMS	Root mean square
QFE	Air pressure at helideck level
QNH	Air pressure at mean sea level
SHR	Significant heave rate. The heave rate calculation for the CAP 437.
UTC	Universal Time Coordinated. This is the official time in the world and has replaced GMT (Greenwich Mean Time) as the official time.
WEEE	Waste Electrical and Electronic Equipment

Definitions

Alignment	Is the process of adjusting the current internal navigation frame in the instrument to the true external frame.
Attitude	The orientation relative to the vertical axis of a vehicle. Heading is not included. If heading is included, the word "orientation" is used for the vehicle.
b-frame	Body frame. An orthogonal frame fixed to the MRU housing or to the vehicle where the MRU is fixed.
g-frame	Geographic frame. An orthogonal frame having axes pointing North, East, and Down at the current location of the vehicle.
Heave	The vertical dynamic motion of a vehicle and defined positive down. Heave position and velocity are dynamic motion variables calculated for a selected average heave period.
Pitch	A rotation about the pitch axis is positive when the bow moves up. Normally, pitch means the dynamic pitch angle motions.
Roll	A rotation about the roll axis is positive when starboard side of the vehicle moves down. Normally, roll means the dynamic roll angle motion.
Starboard	When looking in the bow direction of a vehicle, this is the right hand side of the vehicle.
Yaw	A rotation about the vertical axis is positive when turning Eastward (Clockwise) when the vehicle cruises in North direction. Normally, yaw means the dynamic yaw motion.

About this manual

Purpose of manual

This installation manual provides you with the descriptions and procedures required to install the HMS system on a vessel. For more detailed information about the operational use of the product, please refer to the *HMS 300 Operator manual*.

Target audience

This manual is intended for technical personnel such as skilled shipyard workers, electricians, qualified engineers, naval architects or system integrator company for installation and configuration of the HMS system.

License information

An export license is required for the export of the Inertial Measurement Units (MGC and MRU).

Registered trademarks

MGC® is a registered trademark in Norway and Europe.

Windows® and Windows 10® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Maintenance purposes

This manual is also intended as reference material for the maintenance personnel. Keep this manual for later use.

HMS 300

System description

The HMS 300, Helideck Monitoring System, measures the helideck motion during helicopter pre-landing and on-deck operations. HMS 300 monitors the helidecks acceleration, heave velocity, inclination, roll and pitch in real-time.

The HMS 300 will improve flight and passenger safety in challenging environments by providing real-time monitoring of helideck motion and weather conditions.


The HMS 300 is fully compliant with the prevailing recommendations and guidelines issued by the Civil Aviation Authorities in the UK, Norway and Brazil. The HMS 300 is compliant with the CAP 437 from September 2018 and accompanying Helideck Certification Agency (HCA) document revision 9b. In addition the HMS 300 is compliant to NOROG ver. 9.2 for the Norwegian sector and NORMAM-27 for the Brazilian sector.

The HMS 300 will monitor and present the Motion Severity Index (MSI) and Wind Severity Index (WSI) data together with significant heave rate (SHR), inclination, roll and pitch of the helideck in real-time. The system uses the Inertial Measurement Units MRU (models E, H, 5 or 5+) or MGC (models R2 or R3) to precisely monitor vessel motion and accelerations in the helideck centre. These data are transferred to the Processing Unit, which processes helideck motion data and MSI and WSI figures to determine whether the helicopter operation is safe or not.


Live vessel data from the system will be available through the Kognifai cloud based digital platform (optional). The Web access will be available to customers through a paid service. This web service will assist helicopter operators in planning the flight prior to take-off from the heliport. Both onboard and onshore personnel can monitor helideck movements and meteorological data in real-time and see the same operational picture in order to increase operational awareness.

The HMS 300 is a two-module solution with a Processing Unit and an EDGE Unit (HMI Unit) connected via Ethernet. The Processing Unit runs critical computations independent of the user interface on the EDGE Unit to ensure continuous and reliable operation. The EDGE Unit presents the helideck motion and the weather conditions in an easy-to-understand format.

The illustration shows a typical view for the operator on the EDGE Unit (HMI Unit).



System diagram



Units	Cables
A Wind sensor	1 Wind data
B Meteorological sensor	2 Pressure, temperature and humidity data
C Inertial Measurement Unit (IMU)	3 IMU data
D Junction box	4 Ethernet cable
E GSN router	5 Monitor cable
F Monitor	6 Ethernet cable
G EDGE Unit (HMI Unit)	7 Power and data cable
H Processing Unit	8 Alarm signal cable
I Control Unit for repeater lights	9 Data cable
J Repeater lights	10 Power and data cable
K External light relay box	
L Status light control panel	
M Status light (optional)	

Note

The EDGE/HMI Unit (item E) may be supplied with two (2) IOT units inside and will then require two (2) Ethernet cables (item 4) to be installed. See Chapter 14 for detailed drawings.

Note

To apply with CAP 437 of September 2018 the wind data have to be output at 4 Hz. This require a separate wind sensor for CAP 437 installation..

Scope of supply

Basic items

These are the basic items provided with an HMS system with minimum meteorological instrumentation which meet the requirements for ships with less or equal to 12 helicopter landings per year.

Units

- Processing Unit (2U)
Part number M450-10
- EDGE/HMI Unit (1U)

- Part number M450-11
- Repeater light
Part number M450-60
- Repeater light control unit
Part number M450-61
- Optional: Repeater light control unit mounted within enclosure
Part number M450-64

Cables

- Power cable to Processing and HMI Unit
Two metres length, part number G032-10
- Power and communication cable to repeater lights
Delivery specific length, part number M450-63

Other items

- Software recovery stick
Part number M450-07
- Product manual
Part number M450-72

Additional required items

Observe the additional items which are required for installation and/or operation. They can be ordered from Kongsberg Seatex AS or purchased locally.

- Inertial Measurement Unit, MRU or MGC
MRU models MRU 5+, MRU 5, MRU E, MRU H.
MGC models R2, R3.
- A 19-inch rack for mounting of the rack components
(minimum 4U space is required if rack-mountable keyboard/mouse is use)
- Monitor
(recommended resolution 1280 x 1024, minimum resolution 1024 x 768)
- Keyboard and mouse
- Multi power rail with serial DIN and net switch
Part number M410-75
- GSN router, Cisco 891-24X with 24 ports
Part number 417936

Additional items

The product can optionally be delivered with:

Wind sensor

- The wind sensor (Wind Speed/Direction), part number M440–59.
Including:
 - The wind sensor, part number M410–51.
 - Wind sensor mounting bracket, M410–34.

Multi-weather sensor

- The multi-weather sensor (Wind Speed/Direction, Air Temperature, Barometric Pressure, Humidity) with heating.
Including:
 - Multi-weather sensor, part number M440-58
 - Power supply, part number G072-78
 - Mounting rod, part number M410-68
 - Connection box, part number M410-69

Dual barometric pressure sensor

- The dual pressure sensor has packet number MET-S-2XPressure.
Including:
 - Dual pressure sensor, part number M440–50.

Cloud height sensor

- The cloud height sensor with sky condition software and heating has packet number MET-S-Cloud.
Including:
 - Cloud height sensor, part number M410-44.
 - Shock absorber, part number CT35022
 - Phoenix converter box, RS–232/485, part number 50.081
 - Junction box, part number Termbox-1200

Present weather and visibility sensor

- The present weather and visibility sensor with heating has packet number MET-S-Visibility.
Including:
 - Present weather and visibility sensor with heating, part number M410-46
 - Power supply, 24 V DC for operation, part number G071-78
 - Power supply, 240 V AC/24 V DC for heater, part number G072–59
 - Phoenix converter box, RS–232/485, part number 50.081
 - Connection box, part number M410-69

Wave and water level system

- Significant wave height and water level system, part number MET-S-WWL.

Including:

- RangeFinder Narrow Motion sensor with range 2 to 95 meters, part number M440-40

Main system units

Processing Unit description

The Processing Units runs the processing software. The software handles all critical computations. It is connected to the HMI Unit via Ethernet and network switch.



The unit receives data from the Inertial Measurement Unit and the meteorological sensors. The unit outputs status light signals to the repeater lights.

The unit is designed to fit standard 19" racks. It is typically installed on the bridge or in the instrument room.

The power on/off switch, local area network (LAN) port and USB connection are located behind the lid to the left on the front panel. Push lid on left side to open.



LAN 1 is type RJ-45, 10/100 Mbits/s and reserved for support. The rear panel of the unit contains communication interface ports for interfacing to external equipment. These ports are individually galvanically isolated.

Note

The USB ports are not compatible with USB 3 devices.

EGDE/HMI Unit description

HMI Unit holds the operator software which is used for configuration of the system, performance monitoring and presentation of helideck motion and weather conditions.



The unit is a 1U unit designed to fit standard 19" racks. It is typically installed on the bridge or in the instrument room.

The power on/off switch and two USB connection are located on the front panel. The rear panel of the unit contains power inlet, LAN port, mouse and keyboard ports, a display port and four USB ports.



Note

For some HMS 300 installations the 1U HMI Unit will be delivered with two EDGE Units installed.

MRU description

The MRU (Motion Reference Unit) is designed for motion measurement in marine applications. The unit incorporates 3-axis sensors for linear acceleration and angular rate, along with complete signal processing electronics and power supply. The MRU outputs absolute roll and pitch as well as dynamic acceleration in the north, east and down direction, velocity and relative position.

The interior of the MRU is divided into two sub-assemblies consisting of an electronic part and a sensor part. The sensor unit shall not be repaired or serviced by anyone else than Kongsberg Maritime AS.



MGC description

The MGC (Motion Sensor and Gyro Compass) is a north-seeking gyro compass. It is based on three Ring Laser Gyros (RLG) and three linear accelerometers. The unit can also be operated as an inertial navigation system. Then it will output position and heading.



Repeater lights description

A sufficient number of repeater lights shall be provided on the helideck to ensure that the flight crew will be able to easily see at least one light regardless of the orientation of the helicopter on the helideck. This is expected to require at least four lights on the helideck. The repeater lights on the helideck must be connected to a control module mounted in an enclosure as close as possible to the HMS Processing Unit.



Each repeater light is connected to the control module with the Orga combined power and communication cable SLxx3 (Strobeline cable). This cable is armoured offshore grade single pair halogen free signal cable.



Repeater lights control unit/module description

The repeater light control module (in an enclosure if required) should be mounted as near to the HMS Processing Unit as possible to ensure a short Ethernet cable run between the two system.



Meteorological sensors

For technical description of the meteorological sensors:


- wind sensor
- multi-weather sensor
- dual-pressure sensor
- cloud height sensor
- visibility sensor

see their individual documentation referred to in *References* on page 157.

Wave and water level system

The wave and water level system is delivered with the Miros SM-140 RangeFinder Narrow Motion sensor and Miros RangeFinder software.

See their individual documentation referred to in *References* on page 157.



Product restrictions

Restrictions in export

Export of the Inertial Measurement Unit (MGC or MRU) requires an export license.

Note

*Notice to importer: The MRU product specified in this document is shipped from Norway in accordance with The Ministry of Foreign Affairs' Official Notification on Export Control and U.S. Export Administration Regulations (EAR). The MRU may therefore be subject to restrictions from your national export control authorities if exported/re-exported from your country. **Any valid and approved export license granted to Kongsberg Seatex AS from the Norwegian Ministry of Foreign Affairs is not an authorization for you to export/re-export the MRU.***

Note

Notice to importer: The MGC product specified in this document is shipped from Norway in accordance with The Ministry of Foreign Affairs' Official Notification on Export Control and U.S. Export Administration Regulations (EAR). The MGC product will be subject to restrictions if re-exported from your country, including but not limited to a re-export license from the U.S. Government.

Restrictions in guarantee

Changes or modifications to the product not explicitly approved by Kongsberg Maritime AS will void the guarantee.

The liability of Kongsberg Maritime AS is limited to repair of this system only under the given terms and conditions stated in the sales documents. Consequential damages such as customer's loss of profit or damage to other systems traceable back to this system's malfunctions, are excluded. The warranty does not cover malfunctions of the system resulting from the following conditions:

- Incorrect power connection.

Restrictions in use

The HMS system is designed for use on board marine surface operated vessels with linear acceleration less than $\pm 30 \text{ m/s}^2$ ($\pm 3g$) and an angular rate range less than $\pm 75 \text{ }^\circ/\text{s}$.

Only relative dynamic heave position is calculated and the measurements are limited by the selection of their motion periods available in the range 1 to 25 seconds.

The HMS system is designed as a landing aid only and is not to be used as a landing guide in helicopter operations.

General safety rules

General safety guidelines to be followed when working in mast and on deck.

Network security

Equipment manufactured by Kongsberg Maritime AS is frequently connected to a local area network (LAN). Connecting any computer to a network will always expose the data on that computer to all other computers connected to the same network. Several threats may immediately occur:

- Remote computers can read the data.
- Remote computers can change the data.
- Remote computers can change the behavior of the computer, for example by installing unwanted software.

Usually, two parameters are used to define the threat level:

- 1 The likelihood that any remote connection will do any of the above.
- 2 The damage done if a remote connection succeeds doing this.

Because Kongsberg Maritime AS has no information regarding the complete system installation, we can not estimate the threat level and the need for network security. For this reason, we can not accept responsibility for network security. Systems provided by Kongsberg Maritime AS are regarded as stand-alone offline systems, even though they may be connected to a network for sensor interfaces and/or data distribution.

Note

No network safety applications are installed on any Kongsberg Maritime computers. The computers are thus not protected against viruses, malware or unintentional access from external users.

Securing the system itself has no meaning unless there is a policy in place that secures all computers in the network. This policy must include physical access by trained and trusted users. The customer/end user of the system will always be in charge of defining and implementing a security policy, and providing the relevant network security applications.

Note

Kongsberg Maritime AS will not accept any responsibility for errors and/or damages caused by unauthorized use or access to the product.

Support information

- **Company name:** Kongsberg Maritime AS, Seatex
- **Address:** Havnegata 9, 7010 Trondheim, Norway
- **Switchboard:** +47 73 54 55 00
- **Duty phone:** +47 33 03 24 07 (24 hours)
- **E-mail address:** km.support.seatex@km.kongsberg.com
- **Website:** <http://www.kongsberg.com>

KM-Support App

Support is also available from the KM Support App. This app is available for free in App Store and Google Play.

Preparations

Installation drawings

General arrangement drawings of the ship should be acquired to simplify determination of offsets between the Inertial Measurement Units, MRU or MGC, the ship's centre of gravity (CG), the centre of the helideck, the air pressure sensor and water level system.

For some applications, references for calibration of roll and pitch measurements, and the meteorological sensors, are needed.

Outline dimension drawings are included in this manual.

Related topics

- *Drawings* on page 104

Necessary tools and equipment

We assume that you are equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks, such as screwdrivers, pliers, spanners, a cable stripper etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Unless stated otherwise, all mounting equipment (such as bolts, nuts, washers, screws etc.) referred to within this document is to be supplied by the customer or the shipyard.

Special equipment

A computer with the MRC+ configuration software installed.

IMU transportation box

The unit is shipped in a specially designed transportation box. Keep the unit stored within the box until everything is ready for installation of the unit in the mounting bracket.

Note


After the unit has been installed, please keep the transportation box. The unit must be shipped in this box for maintenance or repair in order to maintain the warranty.

Worker skills

Trained electrical workers.

Determining the location of system parts

These are recommendations on where to install the various system parts for a best possible system performance.



Processing Unit and HMI Unit location

Consider these factors when installing the unit:

- The unit is designed for indoor installation. The best location is typically in the instrument room or on the bridge
- The unit fits on rails in a 19" rack or console.
- The unit has an internal fan and requires free airflow from the rear and out to the sides. It is recommended that ventilation or air conditioning is provided in order to keep the ambient operating temperature at around 20 °C.

- Avoid placing the unit in locations with heavy vibrations, strong electronic fields (close to transformers), excessive heat.
- Keep the area around the unit free from dust and static electricity.
- All connections to the unit are on the rear side and available space for cable connections and service must be provided.

Related topics

- *Processing Unit dimensions* on page 105
- *HMI Unit dimension* on page 106

IMU location

Correct location of the unit is important for the system performance. Consider these factors when installing the unit.

- The unit is designed for installation in an indoor environment and for operation within the temperature range.

Note

The MRU E can be installed in an outdoor environment inside a cabinet or enclosure.

- The unit should be mounted underneath the helideck or as close to it as possible. This location will ensure the best possible acceleration measurements and avoid errors in these measurements due to long lever arms and ship-hull torsion.

Below is a table that shows recommended maximum distance vector (x, y, z) on the lever arms from the MRU and MGC to the helideck centre. Local conditions such as vibration in the hull and helideck structure may reduce the distances indicted to get the acceleration measurements within the requirement.

- Mount the unit along the longitudinal axis of the vessel if possible. Avoid mounting the unit out to the side of the vessel.
- If the helideck is located in an Ex zone, the IMU must be mounted in an Ex enclosure.
- Mount the unit onto a rigid and stable structure. Mount the unit directly onto the hull structure, if possible.

Distance to helideck center	<5 meter	<15 meter	<20 meter
MRU H & E (5th generation)	X		
MRU 5 & 5+ (5th generation)		X	
MGC R2 & R3			X

Be aware of vibrations

The unit is sensitive to vibrations. Avoid mounting the unit on thin walls that may resonate with vibrations driven by machinery, propellers, pumps or motors.

Be aware of temperature changes

The unit is sensitive to frequent temperature changes. The safest location for the unit is where the temperature is low and the changes in temperature are slow.

Be aware of corrosion

The unit must not be subject to an environment which can cause corrosion. For example exposure to sea water.

Related topics

- *MRU dimensions* on page 107

IMU Junction Box location

Consider these factors when installing the Junction Box:

- Mount the Junction Box on the floor or on the wall within three metres from the Inertial Measurement Unit.

The junction box is connected to the IMU with a 3-metre cable.

Related topics

- *MRU junction box dimensions* on page 110

Monitor location

When installing the monitor, consider the following:


- The unit is designed for installation in an indoor environment and for operation within the temperature range. The best location is typically on a table in the instrument room or on the bridge mounted close to the HMI Unit.
- The HMI Unit and the monitor should be mounted close to each other to reduce the length of the VGA cable.
- It is recommended that the area around the unit is kept free from dust and static electricity.

Repeater lights location

Consider these factors when installing the repeater lights:

- A sufficient number of lights must be provided so that the flight crew can easily see at least one light, or set of lights, regardless of the orientation of the helicopter on the helideck.

This means that at least four lights, or sets of lights, are required. They should be arranged in a cross, oriented 45 degrees to the bisector of the Obstacle Free Sector (OFS) on the helideck.



A Repeater lights

- The repeater lights shall be connected to a Control Unit. The Control Unit must be located as close as possible to the Processing Unit.
- Install the repeater lights on a rigid, horizontal surface.
- Make sure that the operation of the repeater lights is not obstructed by any shadows and/or objects around it.
- Make sure that the repeater lights are accessible for maintenance.
- Make sure that the location is clean and dry before installation.
- Make sure that the photocell on each repeater light has the clearest possible view on the environment. Make sure that each photocell points away from obstacles such as: light sources, other lights, other equipment and structure.
- If it is not possible to point the photocell on one or more of the repeater lights away from obstacles or light sources, turn off the photocell of that light.

Related topics

- *Repeater light dimensions* on page 124

Repeater lights Control Unit location

Consider these factors when installing the repeater light Control Unit:

- The Control Unit must be located as close as possible to the Processing Unit.
That is because a short Ethernet cable should connect the two units.
- If required, the unit can be mounted inside an enclosure.
An enclosure with dimensions 300 x 400 x 120 mm is suitable.
- The unit can be mounted on a DIN rail.

Related topics

- *Repeater light control unit enclosure dimensions* on page 126

Meteorological sensors location

When installing the meteorological sensors, consider the following:

Wind sensor

- **For best wind measurements:** mount the sensor high up in the vessel and in a location with an undisturbed wind flow. Avoid mounting the sensor in a location where it is hidden by obstructions generating turbulent wind flows at the sensor location. A preferable location is high up in the vessel mast away from obstructions and heat sources.

Multi-weather sensor

Multi-weather sensor is a combined wind, temperature, humidity and pressure sensor.

- **For best wind measurements:** mount the sensor high up in the vessel and in a location with an undisturbed wind flow. Avoid mounting the sensor in a location where it is hidden by obstructions generating turbulent wind flows at the sensor location. A preferable location is high up in the vessel mast away from obstructions and heat sources.
- **For best air temperature and humidity measurements:** avoid mounting the sensor close to heat sources. A preferable location is high up in the vessel mast.
- **For best barometric pressure measurements:** mount the sensor in an area with clean, dry and non-conducting air.

Dual barometric pressure sensor

- **For best barometric pressure measurements:** mount the sensor in an area with clean, dry and non-conducting air.

Cloud height sensor

- Mount the sensor straight up (not tilted) on a ship installation.
- It is recommended to mount the sensor on the shock absorber.
- Mount the sensor with free sight to the sky.

Visibility and present weather sensor

- Mount the sensor in a location with undisturbed wind flow and at least two metres above the nearest deck. It is also important that there is no superstructure or flashing light sources nearby.

Related topics

- *Meteorology sensor connection box dimensions* on page 112
- *Multi-weather sensor dimensions* on page 113
- *Cloud height sensor dimensions* on page 114

- *Visibility sensor dimensions* on page 116
- *Shock absorber dimensions* on page 115

Wave and water level system

When installing the this system consider the following:

- Mount the RangeFinder sensor at or near the bow of the vessel.
- A mounting arrangement for the RangeFinder sensor have to be made at the ship yard. Optionally, a mounting arrangement for handrail mounting can be delivered (part number M440-47).
- The RangeFinder sensor has measurement range 2 to 95 meters. Ensure that the sensor is mounted within measurement range to the sea level.
- The location should be accessible for periodical cleaning and service.
- The sensor is not certified for installation in explosive atmospheres.

Related topics

- *RangeFinder sensor dimensions* on page 117
- *RangeFinder hand rail mounting bracket dimensions* on page 118
- *Installing the wave and water level system* on page 73

Cabinet requirements

The HMS system can be delivered with or without a cabinet. If the product is delivered with a cabinet, the cabinet components are pre-installed in the cabinet. If the product is delivered without a cabinet with pre-installed components, the Processing Unit and HMI Unit must be installed in a cabinet which is already in place on site. Consider the following to determine whether your cabinet is suitable for the installation.

- The rack must be securely mounted to the floor.
- The rack must be a standard 19-inch rack.
- The minimum depth of the rack must be 600 mm.
- The rack should have air inlet on top and bottom or ventilation splits on the sides. The Unit has ventilation on the sides. Forced ventilation may be required if the rack contains several electronic modules.
- The rack must be mounted in such a way that the minimum bending radius of the cables (on the rear side) is not exceeded.
- The rack must be connected to a grounded outlet.

Related topics

- *Mounting the Processing and HMI Units in a rack* on page 33

Installing the Processing and HMI Units

System units pre-installed in a rack

The HMS system can be delivered with or without a rack. If the product is delivered with a rack, the rack components are pre-installed in the rack.

The rack components in this system are:

- the Processing Unit
- the HMI Unit

With pre-installed components you have to mount the rack in a suitable location and carry out the cabling for the system.

Installing the delivered rack

Your system can be delivered with a rack with the Processing Unit and HMI Unit pre-installed.

Context

When mounting the rack, consider the following:

- Find a suitable location for the rack in the instrument room or bridge.
- Ensure that all cables are long enough to accommodate service from the front. The cables should be long enough to make it possible to pull each unit to the front of the rack for disconnection of cables.
- The rack must be mounted in such a way that the minimum cable bends (on the rear side) are not exceeded.

Caution

The rack must be connected to a grounded outlet.

Procedure

- 1 If not already mounted, attach the mounting plates to the rack feet using four bolts, washers and nuts at each foot.

- 2 Lift the rack into its mounting position.
- 3 Mark on the floor the position of the four attachment holes in the mounting rails.
- 4 Lift the rack away from its position.
- 5 Drill four holes in the marked positions on the floor.
- 6 Lift the rack into its mounting position again.
- 7 Use four bolts, washers and nuts and attach the rack to the floor.

Mounting the Processing and HMI Units in a rack

If your system is delivered without a rack, the Processing Unit and the HMI Unit shall be mounted in a 19" rack or cabinet. In addition you must carry out the cabling and interface configuration.

Context

Important

If you have a rack-mountable keyboard in your system, make sure that you have enough space in the rack for the keyboard. A rack-mountable keyboard and mouse will require 1U space in the rack.

The cable strain relief bracket allows for flexibility in the cables without putting stress on the vulnerable points on the cable.

Note

The Processing Unit and HMI Unit have a plastic film on top, and may have one underneath, to protect from transport scratches. This film must be removed before operation as the plastic film will reduce the heat transfer from the unit and thus cause temperature increase inside the unit.

Note

The recommended keyboard cable length is 3.3 m (10 feet) maximum without degradation. If longer keyboard cable is needed, please use keyboard extender.

Procedure

- 1 Find a suitable location for the units.
Typically on the bridge or in the instrument room.
- 2 Remove any plastic film from the units.
- 3 Place the units on rails or shelves in the 19" rack.


This to ensure that the unit is supported at the rear. Minimum 10 cm free space is needed behind the unit for connection of cables.

- 4 Fasten the units with four screws in the front.
- 5 Install the AC power cable in the power supply and to a suitable grounded power outlet.
- 6 The power supply chassis must be grounded to vessel ground.

Related topics

- *Processing Unit and HMI Unit location on page 26*
- *Cabinet requirements on page 31*
- *Processing Unit dimensions on page 105*
- *HMI Unit dimension on page 106*
- *Installing the delivered rack on page 32*
- *Multi power serial DIN rail dimensions on page 119*

Cables HMS Processing Unit



Units

- 1 WindObserver II (Gill) sensor connection box (not standard solution) *)
- 2 MET-sensor power rail with Phoenix converter and net switch

3 MRU or MGC junction box

4 HMS Processing Unit

Note

**) If an external wind sensor is to be used in combination with the Range Finder sensor system, a specific solution with extended ports is required.*

Cables

- A** Signal/power cable from HMS Processing Unit COM 13 to WindObserver II (Gill) sensor connection box (not standard solution) *)
- B** Serial cable from HMS Processing Unit COM 9 to multi power serial DIN terminal block
- C** Serial cable from HMS Processing Unit COM 12 to multi power serial DIN terminal block
- D** Serial cable from HMS Processing Unit COM 2 to multi power serial DIN Phoenix converter #1
- E** Serial cable from HMS Processing Unit COM 1 to multi power serial DIN Phoenix converter #2
- F** Ethernet cable from HMS Processing Unit LAN 2 to MET-sensor power rail net switch
- G** Signal and power cable from HMS Processing Unit COM 8 (MRU port) to MRU or MGC junction box
- H** Serial cable from HMS Processing Unit to Wind sensor interface
- I** Serial cable from HMS Processing Unit COM 11 to Gyro interface
- J** Serial cable from HMS Processing Unit COM 10 to GNSS/Seapath
- K** Ethernet cable from HMS Processing Unit LAN 4 to ship network infrastructure through GSN router port 20
- L** Ground cable
- M** Power cable to uninterrupted power supply
- N** Ethernet cable from HMS Processing Unit LAN 3 to repeater light

Processing Unit cable installation procedure

Note

Do not place the cable in between the tongues at the rear of the unit but fasten the cable with cable tie as illustrated.




-
- 1 Connect the 100 - 240 V AC ship's power supply to the power connector at the rear of the Processing Unit.
 - 2 Connect an Ethernet cable from a LAN port on the rear of the Processing Unit to the network on board the vessel through the GSN router.
 - 3 Connect the signal cables from the GNSS sensor and the Compass/Gyro to free terminals at the rear of the Processing Unit
 - 4 Connect the cable between the MRU port at the rear of the Processing Unit and the MRU or MGC junction box. See separate chapter on how to terminate the MRU or MGC sensor.
 - 5 Connect the number of cables required from the meteorological sensors to free terminals at the rear of the Processing Unit. See *Wiring of meteorology sensors* on page 65 on how to terminate the meteorology sensors.

Note

For maximum protection against lightning and for safety the wind sensor must be earthed via its mountings. This unit is NOT an intrinsically safe (IS) device. The unit MUST be earthed or grounded to an appropriate grounding point with a minimum of 6 mm² copper wire, via the M5 base screws. The cable screen must be joined with any cable screen continuing from the unit cable via a junction box. Do NOT connect the unit 0v, heading -ve, analog output 0v or digital 0v to the screen earth.

- 6 If a cloud and visibility sensor is part of the delivery, a converter of the RS-485 signals from these sensors to an RS-232 signal on the Processing Unit has to be used. See *Wiring of meteorology sensors* on page 65 on how to install the RS-485/232 converter and how to terminate the signals from the cloud and visibility sensor.
- 7 When all cables are connected, power on the Processing and HMI Units. The four LED indicators located on the front panel of the Processing Unit should then start to shine red. The LED indicator located next to the connector on the MRU or MGC sensor unit should start flashing indicating that the IMU receives power. If the software starts on both the Processing and the HMI Units, the installation is now completed and the setup of the configuration parameters can continue.

Cables EDGE/HMI Unit



Units

- 1 GSN router
- 2 HMI Unit
- 3 KVM switch
- 4 Monitor

Cables

- A Ethernet cable from HMI Unit to GSN router or switch
- B Monitor cable from HMI Unit to KVM switch
- C Power cable to uninterruptible power supply
- D Ground cable
- E Monitor cable from KVM switch to monitor

HMI Unit cable installation procedure

- 1 Connect the 100 - 240 V AC ship's power supply to the power connector at the rear of the HMI Unit.
- 2 Connect the Displayport (DP) cable from the EDGE/HMI Unit IOT-2 display port to the KVM switch.
- 3 Connect a Monitor cable from the KVM switch to the monitor.
- 4 Connect an USB cable from the EDGE/HMI Unit IOT-2 USB 3 to the KVM switch.
- 5 Connect an Ethernet cable from the EDGE/HMI Unit IOT-2 LAN to the GSN rourther port 15.
- 6 Connect an Ethernet cable from the EDGE/HMI Unit IOT-1 LAN to the GSN rourther port 9.
- 7 When all cables are connected, power on the Processing and HMI Units. The four LED indicators located on the front panel of the Processing Unit should then start to shine red. The LED indicator located next to the connector on the MRU or MGC sensor unit should start flashing indicating that the IMU receives power. If the software starts on both the Processing and the HMI Units, the installation is now completed and the setup of the configuration parameters can continue.

Installing the MRU and Junction Box

Installing the MRU with wall mounting bracket

A correct installation of the MRU Sensor Unit is important in order to ensure high quality and accurate measurements.

Context

The MRU can be mounted on board by use of the **wall mounting bracket** (MRU-M-MB4).


Note

After the installation of the MRU, please save the transportation container. The MRU must be shipped in this container for service or repair to maintain the warranty.

How to install the MRU with wall mounting bracket

- 1 Identify the best mounting location for the MRU. Preferably mount the Bracket on longitudinal or transversal bulkheads of the hull structure, this to assist alignment and to prevent vibration.
- 2 Preferably mount the MRU with the opening pointing downwards, as illustrated.
- 3 Reserve sufficient space below the Bracket for the MRU and the cable.
- 4 Mount the Bracket to the wall with the screws, pos. 5, before the MRU is mounted to the Bracket.
- 5 Clean the surface between the MRU and the Bracket carefully prior to assembly. Connecting surfaces between MRU and Bracket must in no way be damaged before mounting.
- 6 Mount the MRU to the Bracket with the screws, pos. 6.

Figure 1 MRU with wall mounting bracket



- 7 When disassembling the MRU from the Bracket for service purposes, only remove the screws, pos. 6. Do not remove the Bracket from its position.

Related topics

- *MRU dimensions* on page 107
- *MRU wall mounting bracket dimensions* on page 108

Installing the MRU with protected mounting bracket

A correct installation of the MRU Sensor Unit is important in order to ensure high quality and accurate measurements.

Context

The MRU can be mounted on board by use of the **protected mounting bracket** (MRU-M-MB6).


Note

After the installation of the MRU, please save the transportation container. The MRU must be shipped in this container for service or repair to maintain the warranty.

How to install the MRU with protected mounting bracket

- 1 Identify the best mounting location for the MRU on the wall. Preferably mount the Bracket on longitudinal or transversal bulkheads of the hull structure, this to assist alignment and to prevent vibration.
- 2 Mount the Bracket with the opening pointing downwards, as illustrated. Reserve sufficient space below the Bracket for the MRU and the cable.

Figure 2 Wall mounting with the Bracket opening pointing down



- 3 Mark and drill an M8 hole for the top screw, pos. 1, and enter the screw without tightening it completely. Align the bracket vertically using its own weight or by aligning it in relation to the wall. Drill two holes for the lower screws, pos. 2, and insert and securely tighten all three screws, using lock washers and nuts.

Figure 3 Wall mounting with the Bracket opening pointing down



- 4 Unscrew the cover on the bottom of the Bracket, as illustrated.

Figure 4 Bracket with cover



Figure 5 Bracket without cover



- 5 Fasten the MRU cable (MRU-M-CS8) to the MRU connector and insert the MRU into the bracket.

Figure 6 Bracket with the MRU and cable inserted



Note


The MRU mounting angles have to be modified by use of the MRU configuration to correspond with the actual mounting orientation of the MRU in the Bracket. Precise MRU orientation is important to ensure that high quality and accurate measurements are available to the host system.

- 6 Fasten the MRU to the Bracket with the four M4 screws, pos. 1, with lock washers and push down the cover caps , pos. 2, at the top of the screw holes, as illustrated, to ensure that water is not entering the holes.

Figure 7 The four mounting screws for the MRU



Figure 8 The cover caps entered above the screws



- 7 Mount the cover on the bottom of the Bracket with the three M4 screws, as illustrated.

Figure 9 MRU with wall mounting bracket



- 8 When disassembling the MRU from the Bracket for service purposes, do not remove the Bracket from its position only the MRU inside.

Related topics

- *MRU dimensions* on page 107

- *MRU protected mounting bracket dimensions* on page 109


Installing the MRU junction box

When mounting the MRU junction box, consider the following:

- The junction box can be placed on the floor or on a wall.
- Make sure that the location is within the length of the 3-metre cable.
- Provide for a minimum space of 100 mm below the connectors when using the cable MRU-E-CS8.

Procedure


- 1 Remove the junction box cover by unscrewing the four cover screws.
- 2 Place the junction box onto its mounting position.
- 3 Mark four M6 holes on the mounting surface for the junction box.
- 4 Remove the junction box.
- 5 Drill four M6 holes in the marked positions.
- 6 Check that no metal shavings have entered into the junction box while drilling. If so, remove the metal shavings.
- 7 Replace the junction box onto its mounting position.
- 8 Use screws with washers and self-locking nuts to attach the junction box to the mounting surface.
- 9 Replace the junction box cover and fasten it with the four cover screws.



Related topics

- *MRU junction box dimensions* on page 110

Cables



A MRU cable, MRU-E-CS8

B Junction box to Processing Unit cable, MRU terminal, ship cable

Cable from Processing Unit to junction box

Cable specification

Type	3 x 2 x 0.5 mm ² individually shield twisted pairs
Maximum length	100 m
Diameter	10 mm
Flame retardation	IEC 332-3/A

MRU to Processing Unit cable wiring

The MRU is connected to the Processing Unit with a cable which is terminated in the MRU junction box in one end and with a 10-pin terminal for the Processing Unit in the other end. The MRU is then powered from the Processing Unit.

Table 1 MRU to Processing Unit cable wiring

Processing Unit/MRU Pin no.	Signal	Pair no. Colour	MRU junction box Pin no.	MRU connector Pin no.
3	NC	Screen	Chassis (P3 side)	
10	24V_MRU	1 white	1 (P2 side)	R
1	GND	1 blue	2(P2 side)	B
9	RX_B	2 white	3(P2 side)	C
8	RX_A	2 blue	4(P2 side)	T

Table 1 MRU to Processing Unit cable wiring (cont'd.)

Processing Unit/MRU Pin no.	Signal	Pair no. Colour	MRU junction box Pin no.	MRU connector Pin no.
5	XIN/MRU_1PPS_P	3 white	23(P2 side)	U
2	LGND	3 blue	24(P2 side)	a

The MRU is supplied with 24 V DC power from the MRU port on the Processing Unit.

Note

The shield around each pair in the cable has to be individually isolated in the 10-pin terminal. The outer shield is connected to pin 3 (screen) in this terminal, which is an open end (not connected to earth). In the MRU junction box both the shield around each pair and the outer shield are terminated in pin 40 (chassis) on the P3 side.

Junction box to Processing Unit cable installation procedure

- 1 Enter the cable from the MRU port at the rear of the Processing Unit through one of the free nipples on the junction box. Ensure that the cable shield is in contact with the nipple for grounding before the cable is fastened to the box. Use the required number of clips to fasten the cable to the wall.

Note

Fill the nipples not used with self-bounding tape. Press the self-bounding tape together as ball and fill it into the nipple. Screw in the nipples properly afterwards to ensure it is watertight. This to fulfil the enclosure protection specification.

- 2 Insert each of the MRU to Processing Unit cable wires into the correct terminal on the user side (P2) and all cable shields to pin 40 (chassis) on the user side (P3) within the box. Ensure that the shield around each pair in the cable is individually isolated on the 10-pin terminal on the Processing Unit. The outer shield is connected to pin 3 (screen) on this terminal, which is an open end (not connected to earth).

Note

The junction box housing is grounded to earth through the screws for mounting the box to the wall or floor. Please note that if the foundation on which the junction box is mounted, is NOT connected to earth, one of the junction box mounting screws has to be connected to earth by connecting a wire from the screw to an object that is connected to earth.

User side P2

Pin	Signal description		Pin	Signal description
1	PWR+ (power +)		23	XIN (to MRU)
2	PWR- (power GND)		24	CGND
3	Com1_Out_B			
4	Com1_Out_A			


Installing the MGC and Junction Box

Installing the MGC and Junction Box

This chapter describes a shared MGC installation where the HMS 300 is one of many systems connected to the MGC. If the MGC installation is dedicated to the HMS 300 system only, then 24 VDC power to the MGC JB7 box can be supplied from the HMS 300 Processing Unit as described for the MRU installation.

For the physical installation of the MGC and the MGC JB7 junction box, refer to *MGC COMPASS R-series Installation Manual*.

Cables



- A MGC cable, MGC-E-CJB7
- B MGC JB7 junction box to Processing Unit cable, MRU port terminal, ship cable

Cable from Processing Unit to MGC JB7 junction box

Cable specification

Type	2 x 2 x 0.5 mm ² individually shield twisted pairs
Maximum length	100 m
Diameter	10 mm
Flame retardation	IEC 332-3/A

MGC to Processing Unit cable wiring

The MGC is connected to the Processing Unit with a cable which is terminated in the MGC JB7 junction box in one end and with a 10-pin terminal for the Processing Unit in the other end (MRU port). The MGC is powered with 24 V DC from an external source.

Table 2 MGC to Processing Unit cable wiring

Processing Unit/MRU Pin no.	Signal	Pair no. Colour	MGC JB7 junction box Pin no.	MGC connector Pin no.
3	NC	Screen		
9	RX_B	1 white	4 (J1)	C
8	RX_A	1 blue	5 (J1)	T
2	LGND	2 white	3 (J1)	a
2	LGND	2 blue	3 (J1)	a


It is recommended to terminate the two wires for the second pair (LGND/GND1) on the same terminal on both ends.

Note

The shield around each pair in the cable has to be individually isolated in the 10-pin terminal on the HMS PU. The outer shield is connected to pin 3 (screen) in this terminal, which is an open end (not connected to earth). Both the shield around each pair and the outer shield are terminated in cable gland on the cabinet which the MGC JB7 junction box is mounted within.

Junction box to Processing Unit cable installation procedure

- 1 Enter the cable from the MRU port at the rear of the Processing Unit to one of the free serial ports on the MGC JB7 junction box. We recommend to use COM1, but any free port (COM1 to 8) can be used.



- 2 Terminate the signal wires in the cable from the HMS 300 PU to COM1 (pin1 to 3) to the J1 terminals (marked red on the figure below).

J1														
COM1			COM2			COM3								
Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	Pin 9	Pin 10	Pin 11	Pin 12	Pin 13	Pin 14	Pin 15
TX1B+	TX1A-	GND1	RX1B+	RX1A-	TX2B+	TX2A-	GND2	RX2B+	RX2A-	TX3B+	TX3A-	GND3	RX3B+	RX3A-
COM4 COM5														
Pin 16	Pin 17	Pin 18	Pin 19	Pin 20	Pin 21	Pin 22	Pin 23	Pin 24	Pin 25	Pin 26	Pin 27	Pin 28	Pin 29	Pin 30
TX4B+	TX4A-	GND4	RX4B+	RX4A-	TX5B+	TX5A-	GND5	RX5B+	RX5A-	TXPB+	TXPA-	GND5	PPSB+	PPSA-

- 3 It is recommended to terminate the two wires for the second pair (LGND/GND1) on the same terminal on both ends.

Installing the Repeater Lights and Control Unit


Installing the repeater lights

Prerequisites


- At least four repeater lights for mounting on each corner of the helideck.
- The repeater light control module is mounted in an enclosure.
- Each repeater light is connected to the control module with the Orga combined power and communication cable SLxx3 (Strobeline cable). This cable is armoured offshore grade single pair halogen free signal cable.
- For more details of the installation, see the *HMS Repeater Lights System, Installation, operation and maintenance manual* from Orga.

Procedure


- 1 Identify the best mounting location for the repeater lights.
- 2 Mark and drill four M16 holes in the foundation according to the bolt pattern for the light screws.




- 3 Thread four M16 mounting holes with threaded depth minimum 25 mm.
- 4 Open the repeater light cover by unscrew the six screws marked with red cycles in the figure below.




- 5 Put the mounting feet (D) in the correct. Use the level (E) to make sure that the light is horizontal.



- 6 Install the rings (B and C) and the fasteners (A).
- 7 Enter the cable wires into the terminals.




- 8 Close the repeater light cover and fasten the six screws for the cover.
- 9 Connect the metric earth connection on the foot of the base with a bolt to a grounded structure on the platform.
 - Use a PE wire (D) with a crosssectional area of at least 4 mm² with a suitable cable lug (C).
 - Use an earth cable mounting bolt (A) in combination with the provided spring lock washer (B).
 - Keep the earthing tag (E).



Installing the repeater light control unit

Procedure


- 1 Identify the best mounting location for the repeater light control unit enclosure.



- 2 Fasten the enclosure to the structure.
- 3 Mount the CIP400-H-BN control unit in the enclosure, if not already done.



- 4 Terminate the cables to the HMS 300 Processing Unit and the repeater lights on the termination list within the enclosure. The control unit is connected to the Processing Unit with Ethernet cable connected to sensor net/LAN3. The control unit IP address to be in range 192.168.2.75.



- 5 When all cables are connected, close the enclosure cover.

Installing the meteorological sensors

The meteorological sensors are not necessarily a part of the Kongsberg Maritime AS delivery. If they are, please refer to the documentation for the respective sensors for detailed installation instructions. The documentation can be found in the box when unpacking the sensor.

For some of the sensors a Kongsberg Maritime AS connection box, part no. M410–69, is delivered with the sensor.


A short description on what to consider when installing the various sensors, is provided.

Wind sensor


What to consider when installing the wind sensor:

- Find a suitable location for the sensor on the vessel.
- The sensor is preferably mounted in an upright position. Use the Kongsberg Maritime AS mounting bracket M410–34 for this purpose.
- Set the wind sensor to point in the bow direction, or to some known reference direction, using the North alignment indicator at the base of the instrument.
- To apply with the requirements in CAP 437 of September 2018 the wind sensor has to be setup with output data rate of 4 Hz. See the *WindObserver II Ultrasonic Anemometer; User Manual* for how to configure the sensor for 4 outputs per second.

Suggested mounting arrangement for the wind sensor is illustrated.



Shows North pointing spar (bow direction) of unit aligned with dividing line between silver and blue portions of Gill Instrument Model and Serial No. label.




Refer to the *WindObserver II Ultrasonic Anemometer, User Manual* in *References* on page 157 for a detailed installation description.

Multi-weather sensor

What to consider when installing the multi-weather sensor:

- Find a suitable location for the sensor on the vessel.
- Mount the sensor in an upright position.
- Set the sensor to point in a known reference direction, such as the ship longitudinal axis, here referred to as North.

Orientation direction to North on the multi-weather sensor is illustrated.



Refer to the *Vaisala Weather Transmitter WXT530, User's Guide in References* on page 157 for a detailed installation description.

Related topics

- *Multi-weather sensor dimensions* on page 113

Dual-pressure sensor

What to consider when installing the dual-pressure sensor:


- Find a suitable outdoor location for the sensor on the vessel.

The pressure sensor can be mounted on a wall or to a rail or mast by the use of U-bolts. The screws and U-bolts are provided in the mounting kit.

This procedure describes how to install the dual-pressure sensor on a mast or pole.

Procedure


- 1 Fasten the rain shield (A) to the metal mounting plate (B) with 2 M6 screws (F).



- A Rain shield
- B Metal mounting plate
- C Pressure sensor
- D Pipe or mast
- E Screws for U-bolts
- F Screws for rain shield
- G Screws for mounting plate

- 2 Fasten the mounting plate with rain shield to the mast or pole (horizontal or vertical) by using the U-bolts (2 pcs) M8 (E) for 30 to 102 mm poles.

Figure 10 Horizontal pole mounting Figure 11 Vertical pole mounting




- 3 Fasten the dual-pressure sensor (C) to the mounting plate with 4 fixing screws M6 (G). The mounting orientation of the dual-pressure sensor must be as shown on the figure with the cable connections pointing down.

Refer to the *Vaisala BAROCAP Digital Barometer PTB330, User's Guide* in References on page 157 for a detailed installation description.

Cloud height sensor

What to consider when installing the cloud height sensor:

- Find a suitable location for the sensor on the vessel.
- Mount the sensor in an upright position, not tilted.
- In a ship installation it is recommended to mount the ceilometer on the shock absorber.



A Shows CL31 measurement unit within the pedestal

See *Shock absorber dimensions* on page 115 for dimensions on the shock absorber for the CL31.

Refer to the *Vaisala Ceilometer CL31, User's Guide* in *References* on page 157 for a detailed installation description.

Related topics


- *Cloud height sensor dimensions* on page 114
- *Shock absorber dimensions* on page 115

Visibility sensor

What to consider when installing the visibility sensor:

- Find a suitable location for the sensor on the vessel.
- Mount the sensor in an upright position.

The visibility sensor dimensions are illustrated.



Refer to the *Present Weather Detector PWD22, User's Guide* in *References* on page 157 for a detailed installation description.

Related topics

- *Visibility sensor dimensions* on page 116
- *Phoenix contact DIP switch settings* on page 120

Connection box for meteorology sensors

When installing the connection box consider the following:

- Mount the box in a location where it is easy to enter the cables and with easy access to the terminals within the box.

How to install the connection box

- 1 Remove the lid to gain access to the mounting holes.
- 2 Remove the two nipples located inside the box.

- 3 Make holes in the box for the two nipples by using a screw driver or similar. Preferably make the holes at the side which will point down when the box is mounted so as to prevent water intrusion from above.
- 4 Mount the box to a suitable surface with two screws.
- 5 Place the rubber gaskets on top of the two mounting screws to make the screw hole water tight.
- 6 Mount the two nipples.
- 7 Run the cables through the nipples and tighten.
- 8 Replace the lid and fasten.

Related topics

- *Meteorology sensor connection box dimensions* on page 112

Wiring of meteorology sensors

Wind sensor

Termination of the cabling between the Processing Unit and the for the wind sensor, type WindObserverII, part no. M410–51.

		Cable from Processing Unit COM 13		Cable to connection box for wind sensor	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	RX_A	5-pin screw terminal	1	Terminal block	4
2	RX_B	5-pin screw terminal	2	Terminal block	1
3	GND	5-pin screw terminal	3	Terminal block	
4	TX_A	5-pin screw terminal	4	Terminal block	2
5	TX_B	5-pin screw terminal	5	Terminal block	3
Cable no. W-2229, cable type 2 x 2 x 0.25 mm ² .					

		Cable from wind sensor power supply		Cable to connection box for wind sensor	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	24 V DC			Terminal block	6
2	0 V DC			Terminal block	7

		Cable from wind sensor power supply		Cable to connection box for wind sensor	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
3	24 V DC heating			Terminal block	8
4	0 V DC heating			Terminal block	9
Cable no. W-2230, cable type 2 x 1.5 mm ² + GND.					

		Cable from wind sensor connection box		Cable to wind sensor	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	RX_A	Terminal block	4	Pigtail cable	Pair 1: black
2	RX_B	Terminal block	1	Pigtail cable	Pair 1: green
3	TX_A	Terminal block	2	Pigtail cable	Pair 2: black
4	TX_B	Terminal block	3	Pigtail cable	Pair 2: white
5	24 V DC operating	Terminal block	6	Pigtail cable	Pair 3: red
6	0 V DC operating	Terminal block	7	Pigtail cable	Pair 3: black
7	24 V DC heating	Terminal block	8	Pigtail cable	Pair 5: yellow
8	0 V DC heating	Terminal block	9	Pigtail cable	Pair 5: black
Cable no. W-2231, cable type 10 x 2 x 0.25 mm ² .					

		Cable from wind sensor		Cable to EMC ground/P.E.	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	Earth	P.E.		P.E.	
Cable no. W-2232, cable type 1 x 1 x 4.0 mm ² .					

Multi-weather sensor

Termination of the cabling for the multi-weather sensor, type WXT536, part no. M440–58. You can have two multi-weather sensors.

The multi-weather sensor is configured to output the NMEA messages MWV and XDR (Press, temp, hum) at 9600 baud (9600 n 8 1).

Wiring for multi-weather sensor

		Cable from multi power serial DIN rail		Cable to connection box for multi-weather sensor	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	TX_A (White)	Terminal block	13	Terminal block	1
2	TX_B (Green)	Terminal block	14	Terminal block	2
3	RX_A (Blue)	Terminal block	15	Terminal block	3
4	RX_B (Grey)	Terminal block	16	Terminal block	4
5	Vin+ (Brown)	Terminal block	7	Terminal block	5
6	GND Vin+ (Red)	Terminal block	10	Terminal block	6
7	Vh+ (Yellow)	Terminal block	1	Terminal block	7
8	GND Vh+ (Pink)	Terminal block	4	Terminal block	8
Cable no. W-2213, cable type 4 x 2 x 0.5 mm ² . Power consumption at 24 V DC, 0.6 A					

		Cable from connection box for multi-weather		Cable to multi-weather sensor WXT536	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	TX_A (White)	Terminal block	1	M12 connector	1
2	TX_B (Green)	Terminal block	2	M12 connector	3
3	RX_A (Blue)	Terminal block	3	M12 connector	7
4	RX_B (Grey)	Terminal block	4	M12 connector	5
5	Vin+ (Brown)	Terminal block	5	M12 connector	2
6	GND Vin+ (Red)	Terminal block	6	M12 connector	8
7	Vh+ (Yellow)	Terminal block	7	M12 connector	4
8	GND Vh+ (Pink)	Terminal block	8	M12 connector	6
Cable no. W-2214, cable type 4 x 2 x 0.5 mm ² . Cable delivered with sensor (10 m, ø 6 mm). Power consumption at 24 V DC, 0.6 A.					

		Cable from multi-weather sensor WXT536		Cable to EMC ground/P.E.	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	Earth	P.E.		P.E.	
Cable no. W-2215, cable type 1 x 1 x 4.0 mm ² .					

Dual-pressure sensor

Termination of the cabling for the dual-pressure sensor, type PTB330, part no. M440–50.

The dual-pressure sensor is configured to output the NMEA messages XDR (Press, temp, hum) at 9600 baud (9600 n 8 1).

Wiring for dual-pressure sensor

Core no.	Signal	Cable from multi power serial DIN rail		Cable to Processing Unit, Com 12	
		Terminal	Pin no.	Terminal	Pin no.
1	RX_A	Terminal block	17	5-pin screw terminal	4
2	RX_B	Terminal block	18	5-pin screw terminal	5
	GND	Terminal block			
3	TX_A	Terminal block	19	5-pin screw terminal	1
	TX_B	Terminal block	20	5-pin screw terminal	2
Cable no. W-2252, cable type 2 x 2 x 0.25 mm ² .					

Core no.	Signal	Cable from multi power serial DIN rail		Cable to dual-pressure sensor PTB330	
		Terminal	Pin no.	Terminal	Pin no.
1	24 V DC	Terminal block	8	Terminal block	+
2	0 V DC	Terminal block	11	Terminal block	–
3	TX+	Terminal block	19	Terminal block	TX0–
4	TX–	Terminal block	20	Terminal block	TX0+
Cable no. W-2253, cable type 2 x 2 x 0.5 mm ² .					

Cloud height sensor

Termination of the cabling for the cloud height sensor, CL31, part no. M410–44.

The sensor RS-485 output signal is converted to RS-232 in the Phonix Contact (PSM-ME-RS232/RS485-P) mounted on the Multi power serial DIN rail.

The ceilometer is configured to output data at 19200 baud (19200 n 8 1).

		Cable from Processing Unit COM 1		Cable to Phoenix converter #2 on multi power serial DIN rail	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	RX	9-pin D-sub F	3	9-pin D-sub F	2
2	TX	9-pin D-sub F	2	9-pin D-sub F	3
3	GND	9-pin D-sub F	5	9-pin D-sub F	5
Cable no. W-2223, cable type 3 x 1 x 0.5 mm ² . The cable is delivered with the multi power serial DIN rail (3 m).					

		Cable from multi power serial DIN rail		Cable to Termbox–1200 for cloud height sensor CL31	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	D(A)	Terminal block	23	Terminal block	1
2	D(B)	Terminal block	24	Terminal block	2
Cable no. W-2224, cable type 2 x 2 x 0.5 mm ² .					

		Cable from Termbox–1200 for cloud height sensor CL31		Cable to Uninterrupted Power Supply	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	Neutral (L2) IN	Terminal block	N		
2	Positive Earth	Terminal block	PE		
3	Line 230 V AC IN	Terminal block	L		
Cable no. W-2225, cable type 2 x 2.5 mm + GND. The cable is delivered with the sensor (2 m, ø 8.5 mm). Power consumption 310 W.					

		Cable from Termbox–1200 for cloud height sensor CL31		Cable to EMC ground/P.E.	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	Earth	P.E.		P.E.	
Cable no. W-2226, cable type 1 x 1 x 4.0 mm ²					

		Cable from Termbox-1200 for cloud height sensor CL31		Cable to cloud height sensor CL31	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	D(A)	Terminal block	1	Sensor connector J3	1
2	D(B)	Terminal block	2	Sensor connector J3	2
Cable no. W-2235, cable type 2 x 2 x 0.5 mm ² . The cable is delivered with the sensor (ø 6 mm)					

		Cable from Termbox-1200 for cloud height sensor CL31		Cable to cloud height sensor CL31	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	Neutral (L2) IN	Terminal block	N	Sensor connector J2	3
2	Positive Earth	Terminal block	PE	Sensor connector J2	4
3	Line 230 V AC IN	Terminal block	L	Sensor connector J2	1
Cable no. W-2236, cable type 2 x 2.5 mm ² + GND. The cable is delivered with the sensor (ø 8.5 mm). Power consumption 310 W.					

Visibility sensor

Termination of the cabling for the visibility sensor, PWD22, part no. M410-46. The sensor RS-485 output signal is converted to RS-232 in the Phoenix Contact (PSM-ME-RS232/RS485-P) mounted on the Multi power serial DIN rail.

The visibility sensor is configured to output data at 9600 baud (9600 n 8 1 or 9600 e 7 1).

		Cable from Processing Unit COM 2		Cable to Phoenix converter #1 on multi power serial DIN rail	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	RX	9-pin D-sub F	3	9-pin D-sub F	2
2	TX	9-pin D-sub F	2	9-pin D-sub F	3
3	GND	9-pin D-sub F	5	9-pin D-sub F	5
Cable no. W-2220, cable type 3 x 1 x 0.5 mm ² . The cable is delivered with the multi power serial DIN rail (3 m).					

Core no.	Signal	Cable from multi power serial DIN rail		Cable to connection box for visibility sensor PWD22	
		Terminal	Pin no.	Terminal	Pin no.
1	Operating 24 V DC	Terminal block	9	Terminal block	1
2	Operating 0 V DC	Terminal block	12	Terminal block	2
3	D(A)	Terminal block	21	Terminal block	3
4	D(B)	Terminal block	22	Terminal block	4
5	Heating + 24 V DC	Terminal block	3	Terminal block	5
6	Heating – 0 V DC	Terminal block	6	Terminal block	6
7	Ground	Terminal block		Terminal block	
Cable no. W-2221, cable type 4 x 2 x 0.5 mm ² . Power consumption with heating 72 W.					

Core no.	Signal	Cable from connection box for visibility sensor PWD22		Cable to visibility sensor PWD22	
		Terminal	Pin no.	Terminal	Pin no.
1	Heating + 24 V DC (White, green)	Terminal block	5	Sensor connector	X3 – 5
2	Heating – 0 V DC (Brown, green)	Terminal block	6	Sensor connector	X3 – 6
3	Ground	Terminal block		Sensor connector	Shield
4	Operating 24 V DC (Red)	Terminal block	1	Sensor connector	X1 – 4
5	Operating 0 V DC (Black)	Terminal block	2	Sensor connector	X1 – 5
6	D(A) (White)	Terminal block	3	Sensor connector	X1 – 2
7	D(B) (Brown)	Terminal block	4	Sensor connector	X1 – 3
Cable no. W-2222, cable type 16 x 2 x 0.25 mm ² . The cable is delivered with the sensor (35 m, ø 8 mm). Power consumption with heating 72 W.					

Sea water temperature sensor

Termination of the cabling for the sea water temperature sensor interface. Contact Kongsberg Maritime AS for details.

		Cable from sea water temp. interface		Cable to multi power serial DIN rail	
Core no.	Signal	Terminal	Pin no.	Terminal	Pin no.
1	RJ-45			Port 4, Ethernet switch	
Cable no. W-2237, cable type CAT5e					


Installing the wave and water level system

This chapter describes the installation of the RangeFinder Motion sensor (M440–40) and the MET sensor power rail (M410–75). The RangeFinder sensor is used for measuring waves and the distance from the water level to the helideck.

Although the sensor is constructed for measurements in harsh environments it is an instrument which must be handled with care during installation.

About the RangeFinder sensor

The Miros SM-140 RangeFinder is a microwave radar based sensor operating at 9.6 GHz. It measures the vertical distance from the sensor antenna to the water surface. Typical applications are water measurements from vessel and floating offshore installations for water level measurements and determination of significant wave height.



Sensor location and orientation



When installing the RangeFinder sensor consider the following:

- Mount the sensor on a suitable support structure with an open vertical view of the water surface, e.g. at the bow of the vessel or on the outside of a bridge or platform handrail.
- Mount the sensor away from reflecting objects to avoid problems caused by multi-path signal propagation for the range finder antenna.
- The instrument's measuring range is a determining factor for finding the optimum installation height. The RangeFinder sensor has measurement range 2 to 95 meters. Ensure that the sensor is mounted within measurement range to the sea level.
- Mount the RangeFinder sensor at or near the bow of the vessel.

- A mounting arrangement for the RangeFinder sensor have to be made at the ship yard. Optionally, a mounting arrangement for handrail mounting can be delivered (part number M440-47).
- The location should be accessible for periodical cleaning and service.
- The sensor is not certified for installation in explosive atmospheres.

The drawing illustrates the need for an open view from the range finder to the water.

- $X_{min} = Y * \tan (\alpha/2)$



Refer to the *SM-140 RangeFinder, User Manual* in *References* on page 157 for a detailed installation description.

Related topics

- *RangeFinder sensor dimensions* on page 117
- *RangeFinder hand rail mounting bracket dimensions* on page 118

MET sensor power rail

This rail contains power supply and Ethernet for the RangeFinder sensor, means for connecting up network for the RangeFinder sensor and interfacing of the sea water temperature information to the HMS Processing Unit. The RangeFinder sensor is connected to the Processing Unit with Ethernet cable connected to sensor net/LAN3. The RangeFinder sensor IP address to be in range 192.168.2.80.

Survey of sensors on vessels

In order to achieve the specified accuracy of the IMU (MRU or MGC) the installation has to be surveyed.

The reference systems in use for this system are:

- The vessel reference system
- The Inertial Measurement Unit (GC or MRU) sensor point and axes system
- The helideck
- The wind sensor


A survey has to be performed to determine the offsets in angle and position from the vessel reference system to the IMU, the helideck and the wind sensor.

Vessel reference system definition

The following definitions are used:

- All vessels have a defined Cartesian coordinate system that all sensors can be referenced to. In this right hand system, the X-axis is positive forwards, which is parallel to the centre line of the vessel, the Y-axis, positive towards starboard, and the Z-axis, which is positive downward.
- The origin in the vessel reference system is typically frame 0 at keel level or the surveyed origin in a survey report, i.e. where X, Y and Z are all 0.
- The common reference point (CRP) is defined to be in the intersection between stern, centre line and keel. In case the keel is not parallel with the base line, the reference for CRP is where the keel crosses the vertical section amidships. The location of CRP vs the origin is configurable, and is typically set based on the survey report.
- The reference plane in this system must be well defined and described. This can be a Best Fit Plane on main deck, or a Best Fit Plane through the draught marks on the hull. This is particularly important on a floating vessel, as it is not possible to project the horizontal plane from land.
- The chosen convention must be made clear to all parties involved, both survey personnel performing the survey and the users of the survey results. Any deviation from the defined coordinate system, shown in the figure *Definition of Origin on vessel and positive X, Y and Z axes directions* on page 77, should be well described in both text and drawings to avoid common misunderstandings.

Figure 12 Definition of Origin on vessel and positive X, Y and Z axes directions



- | | |
|---------------------------------------|---------------------------|
| A Stern | F +Z axis |
| B Keel | G +X axis |
| C Main deck | H +Y axis |
| D CRP (common reference point) | I CL (centre line) |
| E Origin | J Amidships |

Surveying the MRU

For the sensor unit the following should be surveyed:

- Position (X,Y,Z) of sensor point. The axis cross centre on the MRU sensor unit is illustrated
- Mounting angles in Roll, Pitch and Yaw (heading).

Figure 13 Sensor point and position (0, 0, 0) for all MRU units




Figure 14 Sensor plane on the wall mounting bracket





Figure 15 Sensor plane on the protected mounting bracket



Note


The MRU mounting bracket allows easy exchange with another MRU without affecting the orientation calibration. This is due to the precision of the dowel pins within the bracket. Therefore, when an MRU is replaced in a system with another unit it is no need for re-surveying position or angles again if the mounting bracket is in the same location.

Surveying the MGC

For the sensor unit the following should be surveyed:

- Position (X,Y,Z) of sensor point. The axis cross centre on the MGC sensor unit is illustrated.
- Mounting angles in Roll, Pitch and Yaw (heading).

Figure 16 MGC sensor point location



Alignment surfaces

The sensor unit mounting bracket is manufactured with accurately machine alignment surfaces to place prisms for surveying the offset angles in roll, pitch and heading by a theodolite. For roll and pitch alignment, space for prisms are made in each corner of the sensor unit plate. The surface on these locations are prepared specially to make it flat and aligned (parallel) with the sensors inside the unit.

Figure 17 Alignment surfaces






Figure 18 Prisms located in three corners of the sensor unit plate



At two sides of the sensor unit plate there are two squared surfaces which stick out. These surfaces are meant for measuring the heading of the unit towards the vessel axes by placing prisms into each of these surfaces.

Figure 19 Two prisms place into the spaced out surfaces for heading alignment



For the gyro compass the following should be surveyed:

- The offset between the gyro compass heading and the vessel centre line (CL).

Static gyro compass calibration/verification (heading log) should be done after the gyro compass system is installed and fully operational. This can be performed in dock or alongside a quay.


Dynamic gyro compass calibration/verification and attitude verification (heading, roll and pitch verification) must be performed at sea.

Surveying the helideck

For the helideck the following should be surveyed:

- Position (X,Y,Z) of the centre point of yellow TD/PM circle on helideck
- Orientation of the H on the helideck in degrees related to the vessel centre line (CL)
- Mounting angles in Roll and Pitch

Figure 20 Helideck centre point location and positive rotation direction



Surveying the wind sensor

For the wind sensor the following should be surveyed:

- Height of point A above the helideck centre
- Orientation of point A towards point B (sensor NORTH) related to the vessel centre line (CL)

Figure 21 Gill WindObserverII sensor location and rotation direction. The red dot under the product label is the North side alignment point.





Figure 22 WXT520/530 wind sensor location and rotation direction



Survey accuracy

The IMU (MRU and MGC) sensor and the helideck must be surveyed to the following accuracy level. If not, the performance of the HMS 300 product will be degraded.

- Distance vector from the Origin to the IMU sensor point (X, Y, Z): <0.1 metre
- Distance vector from the Origin to the centre point of yellow TD/PM circle on helideck (X, Y, Z): <0.5 metre
- Height from the Origin to the wind sensor point A: <0.1 metre
- Distance vector from the Origin to the Centre of Gravity (CG) location (X, Y, Z): <1 metre
- The IMU yaw misalignment angles with the vessel axes: <0.5°
- The IMU misalignment angles (Roll, Pitch) with the vessel axes: <0.1°
- The helideck rotation (heading) angle with the vessel axes: <1°
- The helideck roll and pitch misalignment angles with the vessel axes: <0.1°
- The wind sensor rotation angle with the vessel axes: <1°

Cable layout and interconnections


Cable plan

Cable plan for the HMS system.

Interconnections

The different HMS 300 system parts are connected as follows:

Unit	Connector	Connected to
EDGE/HMI IOT-1	LAN	Port 9 on GSN router
EDGE/HMI IOT-2	LAN	Port 15 on GSN router
EDGE/HMI IOT-2	Display	KVM Extender/DP-VGA
EDGE/HMI IOT-2	USB 3	KVM Extender
HMS PU	LAN 3	Repeater Light
HMS PU	LAN 4	Port 20 on GSN router
GSN via KM network (ShipsNet)		Port 7 on GSN router



Setting to work

Setting to work summary

Once all the hardware units have been installed, and all the cables have been connected, the Seapath can be powered up for the first time, and set to work.

Prerequisites

- All hardware units have been installed according to the relevant instructions.
- All system cables have been installed.
- All connections have been made.
- All operating power is available.
- All external devices which shall communicate with the Seapath are available and operational.
- All relevant personnel and tools are available.

Procedure

- 1 Verify that the HMS 300 is ready for operational use.
 - a Verify that all hardware units have been installed correctly.
 - b Verify that all cables have been connected correctly.
- 2 Power up the HMS 300 PU and EDGE/HMI Units for the first time.
- 3 Configure the HMS for operational use.
 - a Configure the vessel geometry.
 - b Configure the helideck category and location.
 - c Configuration of communication interfaces.
- 4 Set up interfaces to external devices.

To provide correct information the system needs to communicate with external devices. All these interfaces must be set up in the system software.

Verifying that the HMS is ready for operational use

The HMS system is ready for operational use when:

- All cables are properly connected.
- The power is correct. The system operates on 100 to 240 V AC power from the vessel's mains supply.

LED indicators Processing Unit

At the front of the Processing Unit there are four LED indicators, but only one of them are in use. The LED to the left indicates power and software status, while the other three LEDs have for the moment no function and will always be turned off.



LED indications

- The first LED to the left indicates power and software status.
 - The LED is red if the system is not running.
 - The LED is green when the system is running.
 - During normal operation, one LED should be green and the rest should be off.



LED indicator on EDGE/HMI Units

At the front of the EDGE/HMI Unit a LED indicator is located in the center of the power button. The LED indicate power status. When powered the LED is red and if not the unit is unpowered (turned off).




Configuration management description

Entering HMS 300 VMS Core configuration

The HMS 300 Processing Unit includes a web configuration and diagnostics program. Follow the procedure below to configure the HMS 300 by this program.

Procedure

- 1 Connect a PC to the LAN of the Processing Unit.
- 2 Enter the IP address like 10.65.91.7 in a browser on the PC. The configuration and diagnostics program as shown below will appear in the browser.



- 3 Enter the wanted dialog box for Utilities and Diagnostics.

Note

Advanced Settings configuration is for service personnel only.

Required system configuration

Vessel configuration


The vessel configuration includes:

- Vessel, including:
 - Geometry
 - Description

- Helideck Category
- Helideck Report
- Locations
- Operation
- OVs
- Equipment
- Sensors

Vessel geometry

In the **Vessel Geometry** configuration, information needed to specify correct location of various sensors and equipment on a vessel is entered. The unit of the entered coordinates is in [m].




LOA

The overall length of the vessel, i.e. from stern to bow.

SurveyOrigin

All point locations in the configuration refer to the origin. The location of the origin is defined using distance from stern, center line and keel (often referred to as the CRP (common reference point) in survey reports). In HMS 300 the coordinates have to be 0, 0, 0.

Figure 23 Different dimensions and location of Origin



ModelDirectory

The default directory is /data/user/system/cfg/misc.

ModelChecksum

The default Model Checksum is 0 (zero).

Beam (overall width)

The overall width of the vessel.

Height

The distance from the highest point of the vessel to the keel.

Shape

The default Shape is **Ship**.

ShapeFormat

The default Shape Format is **Basic**.

MeanSeaLevel

The distance from the helideck center to waterline defines the Mean Sea Level used for calculation of QNH. MeanSeaLevel is a positive value and the same as the operational draught.

Vessel description

In the **Vessel Description** configuration contains information about the vessel needed for identification purposes.

Field	Value
Name	Not defined
Description	Not defined
MMSI	0
IMO	3456798
Country	Not defined
Owner	Not defined
Telephone	NA
Fax	NA
Mobile	NA
Description	

Name

The name of the vessel. An empty name field is not allowed. The default value is **VESSEL**.

Description

The type of vessel is typically used as description (optional).

MMSI

The MMSI assigned to the vessel. Default value is 0.

IMO

The IMO ID assigned to the vessel. Default value is 0.

Country

The name of the vessel's country of origin (optional).

Owner

The name of the vessel owner (optional).

Telephone

Not applicable (NA).

Fax


Not applicable (NA).

Mobile

Not applicable (NA).

Helideck Category

In the **Helideck Category** configuration of which category the vessel/rig applies to.



HelideckCategory

The category number the vessel/rig applies to.

SemiSubEnable

The night operation limits for semi-submeribles apply (1) or not (0).

Helideck Report

In the **Helideck Report** configuration information for tailoring the helideck report and contact information.

Parameter	Value
DynamicPosition	0
AccMonEquipment	0
CompHelideck	0
RadioNDB	NA
RadioVHF	NA
EmailSubject	Helideck Report
EmailTo	Not defined
EmailCC	Not defined

Description

Save

DynamicPosition

The vessel are on dynamic positioning (1) or not (0).

AccMonEquipment

The vessel has active roll compensated helideck (1) or not (0).

CompHelideck

The vessel has accurate measurement equipment (1) or not (0).

RadioNDB

Not applicable (NA).

RadioVHF

Not applicable (NA).

EmailSubject

The default value is **Helideck Report**.

EmailTo

The email address the helideck report should be sent too. Note: Use only small letters.

EmailCC

The email address to the person in copy for the helideck report. Note: Use only small letters.

Helideck location

In the **Location Helideck** configuration information the helideck is input.

Parameter	Value
Enable	1
Arm	10 0 0 0 -10 0
Name	Helideck
Rotation	0 0 0 0 0
EquipmentIndex	0

Enable

Not applicable (NA).

Arm

Enter the Arm/position of the helideck selected in X, Y, Z coordinated from Origin. The helideck location has to be measured or calculated based upon drawings or previously measured points.

Name

Enter the preferred name on the helideck.

Rotation

Enter the roll and pitch mounting angles of the helideck in degrees and the rotation of the helideck in yaw (degrees) towards the vessel axes. Note: The yaw angle must be input correctly to get the H in the HMI on the screen correctly. In the example below yaw rotation is 0 degrees.



EquipmentIndex

Not applicable (NA).

Equipment

In the **Equipment** configuration information the helideck is input.

Parameter	Value
Name	Helideck
Type	4
Size	20 0 20 0 1 0
Location	0 00 0 00 0 00
Orientation	0 0

Description

Save

Name

Enter the preferred name on the helideck.

Type

The equipment type. Default 4.

Size

Enter the helideck size in **Length, Width and Height**.

Location

Enter the location/position of the helideck selected in X, Y, Z coordinated from Origin. The helideck location has to be measured or calculated based upon drawings or previously measured points.

Orientation

Enter the orientation of the helideck in degrees.

Configuring the MRU

The MRU unit has to be configured separately by connecting an external PC to the unit through the Ethernet port on the MRU junction box (MRU-E-JB3). A description on how to operate the configuration software MRC+ is described in on page .

The MRU configuration includes numerous parameters but for this system only the parameters described here are to be modified.

The parameters are set in the **Configuration** tab in the **MRC+ configuration software** window. The following configuration parameters must be set for the MRU.

Vessel geometry

The vessel geometry has to be input as correctly as possible to ensure that the performance of the MRU will be optimal. The following has to be input:

- **Shape dimension.** Enter the overall vessel dimension to which the HMS system is to be installed.
- **Origin location.** Enter a Origin location. The location can be selected freely and often frame 0 is used.
- **Centre of gravity.** Enter a location of the CG as correct as possible.

MRU geometry

The MRU geometry has to be configured as follows:

- **MRU position in reference to Origin.** Enter X, Y and Z values in metres.
- **Mounting angles.** Default orientation is with the cable down, the +x arrow pointing forward and the +y arrow pointing to starboard. Then the mounting angles are 0, 0, 0. If the MRU is mounted in a different orientation, the correct angles have to be implemented.

Heave configuration

Select **Automatic** in the heave filter **Option** drop-down list to use the Automatic heave filter mode.

Serial #1

For the **Communication interface** → **Input/Output**, select interface **Serial #1**. The COM 1 port is the standard port.

- **Baud rate.** Select baud rate **19200** from the drop-down list.
- **Protocol.** Select **MRU normal** from the drop-down list.
- **Interval.** Select **100 ms (10 Hz)**.
- **Token.** Set token to **55**.
- **Source.** The number of output variables are 16 and the Source IDs are:
 - Roll (63).
 - Pitch (64).
 - Yaw (65).
 - AngRate_R (1).
 - AngRate_P (2).
 - AngRate_Y (3).
 - VelMru_F (212).
 - VelMru_S (213).
 - VelMru_D (214).
 - AccMru_Ff (203).
 - AccMru_Sf (204).

- AccMru_Df (205).
- AccM_Rf (11).
- AccM_Pf (12).
- AccM_Yf (13).
- SampleTime.n (169).

Note

The sequence of the MRU output variables is essential and has to be as described.

Note


For earlier generation MRU models (generation 1 to 4) the output variable sources and sequence are: Roll (63), Pitch (64), Yaw (65), VelAngR (1), VelAngP (2), VelAngY (3), VelMonF (113), VelMonS (114), VelMonD (115), AccMonF (86), AccMonS (87), AccMonD (88), AccMruGR (11), AccMruGP (12), AccMruGY (13), SampleTime.n (169).

Helmet output configuration


Follow the below procedure to configure the HMS for output of the Helmet data

Procedure


- 1 Enter the VMS Core configuration tool as shown below.




- 2 Enter **Advanced Settings** under **Utilities**. Input the password **stx**.
- 3 Scroll down to bottom of the menu and enter **Advanced**. Select **Helmet** as shown below.



- a The **Enable** value should be 1.
 - b The **Interval** has default value 20.
 - c Enter the address from the HMS API in **Domain**.
 - d The **Siteid** is taken from the vessel ID which is set by Helimet.
- 4 Press **Save** and leave the **Advanced Settings** menu.
 - 5 Enter the **Data Monitor** under **Diagnostics** to check that Helimet data is output.



- 6 Enter **core** and **helimet** to check the Helimet data sent output.



7 If data on **payload** is continuously changing, then the Helimet data output works.

Commissioning

The equipment will be commissioned after installation. A trained operator will fill out the Functional Test Form (part of the Site Acceptance Test) with the necessary parameters.


Drawings

Unless otherwise specified, all measurements are in millimetres.


Note

The drawings are not to scale. To-scale drawings are available on request.

Processing Unit dimensions



HMI Unit dimension



MRU wall mounting bracket dimensions

Note:
 Clean the surface between MRU and Bracket carefully before assembly
 Connecting surfaces between MRU and Bracket should in no way be damaged before mounting
 It is preferable that the bracket is attached to the hull structure to prevent vibrations.
 The Bracket (pos 2.) must be mounted with the screws pos.5 before the MRU is mounted to the Bracket.
 To disassemble the MRU from the Bracket, remove the screws pos.6. Do not remove the Bracket from its position.

WALL BRACKET MRU+

6	4	Screw Unbraco M4x12, DIN 912, A4 quality
5	3	Screw Unbraco M6x20, DIN 912, A4 quality
4	3	Washer for M6 DIN 125 form A, A4 quality
3	6	Insulation sleeves
2	1	Bracket MRU-M-MB4
1	1	MRU+

Pos Qty

Tolerance : ISO 2768-M if not specified on drawing

Rev	Description	Date, Sign.
3	Changed dimensions	27.09.12
4	Information of pos 5 & 6 corrected	09.12.13


Sheet: 1/1
 Size: A3
 Scale: NOT to scale
 Sign: KL
 Revision: 04

Kongsberg Seatex AS
 KONGSBERG

Project / Product name: MRU Projection: Mechanical Sheet: 03.05.2011
 Drawing type: Mechanical Document ID: 38.00-MD-009

The reproduction, alteration and distribution of this document without the authorization of the copyright holder is strictly prohibited. Changes will be made without notice. The user assumes all responsibility for any damage caused by the use of this document.

MRU protected mounting bracket dimensions





Material : Anodized Aluminium
 Total weight : MRU + Bracket = 4,8Kg


6	4	Cover Cap, Ld-PE
5	4	M4x10mm, Socket Cap Screw, DIN 912, A4-70 Stainless
4	4	Lock Washer, NL4spss Nord Lock
3	3	Lock Washer, NL8spss Nord Lock
2	6	Insulation Sleeve, PA6
1	3	M8x30mm, Low Head Socket Cap Screw, DIN 7984, A4-70 Stainless




Pos	Qty	Description
Rev.		
Date, Sign.		

 Kongsberg Seatex AS	File: MRU-M-MB6 Bracket Dimensions
	Sheet: 1/1 Size: A3 Scale: Not to scale
Project/Product name: MRU-V Projection: 	Drawing type: Mechanical Date: 27.06.2014 Document ID: 3800-MA-211
This specification, alterations and details of this document are the intellectual property of its author. It is not to be used, copied, or reproduced in any form without the prior written authorization of the author. All rights reserved in the event of patent, utility model or design.	
Revision: 00	Sign: KL


MRU junction box dimensions




MRU Ex enclosure dimensions




Meteorology sensor connection box dimensions




Multi-weather sensor dimensions




Cloud height sensor dimensions



RangeFinder hand rail mounting bracket dimensions



Multi power serial DIN rail dimensions




Phoenix contact DIP switch settings

DIP-switch settings for use with Vaisala PWD-22

Speed [kBit/s]	DIP-Switch				DIP-Switch			
	1	2	3	4	5	6	7	8
115.2	OFF	ON	OFF	ON	RTS/CTS-CONTROLLED	ON		
93.75	OFF	ON	ON	OFF	SELF-CONTROLLED	OFF		
75	OFF	ON	ON	ON	RTS/CTS-INVERS	ON		
57.6	ON	OFF	OFF	OFF	RTS/CTS-STANDARD	OFF		
38.4	ON	OFF	OFF	ON	RS-485 4-WIRE		ON	
19.2	ON	OFF	ON	OFF	RS-485 2-WIRE		OFF	
9.6	ON	OFF	ON	ON	RS-422			ON
4.8	ON	ON	OFF	OFF	RS-485			OFF

Abb./Fig. 8

8-pole DIP-switch for communication parameters should be configured according to above table.
Note ! ON direction is DOWN



Termination switch in ON position
Equipment type switch in DCE position

DIP-switch settings for use with Vaisala CL-31

Speed [kBit/s]	DIP-Switch				DIP-Switch			
	1	2	3	4	5	6	7	8
115.2	OFF	ON	OFF	ON	RTS/CTS-CONTROLLED	ON		
93.75	OFF	ON	ON	OFF	SELF-CONTROLLED	OFF		
75	OFF	ON	ON	ON	RTS/CTS-INVERS	ON		
57.6	ON	OFF	OFF	OFF	RTS/CTS-STANDARD	OFF		
38.4	ON	OFF	OFF	ON	RS-485 4-WIRE		ON	
19.2	ON	OFF	ON	OFF	RS-485 2-WIRE		OFF	
9.6	ON	OFF	ON	ON	RS-422			ON
4.8	ON	ON	OFF	OFF	RS-485			OFF


Abb./Fig. 8

8-pole DIP-switch for communication parameters should be configured according to above table.
Note ! ON direction is DOWN



Termination switch in ON position
Equipment type switch in DCE position

System components and schematics



Repeater light dimensions

FRONT VIEW
 $\varnothing 406$
 $\varnothing 329$
 M20x1.5 cable entry (4x)

SIDE VIEW
 143
 79
 10

BOTTOM VIEW
 $\approx 275=$
 $\approx 275=$
 4x M16 - 4x
 4x2

M6 External earth connection
 Use M4 Cable Lug

CLIENT CONNECTION (left to right):

L in	Mains - Power in
L out	Mains - Power out
N in	Mains - Power in
N out	Mains - Power out
PE	Mains - Potential Earth
PE	Mains - Potential Earth
A in	OrTalk - Communication in
A out	OrTalk - Communication out
B in	OrTalk - Communication in
B out	OrTalk - Communication out
S	OrTalk - Communication
S	OrTalk - Communication

TYPE: L480
 Unit: mm
 Scale: 1:5
 Sheet Size: A3


Doc type: GA Offshore Drawing
Revision: 01
Revision Date: 21-01-2021

Project No.: RD000580
Project Name: HMS sign
Drawing no.: SW-0020728

orga.
 Strömlinje 13
 111 23
 T: +46 (0) 200 5555
 info@orga.se
 www.orga.se


Sheet 1 of 1

Repeater light control unit enclosure dimensions




Project Name		Installation No. / Item No.		Product Name		The Supplier's Drawing Title	
A		-		M450-64_HMS Repeater Light CM M450-61 in cabinet		M450-64	
Rev.		Reason for Issue / Description of Change		Designed by		Information Classification	
A		2021-10-06		RJR		To be evaluated	
Date		Created by		Approved by		Document ID	
						Kongsberg Maritime	
						HMS Repeater Light CM M450-61 in cabinet, Orga	
						Mechanical drawing,	
						1/1	
						Revision	
						A	
						Sheet	
						Size	
						Scale	

Repeater light control unit enclosure wiring diagram



Repeater light control unit enclosure arrangement



Technical specifications

Performance specifications

MRU

Type of MRU	MRU E (used as an example of performance for the MRU models)
Resolution in all axes	0.001°
Static accuracy roll, pitch ^[1]	0.05° RMS
Dynamic accuracy roll, pitch (for a ±5° amplitude) ^[2]	0.05° RMS
Scale factor error	0.2 % RMS
Heave output range	±50 m, adjustable
Heave motion periods	1 to 25 s
Dynamic heave accuracy	5 cm or 5 %, whichever is highest

Wind sensor, optional

Type	WindObserver II, part no. M410–51
Wind speed measurement range	0 to 65 m/s
Wind speed accuracy	±2 %
Wind speed resolution	0.01 m/s
Wind speed offset	±0.01 m/s
Direction measurement range	0 to 359°
Direction accuracy	±2°
Direction resolution	1°

-
1. When the MRU is stationary over a 30-minute period.
 2. When the MRU is exposed to a combined two-axis sinusoidal angular motion with five minutes duration.

Multi-weather sensor, optional

Type	WXT536, part no. M440-58
Wind speed measurement range	0 to 60 m/s
Wind speed accuracy	±3 %
Wind speed resolution	0.1 m/s
Wind direction measurement range	0 to 359°
Wind direction accuracy	±3°
Wind direction resolution	1°
Temperature measurement range	-52 to +60 °C
Temperature accuracy at +20 °C	±0.3 °C
Humidity measurement range	0 to 100% RH
Humidity accuracy	±5 % RH
Pressure range	600 to 1100 hPa
Pressure accuracy	0.5 hPa
Pressure resolution	0.1 hPa

Dual-pressure sensor, optional

Type	PTB330, part no. M440-50
Pressure range	500 to 1100 hPa
Pressure accuracy	0.15 hPa
Pressure resolution	0.01 hPa

Cloud height sensor, optional

Type	CL31, part no. M410-44
Measurement range	0 to 25000 feet
Distance measurement range	±1 % or ±17 feet, whichever is highest
Resolution	10 feet

Visibility sensor, optional

Type	PWD22, part no. M410–46
Measurement range	10 to 20000 m
Accuracy	±10 %, range 10 to 10000 m

RangeFinder Motion sensor, optional

Type	SM-140/02, part no. M440–40
Beam width	5° (–3 dB one way)
Measurement range	2 to 95 m
Measurement error	1 cm

Weights and outline dimensions

Processing Unit

Height	88.1 mm (2U)
Width	485 mm (19")
Depth	Min 357 mm (including connectors on rear panel) and max 412 mm (including cable relief bracket)
Weight	5.4 kg

HMI Unit (dual)

Height	44.55 mm (1U)
Width	482.6 mm (19") including mounting bracket
Depth	Min 452.1 mm
Depth	477.8 mm (including hank on front panel)
Slide length	292 mm
Weight	7.5 kg

MRU Unit

Type	5 th generation MRU
Height	140 mm (5.525")
Diameter	105 mm (4.134")
Weight	2.2 kg

Colour	Titanium
Connector	Souriau 851-36RG 16-26S50 (MIL. spec.)

MRU wall mounting bracket

Type	MRU-M-MB4
Length	123.5 mm
Width	110 mm
Height	140 mm
Weight	0.8 kg
Colour	Black
Material	Aluminium

MRU protected mounting bracket

Type	MRU-M-MB6
Length	134.5 mm
Width	130 mm
Height	300 mm
Weight	2.4 kg
Colour	Black
Material	Aluminium

MRU junction box

Type	MRU-E-JB3
Length	226 mm
Width	126 mm
Height	90 mm
Weight	2.0 kg
Glands (clamping range)	9 to 21 mm
Colour	Black
Material	Aluminium
Enclosure protection	IP-65

Wind sensor, optional

Type	WindObserver II, part no. M410–51
Height	381 mm
Diameter	213 mm
Weight	2.0 kg

Multi-weather sensor, optional

Type	WXT536, part no. M440–58
Height	238 mm
Diameter	115 mm
Weight	0.65 kg

Dual-pressure sensor, optional

Type	PTB330, part no. M440–50
Length with mounting plate	237 mm
Width with mounting plate	107 mm
Height with mounting plate	179 mm

Cloud height sensor without damper, optional

Type	CL31, part no. M410–44
Width	335 mm
Height	1190 mm
Depth	325 mm
Weight	31 kg

Visibility sensor, optional

Type	PWD22, part no. M410–46
Width	404 mm
Height	199 mm
Length	695 mm
Weight	3 kg

RangeFinder Motion sensor, optional

Type	SM-140/02, part no. M440–40
Height	136 mm
Width	500 mm
Depth	440 mm
Weight	11 kg

RangeFinder sensor hand rail mounting bracket, optional

Type	MP-327/140N, part no. M440–47
Height	595 mm
Width	596 mm
Depth	779 mm
Weight	18 kg

Repeater light

Type	ORGA L430, part no. M450–60
Height	143 mm
Diameter	406 mm
Weight	18 kg

Repeater light control unit enclosure

Type	M450–64
Height	200 mm
Width	300 mm
Depth	120 mm
Weight	5.5 kg

GSN router

Type	Part no. 417936, Cisco 891-24X
Height	44.5 mm (without rubber feet)
Width	438.1 mm
Depth	304.8 mm
Weight	2.5 kg

Connection box for meteorology sensors

Type	Hensel , part no. M410–69
Length	77 mm
Width	130 mm
Height	130 mm
Weight	0.31 kg

Power specifications

Processing Unit

Voltage	100 to 240 V AC, 50/60 Hz
Power consumption	Max. 75 W ^[3]
Batteries	None, connection to UPS recommended

HMI Unit (dual)

Voltage	100 to 240 V AC, 50/60 Hz
Power consumption, max.	270 W
Power consumption, typical	120 W

MRU Unit

Voltage	24 V DC, from Processing Unit
---------	-------------------------------

Wind sensor, optional

Type	WindObserver II, part no. M410–51
Voltage (anemometer only)	9 to 30 V DC
Power consumption (anemometer only)	60 mA max.
Voltage for separate heating module	22 to 30 V DC
Power consumption for separate heating module	3 A

3. With Inertial Measurement Unit connected.

Multi-weather sensor, optional

Type	WXT536, part no. M440-58
Voltage	5 to 32 V DC
Power consumption with heating (at 24 V DC)	0.4 A, typical

Dual-pressure sensor, optional

Type	PTB330, part no. M440-50
Voltage	10 to 35 V DC
Power consumption (at 24 V DC)	0.2 A, typical

Cloud height sensor, optional

Type	CL31, part no. M410-44
Voltage	230 V AC
Power consumption with heating	310 W

Visibility sensor, optional

Type	PWD22, part no. M410-46
Voltage	24 V DC
Power consumption with heating	72 W

RangeFinder Motion sensor, optional

Type	SM-140/02, part no. M440-40
Voltage	12 to 36 V DC (nominal 24 V DC)
Power consumption	< 7 W

Repeater light

Type	ORGA L430, part no. M450-60
Voltage	110 to 254 V AC
Power consumption	45 W per light (190 W total for 4 lights)

Repeater control unit

Type	ORGA CIP400-H-BN, part no. M450–61
Voltage	110 to 254 V AC
Power consumption	1.3 W

GSN router

Type	Part no. 417936, Cisco 891-24X
Voltage	110 to 240 V AC
Power consumption, max.	60 W

Environmental specifications

Processing Unit

Enclosure material	Aluminium
Operating temperature range	-15 °C to +55 °C [4]
Recommended operating temperature	Room temperature (+20 °C)
Storage temperature range	-20 °C to +70 °C [5]
Operating humidity	Max. 95 % non-condensing
Storage humidity	Less than 55 %
Ingress protection front	IP 42
Ingress protection rear	IP 21
Electromagnetic compatibility (immunity/emission)	IEC 60945/EN 60945
Vibration	IEC 60945/EN 60945

HMI Unit

Enclosure material	Aluminium
Operating temperature range	-15 °C to +55 °C
Recommended operating temperature	Room temperature (+20 °C)
Storage temperature	-10 °C to +70 °C

4. Operating temperature up to +55 °C for 10 hours.

5. Recommended long term storage temperature range between +5 to +35 °C.

Operating humidity	Max. 95%, non-condensing
Storage humidity	< 55 %
Type approved by	ABS, BV, CCS, DNV, KR, LR, RS, NKK, PRS and RINA. IACS E10 and IEC 60945

MRU Unit

Enclosure material	Anodised aluminium
Enclosure protection	IP-66
Operating humidity (max)	Sealed, no limit
Storage temperature range	-25 °C to +70 °C
Storage humidity	Sealed, no limit
Electromagnetic compatibility (immunity/emission)	IEC 60945/EN 60945
Vibration	IEC 60945/EN 60945
Max shock non-operational (10 ms peak)	1000 m/s ²
MTBF (computed)	50000 h
MTBF (service history based))	100000 h

MRU junction box

Type	MRU-E-JB3
Enclosure material	Aluminium
Operating temperature range	-25 °C to +70 °C
Storage temperature	-25 °C to +70 °C
Ingress protection	IP 66

Wind sensor, optional

Type	WindObserver II, part no. M410-51
Enclosure material	Stainless steel
Enclosure protection, mounted upright	IP 66
Operating temperature range, heated version	-55 to +70 °C
Storage temperature range	-55 to +75 °C
Storage humidity	5 % to 100 % RH

Multi-weather sensor, optional

Type	WXT536, part no. M440–58
Enclosure material	Polycarbonate/glass fibre
Operating temperature range	–52 to +60 °C
Storage temperature range	–60 to +70 °C
Ingress protection with mounting kit	IP 66

Dual-pressure sensor, optional

Type	PTB330, part no. M440–50
Operating temperature range	–40 to +60 °C
Storage temperature range	–55 to +80 °C
Ingress protection	IP 65

Cloud height sensor, optional

Type	CL31, part no. M410–44
Enclosure material	Anodised aluminium
Temperature range	–40 to +60 °C
Ingress protection	IP 65

Visibility sensor, optional

Type	PWD22, part no. M410–46
Operating temperature range	–40 to +60 °C
Ingress protection	IP 66

RangeFinder Motion sensor, optional

Type	SM-140/02, part no. M440–40
Enclosure material	Aluminium/polyethylen
Temperature range	–30 to +50 °C
Ingress protection	IP 67
Humidity	0 to 100 % RH

Repeater light

Type	ORGA L430, part no. M450–60
Enclosure material	TBD
Temperature range	–25 to +55 °C
Ingress protection	IP 66
Humidity	TBD

Repeater light control unit enclosure

Type	ORGA CIP400–H-R00, part no. M450–64
Enclosure material	Steel
Temperature range	–40 to +55 °C
Ingress protection	IP 66
Humidity	TBD

Connection box for meteorology sensors

Type	Hensel RK 0610 T, part no. M410–69
Enclosure material	Polypropylene (PP)
Temperature range	–25 to +40 °C
Relative humidity	50 % at 40 °C and 100 % at 25 °C
Ingress protection	IP 66

External interface specifications

Processing Unit

Serial ports	6 non-dedicated isolated ports, RS-232 or RS-422 ^[6] Isolated COM1 and COM2, 9-pin DSub, RS-232
Baud rate	Up to 115 200 bytes/sec
LAN	4 Ethernet ports
USB	3 ports, 1 in front and 2 in rear
Analog inputs	Two user configurable channels, 4 to 20 mA

6. Number of serial ports may be expanded by using a serial port extender.

HMI Unit

LAN	5 Ethernet ports in rear
USB	6 ports, 2 in front and 4 in rear

MRU Unit

Serial ports	1 RS-232 and 1 RS-422
Ethernet UDP/IP	10/100 Mbps
Digital output variables	Max. 24, serial or Ethernet
Data output rates	Max. 200 Hz
Timing	< 1 ms

Product safety specifications

Processing Unit

Electrical safety (LVD) ^[7]	IEC 61010-1/EN 61010-1
--	------------------------

Data output specifications

Processing Unit

Message type	NMEA XDR, MWV and MWD
--------------	-----------------------

Data input specifications

Processing Unit

Formats:	
External gyro compass	NMEA 0183 HDT and HDG
External wind sensor	NMEA 0183 MWV and MWD
External temperature sensor	NMEA 0183 XDR(,,C)
External humidity sensor	NMEA 0183 XDR(,,H)

7. This equipment is intended for professional use only.

External pressure sensor	NMEA 0183 XDR(,,P)
External position signal	NMEA 0183 GGA, GLL and RMC
External speed signal	NMEA 0183 VTG
Optional speed time and date signal	NMEA 0183 ZDA

Cable specifications

See the various wiring tables in this document for cable specifications.

MRU cable

Type	MRU-E-CS8, Heavy duty screened, 14 x 2 x 0.25 mm ²
Length	3 m
Diameter	13.5 mm
Weight	0.27 kg/m
Flame retardation	IEC 60332-1
Insulation	PP (conductors) and PUR (outer cover)
Screen	Cu-braid
Bend radius	100 mm

Cable from Processing Unit to MRU/MGC junction box

Type	4 x 2 x 0.5 mm ² individually shield twisted pairs
Maximum length	100 m
Diameter	10 mm
Flame retardation	IEC 332-3/A

Data cable

Specification for cables connected to the communication interface ports.

Clamping range, max.	0.08 to 1.50 mm ²
Cable types:	
Solid H05(07) V-U, Stranded H07 V-R, Flexible H05(07) V-K, Flexible with ferrule, Ferrule with plastic collar	0.50 to 1.50 mm ²
Stripping length	6.0 mm

Repeater light cable

Orga Strobeline cable for Orga obstruction light systems.

Standards/certification Halogen free AWM Style 20233 E63216 I/II
A/B 80 °C 300V FT1/FT2

Electrical characteristics

System voltage 110 - 230 VAC

Impedance fieldbus wires 120 Ω

Physical characteristics

Colour Grey/black, Ral 7021 + Orange stripe Ral 2004

Weight 261 g/m

Operating temperature range -40 °C – 50 °C

Installation temperature range -10 °C – 70 °C

Power conductor 2 cores + PE; 1.50 mm²

Fieldbus conductor 0.50 mm²/; separately shielded

Alarm wires 0.50 mm²

Cable bending radius static 7x cable diameter

Outer cable diameter Ø 12.5 ± 0.5 mm

Outer shield braided.

Halogen free materials.

Repeater light control unit cable

Type CAT 7

Length 100 m max TBD

Interface descriptions

Processing Unit interfaces

The Processing Unit is a platform which is used for many different Kongsberg Maritime products. The interfaces which are applicable to the HMS system, are described here.

Front interfaces Processing Unit

The power switch, LAN 1 and USB 1 are located behind the lid to the left on the front panel. Push lid on left side to open.

Note _____

The USB port is not compatible with USB 3 devices.




Connector	Type	Connected to
LAN 1	RJ-45 – 10/100 Mbit/s	Reserved for support
USB	USB	For software upgrade and data logging

Rear interfaces Processing Unit

The rear panel of the unit contains communication interface ports for interfacing to external equipment.

Note _____

The USB ports are not compatible with USB 3 devices.



Connector	Type	Connected to
GNSS 1	N connector 50 Ohm female	Not used in this system
GNSS 2	N connector 50 Ohm female	Not used in this system
IALA	N connector 50 Ohm female	Not used in this system
LAN 2	RJ-45 – 10/100/1000 Mbit/s	HMI Unit
USB 2	USB	User configurable
USB 3	USB	User configurable
LAN 3	RJ-45 – 10/100/1000 Mbit/s	MET-sensor power rail
LAN 4	RJ-45	GSN Router/switch
Mouse	PS/2	Not in use
Keyboard	PS/2	Not in use
COM 1	9-pin DSub male, RS-232	User configurable
COM 2	9-pin DSub male, RS-232	User configurable
VGA ^[8]	HD15 female	Not in use
COM 9 to COM 14	5-pin terminal, RS-422	User configurable
ALARM	3-pin terminal, relay	External alarm system
MRU/COM 8	10-pin terminal, RS-422	MRU 5+, MRU 5, MRU E, MRU H and MGC R2/R3
IMU	10-pin terminal	Not used in this system
1PPS	6-pin terminal	Not used in this system
ANALOG OUT	10-pin terminal	Not used in this system
ANALOG IN	6-pin terminal	Not used in this system
Power	100 to 240 V AC	Input of 100 to 240 V AC

Note

All terminal pin numbering goes from left (no. 1) to right.

RS-422 A and B signal definition

According to the following standard the signal state definitions are:

- Note that VGA output connector on Processing Unit provides + 5 V on pin 9 of VGA connector. When KVM switches are used this could cause a problem, if so, use a VGA cable without pin 9 connected.

- IEC 61162-1. The idle, marking, logical 1, OFF or stop bit states are defined by a negative voltage on line A with respect to line B. The active, spacing, logical 0, ON or start bit states are defined by a positive voltage on line A with respect to line B. It should be noted that the above A with respect to B levels are inverted from the voltage input/output requirements of standard UARTs and that many line drivers and receivers provide a logic inversion.

With reference to the table showing the pin layout for the serial ports on the rear panel screw terminals, note that the separate GND (ground) pin for each port is isolated from the chassis and shall act as a common signal intended to be connected between the talker (-TX) and the listener side (RX) of other equipment, for example the corresponding isolated GND (ground) pin or common pin. The purpose of the common signal is to increase the reliability of the hardware transmission. It must not be connected to the chassis or the cable screen. This applies to both sides of a connection. The cable screen shall be connected to the equipment chassis on one side only, preferably talker side, -TX.

COM 1 and COM 2

COM 1 and COM 2 at the rear of the Processing Unit are 9-pin DSub male and have the following pin layout.


Pin no.	RS-232	Pin no.	RS-232
1	DCD1	6	DSR1
2	RXD1	7	RTS1
3	TXD1	8	CTS1
4	DTR1	9	RI1
5	GND		

Note

COM 1 and 2 are not as accurate with regard to timing as COM 9 to 14 and are not recommended used for timing critical outputs.

Connector board

The illustration shows the screw terminal pin layout on the connector board at the rear of the Processing Unit.



Serial lines

This system communicates with external equipment through the RS-232 or RS-422 configurable serial input and output lines.

Table 3 Pin layout of serial input/output lines

Pin no.	Signal	
	RS-422	RS-232
1	RX_A	CTS
2	RX_B	RX
3	GND isolated	GND isolated
4	TX_A	RTS
5	TX_B	TX


Alarm signal

The Processing Unit has a built-in alarm functionality and can be connected to an external alarm. An alarm will open the alarm relay, which can be used to trigger an external alarm. The external alarm can be connected to the Alarm 3 pin terminal.

Table 4 Pin layout of Alarm port

Pin no.	Signal
1	Alarm_NO
2	Alarm_Com
3	Alarm_NC

The diagram shows how an external alarm can be connected to the Processing Unit ALARM terminal.



MRU

The MRU connector is used for power and interface to an MRU. Usually when an MRU is connected to a Processing Unit, a junction box is used to make the wiring easier.

Table 5 Pin layout of MRU

Pin no.	Signal
1	GND
2	LGND
3	NC
4	MRU_1PPS_N
5	XIN/MRU_1PPS_P
6	TX_A
7	TX_B
8	RX_A
9	RX_B
10	24V_MRU

Analog output

The analog output terminal is not used in this product.

IMU

The IMU terminal is not used in this product.

PPS signal

The PPS terminal is not used in this product.

Analog in

The Analog in terminal is not used in this product.

Ethernet connection

The Processing Unit has the possibility to input and output data on individually configurable network ports. The format and update rate are configured for each port in the **VMS Core Configuration** view.

- **LAN 1 in the front.** This is a service port and has less capacity (10/100 Mbps) than the other LANs. For direct connection to a PC you might need a crossover cable instead of a straight-through cable. The pin wiring for the different cable configurations is according to the table.

Straight-through		Crossover			
Signal	Pin no.	Signal	Pin no.	Pin no.	Signal
TX+	1	TX+	1	3	RX+
TX-	2	TX-	2	6	RX-
RX+	3	RX+	3	1	TX+
RX-	6	RX-	6	2	TX-

Note

The pins 4, 5, 7 and 8 are not used.

- **LAN 2, 3 and 4 at the rear.** These local area networks (LAN) are of high capacity (10/100/1000 Mbps) and are of type auto crossover and auto-negotiation. Below is the pin wiring for these LANs connected to different network capacities:

10/1000 or 100/1000 Mbps Ethernet			1000/1000 Mbps Ethernet		
Pin no.	Signal	Description	Pin no.	Signal	Description
1	TX_DA+	Transceive data +	1	BI_DA+	Bi-directional pair +A
2	TX_DA-	Transceive data -	2	BI_DA-	Bi-directional pair -A
3	RX_DB+	Receive data +	3	BI_DB+	Bi-directional pair +B
4			4	BI_DC+	Bi-directional pair +C
5			5	BI_DC-	Bi-directional pair -C
6	RX_DB-	Receive data -	6	BI_DB-	Bi-directional pair -B
7			7	BI_DD+	Bi-directional pair +D
8			8	BI_DD-	Bi-directional pair -D

To connect the unit network, use twisted pair (TP) cable with RJ-45 connectors. To comply with the IEC 60945 standard, shielded (screened) cable has to be used. Recommended cable type is CAT-5e. Category 5e cable is an enhanced version of Category 5 that adheres to more stringent standards. It is capable of transmitting data at speeds of up to 1000 Mbps (1 Gigabit per second). The maximum length of the cable which can be used is 100 metres (328 ft).

HMI Unit interfaces

The HMI Unit is a platform which is used for many different Kongsberg Maritime products. The interfaces which are applicable to the HMS system, are described here.

Front interface HMI Unit

Audio output port together with two USB ports are situated at the front together with the power switch.



Connector	Type	Connected to
Audio	Audio Out	User configurable
USB 1	USB 3.2 Gen. 1 (type-C)	User configurable
USB 2	USB 3.2 Gen. 2 (type-A)	User configurable

Rear interface HMI Unit

The rear panel of the HMI Unit contains communication interface ports for interfacing to the Processing Unit through a network switch.



Connector	Type	Connected to
LAN (marked RED rectangle)	RJ-45	Connected to the Processing Unit through GSN router
USB 3	USB 3.2 Gen. 1 (type-C)	User configurable
USB 4	USB 3.2 Gen. 1 (type-C)	User configurable
USB 5	USB 3.2 Gen. 2 (type-A)	User configurable
USB 6	USB 3.2 Gen. 2 (type-A)	User configurable
Display	Displayport	Display
HDMI	HDMI port	HDMI
100 to 240 V AC	Power	Input of 100 to 240 V AC

Ethernet connection

The HMI Unit has one LAN port at the rear. This port is mainly used to connect the HMI Unit to the Processing Unit (normally LAN 2). This LAN has 10/100 Mbps capacity.

To connect this LAN to a network, a straight-through twisted pair (TP) cable with RJ-45 connectors must be used. A straight-through cable is one where the pins of one connector are connected to the same pins of the other connector. The pin wiring for the twisted pair (TP) cable is according to the table.

Straight-through	
Signal	Pin no.
TX+	1
TX-	2
RX+	3
RX-	6

Note

The pins 4, 5, 7 and 8 are not used.

To connect the HMI Unit network, use twisted pair (TP) cable with RJ-45 connectors. To comply with the IEC 60945 standard, shielded (screened) cable has to be used. Recommended cable type is CAT-5e. Category 5e cable is an enhanced version of Category 5 that adheres to more stringent standards. It is capable of transmitting data at speeds of up to 1000 Mbps (1 Gigabit per second). The maximum length of the cable that can be used is 100 metres (328 ft).


Meteorology sensor interface

This is the use of the different COM ports for the input sensors.

Connector	Type	Connected to
COM 1	RS-232 and 19200 baud	Cloud height sensor CL31, Ceilometer
COM 2	RS-232 and 9600 baud	Visibility sensor PWD22
COM 9	RS-422, 19200 baud and NMEA XDR and MVW format. On XDRFilter select PRESS , TEMP and HUM .	Multi-wether sensor WXT536
COM 10	RS-422, 4800 baud, 1 Hz update rate and NMEA format GGA and VTG	GPS
COM 11	RS-422, 4800 baud, 1 Hz update rate and NMEA HDT format	Gyro compass
COM 12	RS-422, 19200 baud and NMEA XDR. On XDRFilter select PRESS .	Dual-pressure sensor
COM 13	RS-422, 9600 baud and NMEA MWV with 4 Hz sample rate.	Gill wind sensor WindObserver II
COM 14	5-pin terminal, RS-232, 9600 baud	Not in use
MRU/COM 8	RS-422, 9600 baud and MRU Normal format	MRU 5+, MRU 5, MRU E, MRU H, MGC R2, MGC R3
LAN 2	LAN, NMEA MTW or NMEA XDR format. The XDR format must include TS as transducer ID to be accepted as sea water temperature	Net switch on MET-sensor power rail, sea water temperature from automation system
LAN 3	LAN, repeater lights and Rang Finder wave sensor	Net switch on MET-sensor power rail
LAN 4	LAN, GSN router	GSN router

GSN router interfaces


The rear panel of the GSN router C891–24x contains communication ports for interfacing to Processing Unit, HMS Unit (IOT-1), HMS UNIT (IOT-2) and the ship network infrastructure.



1	Console or auxiliary port	7	SFP port
2	Reset Button	8	GE WAN port
3	USB port	9	SFP port
4	PoE enabled GE LAN ports	10	System LED
5	GE LAN ports	11	Kensington security slot
6	GE WAN port		

The C891-24x port mapping for HMS 300 is shown below.

Connector	Connected to
Port 1	GE WAN 0/1 patch cable
Port 7	GSN network via internet (ShipsNet)
Port 8	GE WAN 0/0 patch cable
Port 9	HMS EDGE Unit IOT-1
Port 15	HMS EDGE Unit IOT-2
Port 20	HMS 300 PU



Equipment handling

Taking delivery

When the equipment arrives at its destination:

- Perform an inspection immediately to register any damage which may have occurred in transit.
- If you find any damage, both the insurance company and the shipping agent must be informed immediately.

Unpacking and handling

Care should be taken when unpacking and handling equipment. A visual inspection should be made to check that the equipment has not been damaged during shipment and that all components and parts are present according to the packing list.

The equipment contains delicate electronic components - handle with care and avoid shocks.

The equipment can be lifted by hand.

Storage

All the delivered system components must be stored within their original packing until they have been installed. See the environment specifications for the storage conditions.

If the system components have been installed but are not powered, the temperature at the installation location has to be within the specified operation temperature range and humidity for each component. See the environment specifications for operation conditions.

Related topics


- *Environmental specifications* on page 137

Health and safety

Operation or troubleshooting of this equipment will not imply any risk for high voltages, explosions or exposure to gas. The equipment complies with IEC 61010-1/EN 61010-1 standards regarding product safety and IEC 60945/EN 60945 standards on electromagnetic compatibility (immunity/radiation) and vibration.

Disposal

All electrical and electronic components have to be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or local authorities. The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment. For more detailed information about disposal of your old appliance, please contact your local authorities or waste disposal service.



The equipment may be returned to Kongsberg Maritime AS if there is no local WEEE (Waste Electrical and Electronic Equipment) collection. The equipment is marked with this pictogram.

Virus protection

The system is delivered from Kongsberg Maritime AS without any virus protection software installed. If the system is connected to the network on board the vessel, the network administration on board has to ensure that the HMS system is protected against viruses.

References

Reference documents

- 1 *HMS 300 Operator manual*, Kongsberg Maritime AS
- 2 *MGC COMPASS R-series Installation Manual*, Kongsberg Maritime AS
- 3 HMS Repeater Lights System, Installation, operation and maintenance manual, Orga BV
- 4 WindObserver II Ultrasonic Anemometer, User Manual
- 5 Vaisala Weather Transmitter WXT530, User's Guide
- 6 Vaisala BAROCAP Digital Barometer PTB330, User's Guide
- 7 Vaisala Ceilometer CL31, User's Guide
- 8 Present Weather Detector PWD22, User's Guide
- 9 SM-140 Range Finder, User Manual
- 10 General Conditions for the Supply of Products, Orgalime S 2000 with one exception sheet
- 11 Standard Measuring Equipment for Helideck Monitoring System (HMS) and Weather Data
- 12 CAP 437, Offshore Helicopter Landing Area - Guidance on Standards, CAA, London
- 13 Check and verification procedure, HMS 300 installations in UK, Norwegian and Brazilian waters
- 14 WMO-No.306, Manual on codes, Volume I.1, Part A – Alphanumeric codes, Section A – Code Forms. FM 15–XIV METAR Aerodrome routine meteorological report (with or without trend forecast)

Appendix A


Check list

This check list is used to ensure that every item during an installation of a HMS system is completed before leaving the vessel.

Item no	Description	Done
1)	A dimension survey report is completed	<input type="checkbox"/>
2)	The Function Test Form from SAT is completed	<input type="checkbox"/>
3)	Drawings and cable list updated	<input type="checkbox"/>
4)	HMS system software upgraded to latest version	<input type="checkbox"/>
5)	Correct operation limits (vessel category) selected	<input type="checkbox"/>

Appendix B Status light

The HMS 300 can be connected to the Orga status light and the light controlled through the alarm connector on the rear of the Processing Unit. The figure below shows an overview of the connections and the parts required.




Alarm signal

The Processing Unit has a built-in alarm functionality and can be connected to an external alarm. An alarm will open the alarm relay, which can be used to trigger an external alarm. The external alarm can be connected to the Alarm 3 pin terminal on the rear of the Processing Unit.

Table 6 Pin layout of Alarm port

Pin no.	Signal
1	Alarm_NO
2	Alarm_Com
3	Alarm_NC


The diagram shows how an external alarm can be connected to the Processing Unit ALARM terminal.



The alarm output signal on pin 1 and 2 are used to control the status light.


External light relay box

The external light relay box with part no. M440-62 is used to connect the HMS 300 alarm signal to the status light control panel. The connections in the external light relay box is shown in the below figure.



Status light control panel

The output from the external light relay box is connected to the Orga Helideck Status Light Control Panel as shown in the figure below.




Installation

Prerequisites

- The status light is mounted on the helideck. See the *L425EX Helideck status light, Installation and maintenance manual* from Orga for how this is done.
- The status light control panel is mounted and connected to the status light. See the *Helideck status light Control panel, Installation and maintenance manual* from Orga for how this done.
- The HMS 300 system is installed and in operation.

Procedure

- 1 Identify the best mounting location for the external light relay box (M440–62).
- 2 Mark and drill four M6 holes in the foundation according to the bolt pattern shown in the figure below.



- 3 Supply the external light relay box with 100 to 240 V AC power on connector N and L.
- 4 Connect a cable between the ALARM terminal on the Processing Unit to the external light relay box. Connect one of the wires between pin 1 on the ALARM terminal to connector 2 on the external light relay box and a wire between pin 2 on the ALARM terminal to connector 1 on the external light relay box.
- 5 Connect a cable between the external light relay box and the status light control panel. Connect one of the wires between pin 12 on the external light relay box to terminal X11-6 on the control panel and a wire between pin 22 on the external light relay box to terminal X11-19 on the control panel.
- 6 Connect a cable from the status light control panel to the status light. See the *L425EX Helideck status light, Installation and maintenance manual* from Orga for how this done.

Appendix C

NMEA protocols

The interfacing protocol NMEA 0183 which is used is defined in *References* on page 157. The system accepts these NMEA protocols for input and output of data.

Wind speed and direction data

MWD message

The MWD message contains the direction which the wind blows across the earth's surface, with respect to north, and the speed of the wind.

Format

\$--MWD, x.x, T, x.x, M, x.x, N, x.x, M*hh<CR><LF>

Format description

- 1 x.x,T = Wind direction, 0 to 359 degrees True
- 2 x.x,M = Wind direction, 0 to 359 degrees Magnetic
- 3 x.x,N = Wind speed, knots
- 4 x.x,M = Wind speed, metres/second

MWV message

The MWV message contains the transferring wind speed and true or relative wind direction.

For further details, refer to the NMEA standard.

Format

\$--MWV, x.x, a, x.x, a, A*hh<CR><LF>

Format description

- 1 x.x = Wind angle, 0 to 350 degrees
- 2 a = Reference: R = relative, T = Theoretical
- 3 x.x = Wind speed

- 4 a = Wind speed units, K/M/N/S
- 5 A = Status: A = Data valid, V = Data invalid.

Pressure, temperature and humidity data

XDR message

The XDR message contains the transducer measurements for pressure, temperature and humidity. This message can also be used for sea water temperature.

For further details, refer to the NMEA standard.

Format

\$--XDR, a, x.x, a, c-c*hh<CR><LF>

Format description

- 1 a = Transducer type: P = pressure, C = temperature, H = humidity
- 2 x.x = Measurement data
- 3 a = Units of measure
- 4 c-c = Transducer ID

This system supports transmission of up to four measurements in each XDR message. All sensor types can occur anywhere in the message, like: .

\$..XDR, <type>, <data>, <unit>, <ident>, <type>, ...<ident>*<chk>

The following adjustments to the XDR message is implemented:

- In the example below the check sum is omitted. The check sum is checked if it is included in the message.
- The Talker (WI in the example) can include any character.
- There are no limitations in the number of decimals for a value.
- The unit field has to be included for the pressure measurement. This field is also checked for the other sensor types, if it is included.
- The transducer ID field is used to identify whether the information is air or sea water temperature. If the ID is TA then its identified as air temperature, if ID is TS its identified as sea water temperature and if the ID is omitted then its identified as air temperature.
- Both type and the unit field is case sensitive.

Example 1 Omission of checksum in XDR message

- Transmission of a pressure value: 954.2 hPa = 0.954 Bar

\$WIXDR, P, 0.954392, B,

- Transmission of a humidity value: 90.5 %

Example 1 Omission of checksum in XDR message (cont'd.)

```
$WIXDR,H,90.5,,
```

- Transmission of a temperature value: 6.6 deg C

```
$WIXDR,C,6.6,,
```

Sea water temperature

The MTW message contains the water temperature in degrees C.

Format

```
$--MTW,x.x,C*hh<CR><LF>
```

Format description

- 1 x.x = Temperature,
- 2 C = Degrees C

Heading data

HDT message

The HDT message contains the actual vessel heading in degrees. True produced by any device or system producing true heading.

Format

```
$--HDT,x.x,T*hh<CR><LF>
```

Format description

- 1 x.x = Heading.
- 2 T = Degrees True.

HDG message

The HDG message contains heading (magnetic sensor reading), which if corrected for deviation, will produce Magnetic heading, which if offset by variation, will provide True heading.

For further details, refer to the NMEA standard.

Format

```
$--HDG,x.x,x.x,a,x.x.a*hh<CR><LF>
```

Format description

- 1 **x.x** = Magnetic sensor heading, degrees
- 2 **x.x,a** = Magnetic deviation, degrees E/W
- 3 **x.x,a** = Magnetic variation, degrees E/W

Position and speed data

GGA messages

The GGA message contains time, position and GPS/GLONASS data. The message is as specified in NMEA 0183 version 3.0. The message structure is as follows:

Format

```
$--GGA,hhmmss.ss,llll.ll,a,yyyy.yy,a,x,xx,x.x,x.x,M,x.x,M,  
x.x,xxxx*hh
```

Format description

- 1 **hhmmss.ss** = UTC of position (hours, minutes, seconds)
- 2 **llll.ll** = Latitude (degrees, minutes and fractions of minutes)
- 3 **a** = Latitude sector, N - North or S - South
- 4 **yyyy.yy** = Longitude (degrees, minutes and fractions of minutes)
- 5 **a** = Longitude sector, E - East or W - West
- 6 **x** = GPS Quality indicator: 0 = Fix not valid, 1 = GPS/GLONASS fix, 2 = DGPS/DGLONASS fix, 5 = Float RTK fix (XP/G2 corrections used), 6 = Estimated (dead reckoning). This field shall not be a null field.
- 7 **xx** = Number of satellites in use, 00 - 12
- 8 **x.x** = HDOP - horizontal dilution of precision 00.0 to 99.9
- 9 **x.x** = Altitude, reference: mean-sea-level (geoid)
- 10 **M** = Altitude unit, M = metres.
- 11 **x.x** = Geoidal separation: the difference between the WGS-84 ellipsoid and mean-sea-level (geoid)
- 12 **M** = Geoidal separation unit, M = metres
- 13 **x.x** = Age of differential corrections, in seconds. 0 when DGPS not used
- 14 **xxxx** = Differential reference station ID, 0000-1023
- 15 ***hh** = Checksum.

GLL messages

The GLL message presents latitude and longitude of vessel position, time at position fix and status. The message is as specified in NMEA 0183 version 3.0. The message structure is as follows:

Format

```
$--GLL, llll.ll, a, yyyyy.yy, a, hhmmss.ss, A, a*hh
```

Format description

- 1 **llll.ll** = Latitude component of position, in degrees, minutes and fraction of minutes
- 2 **a** = Latitude sector, N - North or S - South
- 3 **yyyyy.yy** = Longitude component of position, in degrees, minutes and fraction of minutes
- 4 **a** = Longitude sector, E - East or W - West
- 5 **hhmmss.ss** = UTC of position (hours, minutes, seconds)
- 6 **A** = Status, A = valid, V = invalid
- 7 **a** = Mode indicator, A = autonomous mode, D = differential mode, N = data not valid
- 8 ***hh** = Checksum.

VTG messages

The VTG message contains actual course and speed relative to the ground. The message is as specified in NMEA 0183 version 3.0. The message structure is as follows:

Format

```
$--VTG, x.x, T, x.x, M, x.x, N, x.x, K, a*hh
```

Format description

- 1 **x.x** = True course over ground in degrees
- 2 **T** = True course over ground marker
- 3 **x.x** = Magnetic course over ground in degrees
- 4 **M** = Magnetic course over ground marker
- 5 **x.x** = Speed over ground in knots
- 6 **N** = "N" shows that speed over ground is in knots
- 7 **x.x** = Speed over ground in kilometres/hour
- 8 **K** = "K" shows that speed over ground is in kilometres/hour
- 9 **a** = Mode indicator. A=automatic mode, D=differential mode, N=data not valid. Shall not be a null field
- 10 ***hh** = Checksum

RMC messages

The RMC message contains time, date, position, course and speed data. The message is as specified in NMEA 0183 version 3.0. The message structure is as follows:

Format

```
$--RMC,  
hhmmss.ss,A,llll.ll,a,yyyy.yy,a,x.x,x.x,xxxxxx,x.x,a,a*hh
```

Format description

- 1 **hhmmss.ss** = UTC of position fix
- 2 **A** = Status: A = Data valid, V = Navigation receiver warning
- 3 **lll.ll** = Latitude
- 4 **a** = Latitude sector, N = North, S = South
- 5 **yyyy.yy** = Longitude
- 6 **A** = Longitude sector, E = East, W = West
- 7 **x.x** = Speed over ground, knots
- 8 **x.x** = Course over ground, degrees True
- 9 **xxxxxx** = Date: day, month, year.
- 10 **x.x** = Magnetic variation in degrees
- 11 **a** = Magnetic variation direction, E = Easterly variation, subtracts from True course, W = Westerly variation, adds to True course
- 12 **a** = Mode indicator, A = Autonomous mode, D = differential mode, E = Estimated (dead reckoning) mode, N = Data not valid
- 13 ***hh** = Checksum.

Time sync data

ZDA message

The ZDA message contains UTC time, day, month, year and local time. The message is as specified in NMEA 0183 version 3.0. The message structure is as follows:

For further details, refer to the NMEA standard.

Format

```
$--ZDA, hhmmss.ss, xx, xx, xxxx, xx, xx*hh
```

Format description

- 1 **hhmmss.sss** = UTC time, hours, minutes and seconds
- 2 **xx** = Current day in UTC, day 01 - 31
- 3 **xx** = Current month in UTC, month 01 - 12

- 4 **xxxx** = Current year in UTC
- 5 **xx** = Local zone-hours offset from UTC, 00 to ±13 hrs
- 6 **xx** = Local zone minutes offset from UTC, 00 to ±59
- 7 ***hh** = Checksum

Appendix D

Free and open source software

Some of the software components in this product are free and open source software released under the licenses shown below.

Source code for the relevant software components is available from:

Kongsberg Maritime AS

Attn.: Customer support

Pirsenteret

N-7462 Trondheim

Norway

E-mail km.support.seatex@kongsberg.com

The application software is proprietary, and no source code is available for it.

BSD license

Copyright (c) 1983, 1988, 1989, 1990, 1993 The Regents of the University of California.

Copyright (c) 1996, 1997, 1998, 1999, 2003 Theodore Ts'o.

Copyright (c) 1997, 1998, 2001 Kungliga Tekniska Högskolan.

Copyright (c) 1991, 1992 Paul Kranenburg <pk@cs.few.eur.nl>

Copyright (c) 1993 Branko Lankester <branko@hacktic.nl>

Copyright (c) 1993 Ulrich Pegelow <pegelow@moorea.uni-muenster.de>

Copyright (c) 1995, 1996 Michael Elizabeth Chastain <mec@duracef.shout.net>

Copyright (c) 1993, 1994, 1995, 1996 Rick Sladkey <jrs@world.std.com>

Copyright (c) 1998-2001 Wichert Akkerman <wakkerma@deephackmode.org>

Copyright (c) 1995 Nick Simicich (<njs@scifi.emi.net>)

Copyright (c) 2000-2001 Gunnar Ritter.

Copyright (c) 2004, Jan Kneschke, incremental

Copyright (c) 1997-2010 University of Cambridge

Copyright (c) 2007-2010, Google Inc.

All Rights Reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Curl license

COPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1996 - 2017, Daniel Stenberg, daniel@haxx.se, and many contributors, see the THANKS file.

All rights reserved. Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

f2c license

Copyright 1990 - 1997 by AT&T, Lucent Technologies and Bellcore.

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that the copyright notice and this permission notice and warranty disclaimer appear in supporting documentation, and that the names of AT&T, Bell Laboratories, Lucent or Bellcore or any of their entities not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

AT&T, Lucent and Bellcore disclaim all warranties with regard to this software, including all implied warranties of merchantability and fitness. In no event shall AT&T, Lucent or Bellcore be liable for any special, indirect or consequential damages or any damages whatsoever resulting from loss of use, data or profits, whether in an action of contract, negligence or other tortious action, arising out of or in connection with the use or performance of this software.

GCC license

GCC is released under the license shown below in addition to GPL and LGPL.

GCC RUNTIME LIBRARY EXCEPTION

Version 3.1, 31 March 2009

Copyright (C) 2009 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. This GCC Runtime Library Exception ("Exception") is an additional permission under section 7 of the GNU General Public License, version 3 ("GPLv3"). It applies to a given file (the "Runtime Library") that bears a notice placed by the copyright holder of the file stating that the file is governed by GPLv3 along with this Exception. When you use GCC to compile a program, GCC may combine portions of certain GCC header files and runtime libraries with the compiled program. The purpose of this Exception is to allow compilation of non-GPL (including proprietary) programs to use, in this way, the header files and runtime libraries covered by this Exception.

0. Definitions.

A file is an "Independent Module" if it either requires the Runtime Library for execution after a Compilation Process, or makes use of an interface provided by the Runtime Library, but is not otherwise based on the Runtime Library. "GCC" means a version of the GNU Compiler Collection, with or without modifications, governed by version 3 (or a specified later version) of the GNU General Public License (GPL) with the option of using any subsequent versions published by the FSF. "GPL-compatible Software" is software whose conditions of propagation, modification and use would permit combination with GCC in accord with the license of GCC. "Target Code" refers to output from any compiler for a real or virtual target processor architecture, in executable form or suitable for input to an assembler, loader, linker and/or execution phase. Notwithstanding that, Target Code does not include data in any format that is used as a compiler intermediate representation, or used for producing a compiler intermediate representation. The "Compilation Process" transforms code entirely represented in non-intermediate languages designed for human-written code, and/or in Java Virtual Machine byte code, into Target Code. Thus, for example, use of source code generators and preprocessors need not be considered part of the Compilation Process, since the Compilation Process can be understood as starting with the output of the generators or preprocessors. A Compilation Process is "Eligible" if it is done using GCC, alone or with other GPL-compatible software, or if it is done without using any work based on GCC. For example, using non-GPL-compatible Software to optimize any GCC intermediate representations would not qualify as an Eligible Compilation Process.

1. Grant of Additional Permission.

You have permission to propagate a work of Target Code formed by combining the Runtime Library with Independent Modules, even if such propagation would otherwise violate the terms of GPLv3, provided that all Target Code was generated by Eligible Compilation Processes. You may then convey such a combination under terms of your choice, consistent with the licensing of the Independent Modules.

2. No Weakening of GCC Copyleft.

The availability of this Exception does not imply any general presumption that third-party software is unaffected by the copyleft requirements of the license of GCC.

GNU general public license, version 2

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it. Thus, it is not the intent of this section to claim rights or contest your rights

to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or, Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and an idea of what it does>

Copyright ©<year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of TyCoon> 1 April 1989 Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

GNU general public license, version 3

GNU GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright (C) 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The GNU General Public License is a free, copyleft license for software and other kinds of works.

The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program—to make sure it remains free software for all its users. We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors. You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things. To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others. For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights. Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it. For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions. Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users. Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special danger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL assures that patents cannot be used to render the program non-free. The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS

0. Definitions.

"This License" refers to version 3 of the GNU General Public License. "Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks. "The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations. To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work. A "covered work" means either the unmodified Program or a work based on the Program. To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy. Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well. To "convey" a work means any kind of propagation that

enables other parties to make or receive copies. Mere interaction with a user through a computer network, with no transfer of a copy, is not conveying. An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion.

1. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work. A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language. The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it. The "Corresponding Source" for a work in object code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities. However, it does not include the work's System Libraries, or general-purpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work. The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source. The Corresponding Source for a work in source code form is that same work.

2. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are irrevocable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law. You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you. Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary.

3. Protecting Users' Legal Rights From Anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures. When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this

License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures.

4. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program. You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee.

5. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions: a) The work must carry prominent notices stating that you modified it, and giving a relevant date. b) The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to "keep intact all notices". c) You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7 additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it. d) If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so. A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, in or on a volume of a storage or distribution medium, is called an "aggregate" if the compilation and its resulting copyright are not used to limit the access or legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate.

6. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways: a) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange. b) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge. c) Convey individual copies of the object code with a copy of the written offer to provide the Corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b. d) Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain

obligated to ensure that it is available for as long as needed to satisfy these requirements. e) Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d. A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work. A "User Product" is either (1) a "consumer product", which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, "normally used" refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial or non-consumer uses, unless such uses represent the only significant mode of use of the product. "Installation Information" for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made. If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM). The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network. Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying.

7. Additional Terms.

"Additional permissions" are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions. When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission. Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms: a) Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or b) Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or c) Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or d) Limiting the use for publicity purposes of names of licensors or authors of the material; or e) Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or f) Requiring

indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors. All other non-permissive additional terms are considered "further restrictions" within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying. If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms. Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way.

8. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11). However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation. Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice. Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10.

9. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program. Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so.

10. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License. An "entity transaction" is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest, if the predecessor has it or can get it with reasonable efforts. You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it.

11. Patents.

A "contributor" is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's "contributor version". A contributor's "essential patent claims" are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the contributor version. For purposes of this definition, "control" includes the right to grant patent sublicenses in a manner consistent with the requirements of this License. Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version. In the following three paragraphs, a "patent license" is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To "grant" such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party. If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with the requirements of this License, to extend the patent license to downstream recipients. "Knowingly relying" means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid. If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you grant is automatically extended to all recipients of the covered work and works based on it. A patent license is "discriminatory" if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on the non-exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license (a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or (b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007. Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law.

12. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program.

13. Use with the GNU Affero General Public License.

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such.

14. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation. If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program. Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version.

15. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

17. Interpretation of Sections 15 and 16.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal effect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively state the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found. <one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author> This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program. If not, see <<http://www.gnu.org/licenses/>>. Also add information on how to contact you by electronic and paper mail. If the program does terminal interaction, make it output a short notice like this when it starts in an interactive mode: <program> Copyright (C) <year> <name of author> This program comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details. The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, your program's commands might be different; for a GUI interface, you would use an "about box". You should also get your employer (if you work as a programmer) or school, if any, to sign a "copyright disclaimer" for the program, if necessary. For more information on this, and how to apply and follow the GNU GPL, see <<http://www.gnu.org/licenses/>>. The GNU General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License. But first, please read <<http://www.gnu.org/philosophy/why-not-lgpl.html>>.

GNU lesser general public license, version 2.1

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages—typically libraries—of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it. For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".) "Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

The modified work must itself be a software library.

You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW.

EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and an idea of what it does>

Copyright ©<year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail. You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library. `Frob' (a library for tweaking knobs) written by James Random Hacker..

<signature of TyCoon> 1 April 1990 Ty Coon, President of Vice

That's all there is to it!

GNU lesser general public license, version 3

GNU LESSER GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright (C) 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

This version of the GNU Lesser General Public License incorporates the terms and conditions of version 3 of the GNU General Public License, supplemented by the additional permissions listed below.

0. Additional Definitions.

As used herein, "this License" refers to version 3 of the GNU Lesser General Public License, and the "GNU GPL" refers to version 3 of the GNU General Public License. "The Library" refers to a covered work governed by this License, other than an Application or a Combined Work as defined below. An "Application" is any work that makes use of an interface provided by the Library, but which is not otherwise based on the Library. Defining a subclass of a class defined by the Library is deemed a mode of using an interface provided by the Library. A "Combined Work" is a work produced by combining or linking an Application with the Library. The particular version of the Library with which the Combined Work was made is also called the "Linked Version". The "Minimal Corresponding Source" for a Combined Work means the Corresponding Source for the Combined Work, excluding any source code for portions of the Combined Work that, considered in isolation, are based on the Application, and not on the Linked Version. The "Corresponding Application Code" for a Combined Work means the object code and/or source code for the Application, including any data and utility programs needed for reproducing the Combined Work from the Application, but excluding the System Libraries of the Combined Work.

1. Exception to Section 3 of the GNU GPL. You may convey a covered work under sections 3 and 4 of this License without being bound by section 3 of the GNU GPL.

2. Conveying Modified Versions.

If you modify a copy of the Library, and, in your modifications, a facility refers to a function or data to be supplied by an Application that uses the facility (other than as an argument passed when the facility is invoked), then you may convey a copy of the modified version: a) under this License, provided that you make a good faith effort to ensure that, in the event an Application does not supply the function or data, the facility still operates, and performs whatever part of its purpose remains meaningful, or b) under the GNU GPL, with none of the additional permissions of this License applicable to that copy.

3. Object Code Incorporating Material from Library Header Files.

The object code form of an Application may incorporate material from a header file that is part of the Library. You may convey such object code under terms of your choice, provided that, if the incorporated material is not limited to numerical parameters, data structure layouts and accessors, or small macros, inline functions and templates (ten or fewer lines in length), you do both of the following: a) Give prominent notice with each copy of the object code that the Library is used in it and that the Library and its use are covered by this License. b) Accompany the object code with a copy of the GNU GPL and this license document.

4. Combined Works.

You may convey a Combined Work under terms of your choice that, taken together, effectively do not restrict modification of the portions of the Library contained in the Combined Work and reverse engineering for debugging such modifications, if you also do each of the following: a) Give prominent notice with each copy of the Combined Work that the Library is used in it and that the Library and its use are covered by this License. b) Accompany the Combined Work with a copy of the GNU GPL and this license document. c) For a Combined Work that displays copyright notices during execution, include the copyright notice for the Library among these notices, as well as a reference directing the user to the copies of the GNU GPL and this license document. d) Do one of the following: 0) Convey the Minimal Corresponding Source under the terms of this License, and the Corresponding Application Code in a form suitable for, and under terms that permit, the user to recombine or relink the Application with a modified version of the Linked Version to produce a modified Combined Work, in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source. 1) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (a) uses at run time a copy of the Library already present on the user's computer system, and (b) will operate properly with a modified version of the Library that is interface-compatible with the Linked Version. e) Provide Installation Information, but only if you would otherwise be required to provide such information under section 6 of the GNU GPL, and only to the extent that such information is necessary to install and execute a modified version of the Combined Work produced by recombining or relinking the Application with a modified version of the Linked Version. (If you use option 4d0, the Installation Information must accompany the Minimal Corresponding Source and Corresponding Application Code. If you use option 4d1, you must provide the Installation Information in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source.)

5. Combined Libraries.

You may place library facilities that are a work based on the Library side by side in a single library together with other library facilities that are not Applications and are not covered by this License, and convey such a combined library under terms of your choice, if you do both of the following: a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities, conveyed under the terms of this License. b) Give prominent notice with the combined library that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

6. Revised Versions of the GNU Lesser General Public License.

The Free Software Foundation may publish revised and/or new versions of the GNU Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Library as you received it specifies that a certain numbered version of the GNU Lesser General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that published version or of any later version published by the Free Software Foundation. If the Library as you received it does not specify a version number of the GNU Lesser General Public License, you may choose any version of the GNU Lesser General Public License ever published by the Free Software Foundation. If the Library as you received it specifies that a proxy can decide whether future versions of the GNU Lesser General Public License shall apply, that proxy's public statement of acceptance of any version is permanent authorization for you to choose that version for the Library.

GNU C library license

The GNU C library is released under the licenses shown below in addition to GPL and LGPL.

This file contains the copying permission notices for various files in the GNU C Library distribution that have copyright owners other than the Free Software Foundation. These notices all require that a copy of the notice be included in the accompanying documentation and be distributed with binary distributions of the code, so be sure to include this file along with any binary distributions derived from the GNU C Library.

All code incorporated from 4.4 BSD is distributed under the following license:

Copyright (C) 1991 Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. [This condition was removed.] 4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The DNS resolver code, taken from BIND 4.9.5, is copyrighted both by UC Berkeley and by Digital Equipment Corporation. The DEC portions are under the following license: Portions Copyright (C) 1993 by Digital Equipment Corporation. Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software without specific, written prior permission.

THE SOFTWARE IS PROVIDED ``AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

The Sun RPC support (from rpcsrc-4.0) is covered by the following license: Copyright (C) 1984, Sun Microsystems, Inc. Sun RPC is a product of Sun Microsystems, Inc. and is provided for unrestricted use provided that this legend is included on all tape media and as a part of the software program in whole or part. Users may copy or modify Sun RPC without charge, but are not authorized to license or distribute it to anyone else except as part of a product or program developed by the user.

SUN RPC IS PROVIDED AS IS WITH NO WARRANTIES OF ANY KIND INCLUDING THE WARRANTIES OF DESIGN, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE.

Sun RPC is provided with no support and without any obligation on the part of Sun Microsystems, Inc. to assist in its use, correction, modification or enhancement.

SUN MICROSYSTEMS, INC. SHALL HAVE NO LIABILITY WITH RESPECT TO THE INFRINGEMENT OF COPYRIGHTS, TRADE SECRETS OR ANY PATENTS BY SUN RPC OR ANY PART THEREOF.

In no event will Sun Microsystems, Inc. be liable for any lost revenue or profits or other special, indirect and consequential damages, even if Sun has been advised of the possibility of such damages. The following CMU license covers some of the support code for Mach, derived from Mach 3.0: Mach Operating System Copyright (C) 1991,1990,1989 Carnegie Mellon University All Rights Reserved. Permission to use, copy, modify and distribute this software and its documentation is hereby granted, provided that both the copyright notice and this permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS ``AS IS" CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Carnegie Mellon requests users of this software to return to: Software Distribution Coordinator School of Computer Science Carnegie Mellon University Pittsburgh PA 15213-3890 or Software. Distribution@CS.CMU.EDU any improvements or extensions that they make and grant Carnegie Mellon the rights to redistribute these changes.

The file `if_ppp.h` is under the following CMU license: Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY CARNEGIE MELLON UNIVERSITY AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE UNIVERSITY OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The following license covers the files from Intel's "Highly Optimized Mathematical Functions for Itanium" collection: Intel License Agreement Copyright (c) 2000, Intel Corporation All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

* Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

* The name of Intel Corporation may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL INTEL OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The files inet/getnameinfo.c and sysdeps/posix/getaddrinfo.c are copyright (C) by Craig Metz and are distributed under the following license: /* The Inner Net License, Version 2.00 The author(s) grant permission for redistribution and use in source and binary forms, with or without modification, of the software and documentation provided that the following conditions are met: 0. If you receive a version of the software that is specifically labelled as not being for redistribution (check the version message and/or README), you are not permitted to redistribute that version of the software in any way or form. 1. All terms of the all other applicable copyrights and licenses must be followed. 2. Redistributions of source code must retain the authors' copyright notice(s), this list of conditions, and the following disclaimer. 3. Redistributions in binary form must reproduce the authors' copyright notice(s), this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution. 4. [The copyright holder has authorized the removal of this clause.] 5. Neither the name(s) of the author(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ITS AUTHORS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

If these license terms cause you a real problem, contact the author. */

ISC license

Copyright (c) 2004-2010 by Internet Systems Consortium, Inc. ("ISC")

Copyright (c) 1995-2003 by Internet Software Consortium

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND ISC DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL ISC BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

OpenSSL license

LICENSE ISSUES

=====

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact openssl-core@openssl.org.

OpenSSL License

=====

Copyright (c) 1998-2011 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org/>)"

4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.

5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.

6. Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit
(<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

=====

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License

Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This package is an SSL implementation written

by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are aheared to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

"This product includes cryptographic software written by

Eric Young (eay@cryptsoft.com)"

The word 'cryptographic' can be left out if the rouines from the library being used are not cryptographic related :-).

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement:

"This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

OpenSSH license

This file is part of the OpenSSH software.

The licences which components of this software fall under are as follows. First, we will summarize and say that all components are under a BSD licence, or a licence more free than that.

OpenSSH contains no GPL code.

1) * Copyright (c) 1995 Tatu Ylonen , <ylo@cs.hut.fi>, Espoo, Finland

* All rights reserved * * As far as I am concerned, the code I have written for this software * can be used freely for any purpose. Any derived versions of this * software must be clearly marked as such, and if the derived work is * incompatible with the protocol description in the RFC file, it must be * called by a name other than "ssh" or "Secure Shell". [Tatu continues] * However, I am not implying to give any licenses to any patents or * copyrights held by third parties, and the software includes parts that * are not under my direct control. As far as I know, all included * source code is used in accordance with the relevant license agreements * and can be used freely for any purpose (the GNU license being the most * restrictive); see below for details. [However, none of that term is relevant at this point in time. All of these restrictively licenced software components which he talks about have been removed from OpenSSH, i.e., - RSA is no longer included, found in the OpenSSL library - IDEA is no longer included, its use is deprecated - DES is now external, in the OpenSSL library - GMP is no longer used, and instead we call BN code from OpenSSL - Zlib is now external, in a library - The make-ssh-known-hosts script is no longer included - TSS has been removed - MD5 is now external, in the OpenSSL library - RC4 support has been replaced with ARC4 support from OpenSSL - Blowfish is now external, in the OpenSSL library [The licence continues] Note that any information and cryptographic algorithms used in this software are publicly available on the Internet and at any major bookstore, scientific library, and patent office worldwide. More information can be found e.g. at "<http://www.cs.hut.fi/crypto>". The legal status of this program is some combination of all these permissions and restrictions. Use only at your own responsibility. You will be responsible for any legal consequences yourself; I am not making any claims whether possessing or using this is legal or not in your country, and I am not taking any responsibility on your behalf.

NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

2) The 32-bit CRC compensation attack detector in deattack.c was contributed by CORE SDI S.A. under a BSD-style license. * Cryptographic attack detector for ssh - source code * * Copyright (c) 1998 CORE SDI S.A., Buenos Aires, Argentina. * * All rights reserved. Redistribution and use in source and binary * forms, with or without modification, are permitted provided that * this copyright notice is retained. *

* THIS SOFTWARE IS PROVIDED ``AS IS" AND ANY EXPRESS OR IMPLIED * WARRANTIES ARE DISCLAIMED. IN NO EVENT SHALL CORE SDI S.A. BE * LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR * CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR MISUSE OF THIS * SOFTWARE. * * Ariel Futoransky <futo@core-sdi.com> <<http://www.core-sdi.com>>

3) ssh-keyscan was contributed by David Mazieres under a BSD-style license. * Copyright 1995, 1996 by David Mazieres <dm@lcs.mit.edu>. * * Modification and redistribution in source and binary forms is * permitted provided that due credit is given to the author and the * OpenBSD project by leaving this copyright notice intact.

4) The Rijndael implementation by Vincent Rijmen, Antoon Bosselaers and Paulo Barreto is in the public domain and distributed with the following license: * @version 3.0 (December 2000) * * Optimised ANSI C code for the Rijndael cipher (now AES) * * @author Vincent Rijmen <vincent.rijmen@esat.kuleuven.ac.be> * @author Antoon Bosselaers <antoon.bosselaers@esat.kuleuven.ac.be> * @author Paulo Barreto <paulo.barreto@terra.com.br>* * This code is hereby placed in the public domain. *

* THIS SOFTWARE IS PROVIDED BY THE AUTHORS "AS IS" AND ANY EXPRESS * OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE * ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE * LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR * CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF * SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR * BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, * WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE * OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, * EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

5) One component of the ssh source code is under a 3-clause BSD license, held by the University of California, since we pulled these parts from original Berkeley code. * Copyright (c) 1983, 1990, 1992, 1993, 1995 * The Regents of the University of California. All rights reserved. * * Redistribution and use in source and binary forms, with or without * modification, are permitted provided that the following conditions * are met: * 1. Redistributions of source code must retain the above copyright * notice, this list of conditions and the following disclaimer. * 2. Redistributions in binary form must reproduce the above copyright * notice, this list of conditions and the following disclaimer in the * documentation and/or other materials provided with the distribution. * 3. Neither the name of the University nor the names of its contributors * may be used to endorse or promote products derived from this software * without specific prior written permission. *

* THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS" AND * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE * ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) * HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER

IN CONTRACT, STRICT * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY * OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF * SUCH DAMAGE.

6) Remaining components of the software are provided under a standard 2-term BSD licence with the following names as copyright holders: Markus Friedl Theo de Raadt Niels Provos Dug Song Aaron Campbell Damien Miller Kevin Steves Daniel Kouril Wesley Griffin Per Allansson Nils Nordman Simon Wilkinson Portable OpenSSH additionally includes code from the following copyright holders, also under the 2-term BSD license: Ben Lindstrom Tim Rice Andre Lucas Chris Adams Corinna Vinschen Cray Inc. Denis Parker Gert Doering Jakob Schlyter Jason Downs Juha Yrjölä Michael Stone Networks Associates Technology, Inc. Solar Designer Todd C. Miller Wayne Schroeder William Jones Darren Tucker Sun Microsystems The SCO Group Daniel Walsh * Redistribution and use in source and binary forms, with or without * modification, are permitted provided that the following conditions * are met: * 1. Redistributions of source code must retain the above copyright * notice, this list of conditions and the following disclaimer. * 2. Redistributions in binary form must reproduce the above copyright * notice, this list of conditions and the following disclaimer in the * documentation and/or other materials provided with the distribution. *

* THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS" AND ANY EXPRESS OR * IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES * OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. * IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, * INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT * NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, * DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY * THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT * (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF * THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

8) Portable OpenSSH contains the following additional licenses: a) md5crypt.c, md5crypt.h * "THE BEER-WARE LICENSE" (Revision 42): * <phk@login.dknet.dk> wrote this file. As long as you retain this * notice you can do whatever you want with this stuff. If we meet * some day, and you think this stuff is worth it, you can buy me a * beer in return. Poul-Henning Kamp b) snprintf replacement * Copyright Patrick Powell 1995 * This code is based on code written by Patrick Powell * (papowell@astart.com) It may be used for any purpose as long as this * notice remains intact on all source code distributions c) Compatibility code (openbsd-compat) Apart from the previously mentioned licenses, various pieces of code in the openbsd-compat/ subdirectory are licensed as follows: Some code is licensed under a 3-term BSD license, to the following copyright holders: Todd C. Miller Theo de Raadt Damien Miller Eric P. Allman The Regents of the University of California Constantin S. Svintsoff * Redistribution and use in source and binary forms, with or without * modification, are permitted provided that the following conditions * are met: * 1. Redistributions of source code must retain the above copyright * notice, this list of conditions and the following disclaimer. * 2. Redistributions in binary form must reproduce the above copyright * notice, this list of conditions and the following disclaimer in the * documentation and/or other materials provided with the distribution. * 3. Neither the name of the University nor the names of its contributors * may be used to endorse or promote products derived from this software * without specific prior written permission. *

* THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS" AND * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE * ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR

BUSINESS INTERRUPTION) * HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY * OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF * SUCH DAMAGE.

Some code is licensed under an ISC-style license, to the following copyright holders: Internet Software Consortium. Todd C. Miller Reyk Floeter Chad Mynhier * Permission to use, copy, modify, and distribute this software for any * purpose with or without fee is hereby granted, provided that the above * copyright notice and this permission notice appear in all copies. *

* THE SOFTWARE IS PROVIDED "AS IS" AND TODD C. MILLER DISCLAIMS ALL * WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES * OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL TODD C. MILLER BE LIABLE * FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES * WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION * OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN * CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Some code is licensed under a MIT-style license to the following copyright holders: Free Software Foundation, Inc. * Permission is hereby granted, free of charge, to any person obtaining a * * copy of this software and associated documentation files (the * * "Software"), to deal in the Software without restriction, including * * without limitation the rights to use, copy, modify, merge, publish, * * distribute, distribute with modifications, sublicense, and/or sell * * copies of the Software, and to permit persons to whom the Software is * * furnished to do so, subject to the following conditions: * * * * The above copyright notice and this permission notice shall be included * * in all copies or substantial portions of the Software. * * *

* THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS * * OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF * * MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. * * IN NO EVENT SHALL THE ABOVE COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, * * DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR * * OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR * * THE USE OR OTHER DEALINGS IN THE SOFTWARE. * * *

* Except as contained in this notice, the name(s) of the above copyright * * holders shall not be used in advertising or otherwise to promote the * * sale, use or other dealings in this Software without prior written * * authorization.

* *****/

— \$OpenBSD: LICENCE,v 1.19 2004/08/30 09:18:08 markus Exp \$

TinyLogin license

TinyLogin is released under the license shown below in addition to GPL.

The shadow utilities license:

This software is copyright 1988 - 1994, Julianne Frances Haugh. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. 2. Redistributions in binary form must reproduce the above copyright notice,

this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. Neither the name of Julianne F. Haugh nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY JULIE HAUGH AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL JULIE HAUGH OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This source code is currently archived on ftp.uu.net in the comp.sources.misc portion of the USENET archives. You may also contact the author, Julianne F. Haugh, at <jockgrrl@austin.rr.com> if you have any questions regarding this package.

THIS SOFTWARE IS BEING DISTRIBUTED AS-IS. THE AUTHORS DISCLAIM ALL LIABILITY FOR ANY CONSEQUENCES OF USE. THE USER IS SOLELY RESPONSIBLE FOR THE MAINTENANCE OF THIS SOFTWARE PACKAGE. THE AUTHORS ARE UNDER NO OBLIGATION TO PROVIDE MODIFICATIONS OR IMPROVEMENTS. THE USER IS ENCOURAGED TO TAKE ANY AND ALL STEPS NEEDED TO PROTECT AGAINST ACCIDENTAL LOSS OF INFORMATION OR MACHINE RESOURCES.

Special thanks are due to Chip Rosenthal for his fine testing efforts; to Steve Simmons for his work in porting this code to BSD; and to Bill Kennedy for his contributions of LaserJet printer time and energies. Also, thanks for Dennis L. Mumaugh for the initial shadow password information and to Tony Walton (olapw@olgb1.oliv.co.uk) for the System V Release 4 changes. Effort in porting to SunOS has been contributed by Dr. Michael Newberry (miken@cs.adfa.oz.au) and Micheal J. Miller, Jr. (mke@kaber.drain.com). Effort in porting to AT&T UNIX System V Release 4 has been provided by Andrew Herbert (andrew@werple.pub.uu.oz.au). Special thanks to Marek Michalkiewicz (marekm@i17linuxb.ists.pwr.wroc.pl) for taking over the Linux port of this software.

Source files: login_access.c, login_desrpc.c, login_krb.c are derived from the logdaemon-5.0 package, which is under the following license:

/******

Copyright 1995 by Wietse Venema. All rights reserved. Individual files * may be covered by other copyrights (as noted in the file itself.) * *

This material was originally written and compiled by Wietse Venema at * Eindhoven University of Technology, The Netherlands, in 1990, 1991, * 1992, 1993, 1994 and 1995. * *

Redistribution and use in source and binary forms are permitted * provided that this entire copyright notice is duplicated in all such * copies. * *

This software is provided "as is" and without any expressed or implied * warranties, including, without limitation, the implied warranties of * merchantability and fitness for any particular purpose.

*****/

This software is copyright 1988 - 1994, Julianne Frances Haugh. All rights reserved

X11 license

Copyright (c) 1998-2004,2006 Free Software Foundation, Inc

Copyright (c) 1998 Red Hat Software

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, distribute with modifications, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. IN NO EVENT SHALL THE ABOVE COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name(s) of the above copyright holders shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization.

Mosquitto license

Copyright (c) Eclipse Foundation, Inc

Eclipse Mosquitto is an open source (EPL/EDL licensed) message broker that implements the MQTT protocol versions 5.0, 3.1.1 and 3.1. Mosquitto is lightweight and is suitable for use on all devices from low power single board computers to full servers.

Eclipse Public License version 2.0. THE ACCOMPANYING PROGRAM IS PROVIDED UNDER THE TERMS OF THIS ECLIPSE PUBLIC LICENSE ("AGREEMENT"). ANY USE, REPRODUCTION OR DISTRIBUTION OF THE PROGRAM CONSTITUTES RECIPIENT'S ACCEPTANCE OF THIS AGREEMENT.

Google Protobuf license

Copyright (c) 2008 Google Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. * Neither the name of Google Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Code generated by the Protocol Buffer compiler is owned by the owner of the input file used when generating it. This code is not standalone and requires a support library to be linked with it. This support library is itself covered by the above license.

Libmodbus license

Copyright (c) 2019.

libmodbus is a free software library to send/receive data according to the Modbus protocol. This library is written in C and supports RTU (serial) and TCP (Ethernet) communications. The license of libmodbus is LGPL v2.1+ and the licence of programs in the tests directory is BSD 3-clause.

A

about, purpose of this manual, 13
 about, target audience, 13
 accuracy, survey, 85
 alarm signal, 147
 alignment, 11
 alignment surfaces, 81
 analog in, 149
 analog output, 148
 attitude, 11
 audience, this manual, 13

B

b-frame, 11

C

cabinet requirements, 31
 cable layout, 86
 cable plan, 86
 cable specifications, 142–143
 cable specifications, repeater light cable, 143
 cables, 86, 142
 cables, HMI Unit, 37
 cables, MGC, 49
 cables, MRU, 46
 cables, Processing Unit, 34
 cabling, HMI Unit, 38
 cabling, Processing Unit, 34, 36
 CG, 10
 CGND, 10
 check list, 158
 CL, 10
 cloud height sensor dimensions, 114
 cloud height sensor installation, 63
 cloud height sensor location, 30
 cloud height sensor wiring, 69
 cloud height sensor, dimensions, 133
 cloud height sensor, environmental specifications, 139
 cloud height sensor, performance, 130
 cloud height sensor, power, 136
 COM ports, 146
 commissioning, 103
 common reference point, CRP, 76
 components, 16, 19

configuration, 89
 connection box met sensors, dimensions, 135
 connection box met sensors, environmental specifications, 140
 connector board, Processing Unit, 146
 contact details, 23
 control unit for repeater light, how to install, 56
 Control Unit, location, 29
 corrosion, 28
 CRP, common reference point, 76

D

data cable, 142
 data input specifications, 141
 data input specifications, Processing Unit, 141
 data output specifications, 141
 data output specifications, Processing Unit, 141
 definition, vessel reference system, 76
 description, EDGE Unit, 19
 description, HMI Unit, 19
 description, MGC unit, 20
 description, MRU Unit, 20
 description, Processing Unit, 19
 description, repeater light, 20
 description, repeater light control unit, 21
 diagram power, 122
 diagram wiring, 123
 dimensions, 131
 dimensions, cloud height sensor, 114, 133
 dimensions, connection box met sensors, 135
 dimensions, Control Unit enclosure, 126–128
 dimensions, dual-pressure sensor, 133
 dimensions, GSN router, 134
 dimensions, hand rail, 118
 dimensions, hand rail mounting bracket, 134
 dimensions, HMI Unit, 106, 131
 dimensions, junction box, 132
 dimensions, MGC Ex enclosure, 111

dimensions, MRU junction box, 110
 dimensions, MRU Unit, 131
 dimensions, MRU5+, 107
 dimensions, multi-weather sensor, 113, 133
 dimensions, Processing Unit, 105, 131
 dimensions, protected mounting bracket, 132
 dimensions, range finder sensor, 119
 dimensions, range findersensor, 117
 dimensions, RangeFinder sensor, 134
 dimensions, repeater light, 124, 134
 dimensions, repeater light control unit enclosure, 134
 dimensions, shock absorber, 115
 dimensions, visibility sensor, 116, 133
 dimensions, wall mounting bracket, 108, 132
 dimensions, wind sensor, 133
 DIP switch Phoenix contact, 120
 DIP switch settings, 120
 disposal of electrical components, 156
 drawings, 25, 104
 dual barometric pressure sensor location, 30
 dual-pressure sensor installation, 61
 dual-pressure sensor wiring, 68
 dual-pressure sensor, dimensions, 133
 dual-pressure sensor, environmental specifications, 139
 dual-pressure sensor, performance, 130
 dual-pressure sensor, power, 136

E

EDGE Unit, description, 19
 enclosure, dimensions Control Unit enclosure, 126–128
 environmental specifications, 137

environmental specifications, cloud height sensor, 139
environmental specifications, connection box met sensors, 140
environmental specifications, dual-pressure sensor, 139
environmental specifications, HMI Unit, 137
environmental specifications, junction box, 138
environmental specifications, MRU Unit, 138
environmental specifications, multi-weather sensor, 139
environmental specifications, Processing Unit, 137
environmental specifications, Range Finder sensor, 140
environmental specifications, RangeFinder sensor, 139
environmental specifications, repeater light, 140
environmental specifications, visibility sensor, 139
environmental specifications, wind sensor, 138
equipment and tools, 25
equipment storage, 155
ethernet connection, 149
export, 21
external interfaces, 140

F

free and open source software, 170
front interfaces, 144
front panel HMI Unit, 150
front panel of Processing Unit, 144

G

g-frame, 11
GGAmesssage, 166

GGND, 10
GLL message, 167
GPS, 10
GSN router, dimensions, 134
GSN router, power, 137
guarantee, restrictions, 22
GUI, 10

H

hand rail dimensions, 118
hand rail mounting bracket, dimensions, 134
handling of equipment, 155
HDG message, 165
HDT message, 165
health and safety, 156
heave, 11
helideck, survey, 82
HMI, 10
HMI Unit cables, 37
HMI Unit dimensions, 106
HMI Unit location, 26
HMI Unit, description, 19
HMI Unit, dimensions, 131
HMI Unit, environmental specifications, 137
HMI Unit, how to install, 33
HMI Unit, interfaces, 141
HMI Unit, power, 135
how to, dispose of electrical components, 156
how to, install the junction box, 45
how to, verify HMS for operational use, 90

I

IMU terminal, 148
IMU, location, 27
IMU, transportation box, 26
installation, cloud height sensor, 63
installation, dual-pressure sensor, 61
installation, junction box, 45
installation, meteorology sensors, 58
installation, MRU, 39
installation, MRU junction box, 45
installation, multi-weather sensor, 60
installation, visibility sensor, 64
installation, wave and water level system, 73

installation, wind sensor, 58
installing, HMI Unit, 33
installing, Processing Unit, 33
installing, rack, 32
installing, repeater light, 52
installing, repeater light control unit, 56
installing, status light, 161
interface specifications, Processing Unit, 140
interfaces, HMI Unit, 141
interfaces, met sensors, 152
interfaces, MRU Unit, 141
interfaces, Processing Unit, 34, 144

J

junction box, 138
junction box mounting, 43
junction box, dimensions, 132
junction box, environmental specifications, 138
junction box, how to install, 45

L

LAN 1, 149
LAN 2, 149
LAN 3, 149
LAN 4, 149
LCD display, 90
LED, 10, 90
LED indicators Processing Unit, 90
LGND, 10
license information, 13
licenses, 13
local area network (LAN), 23
location, cloud height sensor, 30
location, Control Unit, 29
location, dual barometric pressure sensor, 30
location, HMI Unit, 26
location, IMU, 27
location, meteorological sensor, 30
location, MGC, 27
location, MGC junction box, 28
location, monitor, 28
location, MRU, 27
location, MRU junction box, 28
location, multi-weather sensor, 30

location, Processing Unit, 26
 location, RangeFinder
 sensor, 31, 73
 location, repeater light, 28
 location, system parts, 26
 location, visibility sensor, 30
 location, wind sensor, 30

M

maintenance, 13
 manual, purpose, 13
 manual, target audience, 13
 meteorological sensor
 location, 30
 meteorology sensor,
 interfaces, 152
 meteorology sensors, 21
 meteorology sensors,
 installation, 58
 MGC cables, 49
 MGC Ex enclosure,
 dimensions, 111
 MGC junction box,
 location, 28
 MGC unit, description, 20
 MGC Unit, survey, 79
 MGC, location, 27
 monitor location, 28
 MP, 10
 MRC, 10
 MRU, 10
 MRU cable, specifications, 142
 MRU cables, 46
 MRU installation, 39
 MRU junction box, 132
 MRU junction box
 dimensions, 110
 MRU junction box
 installation, 45
 MRU junction box,
 location, 28
 MRU mounting angles, 43
 MRU performance, 129
 MRU Unit, description, 20
 MRU Unit, dimensions, 131
 MRU Unit, environmental
 specifications, 138
 MRU Unit, interfaces, 141
 MRU Unit, power, 135
 MRU Unit, survey, 77
 MRU, location, 27
 MRU, pin layout, 148
 MRU5+ dimensions, 107
 MSL, 10
 MTW message, 165
 multi-weather sensor
 dimensions, 113

multi-weather sensor
 installation, 60
 multi-weather sensor
 location, 30
 multi-weather sensor
 wiring, 66
 multi-weather sensor,
 dimensions, 133
 multi-weather sensor,
 environmental
 specifications, 139
 multi-weather sensor,
 performance, 130
 multi-weather sensor,
 power, 136
 MWD message, 163
 MWV message, 163

N

network security, 23
 NMEA, 10
 NMEA protocols, 163

O

ocean sensor power rail, 75
 operational use, how to
 verify that HMS is ready, 90
 orientation, RangeFinder
 sensor, 73
 origin, 85
 overview, system, 15

P

parts, additional, 17
 parts, locations, 26
 parts, standard, 16
 performance, 129
 performance, cloud height
 sensor, 130
 performance, dual-pressure
 sensor, 130
 performance, MRU, 129
 performance,
 multi-weather sensor,
 130
 performance, RangeFinder
 sensor, 131
 performance, visibility
 sensor, 131
 performance, wind sensor, 129
 PGND, 10
 Phoenix contact DIP
 switch, 120
 pin layout COM ports, 146

pin layout ethernet, 151
 pin layout MRU, 148
 pitch, 11
 power, 135
 power diagram, 122
 power MRU Unit, 135
 power rail, ocean sensor, 75
 power, cloud height sensor, 136
 power, dual-pressure
 sensor, 136
 power, GSN router, 137
 power, HMI Unit, 135
 power, multi-weather
 sensor, 136
 power, Processing Unit, 135
 power, RangeFinder
 sensor, 136
 power, repeater light, 136
 power, repeater light
 control unit, 137
 power, visibility sensor, 136
 power, wind sensor, 135
 PPS signal, 149
 pre-installation, 25
 pre-installed rack units, 32
 preparations, 25
 procedure, installing HMI
 Unit, 33
 procedure, installing
 Processing Unit, 33
 procedure, installing rack, 32
 procedure, installing
 repeater light, 52
 procedure, installing
 repeater light control unit, 56
 procedure, installing status
 light, 161
 Processing Unit
 dimensions, 105, 131
 Processing Unit location, 26
 Processing Unit safety, 141
 Processing Unit, cables, 34
 Processing Unit, data input
 specifications, 141
 Processing Unit, data
 output specifications, 141
 Processing Unit,
 description, 19
 Processing Unit,
 environmental
 specifications, 137
 Processing Unit, how to
 install, 33
 Processing Unit, interface
 specifications, 140
 Processing Unit, interfaces, 144
 Processing Unit, LED, 90

Processing Unit, power, 135
product restrictions, 21
protected mounting
 bracket, 41
protected mounting
 bracket, dimensions,
 132
protocols, NMEA, 163
purpose, this manual, 13

Q

QFE, 10
QNH, 10

R

rack units, pre-installed, 32
rack, how to install, 32
Range Finder, 21
range finder sensor
 dimensions, 119
Range Finder sensor,
 environmental
 specifications, 140
rangefinder sensor
 dimensions, 117
RangeFinder sensor
 location, 31
RangeFinder sensor,
 dimensions, 134
RangeFinder sensor,
 environmental
 specifications, 139
RangeFinder sensor,
 location, 73
RangeFinder sensor,
 orientation, 73
RangeFinder sensor,
 performance, 131
RangeFinder sensor,
 power, 136
RangFinder sensor, 73
rear interfaces, 145
rear panel HMI Unit, 151
rear panel of Processing
 Unit, 144
references, 157
registered trademarks, 13
relay alarm signal, 147
repeater light control unit
 enclosure, dimensions, 134
repeater light control unit,
 description, 21
repeater light control unit,
 power, 137
repeater light, description, 20
repeater light, dimensions,
 124, 134

repeater light,
 environmental
 specifications, 140
repeater light, how to
 install, 52
repeater light, location, 28
repeater light, power, 136
repeater light, schematics, 125
restrictions, 21
restrictions, guarantee, 22
restrictions, in product use, 21
RMC message, 168
RMS, 10
roll, 11
RS-422 signal, 145

S

safety, 22, 141
safety, Processing Unit, 141
schematics, repeater light, 125
scope of supply, 16
sea water temperature
 sensor wiring, 72
sensor unit, survey, 76–77
serial lines, 147
serial port extender, 159
settings, DIP switch, 120
shock absorber
 dimensions, 115
SHR, 10
skills, workers, 26
specifications, 129
specifications, cable, 142–143
specifications, MRU cable, 142
specifications, repeater
 light cable, 143
starboard, 11
status light, how to install, 161
storage, 155
support information, 23
survey accuracy, 85
survey of sensor unit, 76
survey, helideck, 82
survey, MGC Unit, 79
survey, MRU Unit, 77
survey, wind sensor, 83
system components, 121
system description, 14
system diagram, 15
system parts, location, 26
system schematics, 121
system units, 19

T

taking delivery, 155
technical specifications, 129
temperature changes, 28

tools and equipment, 25
trademarks, 13
transportation box, IMU, 26

U

units, 19
unpacking of equipment, 155
use, restrictions, 22
UTC, 10

V

verifying that HMS is
 ready for operational use, 90
vessel reference system,
 definition, 76
vibrations, 27
virus protection, 156
visibility sensor
 dimensions, 116
visibility sensor
 installation, 64
visibility sensor location, 30
visibility sensor wiring, 70
visibility sensor,
 dimensions, 133
visibility sensor,
 environmental
 specifications, 139
visibility sensor,
 performance, 131
visibility sensor, power, 136
VTG message, 167

W

wall mounting bracket, 39
wall mounting bracket
 dimensions, 108–109
wall mounting bracket,
 dimensions, 132
warranty, 26
wave and water level
 system, 21
wave and water level
 system, installation, 73
WEEE, 10
wind sensor,
 environmental
 specifications, 138
wind sensor installation, 58
wind sensor location, 30
wind sensor wiring, 65
wind sensor, dimensions, 133
wind sensor, performance, 129
wind sensor, power, 135
wind sensor, survey, 83

wiring cloud height sensor, 69
wiring diagram, 123
wiring dual-pressure
 sensor, 68
wiring meteorology
 sensors, 65
wiring multi-weather
 sensor, 66
wiring sea water
 temperature sensor, 72
wiring visibility sensor, 70
wiring wind sensor, 65
worker skills, 26

X

XDR message, 164

Y

yaw, 11

Z

ZDA message, 168

©2023 Kongsberg Maritime