




KONGSBERG

Kongsberg EM 124 Multibeam Echo Sounder Maintenance Manual



*Image: Bathymetry of the Northern Portion of the Mariana Trench.
Courtesy of Dr James V. Gardener, University of New Hampshire.*

458499/A

March 2020 © Kongsberg Maritime AS

Document information

- **Product:** Kongsberg EM 124
- **Document:** Maintenance Manual
- **Document part number:** 458499
- **Revision:** A
- **Date of issue:** 17 March 2020

Copyright

The information contained in this document remains the sole property of Kongsberg Maritime AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Maritime AS.

Warning

The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. You must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.

Kongsberg Maritime disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.

Disclaimer

Kongsberg Maritime AS endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.

Support information

If you require maintenance or repair, contact Kongsberg Maritime's support organisation. You can also contact us using the following address: km.hydrographic.support@kongsberg.com. If you need information about our other products, visit <https://www.kongsberg.com/maritime>.

Table of contents

ABOUT THIS MANUAL.....	9
KONGSBERG EM 124.....	10
System description.....	11
Technical details.....	12
System diagram.....	13
System units.....	14
Transducer description.....	14
Transmitter Unit description.....	15
Receiver Unit description.....	15
Processing Unit description.....	15
Hydrographic Work Station description.....	16
Support information.....	17
TROUBLESHOOTING	18
Tools for troubleshooting.....	19
BIST (Built-In Self Test) dialog box.....	20
BIST (Built-In Self Test) theory.....	23
BIST Introduction.....	24
CPU Test.....	25
CBMF test.....	26
RX unit test.....	27
TX unit test.....	28
CBMF-CPU link.....	29
RX-CBMF link.....	30
RX channels.....	31
TX channels.....	32
RX noise level.....	33
RX noise spectrum.....	34
Software date and versions.....	35
System information.....	35
PREVENTIVE MAINTENANCE.....	36
Inspecting and cleaning the transducer face.....	37
Painting the transducer face.....	39
Inspecting and replacing sacrificial anodes.....	41
Approved anti-fouling paints.....	42
PARTS REPLACEMENT.....	44
Tools and equipment required for parts replacement.....	45
Processing Unit - Parts replacement.....	47

Processing Unit replacement	48
CPU board replacement.....	51
VadaTech CP219 Ethernet switch replacement - Processing Unit	54
CBMF board replacement	57
Fan unit replacement - Processing Unit	60
Processing Unit fuse replacement	63
Transmitter Unit - Parts replacement	66
Fan unit replacement - Transmitter Unit	67
12V Power supply replacement - Transmitter Unit.....	72
HV Power supply replacement - Transmitter Unit.....	78
Receiver Unit - Parts replacement	83
Receiver Unit replacement	84
Power supply replacement - Receiver Unit.....	89
SPARE PARTS AND CONSUMABLES	95
Ordering spare parts	96
Processing Unit - List of spare parts	97
Processing Unit spare part 436571	97
CBMF board spare part 430675	97
CPU board spare part 457015	98
Power supply spare part 373897	98
Fan unit spare part 385387	99
Transmitter Unit - List of spare parts.....	100
LPTX36 Transmitter board spare part 446679.....	100
TX RIO board spare part 426321	100
Ethernet switch spare part 338124	101
TXU Fan unit spare part 430443	101
TXU 12V Power supply spare part 437247	101
TXU HV Power supply spare part 437225	102
Receiver Unit - List of spare parts	103
Receiver Unit 1 degree - spare part 424633	103
Receiver Unit 2 degrees - spare part 424634	103
Receiver Unit 4 degrees - spare part 424635	104
RXU Power supply spare part 428206	104
PROCESSING UNIT	105
Processing Unit description	106
Processing Unit familiarization.....	106
Processing Unit front panel description.....	107
Processing Unit rear panel description	108
Processing Unit circuit boards and modules.....	109
CPU board.....	110

Concurrent PP B12 CPU board overview	110
Concurrent PP B12 CPU board connectors	111
Concurrent PP833 CPU board overview	111
Concurrent PP833 CPU board connectors	112
CP219 Ethernet switch	113
Ethernet switch overview	113
Ethernet switch connectors	114
CBMF board	115
CBMF board overview	115
CBMF board configuration	116
CBMF board connectors	117
TRANSMITTER UNIT	118
Transmitter Unit familiarization	118
Transmitter Unit bottom panel description	120
Transmitter Unit top panel description	122
Transmitter Unit power supplies	124
RIO-P board - dip switch setting	125
RECEIVER UNIT	126
Receiver Unit familiarization	127
Receiver Unit bottom panel description	128
Receiver Unit - dip switch setting	129
HYDROGRAPHIC WORK STATION	130
Hydrographic Work Station description	131
Hydrographic Work Station front panel description	131
Hydrographic Work Station rear panel description	132
DRAWING FILE	133
213673 TX module outline dimensions	135
213217 RX module outline dimensions	136
372053 TX mounting frame - 0.5 degrees	137
213433 TX mounting frame - 1 degree	138
213370A TX mounting frame - 2 degrees	139
213370B TX mounting frame - 2 degrees	140
213744 RX mounting frame - 1 degree	141
213389 RX mounting frame - 2 degrees	142
213803 RX mounting frame - 4 degrees	143
372981 TX Casing with frame - 0.5 degrees	144
213754 TX Casing with frame - 1 degree	145
213755 TX Casing with frame - 2 degrees	146
213749 RX Casing with frame - 1 degree	147

213756 RX Casing with frame - 2 degrees.....	148
213810 RX Casing with frame - 4 degrees.....	149
365207 Baffle plate 1 dimensions.....	150
365208 Baffle plate 2 dimensions.....	151
365209 Baffle plate 3 dimensions.....	152
426226 Transmitter Unit dimensions.....	153
435444 Receiver Unit dimensions.....	154
385422 Processing Unit dimensions.....	155
378828 HWS dimensions.....	156
445723 Rack installation kit dimensions.....	157
365290 KM 1000 mounting kit dimensions.....	158
409067 Fibre cable kit.....	159
370275 Remote Control Unit (K-REM) dimensions.....	160
373962 Remote Control Unit (K-REM) wiring diagram.....	161
TECHNICAL SPECIFICATIONS.....	162
Performance specifications.....	163
Interface specifications.....	165
Datagram formats.....	166
Interface specifications - Processing Unit - KMall format.....	167
External sensors requirements.....	170
Interface specifications - Hydrographic Work Station - KMall format.....	171
Weight and outline dimensions.....	172
Power requirements.....	175
Environmental requirements.....	177
Dimensional survey accuracy requirements.....	180
Alignment specifications.....	182
CABLE LAYOUT AND INTERCONNECTIONS.....	183
Cable plans.....	184
Cable plan, Processing Unit.....	185
Cable plan - Transmitter Unit.....	186
Cable plan, Receiver Unit, 1 degree.....	194
Synchronization overview, 2 Transmitter Units 1 Receiver Unit.....	197
Remote on/off overview, 2 Transmitter Units 1 Receiver Unit.....	198
Cable plan, Hydrographic Work Station.....	199
List of EM 124 cables.....	200
Clock synchronization (1PPS).....	204
External synchronization.....	206
Cable drawings and specifications.....	209
RS-232 serial line using three wires and RJ45 connector.....	210
RS-422 serial line using five wires and RJ45 connector.....	211

Clock synchronisation (1PPS) using a coax cable	212
External synchronisation	213
Remote control	214
Remote Control using K-Rem	215
Dummy plug for not using remote control	216
Remote control of Transmitter Unit	217
Remote control of Receiver Unit.....	219
Remote control overview	221
Transmit Transducer cable	223
Receive Transducer cable.....	224
EQUIPMENT HANDLING.....	225
Transporting Kongsberg Maritime equipment.....	226
Lifting units and transportation boxes	227
Inspection of units and transportation boxes after arrival.....	229
Specifications for storage prior to installation or use.....	230
Unpacking instructions	232
Unpacking standard parts and units.....	232
Unpacking mechanical units	233
Unpacking electronic and electromechanical units	234
Unpacking transducers	235
Specifications for storage after unpacking.....	237

About this manual

The purpose of this manual is to present the descriptions and drawings required to do basic maintenance tasks on the EM 124 Multibeam Echo Sounder. The equipment described in this manual includes the complete system with associated cabinets, but not those system units provided locally by the customer, installation shipyard or local dealer.

Target audience

The manual is intended for technical personnel; qualified maintenance engineers and technicians. You must understand the general principles of maritime electronic equipment. You must also be familiar with computer hardware, signal processing, interface technology and traditional troubleshooting on electronic and mechanical products.

We assume that you are familiar with the basic acoustic principles of sound in water. We also expect that you have some experience with multibeam, split-beam and/or single-beam echo sounders in scientific applications.

Online information

All relevant end-user documentation provided for your EM 124 can be downloaded from our website.

- <https://www.kongsberg.com/maritime/>

Our website also provides information about other Kongsberg products.

Technical information is available for registered users in our password protected database.

Registered trademarks

Observe the registered trademarks that apply.

EM® is a registered trademark of Kongsberg Maritime AS in Norway and other countries.

Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.

Kongsberg EM 124

Topics

[System description, page 11](#)

[Technical details, page 12](#)

[System diagram, page 13](#)

[System units, page 14](#)

[Support information, page 17](#)

System description

EM 124 multibeam echo sounder is a high performance echo sounder for deep water mapping.

The EM 124 is designed to perform seabed mapping to full ocean depth with an unsurpassed resolution, coverage and accuracy. The system is cost effective, reliable, and easily operated. The design of the EM 124 is based on more than 50 years of hydrographic experience with echo sounders, sonars and underwater positioning for civilian and military use. It is the latest model in a series of deep sea multibeam echo sounders that started with the EM 12 in 1990.

The EM 124 consist of new state-of-the-art electronics and separate transmit and receive transducers in a Mills Cross configuration. It uses the same field-proven transducers as the EM 122, making it easy to upgrade. Care has been taken to design a highly, modular and flexible solution with compact electronics for easier and faster installation. Due to a flexible transducer design, the system can be tailored to almost any required size. The largest standard size, 0.5 x 1 degrees, gives the ultimate system performance in terms of resolution and range, while a smaller 4 x 4 degrees solution allowing full ocean depth surveys even on smaller vessels.

The EM 124 multibeam echo sounder consists of the following main units.

- Transducer arrays
- Transmitter Unit(s)
- Receiver Unit(s)
- Processing Unit
- Hydrographic Work Station

To form a complete system it is also required to have sensors providing vessel attitude, velocity, position, sound speed profile of the water column and speed of sound at the transducer depth.

Technical details

The EM 124 operates at sonar frequencies in the 10.5-13.5 kHz range. The transmit fan is divided into 4 sectors in shallow modes (8 sectors in deep modes) to maximize range capability but also to suppress interference from multiples of strong bottom echoes. The sectors are transmitted sequentially within each ping, and uses distinct frequencies or waveforms.

The nominal sonar frequency is 12 kHz with an angular coverage sector of up to 150 degrees and 1600 beams per ping. Achievable swath width on a flat bottom will normally be up to 6 times (143 degrees) the water depth. The angular coverage sector is operator controllable or may be set to a fixed range. It may also be set to vary automatically with depth according to achievable coverage. This maximizes the number of usable beams. The beam spacing is normally high density equidistant with equiangle available.

The transmit fan is split in several individual sectors with independent active steering according to vessel roll, pitch and yaw. This places all beams on a "best fit" to a line perpendicular to the survey line, thus ensuring a uniform sampling of the bottom and 100% coverage.

In dual swath mode the transmit fan is duplicated and transmitted with a small difference in alongtrack tilt. The applied tilt takes into account depth, coverage and vessel speed to give a constant beam separation alongtrack.

The sectors are frequency coded or have FM chirps, and they are transmitted sequentially at each ping. The sector steering is fully taken into account when the position and depth of each beam is calculated, as is the refraction due to the sound speed profile, vessel attitude and installation angles. The pulse length and range sampling rate are variable with depth (auto or manual) for best resolution.

In shallow waters due care is taken to the near field effects through nearfield focusing individually applied in the different sectors.

EM 124 applies one focus range for each of the transmit sectors which are used for shallow water environment. Dynamic beam focusing is used for the reception beams.

The ping rate is mainly limited by the round trip travel time in the water up to a ping rate of more than 5 Hz.

The number of individual TX and RX modules in the two arrays depends on the chosen configuration. The standard types identified by "transmission x reception" beamwidth are:

- **0.5 x 1 degree system:** 96 transmit transducer modules and 16 receive transducer modules
- **1 x 1 degree system:** 48 transmit transducer modules and 16 receive transducer modules
- **1 x 2 degrees system:** 48 transmit transducer modules and 8 receive transducer modules
- **2 x 2 degrees system:** 24 transmit transducer modules and 8 receive transducer modules
- **2 x 4 degrees system:** 24 transmit transducer modules and 4 receive transducer modules
- **4 x 4 degrees system:** 12 transmit transducer modules and 4 receive transducer modules

System diagram

The system diagram identifies the main components of a basic EM 124 system. Only the main connections between the units are shown. Detailed interface capabilities and power cables are not shown.

A *Hydrographic Work Station*

B *Interfaces:*

- *Sound speed sensors*
- *Tide*
- *Centre depth output*

C *Processing Unit*

D *Interfaces:*


- *Positioning systems*
- *Attitude (roll, pitch and heave)*
- *Sound speed sensor*
- *Velocity*
- *Clock*
- *Trigger input/output*
- *Clock synchronisation (1PPS)*

E *Transmitter Unit (TXU)*

F *Receiver Unit (RXU)*

G *Transmit transducer modules*

H *Receive transducer modules*



System units

Topics

[Transducer description, page 14](#)

[Transmitter Unit description, page 15](#)

[Receiver Unit description, page 15](#)

[Processing Unit description, page 15](#)

[Hydrographic Work Station description, page 16](#)

Transducer description


A transducer is a device that converts one form of energy to another. In an echo sounder system the transducer converts between electric energy and sound.

The EM 124 uses separate transducer arrays for transmitting and receiving sound pulses. Both transducer arrays have several modules which are assembled in mounting frames.

The two transducer arrays are normally mounted as “T” or “L” configurations under the vessel’s hull (Mills Cross configuration). The transmit transducer array should be aligned parallel to the vessel’s keel. The receiver transducer array should be aligned 90 ° on the keel. Both transducer arrays should be horizontal on a plane on the keel.

The transmit transducer array contains up to 96 modules in accordance with the chosen beamwidth. Each module contains 18 elements arranged in rows of 6 elements. Each element is individually connected to its corresponding transmitter in the Transmitter Unit(s). It can thus be driven with an unique amplitude level and phase to allow forming of the required transmit sectors with individual steering.

The receive transducer contains up to 16 modules in accordance with the chosen beamwidth. Each module contains 8 transducer staves, and these have individual electrical connections to their corresponding preamplifiers in the Receiver Unit(s). Each staff can thus be given unique amplitude and phase control to allow forming of the required receive beams.



Receive transducer module

Transmitter Unit description

The EM 124 Transmitter Unit has all transmit electronics, like control processors, power amplifiers, power supply, capacitor battery and Ethernet interface.

The Transmitter Unit is a wall-mounted steel cabinet with integrated shock and vibration absorbers, designed for bulkhead mounting. One 19 inch sub-rack is contained in the cabinet. The number of circuit boards in the sub-rack will depend on the chosen transducer configuration.

Twisted pair Ethernet is used for data communication with the Processing Unit.

The Transmitter Unit is normally located in a "sonar room" close to the transducer arrays.



Receiver Unit description

The EM 124 Receiver Unit has all receive electronics, like control processor, amplifiers, Analog-to-Digital Converters, power supply and Ethernet interface.

The Receiver Unit is a small wall-mounted steel cabinet with integrated shock and vibration absorbers, designed for bulkhead mounting. The number of circuit boards in the Receiver Unit will depend on the chosen transducer configuration. Twisted pair Ethernet is used for data communication with the Processing Unit.

The Receiver Unit is normally located in a "sonar room" close to the transducer arrays.



Processing Unit description

The EM 124 Processing Unit is provided to process the signals to and from the Transmitter and Receiver Units.

The EM 124 Processing Unit is an industrial computer using both COTS (commercial off-the-shelf) components and custom made components. The unit is designed and tested for rugged use.

The Processing Unit performs the receiver beamforming, bottom detection, and motion and sound speed corrections. It contains all interfaces for time-critical external sensors such as vessel attitude (roll, pitch, heading and heave), vessel position and external clock. More than one sensor of each type may be connected simultaneously, with one in use and all of them logged.

The Processing Unit controls the Transmitter and Receiver units via Ethernet communication, and is also interfaced to the Operator station via Ethernet.



The 48 V output from the Processing Unit can be used for remote on/off control of the Transmitter and Receiver Units.

The Processing Unit is normally located in a "sonar room" close to the transducer arrays. The unit can also be placed in the "survey room" or on the bridge.

Hydrographic Work Station description

The Hydrographic Work Station is the operator station for the EM 124.

A dedicated maritime computer is provided with the EM 124 Multibeam Echo Sounder. It is set up with all necessary software.

The Hydrographic Work Station is based on the Microsoft® Windows 10 operating system.

The Hydrographic Work Station is normally mounted near the operator work space.



Support information

Should you need technical support for your EM 124 you must contact a Kongsberg Maritime office. A list of all our offices is provided on our website. You can also contact our main support office in Norway.

A 24 hour telephone support service may also be available depending on your Service Level Agreement.

- **Company name:** Kongsberg Maritime AS
- **Address:** Strandpromenaden 50, 3183 Horten, Norway
- **Website:** <https://www.kongsberg.com/maritime/>
- **E-mail address:** km.hydrographic.support@kongsberg.com

Troubleshooting

Topics

[Tools for troubleshooting, page 19](#)

[BIST \(Built-In Self Test\) dialog box, page 20](#)

[BIST \(Built-In Self Test\) theory, page 23](#)

Tools for troubleshooting

Efficient EM 124 troubleshooting requires a good knowledge of its functionality and design. Specific tools may also be required for certain tasks.

The following tools are relevant for troubleshooting the Kongsberg EM 124 Multibeam Echo Sounder.

- Built-In Self Test (BIST)
- Analysis of the data presentations made by the EM 124
- Messages
- Visual checks
- Relevant measurements with applicable test instruments
- Test and verification procedures
- Your own knowledge of how the system works

We assume that you are equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks. This includes different screwdriver types, pliers, spanners, a cable stripper, a soldering iron, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Note

If one or more special tools are required for a task, these are specified in the relevant procedure.

It is impossible to create a detailed list of all possible errors and error symptoms in the EM 124.

However, key components that fail will in most cases be detected by the tools you have available.


The most important tool is your own knowledge about the EM 124. Based on a list of the main components in the system, brief descriptions of what they do and how they work, including suggested certain symptoms, you may work out the possible solutions.

BIST (Built-In Self Test) dialog box

The **BIST** dialog box provides several automatic tests to check the operation of the echo sounder system.

How to open


- **SIS:** Select **Installation Parameters** on the View menu. Select the **Installation Parameters** icon and select **BIST**.
- **K-Controller:** Select the **Installation Parameters** icon and select **BIST**.



Description

The BIST (Built-In Self Test) options provide a number of automatic tests that may be started to check the operation of the echo sounder system.

Various test are available, depending on what system you have.



Details

CPU Test

This test presents the CPU type, the CPU clock frequency, the current and maximum temperatures for the CPU die and for the CPU board. In addition some key voltages are reported, and finally the network addresses for the board's interfaces.

CBMF test

This test presents the CBMF board temperature, the internal power supply voltages. In addition software and firmware versions are displayed.

RX unit test

This test presents the internal temperatures and voltages in the receiver electronics. In addition software and firmware versions are displayed.

TX unit test

This test presents the internal temperatures and voltages in the transmitter electronics. In addition software and firmware versions are displayed.

CBMF-CPU link

This test checks CBMF board(s), Ethernet connection and the parallel bus interface between the CBMF board(s) and the CPU circuit board. A large set of known data is transferred from the CPU unit on Ethernet via CBMF back to the CPU board. The data received is checked by the CPU board.

RX-CBMF link

This test checks the GBit interface between the RX unit and the CBMF boards. A large set of known data is transferred from RX unit via CBMF to the CPU board on parallel bus. The data received is checked by the CPU board.

RX-CPU link

This test is not implemented yet.

RX channels

The Receiver Unit has a programmable signal generator board that is used to inject a test signal at the preamplifier inputs in the Receiver Unit. The BIST report displays the measured RX transducer impedance for all RX channels. This test may fail at very high noise levels.

TX channels

This test checks the impedance of all TX elements. This is done by measuring the voltage and current used by all individual transmitters. This test may fail at very high noise levels.

RX noise level

This test measures the average isotropic spectral noise level for each receiver channel (in dB rel 1 μ Pa/Hz) for different frequency bands. The receiver directivity index, the transducer sensitivity and the filter bandwidth is used to convert to isotropic spectral noise level. On a quiet ship away from noise sources, the noise level should normally be below 45 dB.

RX noise spectrum

This test measures the isotropic spectral noise level for each receiver channel as done in the RX noise level test. The noise spectrum level is displayed for small frequency bands for groups of 32 channels. In addition the average level for all channels are displayed. This spectrum test can be used to search for external noise sources.

Software date and versions

This test presents the software date and versions for the system components.

System information

This test acquires information needed (serial numbers, software versions, BIST results etc.) for a status report.

Save tests and open folder

Select **Save tests and open folder** to save the test results as a text file.

Clear

Select **Clear** to delete the tests already run.

PU System test result

All the tests will be listed as they are done.

Time

The time the test was run showing as yyymmdd-hhmmss.

Result

The result showing as Passed or Failed.

Description

A short description of the test. Select the description or the text file to get more details.

BIST (Built-In Self Test) theory

Topics

[BIST Introduction, page 24](#)

[CPU Test, page 25](#)

[CBMF test, page 26](#)

[RX unit test, page 27](#)

[TX unit test, page 28](#)

[CBMF-CPU link, page 29](#)

[RX-CBMF link, page 30](#)

[RX channels, page 31](#)

[TX channels, page 32](#)

[RX noise level, page 33](#)

[RX noise spectrum, page 34](#)

[Software date and versions, page 35](#)


[System information, page 35](#)

BIST Introduction

The purpose of the offline BIST system is to detect errors and locate the failed module.

The BIST tests are organized in a sequence, and tests module by module. The CPU executes the BISTs and sends the BIST reply to the operator station.

Temperature, voltage, communication and firmware versions of each board and module are tested.




- A** Processing Unit
- B** Transmitter Unit (TXU)
- C** Receiver Unit
- D** Transmit transducer array
- E** Receive transducer array

CPU Test

Checks the CPU board in the in the EM 124 Processing Unit.

This test presents the CPU type, the CPU clock frequency, the current and maximum temperatures for the CPU die and for the CPU board. Checks all beamformer and signal processing boards (CBMF) in the EM 124 Processing Unit.

In addition some key voltages are reported, and finally the network addresses for the board's interfaces.




(CD020109_110_005)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

CBMF test

Checks all beamformer and signal processing boards (CBMF) in the EM 124 Processing Unit.

This test presents the CBMF board temperature, the internal power supply voltages. In addition software and firmware versions are displayed.




(CD020109_110_006)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

RX unit test

Checks the receiver electronics in the EM 124 Receiver Unit.

This test presents the internal temperatures and voltages in the receiver electronics. In addition software and firmware versions are displayed.




(CD020109_110_007)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

TX unit test

Checks the transmitter electronics in the EM 124 Transmitter Unit.

This test presents the internal temperatures and voltages in the transmitter electronics. In addition software and firmware versions are displayed.




(CD020109_110_008)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

CBMF-CPU link

Checks the parallel bus interface between the CBMF board and the CPU board.

This test checks CBMF board(s), Ethernet connection and the parallel bus interface between the CBMF board(s) and the CPU circuit board. A large set of known data is transferred from the CPU unit on Ethernet via CBMF back to the CPU board. The data received is checked by the CPU board.




(CD020109_110_009)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

RX-CBMF link

This test checks the GBit interface between the RX unit and the CBMF boards.

A large set of known data is transferred from RX unit via CBMF to the CPU board on parallel bus. The data received is checked by the CPU board.




(CD020109_110_010)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

RX channels

Checks the RX channels including transducers by injecting a test signal at receiver input.

The Receiver Unit has a programmable signal generator board that is used to inject a test signal at the preamplifier inputs in the Receiver Unit. The BIST report displays the measured RX transducer impedance for all RX channels.




(CD020109_110_011)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

TX channels

Checks all TX channels including the transducers.

This test checks the impedance of all TX elements. This is done by measuring the voltage and current used by all individual transmitters.




(CD020109_110_012)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

RX noise level

Checks the isotropic spectral noise level.

This test measures the average isotropic spectral noise level for each receiver channel (in dB rel 1 μ Pa/Hz) for different frequency bands. The receiver directivity index, the transducer sensitivity and the filter bandwidth is used to convert to isotropic spectral noise level.




(CD020109_110_013)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

RX noise spectrum

Checks the isotropic spectral noise level.

This test measures the isotropic spectral noise level for each receiver channel as done in the RX noise level test. The noise spectrum level is displayed for small frequency bands for groups of 32 channels. In addition the average level for all channels are displayed. This spectrum test can be used to search for external noise sources.




(CD020109_110_013)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

Software date and versions

Checks the software date and versions.

This test presents the software date and versions for the system components.



(CD020109_110_016)

Dark green modules are to be tested. Light green modules have to function to be able to perform current test.

System information

Generates a status report for the EM 124 system.

This test acquires information needed (serial numbers, software versions, BIST results etc.) for a status report. This report can be sent to the factory to update the EM 124 product database.

Preventive maintenance

Topics

[Inspecting and cleaning the transducer face, page 37](#)

[Painting the transducer face, page 39](#)

[Inspecting and replacing sacrificial anodes, page 41](#)

[Approved anti-fouling paints, page 42](#)

Inspecting and cleaning the transducer face

Marine growth (biological fouling) on the transducer face reduces the EM 124 performance. For this reason, it is important to keep the transducer face clean. Every time your vessel is in dry dock, you must remove the marine growth. At the same time, you must inspect the transducer closely for physical damage.

Prerequisites

The following tools and consumables are required.

- Personal protection
- Fresh water
- A mild synthetic detergent and a plastic brush
- A piece of wood or plastic without sharp corners
- Citric acid (<50%) (only if required)

Context

During normal use, the transducer is subjected to biological fouling. If this marine growth is excessive, it will reduce the performance of the EM 124. Whenever opportunity arise, typically when the vessel is dry-docked, the transducer face must be cleaned for shells and other marine growth.

It is important to check the transducer for physical damage. Any cracks, fractures or holes in the red protective coating may result in a water leak, and a leak may cause irreparable damage to the transducer.

A transducer must always be handled as a delicate instrument. Incorrect actions may damage the transducer beyond repair. Observe these transducer handling rules:

- **Do not** activate the transducer when it is out of the water.
- **Do not** handle the transducer roughly and avoid impacts.
- **Do not** expose the transducer to direct sunlight or excessive heat.
- **Do not** use high-pressure water, sandblasting, metal tools or strong solvents to clean the transducer face.
- **Do not** damage the outer protective skin of the transducer face.
- **Do not** lift the transducer by the cables.
- **Do not** step on the transducer cables.
- **Do not** damage the transducer cables, and avoid exposure to sharp objects.

Procedure

- 1 Allow for sufficient access to clean and inspect the entire surface of the transducer.
- 2 Remove biological fouling carefully using a plastic brush, a suitable synthetic detergent and fresh water.

Biological material which is strongly rooted in the substrate can be removed carefully with a piece of wood or plastic.

If required, you can also use citric acid. Apply, leave it working for several hours, and rinse thoroughly with fresh water.

Note _____

Do not use high-pressure water, sandblasting, metal tools or strong solvents to clean the transducer face.

Do not damage the outer protective skin of the transducer face.

- 3 Allow the transducer surface to dry.
- 4 Do a thorough visual inspection of the transducer. Check for dents, scratches, holes or other damage to the surface.

If you suspect damage, take a high resolution photo. Contact your dealer or the Kongsberg support organization for advice.
- 5 Apply anti-fouling paint as described in the dedicated procedure.

Note _____

Because some paint types may be aggressive to the polyurethane in the transducer, consult our list of approved paints.

The list can also be found on Kongsberg Maritime (<https://www.kongsberg.com/maritime/>).

Painting the transducer face

Marine growth (biological fouling) on the transducer face reduces the EM 124 performance. We recommend that you paint the transducer face immediately after installation, and then again as often as required to maintain the protection.

Prerequisites

The following tools and consumables are required.

- Personal protection
- Fresh water
- A mild synthetic detergent and a plastic brush
- Fine-grade sandpaper (240 inch grit size)
- Primer
- Anti-fouling paint
- Wet film gauge
- Airless spray

Because some paint types may be aggressive to the polyurethane in the transducer, consult our list of approved paints.

Context

The transducer has not been designed with any protection against biological fouling. Anti-fouling paint may therefore be applied to the transducer face. To minimize the negative acoustical effects the layer of anti-fouling paint must be as thin as possible.

Note

The anti-fouling paint will reduce the acoustical performance of the transducer. The surface roughness of the transducer substrate and the thickness of the paint may also influence the performance. Kongsberg Maritime cannot be held responsible for any negative consequences of the anti-fouling paint.

Observe the relevant instructions and safety information provided by the paint manufacturer.

Procedure

- 1 Clean the transducer thoroughly.
Make sure that you remove all oil grease residues, as well as salt and other contamination.
- 2 Allow the transducer surface to dry.

- 3 Abrade the transducer surface using a sanding paper with 240 inch grit size.
Do not exceed a surface roughness (R_{max}) of 35 microns as this can influence the EM 124 performance.

- 4 Remove all dust.

- 5 Apply the primer, and let it dry.

- 6 Apply the paint.

Observe the instructions provided by the paint manufacturer. Use airless spray. Apply the minimum specified film thickness per coat and for the complete layer. It is not possible to measure dry film thickness on transducer surface. You must therefore use a wet film gauge to frequently measure the paint thickness.

Note

We strongly recommend that you do not use a paintbrush and/or a roller.

- 7 Allow the paint to dry.

Further requirements

The contractor or shipyard must keep a daily paint log recording all relevant information from the surface treatment.

Inspecting and replacing sacrificial anodes

Anodes are used on various units to prevent metals from corroding in salt water.

Context

Anodes are constructed of a metal alloy with an active voltage that is greater than the metal of the structure; thus, the anode corrodes before the material it is protecting. The three main alloys used are magnesium, aluminum, and zinc.

The sacrificial anodes must be inspected every time the vessel is in dry dock. Replace the anodes if they are damaged or severely corroded.

Procedure

- 1 Inspect all anodes for damage and corrosion.
- 2 Loosen the mounting screws and remove the anode.
- 3 Clean the new anode and mounting surface using Isopropyl alcohol on a soft cloth or paper wipe.
- 4 Grease the mounting screws and threads with Aqua Shield or Molykote P-40 paste.
- 5 Mount the new anode using the same screws. Make sure there is good electrical contact with the unit.

Approved anti-fouling paints

This is our list of approved antifouling paints for all transducer types. Always refer to the manufacturer's documentation and data sheets for a complete procedure and for relevant safety information.

Important

Do not paint the transducer with traditional hull plating paint. Use only the correct type of approved paint specified.

Do not use high-pressure water, sandblasting, metal tools or strong solvents to clean the transducer face.

Jotun

- **Manufacturer:** Jotun
- **Address:** P.O.Box 2021, N-3248 Sandefjord, Norway
- **Manufacturer's website:** <http://www.jotun.com>

Products:

- SeaQuantum Ultra S
 - **Primer:** Safeguard Universal ES
Apply 80 µm wet film thickness (50 µm dry film thickness).
 - **Paint:** SeaQuantum Ultra S
Apply 250 µm wet film thickness (125 µm dry film thickness).
- Seaforce 200 AV
 - **Primer:** Safeguard Universal ES AV
Apply 70 µm wet film thickness (50 µm dry film thickness).
 - **Paint:** Seaforce 200 AV
Apply 140 µm wet film thickness (90 µm dry film thickness).

Data sheets and application guides can be downloaded from:

<http://www.jotun.com/ww/en/b2b/technical-info/tds/index.aspx>

International Marine Coatings

- **Manufacturer:** International Marine Coatings
- **Address:** Stoneygate Lane, Felling, Gateshead, Tyne & Wear, NE10 0JY United Kingdom
- **Manufacturer's website:** www.international-marine.com

Products:

- Intersleek 1100SR

- **Primer:** Intersleek 737
Apply 50 µm dry film thickness.
- **Paint:** Intersleek 1100SR
Apply 150 µm dry film thickness.
- Intersmooth 7465Si SPC
 - **Primer:** Intergard 269
Apply 40 µm dry film thickness.
 - **Paint:** Intersmooth 7465Si SPC
Apply 100 µm dry film thickness.

The list can also be found on Kongsberg Maritime (<https://www.kongsberg.com/maritime/>).

Parts replacement

Topics

[Tools and equipment required for parts replacement, page 45](#)

[Processing Unit - Parts replacement, page 47](#)

[Transmitter Unit - Parts replacement, page 66](#)

[Receiver Unit - Parts replacement, page 83](#)

Tools and equipment required for parts replacement

In order to safely remove and replace printed circuit boards modules, generic and specific tools are required.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks. This includes different screwdriver types, pliers, spanners, a cable stripper, a soldering iron, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

- Screwdriver (various types and sizes)
- Allen keys (various sizes)
- Cable cutter, knife and/or scissors
- Wire stripper
- Pliers (various types and sizes)
- Spanner (various sizes) (US: Wrench)
- Tweezers

Note

If you need specific consumables, or if special tools and/or test instruments are required, these are identified in the relevant procedure(s).

Note

Circuit boards and electronic modules are delicate items. They may work year after year in an advanced product, but then fail due to a small spark of static electricity. For this reason, it is very important that they are properly handled and protected during handling. You must be familiar with the applicable handling precautions. Take all necessary steps to avoid Electrostatic Discharge (ESD).

As a minimum, the following precautions must be taken:

- 1 For correct and safe handling of printed circuit boards and electronic modules, you need a suitable working area. The working area must be covered by an approved conductive service mat that has a resistance of between 50 k Ω and 2 M Ω , and is connected directly to a reliable earth point via its earthing cord.
- 2 You - and all other service personnel involved - must wear a wristband in direct contact with the skin. The wristband must be electrically connected to the service mat.
- 3 Printed circuit boards and electronic modules must be placed on the conductive service mat during installation and maintenance operations.

- 4 If, for any reason, it is necessary to move the circuit board from the conductive service mat, it must be placed in an approved antistatic transportation container (for example a static shielding bag) before transportation.
- 5 During installation and servicing, all electrical equipment (for example soldering irons and test equipment) must be earthed.

WARNING

Personell must check that all the equipment is earthed before power is connected or switched on.

Processing Unit - Parts replacement

Topics

[Processing Unit replacement, page 48](#)

[CPU board replacement, page 51](#)

[VadaTech CP219 Ethernet switch replacement - Processing Unit, page 54](#)

[CBMF board replacement, page 57](#)

[Fan unit replacement - Processing Unit, page 60](#)

[Processing Unit fuse replacement, page 63](#)

Processing Unit replacement

If a Processing Unit fails to operate, it must be replaced with a new unit. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

The Processing Unit is the central controlling device in the EM multibeam system. It is provided to process the signals to and from the transducer(s).



Note _____

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.

Topics

[Removing the Processing Unit, page 49](#)

[Installing the Processing Unit, page 50](#)

Removing the Processing Unit

One or two Processing Units are used in the EM 124 system. The complete Processing Unit can be supplied as a spare part.

Prerequisites

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for mechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.



Context

Refer to the detailed information in the *Cable layout and interconnections* chapter.

Procedure

- 1 Locate the unit you wish to remove.
The Processing Unit is normally mounted in a cabinet, in a rack or placed on a table.
- 2 Turn off the EM 124.
- 3 Disconnect the power cable on the rear side of the unit.
- 4 Disconnect the cables.
- 5 Loosen the unit by removing the mounting bolts on both sides.
- 6 Grab a firm hold of the unit, and pull it straight out.
- 7 Place the unit on a conductive service mat on your work table.

Further requirements

To return the unit for repair or replacement, follow the relevant handling instructions.

Installing the Processing Unit

The Processing Unit is designed to be installed in a 19" rack.

Prerequisites

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks. This includes different screwdriver types, pliers, spanners, a cable stripper, a soldering iron, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.



Context

Refer to the detailed information in the *Cable layout and interconnections* chapter.

Procedure

- 1 Grab a firm hold of the unit, and push it straight in.
- 2 Fasten the unit by securing the mounting bolts on both sides.
- 3 Connect the power cable on the rear side of the unit.
- 4 Connect the cables.

Note


When you connect the cables, make sure that they are all properly secured, and able to withstand the vibration and movements of the vessel.

Further requirements

Once the unit has been installed, follow the normal procedure to turn on the EM 124.

CPU board replacement

If a CPU board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.



This is a generic photo. The CPU board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

There is one CPU board in the Processing Unit.

Note

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.

Topics

[Removing the CPU board, page 52](#)

[Installing the CPU board, page 53](#)

Removing the CPU board

If a CPU board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



This is a generic photo. The CPU board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

Removal is done by pulling the board straight out of the Processing Unit.

Procedure

- 1 Turn off the Processing Unit.
- 2 Disconnect the power cable on the rear side of the unit.
- 3 Identify the circuit board you wish to remove.
- 4 Disconnect all relevant cables.
- 5 Loosen the screws. **(A)**
- 6 Loosen the circuit board by pushing the two red locking devices on the handles. **(B)**
- 7 Push the handles outward. **(C)**
- 8 Grab the handles and pull the circuit board straight out.
- 9 Place the circuit board on a conductive service mat on your workbench.

Further requirements

To return the circuit board for repair or replacement, follow the relevant handling instructions.

Installing the CPU board

If a CPU board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



This is a generic photo. The CPU board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

A new circuit board must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment. Depending on the chosen installation method, additional tools may be required.

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Grab the handles and push the circuit board straight in.
- 3 Push the handles inward. (C)
- 4 Tighten the screws. (A)
- 5 Connect the cables.
- 6 Connect AC mains power.

Further requirements

Once the circuit board has been installed, follow the normal procedure to turn on the EM 124.


VadaTech CP219 Ethernet switch replacement - Processing Unit

If a VadaTech CP219 Ethernet switch fails to operate, it must be replaced with a new switch. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

The VadaTech CP219 board is used as an Ethernet switch in the EM 124 Processing Unit.

Note

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.



Topics


[Removing the VadaTech CP219 Ethernet switch , page 55](#)

[Installing the VadaTech CP219 Ethernet switch, page 56](#)

Removing the VadaTech CP219 Ethernet switch

If a VadaTech CP219 Ethernet switch fails to operate, it must be replaced with a new switch. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

Removal is done by pulling the board straight out of the Processing Unit.

Procedure

- 1 Turn off the Processing Unit.
- 2 Disconnect the power cable on the rear side of the unit.
- 3 Identify the circuit board you wish to remove.
- 4 Disconnect all relevant cables.
- 5 Loosen the screws. **(A)**
- 6 Loosen the circuit board by pushing the red locking device on the handle. **(B)**
- 7 Push the handle to the right. **(C)**
- 8 Grab the handle and pull the circuit board straight out.
- 9 Place the circuit board on a conductive service mat on your workbench.


Further requirements

To return the circuit board for repair or replacement, follow the relevant handling instructions.

Installing the VadaTech CP219 Ethernet switch

If a VadaTech CP219 Ethernet switch fails to operate, it must be replaced with a new switch. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



A new circuit board must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Grab the handle and push the circuit board straight in.
- 3 Push the handle to the left. (C)
- 4 Tighten the screws. (A)
- 5 Connect the cables.
- 6 Connect AC mains power.

Further requirements

Once the circuit board has been installed, follow the normal procedure to turn on the EM 124.

CBMF board replacement

If a CBMF board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

The Compact Beamformer (CBMF) board is used by the Processing Unit for beamforming and signal processing purposes.

Note

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.



Topics


[Removing the CBMF board, page 58](#)

[Installing the CBMF board, page 59](#)

Removing the CBMF board

If a CBMF board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

There are one or two Compact Beamformer (CBMF) boards in the Processing Unit. The number of CBMF boards depend upon the configuration of the EM 124 system. Removal is done by pulling the board straight out of the Processing Unit.

Procedure

- 1 Turn off the Processing Unit.
- 2 Disconnect the power cable on the rear side of the unit.
- 3 Identify the circuit board you wish to remove.
- 4 Disconnect all relevant cables.
- 5 Loosen the screws. **(A)**
- 6 Loosen the circuit board by pushing the red locking device on the handle. **(B)**
- 7 Push the handle to the right. **(C)**
- 8 Grab the handle and pull the circuit board straight out.
- 9 Place the circuit board on a conductive service mat on your workbench.


Further requirements

To return the circuit board for repair or replacement, follow the relevant handling instructions.

Installing the CBMF board

If a CBMF board fails to operate, it must be replaced with a new circuit board. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

There are one or two Compact Beamformer (CBMF) boards in the Processing Unit. The number of CBMF boards depend upon the configuration of the EM 124 system.

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Grab the handle and push the circuit board straight in.
- 3 Push the handle to the left. (C)
- 4 Tighten the screws. (A)
- 5 Connect the cables.
- 6 Connect AC mains power.

Further requirements

Once the circuit board has been installed, follow the normal procedure to turn on the EM 124.

Fan unit replacement - Processing Unit

If a fan unit fails to operate, it must be replaced with a new module. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.



The Processing Unit has two fan units for cooling purposes.

Note

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.

Topics


[Removing the fan unit, page 61](#)

[Installing the fan unit, page 62](#)

Removing the fan unit

If a fan unit fails to operate, it must be replaced with a new module. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

The Processing Unit has two fan units for cooling purposes.

Procedure

- 1 Turn off the Processing Unit.
- 2 Disconnect the power cable on the rear side of the unit.
- 3 Locate the unit you wish to remove.
- 4 Loosen the screw. (A)
- 5 Grab the handle and pull the unit straight out. (B)
- 6 Place the unit on a conductive service mat on your workbench.


Further requirements

To return the unit for repair or replacement, follow the relevant handling instructions.

Installing the fan unit

If a fan unit fails to operate, it must be replaced with a new module. All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Prerequisites



You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

The Processing Unit has two fan units for cooling purposes.

Procedure


- 1 Make sure that all AC mains power has been disconnected.
- 2 Grab the handle and push the unit straight in. **(B)**
- 3 Tighten the screw. **(A)**
- 4 Connect AC mains power.

Further requirements

Once the unit has been installed, follow the normal procedure to turn on the EM 124.

Processing Unit fuse replacement

The Processing Unit is protected with two ceramic body cartridge fuses on the power inlet. The fuses are replaced if blown.



Note

These procedures will instruct you to handle electronic circuit boards and/or modules. Before doing so, make sure that you are familiar with the applicable handling precautions. Follow the relevant handling procedures for circuit boards and electronic modules.

Topics


[Removing the fuse in the Processing Unit, page 64](#)

[Installing the fuse in the Processing Unit, page 65](#)

Removing the fuse in the Processing Unit

The Processing Unit is protected with two ceramic body cartridge fuses on the power inlet. The fuses are replaced if blown. Follow this procedure to remove the fuses.


Prerequisites



You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Procedure


- 1 Turn off the Processing Unit.
- 2 Disconnect the power cable on the rear side of the unit.
- 3 Locate the fuse holder.
- 4 Insert a small-blade screwdriver into the side of the fuse holder to release the lid catch.
- 5 Gently pull the fuse holder out.
- 6 Remove the blown fuse from the fuse holder.



Installing the fuse in the Processing Unit

The Processing Unit is protected with two ceramic body cartridge fuses on the power inlet. The fuses are replaced if blown. Follow this procedure to install the fuses.

Prerequisites




A new fuse must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Insert a new fuse into the fuse holder.
- 3 Push the fuse holder in.
- 4 Connect the power cable on the rear side of the unit.
- 5 Turn on the Processing Unit.



Further requirements

Once the unit has been installed, follow the normal procedure to turn on the EM 124.

Transmitter Unit - Parts replacement

Topics

[Fan unit replacement - Transmitter Unit, page 67](#)

[12V Power supply replacement - Transmitter Unit, page 72](#)

[HV Power supply replacement - Transmitter Unit, page 78](#)

Fan unit replacement - Transmitter Unit

Each Transmitter Unit has one fan unit for cooling purposes. If the fan unit fails, it must be replaced with a new unit.

- A** *Lid with mounting screws*
- B** *Mounting screws*
- C** *Fan unit*


The fan is located behind the lid on top of the Transmitter Unit.

All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Topics

[Removing the fan unit, page 68](#)

[Installing the fan unit, page 70](#)



Removing the fan unit

If the fan unit fails, it must be replaced with a new unit. Follow this procedure to remove the fan unit.

Prerequisites



You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

Each Transmitter Unit has one fan unit for cooling purposes. The fan is located behind the lid on top of the Transmitter Unit.

Procedure

- 1 Turn off the EM 124 system.
- 2 Disconnect the power cable from the Transmitter Unit
- 3 Loosen the mounting screws and remove the lid from the Transmitter Unit.
- 4 Locate the fan unit. (A)




(CD020109_001_007)

- 5 Loosen the screws holding the fan unit. **(C)**
- 6 Grab the handles and pull the fan unit straight out. **(B)**
- 7 Place the unit on a clean and stable workbench.

Further requirements

To return the unit for repair or replacement, follow the relevant handling instructions.



Installing the fan unit

If the fan unit fails, it must be replaced with a new unit. Follow this procedure to install the fan unit.

Prerequisites


The failed fan unit must have been removed.

A new fan unit must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context

Each Transmitter Unit has one fan unit for cooling purposes. The fan is located behind the lid on top of the Transmitter Unit.




- A** Fan unit
- B** Handles
- C** Mounting screws

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Grab the handles and push the fan unit straight in. **(B)**


- 3 Tighten the screws holding the fan unit. (C)
- 4 Put the lid on the Transmitter Unit and tighten the screws.



- 5 Connect AC mains power.

Further requirements

Once the unit has been installed, follow the normal procedure to turn on the EM 124.



12V Power supply replacement - Transmitter Unit

There is one 12V power supply in each Transmitter Unit. If the power supply module fails, it must be replaced with a new module.

The power supplies are mounted behind the heat sinks on the sides of the Transmitter Unit.

A *HV Power supply module*


B *12V Power supply module*

All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Topics

[Removing the 12V power supply, page 73](#)

[Installing the 12V power supply, page 75](#)



Removing the 12V power supply

If the power supply module fails, it must be replaced with a new module. Follow this procedure to remove the power supply module.


Prerequisites

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context


There is one 12V and one HV power supply in each Transmitter Unit. The power supplies are mounted behind the heat sinks on the sides of the Transmitter Unit.

The 12V power is mounted on the right side when the Transmitter Unit is seen from the front.




Procedure

- 1 Turn off the EM 124 system.
- 2 Disconnect the power cable from the Transmitter Unit
- 3 Loosen the mounting screws and remove the heat sink from the unit.



- 4 Carefully turn the heat sink around.


- 5 Disconnect the **AC power (C)** and the **Control and monitoring (D)** cables from the power supply.



- A** *VDC Out - Red*
- B** *DC Out Ground - Black*
- C** *AC power connector*
- D** *Control and monitoring signals*

The cables are connected with plugs or connectors.

- 6 Disconnect the **VDC Out (A/B)** cable from the Transmitter Unit backplane.
- 7 Place the heat sink with power supply on a clean and stable workbench.
- 8 Loosen the screws and remove the power supply unit from the heat sink.



Further requirements

To return the power supply for repair or replacement, follow the relevant handling instructions.

Installing the 12V power supply


If the power supply module fails, it must be replaced with a new module. Follow this procedure to install the new power supply module.

Prerequisites

The failed power supply module must have been removed.

A new power supply module must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.



Procedure

- 1 Make sure that all AC mains power has been disconnected.


- 2 Mount the power supply unit on the heat sink.

Note


A thin layer of heat sink compound is required between the power supply and the heat sink.

Usually a sufficient amount of heat sink compound is left from the old power supply assembly.

The power supply module is fastened to the heat sink with screws and clips. Use Loctite 243 or similar to secure the screws.




- 3 Connect the **VDC Out (A/B)** cable from the power supply to the Transmitter Unit backplane.



- A** *VDC Out - Red*
- B** *DC Out Ground - Black*
- C** *AC power connector*
- D** *Control and monitoring signals*

- 4 Connect the **AC power (C)** and the **Control and monitoring (D)** cables to the power supply.

- 5 Mount the heat sink on the unit and tighten the screws.
Use Loctite 243 or similar to secure the screws.



- 6 Connect AC mains power.

Further requirements

Once the power supply has been installed, follow the normal procedure to turn on the EM 124.

HV Power supply replacement - Transmitter Unit

There is one HV power supply in each Transmitter Unit. If the power supply module fails, it must be replaced with a new module.

The power supplies are mounted behind the heat sinks on the sides of the Transmitter Unit.

A *HV Power supply module*


B *12V Power supply module*

All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Topics

[Removing the HV power supply, page 79](#)

[Installing the HV power supply, page 81](#)



Removing the HV power supply

If the power supply module fails, it must be replaced with a new module. Follow this procedure to remove the power supply module.


Prerequisites

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context


There is one 12V and one HV power supply in each Transmitter Unit. The power supplies are mounted behind the heat sinks on the sides of the Transmitter Unit.

The HV power is mounted on the left side when the Transmitter Unit is seen from the front.




Procedure

- 1 Turn off the EM 124 system.
- 2 Disconnect the power cable from the Transmitter Unit
- 3 Loosen the mounting screws and remove the heat sink from the unit.




- Carefully turn the heat sink around.
- Disconnect the **AC power (C)** and the **Control and monitoring (D)** cables from the power supply.



- A** *VDC Out - Orange*
- B** *DC Out Ground - Blue*
- C** *AC power connector*
- D** *Control and monitoring signals*

- Disconnect the **VDC Out (A/B)** cable from the Transmitter Unit backplane.
- Place the heat sink with power supply on a clean and stable workbench.
- Loosen the screws and remove the power supply unit from the heat sink.



Further requirements

To return the power supply for repair or replacement, follow the relevant handling instructions.

Installing the HV power supply


If the power supply module fails, it must be replaced with a new module. Follow this procedure to install the new power supply module.

Prerequisites

The failed power supply module must have been removed.

A new power supply module must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.




Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Mount the power supply unit on the heat sink.


Note

A thin layer of heat sink compound is required between the power supply and the heat sink.

The power supply module is fastened to the heat sink with screws and clips.




- 3 Connect the **VDC Out (A/B)** cable from the power supply to the Transmitter Unit backplane.



- A** *VDC Out - Orange*
- B** *DC Out Ground - Blue*
- C** *AC power connector*
- D** *Control and monitoring signals*

- 4 Connect the **AC power (C)** and the **Control and monitoring (D)** cables to the power supply.
- 5 Mount the heat sink on the unit and tighten the screws.



- 6 Connect AC mains power.

Further requirements

Once the power supply has been installed, follow the normal procedure to turn on the EM 124.

Receiver Unit - Parts replacement

Topics

[Receiver Unit replacement, page 84](#)

[Power supply replacement - Receiver Unit, page 89](#)

Receiver Unit replacement

If a Receiver Unit fails to operate, it must be replaced with a new unit. The complete receiver Unit can be supplied as a spare part.

All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Topics

[Removing the Receiver Unit, page 85](#)

[Installing the Receiver Unit, page 87](#)




Removing the Receiver Unit

If a Receiver Unit fails to operate, it must be replaced with a new unit. Follow this procedure to remove the Receiver Unit.

Prerequisites

- A** Cable connection, behind protection lid
- B** Lid for access to circuit boards and power supply

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for mechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.



(CD020109_003_002)

Context


If a Receiver Unit fails to operate, it must be replaced with a new unit. One or two Processing Units are used in the EM 124 system. The complete receiver Unit can be supplied as a spare part.

The Receiver Unit is a small wall-mounted steel cabinet with integrated shock and vibration absorbers, designed for bulkhead mounting. The connectors of the Receiver Unit are accessed from the bottom.

Refer to the detailed information in the *Cable layout and interconnections* chapter.


Procedure

- 1 Turn off the EM 124.
- 2 Remove all AC mains power.
- 3 Remove the protection lid.



(CD020109_002_003)

- 4 Open the cable support bracket.
- 5 Disconnect the cables.
- 6 Loosen the unit by removing the mounting bolts.



- 7 Place the unit on a clean and stable workbench.
- 8 Remove the cable support bracket.

The cable support bracket has to be moved to the spare unit. The Receiver Unit delivered as spare part does not include the cable support bracket.

Further requirements

To return the unit for repair or replacement, follow the relevant handling instructions.

Installing the Receiver Unit

If a Receiver Unit fails to operate, it must be replaced with a new unit. Follow this procedure to install the new Receiver Unit.

Prerequisites

The failed unit must have been removed.

A new unit must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks. This includes different screwdriver types, pliers, spanners, a cable stripper, a soldering iron, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.




Context

The Receiver Unit is delivered as a complete cabinet with shock absorbers. The Receiver Unit delivered as spare part does not include the cable support bracket.

Refer to the relevant cable plans, cable lists and/or interconnection drawings for the EM 124.

Procedure

- 1 Mount the cable support bracket on the Receiver Unit.
The Receiver Unit delivered as spare part does not include the cable support bracket. Use the cable support bracket that has been removed from the unit being replaced.
- 2 Mount the cabinet to the bulkhead with six (6) M8 bolts.




- 3 Connect the cables.
Refer to the detailed information in the *Cable layout and interconnections* chapter.
- 4 Close the cable support bracket.

Note

Make sure the cables are all properly secured, and able to withstand the vibration and movements of the vessel.

- 5 Install the protection lid.




- 6 Connect AC mains power.

Further requirements

Once the unit has been installed, follow the normal procedure to turn on the EM 124.

Power supply replacement - Receiver Unit

There is one power supply unit in each Receiver Unit. If the power supply module fails, it must be replaced with a new module.



All replacement tasks must be done according to the specified procedures, and you must follow the relevant safety instructions.

Topics

[Removing the power supply, page 90](#)

[Installing the power supply, page 92](#)

Removing the power supply


If the power supply module fails, it must be replaced with a new module. Follow this procedure to remove the power supply module.

Prerequisites

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Context


You have to open the lid on top of the Receiver Unit to access the power supply module. The power supply module is mounted on a bracket.




(CD020109_003_003)

Procedure

- 1 Turn off the EM 124 system.
- 2 Disconnect the power cable from the Receiver Unit
- 3 Loosen the mounting screws and remove the lid from the unit.
- 4 Identify the power supply module.




- 5 Disconnect the cables from the power supply unit.
All cables are connected to the unit with plugs or connectors.
- 6 Loosen the mounting screws and remove the bracket with the power supply unit.



The power supply module is mounted on a bracket.

- 7 Loosen the screws and remove the power supply unit from the mounting bracket.



- A** *Power supply module*
- B** *Mounting bracket*
- C** *Screws*

Further requirements

To return the power supply for repair or replacement, follow the relevant handling instructions.

Installing the power supply


If the power supply module fails, it must be replaced with a new module. Follow this procedure to install the new power supply module.

Prerequisites

The failed power supply module must have been removed.

A new power supply module must be available.

You must be equipped with a standard set of tools. This tool set must comprise the normal tools for electromechanical tasks. This includes different screwdriver types, pliers, adjustable spanners, etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.




(CD020109_003_002)

Procedure

- 1 Make sure that all AC mains power has been disconnected.
- 2 Mount the power supply unit on the bracket.

The power supply module is fastened to the bracket with screws.




(CD020109_005_002)

A Power supply module

B Mounting bracket


C Screws

- 3 Mount the bracket with the power supply unit.




- 4 Connect the cables.

All cables are connected to the unit with plugs or connectors.



- A** AC power connector
- B** DC output module 1 + Red
- C** DC output module 1 - Black
- D** DC output module 2 + White
- E** DC output module 2 - Black
- F** Control and monitoring signals

- 5 Put the lid on the unit and tighten the screws.



(CD020109_003_003)

- 6 Connect AC mains power.

Further requirements

Once the power supply has been installed, follow the normal procedure to turn on the EM 124.

Spare parts and consumables

Topics

[Ordering spare parts, page 96](#)

[Processing Unit - List of spare parts, page 97](#)

[Transmitter Unit - List of spare parts, page 100](#)

[Receiver Unit - List of spare parts, page 103](#)

Ordering spare parts

To make the order process as short and efficient as possible, you must provide accurate information about the product, the part you need, and yourself.

The following information must be provided with your order:

- Part name and/or description
- Our part number
- Number of items required
- Your shipment address
- Preferred shipment method
- Required date of delivery from us

For certain spare parts (typically complete units, printed circuit boards and software) the vessel name is also useful, as this allows us to update our vessel database.

Processing Unit - List of spare parts

Topics

Processing Unit spare part 436571, page 97

CBMF board spare part 430675, page 97

CPU board spare part 457015, page 98

Power supply spare part 373897, page 98

Fan unit spare part 385387, page 99

Processing Unit spare part 436571

The complete Processing Unit can be supplied as a spare part.

- **Part name:** Processing Unit
- **Part number:** 436571
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)



Related topics

Processing Unit replacement, page 48

CBMF board spare part 430675

There are two Compact Beamformer (CBMF) boards in the Processing Unit.

This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

- **Part name:** CBMF board
- **Part number:** 430675
- **Number in use:** 2
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)




Related topics

[CBMF board replacement, page 57](#)

CPU board spare part 457015

There is one CPU board in the Processing Unit.

- **Part name:** Concurrent PP B12/033 CPU board
- **Part number:** 457015
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Concurrent Technologies Plc.
Concurrent Technologies (<http://www.gocct.com>)



Related topics

[CPU board replacement, page 51](#)

Power supply spare part 373897

One power supply unit is used in the EM 124 Processing Unit for supply of 5, 24 and 48 VDC.

- **Part name:** Power supply, Excelsys XLB
- **Part number:** 373897
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Excelsys
Excelsys Technologies (<http://www.excelsys.com>)



Fan unit spare part 385387

Two fan units are used in the EM 124 Processing Unit for side to side cooling.

- **Part name:** Fan unit
- **Part number:** 385387
- **Number in use:** 2
- **Recommended number in spare:** 1
- **True manufacturer:** Recab/Schroff

Related topics

[Fan unit replacement - Processing Unit, page 60](#)



Transmitter Unit - List of spare parts

Topics

[LPTX36 Transmitter board spare part 446679, page 100](#)

[TX RIO board spare part 426321, page 100](#)

[Ethernet switch spare part 338124, page 101](#)

[TXU Fan unit spare part 430443, page 101](#)

[TXU 12V Power supply spare part 437247, page 101](#)

[TXU HV Power supply spare part 437225, page 102](#)

LPTX36 Transmitter board spare part 446679

There are up to 24 LPTX36 Transmitter boards in each Transmitter Unit.

- **Part name:** LPTX36 Transmitter board
- **Part number:** 446679
- **Number in use:** 24
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)

TX RIO board spare part 426321

There are up to 12 TX RIO boards in each Transmitter Unit.

- **Part name:** TX RIO board
- **Part number:** 426321
- **Number in use:** 12
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)

Ethernet switch spare part 338124


There are up to three VadaTech CP218 Ethernet switches in each Transmitter Unit.

- **Part name:** VadaTech CP218 Ethernet switch board
- **Part number:** 338124
- **Number in use:** 3
- **Recommended number in spare:** 1
- **True manufacturer:** VadaTech Incorporated
VadaTech (<http://www.vadatech.com>)

TXU Fan unit spare part 430443

There is one fan unit in each Transmitter Unit.

- **Part name:** TXU Fan unit
- **Part number:** 430443
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Elma (<https://www.elma.com>)



Related topics

[Fan unit replacement - Transmitter Unit, page 67](#)

TXU 12V Power supply spare part 437247

There is one 12V power supply in each Transmitter Unit.

- **Part name:** Power supply Excelsys UX422
- **Part number:** 437247
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Excelsys Technologies
(<http://www.excelsys.com>)



Related topics

[12V Power supply replacement - Transmitter Unit, page 72](#)

TXU HV Power supply spare part 437225

There is one HV power supply in each Transmitter Unit.

- **Part name:** Power supply Excelsys UX6QQ
- **Part number:** 437225
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Excelsys Technologies
(<http://www.excelsys.com>)



Receiver Unit - List of spare parts

Topics

[Receiver Unit 1 degree - spare part 424633, page 103](#)

[Receiver Unit 2 degrees - spare part 424634, page 103](#)

[Receiver Unit 4 degrees - spare part 424635 , page 104](#)

[RXU Power supply spare part 428206, page 104](#)

Receiver Unit 1 degree - spare part 424633

The complete receiver Unit can be supplied as a spare part. The number of Receiver Units used will depend on the system configuration.

The number of circuit boards in the Receiver Unit will depend on the chosen transducer configuration.

- **Part name:** Receiver Unit 1 degree
- **Part number:** 424633
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)



Related topics


[Receiver Unit replacement, page 84](#)

Receiver Unit 2 degrees - spare part 424634

The complete receiver Unit can be supplied as a spare part. The number of Receiver Units used will depend on the system configuration.

The number of circuit boards in the Receiver Unit will depend on the chosen transducer configuration.

- **Part name:** Receiver Unit 2 degrees
- **Part number:** 424634
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)



Related topics

[Receiver Unit replacement, page 84](#)

Receiver Unit 4 degrees - spare part 424635

The complete receiver Unit can be supplied as a spare part. The number of Receiver Units used will depend on the system configuration.

The number of circuit boards in the Receiver Unit will depend on the chosen transducer configuration.

- **Part name:** Receiver Unit 4 degrees
- **Part number:** 424635
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Kongsberg Maritime (<https://www.kongsberg.com/maritime/>)



Related topics

[Receiver Unit replacement, page 84](#)

RXU Power supply spare part 428206

There is one power supply unit in each Receiver Unit.

- **Part name:** Power supply Roal RCB600-AA00
- **Part number:** 428206
- **Number in use:** 1
- **Recommended number in spare:** 1
- **True manufacturer:** Roal/Efore (<https://www.efore.com>)



Related topics

[Power supply replacement - Receiver Unit, page 89](#)

Processing Unit

Topics

[Processing Unit description, page 106](#)

[Processing Unit familiarization, page 106](#)

[Processing Unit front panel description, page 107](#)

[Processing Unit rear panel description, page 108](#)

[Processing Unit circuit boards and modules, page 109](#)

[CPU board, page 110](#)

[CP219 Ethernet switch, page 113](#)

[CBMF board, page 115](#)

Processing Unit description

The EM 124 Processing Unit is provided to process the signals to and from the Transmitter and Receiver Units.

The EM 124 Processing Unit is an industrial computer using both COTS (commercial off-the-shelf) components and custom made components. The unit is designed and tested for rugged use.



The Processing Unit performs the receiver beamforming, bottom detection, and motion and sound speed corrections. It contains all interfaces for time-critical external sensors such as vessel attitude (roll, pitch, heading and heave), vessel position and external clock. More than one sensor of each type may be connected simultaneously, with one in use and all of them logged.

The Processing Unit controls the Transmitter and Receiver units via Ethernet communication, and is also interfaced to the Operator station via Ethernet.

The 48 V output from the Processing Unit can be used for remote on/off control of the Transmitter and Receiver Units.

The Processing Unit is normally located in a "sonar room" close to the transducer arrays. The unit can also be placed in the "survey room" or on the bridge.

Processing Unit familiarization

The Processing Unit consists of an instrument case with integrated rack mounting in a 19 inch rack.

It uses both COTS (commercial off-the-shelf) components and custom made components. Ventilation is provided through slits located on the sides. The front panel of the Processing Unit holds a mains power switch and an information display.

The Processing Unit can be switched on/off with a remote switch.

The receive data from the Gbit link is filtered and beamformed by an FPGA unit on the CBMF board. The result is transferred to the CPU board via the cPCI backplane.

The Transmitter Unit(s) and Receiver Unit(s) are connected to the Ethernet switch in the Processing Unit.

Processing Unit front panel description

The front panel of the Processing Unit holds a mains power switch and an information display.




A *Information display*

B *Power On/Off*

Processing Unit rear panel description

The rear panel of the Processing Unit holds all the connectors used to communicate with external devices and the power input socket. It also holds a fuse for the power input.



A *Fan unit*

The Processing Unit has two fan units for cooling purposes.

B *Remote Control connector*

C *48 Vdc output connector*

D *Ground connector*

E *AC mains power socket*

F *Fuse for the AC mains supply*

G *CPU board*

H *CBMF board*

There are one or two Compact Beamformer (CBMF) boards in the Processing Unit. The number of CBMF boards depend upon the configuration of the EM 124 system.

I *CP219 Ethernet switch*

J *Air filter unit*

Processing Unit circuit boards and modules

In order to do the necessary tasks and meet the operational requirements, the Processing Unit is equipped with several circuit boards and modules. All the circuit boards and modules are line replaceable units (LRU).



The following circuit boards and modules are used in the EM 124 Processing Unit.

A CPU board

Different CPU boards can be used in the EM 124 Processing Unit.

B CBMF board

The Compact Beamformer (CBMF) board is used by the Processing Unit for beamforming and signal processing purposes.

There are one or two Compact Beamformer (CBMF) boards in the Processing Unit. The number of CBMF boards depend upon the configuration of the EM 124 system.

C VadaTech CP219 board

The VadaTech CP219 board is used as an Ethernet switch in the EM 124 Processing Unit.

D Fan unit

The Processing Unit has two fan units for cooling purposes.

• Power supply

One power supply unit is used in the EM 124 Processing Unit for supply of 5, 24 and 48 VDC.

The Excelsys XLB power supply is located inside the Processing Unit, and is not visible from the outside.

CPU board

Topics

[Concurrent PP B12 CPU board overview, page 110](#)

[Concurrent PP B12 CPU board connectors, page 111](#)

[Concurrent PP833 CPU board overview, page 111](#)

[Concurrent PP833 CPU board connectors, page 112](#)

Concurrent PP B12 CPU board overview

Concurrent PP B12 is one version of CPU board used in the EM 124 Processing Unit.



The Concurrent PP B12 is a PC-compatible high functionality Compact PCI (cPCI) board used by the EM 124 Processing Unit as the Central Processing Unit (CPU).

The circuit board is manufactured by Concurrent Technologies and configured by Kongsberg Maritime AS. Different CPU boards can be used in the EM 124 Processing Unit.

Concurrent PP B12 CPU board connectors


The Concurrent PP B12 CPU board holds two large connectors for the backplane, as well as several front mounted connectors.



- A** Console - for Kongsberg Maritime use only
- B** COM1 to COM4 - Four serial ports with RJ45 connectors. The ports can be configured to be RS-232 or RS-422
- C** Ethernet 1 - used for communication to the Operator Station (Hydrographic Work Station)

Concurrent PP833 CPU board overview

Concurrent PP833 is one version of CPU board used in the EM 124 Processing Unit.




The Concurrent PP833 is a PC-compatible high functionality Compact PCI (cPCI) board used by the EM 124 Processing Unit as the Central Processing Unit (CPU).

The circuit board is manufactured by Concurrent Technologies and configured by Kongsberg Maritime AS. Different CPU boards can be used in the EM 124 Processing Unit.

Concurrent PP833 CPU board connectors

The Concurrent PP833 CPU board holds two large connectors for the backplane, as well as several front mounted connectors. Not all of these connectors are used in the EM 124.



- A** *PMC/XMC1 Console - for Kongsberg Maritime use only*
- B** *COM1 to COM4 - Four serial ports with RJ45 connectors. The ports can be configured to be RS-232 or RS-422*
- C** *USB 2 - not used*
- D** *USB 1 - not used*
- E** *Ethernet 1 - used for communication to the Operator Station (Hydrographic Work Station)*
- F** *Ethernet 2 - not used*
- G** *USB 0 - not used*

CP219 Ethernet switch

Topics


[Ethernet switch overview, page 113](#)

[Ethernet switch connectors, page 114](#)

Ethernet switch overview

The VadaTech CP219 board is used as an Ethernet switch in the EM 124 Processing Unit.

This is a generic photo. The Vadatech CP219 board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.




The VadaTech CP219 is a compact PCI module that provides 10 Gigabit Ethernet ports on the front panel.

Ethernet switch connectors

The VadaTech CP219 Ethernet switch holds 10 front mounted connectors, as well as one large connector for the backplane.

*This is a generic photo.
The Vadatech CP219 board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.*



The Vadatech CP219 board is fitted with the following connectors.

- A** Port 1, GbE0
Regular Gigabit Ethernet port
- B** Port 2, GbE1
Regular Gigabit Ethernet port
- C** Port 3, GbE2
Regular Gigabit Ethernet port
- D** Port 4, GbE3
Regular Gigabit Ethernet port
- E** Port 5, GbE4
Regular Gigabit Ethernet port
- F** Port 6, GbE5
Regular Gigabit Ethernet port
- G** Port 7, GbE6
Regular Gigabit Ethernet port
- H** Port 8, GbE7
Regular Gigabit Ethernet port
- I** Port 9, GbE8
Regular Gigabit Ethernet port
- J** Port 10, CPU3
Gigabit Ethernet port reserved for external sensor input over UDP

CBMF board

Topics

[CBMF board overview, page 115](#)

[CBMF board configuration, page 116](#)

[CBMF board connectors, page 117](#)

CBMF board overview


The Compact Beamformer (CBMF) board is used by the Processing Unit for beamforming and signal processing purposes.



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

CBMF board configuration

The CBMF board is a generic circuit board designed for multiple applications and operational frequencies. By means of the on-board software, the links and the switches it can be configured for specific use. When a board is provided as a spare part, it is readily configured.



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

Switches and links

The CBMF board holds several switches and links. These are implemented to allow the circuit board to be used in several different configurations.

The switch setting on the CBMF board has to be correct. All the switches on all the CBMF boards in the Processing Unit should be set to OFF. OFF is when they are pushed towards the edge of the circuit board.




(CD090306_001_001)

Do not touch other switches or link settings.

The CBMF board is configured by Kongsberg Maritime for use in the EM 124. If you receive a spare CBMF board, this is also set up correctly before it is shipped.

CBMF board connectors

The CBMF board holds a large connector for the backplane, as well as several front mounted connectors.



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

The CBMF board is fitted with the following connectors.

- A** *SYNC - signal used for synchronisation when multiple echo sounders are employed on a vessel*
- B** *1PPS - one pulse per second input signal used to synchronise the internal clock in the Processing Unit*
- C** *ETH1 - Ethernet connection to internal switch in the Processing Unit*
- D** *ETH2 - not used for EM 124*

Transmitter Unit

Topics

[Transmitter Unit familiarization, page 118](#)

[Transmitter Unit bottom panel description, page 120](#)

[Transmitter Unit top panel description, page 122](#)

[Transmitter Unit power supplies, page 124](#)

[RIO-P board - dip switch setting, page 125](#)

Transmitter Unit familiarization

The Transmitter Unit holds several circuit boards and two power supplies. All the circuit boards are accessed either from the top or the bottom of the unit.




The Transmitter Unit is a wall-mounted steel cabinet with integrated shock and vibration absorbers, designed for bulkhead mounting. One 19 inch sub-rack is contained in the cabinet. The number of circuit boards in the sub-rack will depend on the chosen transducer configuration.

Twisted pair Ethernet is used for data communication with the Processing Unit.

The Transmitter Unit is normally located in a "sonar room" close to the transducer arrays.




- A** *Bottom view*
Protection cover and cable clamp not shown
- B** *Front view*
- C** *Top view*
Lid not shown



(CD020109_001_001)

Transmitter Unit bottom panel description

All external cables are connected at the bottom of the Transmitter Unit.



(CD020109_001_002)

- A *RIO-P board*
- B *TX RIO board 1*
- C *TX RIO board 12*
- D *AC power connector*
- E *Ground connector*
- F *Ethernet connector*
- G *Ethernet connector*

TX RIO board

There are up to 12 TX RIO boards in each Transmitter Unit. The transducer cables connect to the TX RIO boards.

The number of TX RIO boards depends on the configuration of the EM 124 system.

- 0.5 degrees TX array: 24 (2x12)
- 1 degree TX array: 12
- 2 degrees TX array: 6
- 4 degrees TX array: 3

RIO-P board




There is one RIO-P board in each Transmitter Unit. The signals for remote on/off control and synchronization is connected to the RIO-P board.

In addition there are two Ethernet connectors and connection for power at the bottom of the Transmitter Unit.

Transmitter Unit top panel description

There are only internal connections at the top of the Transmitter Unit.



(CD020109_001_003)

- A *Ethernet switch 1*
- B *Ethernet switch 2*
- C *Ethernet switch 3*
- D *LPTX36 board 1*
- E *LPTX36 board 24*
- F *Fan unit*

LPTX36 Transmitter board

There are up to 24 LPTX36 Transmitter boards in each Transmitter Unit. Each LPTX36 board is connected to the Ethernet switch in the Transmitter Unit.

The number of LPTX36 boards depends on the configuration of the EM 124 system.

- 0.5 degrees TX array: 48 (2x24)
- 1 degree TX array: 24
- 2 degrees TX array: 12
- 4 degrees TX array: 6

VadaTech CP218 Ethernet switch

There are up to three VadaTech CP218 Ethernet switches in each Transmitter Unit. Each LPTX36 board is connected to the Ethernet switch in the Transmitter Unit.

Transmitter Unit power supplies

There is one 12V and one HV power supply in each Transmitter Unit. The power supplies are mounted behind the heat sinks on the sides of the Transmitter Unit.


A *HV Power supply module*

The HV power is mounted on the left side when the Transmitter Unit is seen from the front. The HV power supply provides 130 VDC.

B *12V Power supply module*


The 12V power is mounted on the right side when the Transmitter Unit is seen from the front.

The power supply modules provide the operating voltages to the circuit boards in the EM 124 Transmitter Unit. These include the low voltages for the electronic circuitry, and the high voltage required to create the transmit pulses.



RIO-P board - dip switch setting


The dip switch setting on the RIO-P board has to be correct.



- A** Transmitter Unit 1 (MASTER): All switches must be set to ON.

The position of the dip switches are shown with the LED lights on the front of the RIO-P board when the board is installed and the Transmitter Unit is powered up.

- MASTER should be lit.
- ID5, ID6 and ID7 should not be lit.



(CD090303_005_002)

- B** Transmitter Unit 2 (SLAVE): Switch 1 and 4 must be set to OFF, switch 2 and 3 must be set to ON.

Note

If there is only one Transmitter Unit in the system, it has to be set to Transmitter Unit 1 (MASTER).

Receiver Unit

Topics

[Receiver Unit familiarization, page 127](#)

[Receiver Unit bottom panel description, page 128](#)

[Receiver Unit - dip switch setting, page 129](#)


Receiver Unit familiarization

The EM 124 Receiver Unit has all receive electronics, like control processor, amplifiers, Analog-to-Digital Converters, power supply and Ethernet interface.

- A** Cable connection, behind protection lid
- B** Lid for access to circuit boards and power supply

The Receiver Unit is a small wall-mounted steel cabinet with integrated shock and vibration absorbers, designed for bulkhead mounting.

The connectors of the Receiver Unit are accessed from the bottom. The circuit boards and power supply are accessed from the top.



(CD020109_003_002)

Receiver Unit bottom panel description

The connectors of the Receiver Unit are accessed from the bottom.




The transducer cables connect at the bottom of the Receiver Unit. The number of cables depends on the chosen system configuration.

Receiver Unit - dip switch setting

The dip switch setting in the Receiver Unit has to be correct.


The software in the Processing Unit must know the identification of the Receiver Units. A switch on the processing board inside the Receiver Unit is used for this.



- A** Receiver Unit 1 (MASTER): all switches must be set to OFF.
- B** Receiver Unit 2 (SLAVE): switch 1, 2 and 3 must be set to OFF, switch 4 must be set to ON.

Note

If there is only one Receiver Unit in the system, it has to be set to Receiver Unit 1 (MASTER).



(CD020199_050_001)

Hydrographic Work Station

Topics

[Hydrographic Work Station description, page 131](#)

[Hydrographic Work Station front panel description, page 131](#)

[Hydrographic Work Station rear panel description, page 132](#)

Hydrographic Work Station description

The Hydrographic Work Station is the operator station for the EM 124.

A dedicated maritime computer is provided with the EM 124 Multibeam Echo Sounder. It is set up with all necessary software.

The Hydrographic Work Station is based on the Microsoft® Windows 10 operating system.


The Hydrographic Work Station is normally mounted near the operator work space.



Hydrographic Work Station front panel description


The front panel of the Hydrographic Work Station holds a mains power switch, LED indicators, USB sockets and hard disk drives.

- A** Power On/Off
- B** Power connection indicator
- C** Network connection indicator
- D** Hard disk indicator
- E** Network activity indicator
- F** USB 2.0
2 USB connectors behind lid
- G** Hard disk drive
Raw data
- H** Hard disk drive
Gridded data
- I** Hard disk drive
System disk
- J** Not used



Hydrographic Work Station rear panel description

The rear panel of the Hydrographic Work Station holds all the connectors used by the computer to communicate with external devices. It also holds the power input socket and a mains power switch.



The image shows the MP5810 Fishery SIS5 model. Part number: 438803

If another model is used, the connections can be different.

- A** AC power socket
- B** Ground connector
- C** Slot 1: Dual Ethernet adapter
- D** Slot 2: Graphic adapter

If another model is used, the graphic adapter can be different.

- E** Computer rear panel interfaces

Drawing file

Topics

- [213673 TX module outline dimensions, page 135](#)
- [213217 RX module outline dimensions, page 136](#)
- [372053 TX mounting frame - 0.5 degrees, page 137](#)
- [213433 TX mounting frame - 1 degree, page 138](#)
- [213370A TX mounting frame - 2 degrees, page 139](#)
- [213370B TX mounting frame - 2 degrees, page 140](#)
- [213744 RX mounting frame - 1 degree, page 141](#)
- [213389 RX mounting frame - 2 degrees, page 142](#)
- [213803 RX mounting frame - 4 degrees, page 143](#)
- [372981 TX Casing with frame - 0.5 degrees, page 144](#)
- [213754 TX Casing with frame - 1 degree, page 145](#)
- [213755 TX Casing with frame - 2 degrees, page 146](#)
- [213749 RX Casing with frame - 1 degree, page 147](#)
- [213756 RX Casing with frame - 2 degrees, page 148](#)
- [213810 RX Casing with frame - 4 degrees, page 149](#)
- [365207 Baffle plate 1 dimensions, page 150](#)
- [365208 Baffle plate 2 dimensions, page 151](#)
- [365209 Baffle plate 3 dimensions, page 152](#)
- [426226 Transmitter Unit dimensions, page 153](#)
- [435444 Receiver Unit dimensions, page 154](#)
- [385422 Processing Unit dimensions, page 155](#)
- [378828 HWS dimensions, page 156](#)
- [445723 Rack installation kit dimensions, page 157](#)


[365290 KM 1000 mounting kit dimensions, page 158](#)

[409067 Fibre cable kit, page 159](#)

[370275 Remote Control Unit \(K-REM\) dimensions, page 160](#)

[373962 Remote Control Unit \(K-REM\) wiring diagram, page 161](#)


213673 TX module outline dimensions




Weight: 58kg

REV./SIGN.	B	LK						
DATE	2012.03.06							
PROJ. METHOD			UNLESS OTHERWISE STATED, TOLERANCE: DIM.: ISO 2768-mK THREAD: 6g/6H		PARTS LIST: N.A.		KONGSBERG SIMRAD	
SCALE	1:5		OUTLINE DIMENSIONS			SHEET 1 OF 1	SH.SIZE: A4	REV.:
DRAWN	98.09.07	EEn	TX MODULE			834-213673		B
CHECKED	00.01.27	HF						
APPROVED	00.01.31	EEn	EM120			FILE NO.: 878-37		


213217 RX module outline dimensions




372053 TX mounting frame - 0.5 degrees



213370B TX mounting frame - 2 degrees



213744 RX mounting frame - 1 degree



213389 RX mounting frame - 2 degrees

6-X Baffleplate Kit
 Parts include Kit have Numbers 6-X

Note: All parts must be cleaned and mounted as f.w.p. shows.
 Stop bolts pos 2 to be locked/ greased with Loctite 242 . Stud torque 165Nm.
 Bolts Pos 5 to be mounted without torque.
 Mount all Baffle plates on site.
 Screws pos 6-1 to be locked/ greased with Loctite 242 . Moderate torque.

Note: Alle deler skal være rengjort og sammenskrudt som tegn. viser.
 Stopperbolter Pos 2 låses/smøres med Loctite 242 og tiltrekkes med 165Nm.
 Boltene Pos 5 trekkes slutt uten moment.
 Monter alle baffle plater i økk.
 Skruer Pos 6-1 låses/smøres med Loctite 242 og tiltrekkes med moderat moment.

Note: Behandles forsiktig/ handle with care
 Put the Baffleplates 6-2, 6-3, 6-4 unmounted into the wooden crate.
 Put the Counterplate screws 6-1 into a pocket into wooden crate.
 Sett baffle plates 6-2, 6-3, 6-4, montert inn i kasse.
 Sett skruene 6-1 i en papkasse i kasse.
 All external carrying must be done with wooden crate 358007
 Weight: ~340kg


Monteringsramme kontrolleres med alle Baffle plater.
 Kontroller side avstand mellom Baffle plater (2mm) og at sveisen har kjoring.
 Mounting frame to be checked with all Baffle plates.
 Verify the gap between the Baffle plates (2mm) and that the weld has clearance.

Monteringsramme kontrolleres med 2 stk RX Testmoduler.
 Kontroller avstand mellom modulene (1mm) og at klemstykkeene gir ca. 0,2mm press.
 RX Testmodul: 599-213993
 Mounting frame to be checked with 2 pcs of RX Test module.
 Verify the gap between the modules (1mm) and that the clamps have approx. 0,2mm
 RX Test module: 599-213993


Note: Behandles forsiktig/ handle with care
 Put the Baffleplates 6-2, 6-3, 6-4 unmounted into the wooden crate.
 Put the Counterplate screws 6-1 into a pocket into wooden crate.
 Sett baffle plates 6-2, 6-3, 6-4, montert inn i kasse.
 Sett skruene 6-1 i en papkasse i kasse.
 All external carrying must be done with wooden crate 358007
 Weight: ~340kg

REVISION: LK LC HF LD LK LE LK
 DATE: 2011.02.29 2013.01.08 2013.10.23 2018.02.23
 PROJ: UNLESS OTHERWISE STATED,TOLERANCE: PARTS LIST: **KONGSBERG**
 DESIG: J09-159-2796-000-000 THEO:62/87/00 **SINAD**
 SCALE: 1:10 PARTS LIST: **PARIS LIST**
 DRAWN: 00.01.18 ETL 21 SYSDULE **860-213389 E**
 APPROVED: 00.01.18 ETL EM120 SHEET 1 OF 1 SHEET 1 OF 1
 FILE NO.: 860-54


213803 RX mounting frame - 4 degrees




213754 TX Casing with frame - 1 degree




213755 TX Casing with frame - 2 degrees




213749 RX Casing with frame - 1 degree



365207 Baffle plate 1 dimensions



365208 Baffle plate 2 dimensions




Tolerances ordinate dimensioning: ±0.25


Surface treatment: 2 coats of Jotun Pioner Primer,color Grey, 50-100 micron
 Note: Before painting, the plate dimensions to be checked with the mounting frame.
 Chamfer all edges with 2.5 x45°.

A	2011.10.28	First Issue	LK	HF	BH
REV.	DATE	DESCRIPTION	Designed by	Checked by	Approved by
Material: Divysjell HCP80, 25mm Surface treatment:			Unless Otherwise Stated Tolerances DIM: ISO 2768-mK Thickness: E9/6H Surface: Ra6.3		
Kongsberg Maritime AS Subsea Division Horten - Norway			Title: Baffle Plate 2 Mounting Frame -		
Project / Product name FM22			Drawing type Sheet		
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved. © Kongsberg Maritime			Document ID 365208		
			Revision/Version A		


365209 Baffle plate 3 dimensions



426226 Transmitter Unit dimensions




435444 Receiver Unit dimensions




Rev.	2018-01-15	First Issue	eniksi	hf	km
Material:		Designed by		Checked by	
Surface treatment:		ISO 2783:mk		Broken edges: 0,1 - 0,15 x 45°	
Tolerances unless otherwise stated: ISO 2783:mk		Threading: 90°H		Sheet	
Kongsberg Maritime AS		RX Unit		1 of 1	
Subsea Division		EM 124		A3	
Horten		Outline Drawing (100416)		1 : 4	
Project number / Item ID		Document ID		Revision	
435444		435444		A	

© Kongsberg Maritime


385422 Processing Unit dimensions



378828 HWS dimensions





337
102.5




384

Required
Inst. space





Isometric View




Weight approx. 8Kg


Reference documentation:
 366001 Outline Desk Mounting;
 371591 Outline Rack Unit;
 375288 Rail Kit Rack Unit;
 372140 Instruction Manual Rack Unit;
 365290 Outline KM1000 Mounting Kit;
 327993 Outline Mariner Mounting Kit;

REV.	DATE	FILE ISSUE	DESCRIPTION	HF	LK	TP
A	20121219					
Message: — Unless otherwise stated, Tolerances: DIM: ISO 2768-mK. Thread: B7/8H. Surface: Ra6.3			Approved by: Class Code: 100416			
Project/Product name: — EMX			Checked by: Subcode: Ra6.3			
Project/Product name: — EMX			Designed by: Subcode: Ra6.3			
Project/Product name: — EMX			Drawing type: Outline			
Project/Product name: — EMX			Document ID: 378828			
Project/Product name: — EMX			Revision/Version: A			


445723 Rack installation kit dimensions



365290 KM 1000 mounting kit dimensions



409067 Fibre cable kit




All cables to be labeled as shown with printable heatshrink-tubing.
All fiber connectors ends to be protected with suitable heatshrink-tubing.
This is for extra protection just a precaution while installing on sight,
and must be easy to remove when needed.


Check:
Wire identification, check pin no. vs pin no.

REV	A	2016.01.27	First Issue	HF	ES	KEN
DESIGNED BY	Jens Ole Sævi, Tolmose			DESIGNED BY	ES	KEN
CHECKED BY	Søren Røss			CHECKED BY	ES	KEN
DATE	2016.01.27			DATE	ES	KEN
DESCRIPTION	Kongsberg Maritime AS Subsea Division Horten - Norway			DESCRIPTION	ES	KEN
PROJECT NUMBER	171			PROJECT NUMBER	ES	KEN
PROJECT NAME	On/Off and Fiber Cable Kit TX-RX / RX-RX			PROJECT NAME	ES	KEN
CLASS CODE	378			CLASS CODE	ES	KEN
SIZE	A2			SIZE	ES	KEN
SCALE	1/1			SCALE	ES	KEN
REVISION/VERSION	A			REVISION/VERSION	ES	KEN
DOCUMENT ID	409067			DOCUMENT ID	ES	KEN

370275 Remote Control Unit (K-REM) dimensions



373962 Remote Control Unit (K-REM) wiring diagram



Technical specifications

Topics

[Performance specifications, page 163](#)

[Interface specifications, page 165](#)

[Weight and outline dimensions, page 172](#)

[Power requirements, page 175](#)

[Environmental requirements, page 177](#)

[Dimensional survey accuracy requirements, page 180](#)

[Alignment specifications, page 182](#)

Performance specifications

These performance specifications summarize the main functional and operational characteristics of the EM 124 system.

- Maximum ping rate: More than 5 Hz
- Number of swaths per ping: 2
-

Model	Transmit beamwidth	Receive beamwidth	Transmit waveforms	Number of beams per ping
0.5 x 1 degree	0.5 degrees	1 degree	CW + FM	1024 *
1 x 1 degree	1 degree	1 degree	CW + FM	
1 x 2 degrees	1 degrees	2 degrees	CW + FM	1024
2 x 2 degrees	2 degrees	2 degrees	CW + FM	
2 x 4 degrees	2 degrees	4 degrees	CW + FM	512
4 x 4 degrees	4 degrees	4 degrees	CW + FM	

* 1024 beams, 1600 soundings in high density mode

- Standard beamwidths: 0.5 x 1, 1 x 1, 1 x 2, 2 x 2, 2 x 4 or 4 x 4 degrees
- Beam spacing: Equidistant, Equiangle, High density (only with 1 degrees RX array)
- Coverage sector: Up to 150 degrees
- Transmit beam steering: Stabilized for roll, pitch and yaw
- Receive beam steering: Stabilized for roll
- Depth range from transducers: 20 to 11000 metres
- Pulse lengths: 2 ms CW to 100 ms FM (nominal pulse length)
- Maximum range sampling rate: 2.6 kHz (28cm) at data output
- Source level:
 - 1 degree TX: Up to 240 dB re 1 μ Pa ref 1 m
 - 0.5 degrees TX: Up to 246 dB re 1 μ Pa ref 1 m

Dual swath restrictions

FM mode is used to extend the maximum range capability.

In Very Deep mode long FM pulses are prioritized. Dual swath is not available in this mode.

Reduced power output (Mammal protection)

Maximum intensity is encountered in a thin wedge extending below the ship with an angular coverage of about 140°. The intensity level may be lowered by 10 or 20 dB by the operator. The EM 124 may be set in a mode to begin pinging with a flexible soft-start as a possible means of inducing marine mammals to leave the area of high intensity sound.

Interface specifications

Topics

[Datagram formats, page 166](#)

[Interface specifications - Processing Unit - KMall format, page 167](#)

[External sensors requirements, page 170](#)

[Interface specifications - Hydrographic Work Station - KMall format, page 171](#)

Datagram formats

Different EM multibeams will use and log data on different formats.

The KMall format is the successor of the all format, and uses the file extension kmall. Water column data can be logged in a separate file with extension kmwcd. The format is a generic format with high resolution data and the structure of the datagram is designed to make updates easier.

EM multibeams using KMall will be controlled and configured using the K-Controller and can acquire and log data using SIS 5 or other third party acquisition software.

Older generation EM multibeams will not have support for the new datagram format or use the K-Controller and SIS 5. This includes:

- EM 120/122
- EM 300/302
- EM 3000/3002
- EM 710

Newer generation multibeams will get support for both all and KMall format and will have full compatibility with SIS 4, K-Controller and SIS5. This includes:

- EM 2040 Series multibeams
- EM 712

Next generation multibeams will only have support for KMall format, and as such will require K-Controller and SIS5. This includes:

- EM 124
- EM 304
- Any future EM multibeams

The KM multibeam output datagram format is described in a Doxygen document, a documentation generator writing software reference documentation, and can be downloaded from the Kongsberg websites.

See the [Support EM 124](#) page.

Interface specifications - Processing Unit - KMall format

The EM 124 system will interface with peripheral systems and sensors using standard and/or proprietary datagram formats. This is a description of available datagram formats for EM multibeam systems using KMall format.

Supported datagram formats for position information

The EM 124 supports the following datagram format for position information.

- **NMEA GGA**

The NMEA GGA datagram transfers time-, position- and fix-related data from a global positioning system (GPS).

- **PTNL GSK**

This third party datagram format is used to transfer latitude and longitude of vessel position, time of position fix and status from a global positioning system (GPS).

Supported datagram formats for external clock

The EM 124 supports the following datagram format from an external clock.

- **NMEA ZDA**

The NMEA ZDA datagram contains the universal time code (UTC), day, month, year and local time zone.

Supported datagram formats for motion information

The EM 124 supports the following datagram format from a motion sensor.

- **Kongsberg EM Attitude 3000**

The EM Attitude 3000 is a proprietary datagram format created by Kongsberg Maritime for use with digital motion sensors. It holds roll, pitch, heave and heading information. The datagram contains a 10-byte message.

Supported datagram formats for motion information including velocity

The EM 124 supports the following datagram formats from a motion sensor.

- **KM Binary**

KM Binary is a general datagram format defined by Kongsberg Maritime. This format has very high resolution on timing and sensor parameters.

- **Seapath Binary 11**

This is a proprietary format created by Kongsberg Seatex (<http://www.km.kongsberg.com/seatex>) for position, attitude and velocity data from the Seapath sensor.

Seapath Binary 11 is an old format with low resolution that Kongsberg does not recommend.

- **Seapath Binary 23**

This is a proprietary format created by Kongsberg Seatex (<http://www.km.kongsberg.com/seatex>) for position, attitude and velocity data from the Seapath sensor.

- **Seapath Binary 26**

This is a proprietary format created by Kongsberg Seatex (<http://www.kongsberg.com/seatex>) for position, attitude and velocity data from the Seapath sensor.

- **POS-MV GRP 102/103**

This is a third party proprietary datagram format created by Applanix (<http://www.applanix.com>) for position, attitude and sound speed data.

Supported datagram formats for sound speed probe

Sound speed probe can be interfaced directly to the Processing Unit and configured in K-Controller or interfaced to the Hydrographic Work Station and configured in SIS 5.

The EM 124 supports the following datagram format from a sound speed probe.

- **AML**

This is a third-party proprietary datagram format created by AML Oceanographic for use with their sound speed sensors. The file format is ASCII with a five-line header plus a variable number of data lines. For more information, see <http://www.amloceanographic.com>.

The supported AML Smart Sensor message formats are

- **AML NMEA**: NMEA like format
- **AML SV**: Sound Velocity
- **AML SVT**: Sound Velocity and Temperature
- **AML SVP**: Sound Velocity and Pressure
- **Micro SV**: Sound Velocity
- **Micro SVT**: Sound Velocity and Temperature
- **Micro SVP**: Sound Velocity and Pressure

- **Valeport**

This is a third-party proprietary datagram format created by Valeport Ltd. for use with their sound velocity sensors.

The supported Valeport message formats are

- **MiniSVS SV**: Sound velocity

No longer supported

Some external sensors are no longer supported.

- Position sensor format Simrad 90
- Attitude sensor format Sperry MK-39
- Heading sensor format NMEA HDT, SKR 82

Special interfaces

- Trigger input/output for synchronisation
- 1 pulse per second (1PPS) clock synchronisation signal

Output datagram formats

The KMall format is described in it's own document.

See the [Product support A to Z](#) page.

External sensors requirements

The external sensors must fulfil these requirements to achieve the specified performance for the EM 124 system.

Sensor accuracy

The accuracy of the sensor data, as specified by the sensor manufacturer, must fulfill (preferably surpass) the following requirements

- **Roll, pitch and yaw rate:** 0.03 deg/s RMS
- **Velocity:** 0.03 m/s RMS
- **Latency:** Maximum 5 ms
- **Update rate:** 100 Hz
- **Roll:** 0.02 degrees RMS
- **Pitch:** 0.05 degrees RMS
- **Heading:**
 - 0.5 degrees TX array: 0.1 degrees RMS
 - 1 degree TX array: 0.2 degrees RMS
 - 2 degrees TX array: 0.4 degrees RMS
- **Heave (real-time output):** 5 cm or 5 % whichever is highest

Doppler shifts

All new generation of multibeam echo sounders from Kongsberg Maritime have an extended range performance by use of a frequency modulated transmitter pulse (FM), also called chirp pulse. In the FM mode, the Doppler shift made by the movements of the survey vessel relative to the bottom, causes a range error. This error must be corrected.

The following motion sensors have specifications that fulfils Kongsberg Maritime requirements for Doppler shift corrections.

- Kongsberg Maritime – Seapath series
- Applanix – Pos MV
- IXSEA – Phins

Interface specifications - Hydrographic Work Station - KMall format

The EM 124 system will interface with peripheral systems and sensors using standard and/or proprietary datagram formats. This is a description of available datagram formats for EM multibeam using KMall format.

- Sound speed at transducer
- Printer/plotter
- Interface for input of sound speed profile (Ethernet or serial line)
- Tide input (Ethernet or serial line)
- Single beam echo sounder depths (Ethernet)
- Output of all data normally logged to disk (to Ethernet)
- Output of depth below keel in NMEA DPT format (serial line)

Weight and outline dimensions

These weights and outline dimension characteristics summarize the physical properties of the EM 124 system.

Transmit transducer module

- **Outline dimensions:**
 - **Length:** 179 mm / 131.4 mm
 - **Width:** 760 mm
 - **Height:** 197 mm
- **Weight:** 58 kg

Transmit transducer frame

- **Outline dimensions:**
 - **Length:**
 - * **0.5 degree:** 15200 mm
 - * **1 degree:** 7770 mm
 - * **2 degrees:** 4020 mm
 - **Width:** 780 mm
 - **Height:**
 - * **1 degree:** 261.5 mm
 - * **2 degrees:** 249.5 mm

Receive transducer module

- **Outline dimensions:**
 - **Length:** 447 mm
 - **Width:** 342 mm
 - **Height:** 120 mm
- **Weight:** 24 kg

Receive transducer frame

- **Outline dimensions:**
 - **Length:**
 - * **1 degree:** 7200 mm
 - * **2 degrees:** 3600 mm
 - * **4 degrees:** 1808 mm
 - **Width:** 420 mm

- **Height:** 177 mm

Processing Unit

- **Outline dimensions:**
 - **Length:** 424mm
 - **Width:** 482.5 mm
 - **Height:** 88.6 mm
- **Weight:** 10.5 kg

Transmitter Unit

- **Outline dimensions:**
 - **Height:** 898 mm
 - **Width:** 606 mm
 - **Depth:** 612 mm
- **Weight:**
 - 1 degree: 96 kg
 - 2 degrees: 80 kg
 - 4 degrees: 72 kg

Receiver Unit

- **Outline dimensions:**
 - **Height:** 285 mm
 - **Width:** 488 mm
 - **Depth:** 420 mm
- **Weight:** 21 kg

Hydrographic Work Station

The standard commercial computer has been configured to fit the operational requirements of the EM 124.

- **Make and model:** Hewlett Packard MP5810
- **Outline dimensions:**
 - **Depth:** 379 mm
 - **Width:** 338 mm
 - **Height:** 100 mm
- **Weight:** 7 kg (Approximately)

Display

- **Make and model:** Isic MD24 (DuraMON WS 24)
- **Manufacturer's website:** <http://www.isic-systems.com>
- **Outline dimensions:**
 - **Depth:** 68 mm
 - **Width:** 601 mm
 - **Height:** 408 mm
- **Weight:** 10 kg (Approximately)

Power requirements

These power characteristics summarize the supply power requirements for the EM 124 system.

Transmitter Unit

- **Voltage requirement:** 230 VAC, 47 to 63 Hz
- **Maximum voltage deviation:** 15 %
- **Maximum power consumption:**
 - 1 deg: 1350 W
 - 2 deg: 750 W
 - 4 deg: 450 W

Receiver Unit

- **Voltage requirement:** 230 VAC, 47 to 63 Hz
- **Maximum voltage deviation:** 15 %
- **Maximum power consumption:** 50 W

Processing Unit

- **Make and model:** Kongsberg Maritime, EM PU
- **Voltage requirement:** 100 to 250 VAC, 47 to 63 Hz
- **Maximum power consumption:**
 - **With two CBMF boards :** 125 W

Hydrographic Work Station

- **Make and model:** Hewlett Packard MP5810
The standard commercial computer has been configured to fit the operational requirements of the EM 124.
- **Voltage requirement:** 100/240 VAC, 50 to 60 Hz, autosensing
- **Maximum power consumption:** 240 W (Approximately)

Note

The use of an Uninterruptible Power Supply (UPS) is highly recommended for the Hydrographic Work Station.

Display

- **Make and model:** Isic MD22/24/27 (DuraMON WS 22/24/27)
- **Manufacturer's website:** <http://www.isic-systems.com>
- **Input voltage:** Standard: 90–264 VAC, Optional: 18–36 VDC, 50–60 Hz
- **Power consumption:** Max. 40 W

Environmental requirements

These specifications summarize the temperature requirements and other environmental standards for the EM 124 system.

Transducers

- **Operating temperature:** -5 to +50 °C
- **Storage temperature:** -30 to +70 °C
- **Depth rating:** 60 m

Processing Unit

- **Operational temperature:** 0 to 50 °C
- **Storage temperature:** -30 to 70 °C
- **Relative humidity:** 5 to 95% relative non-condensing
- **Ingress protection (IP) rating:** IP22
- **Certificates:**
 - IEC 60945:2002 and CORRIGENDUM 1:2008
 - IACS E10:2006

Transmitter Unit

- **Operating temperature:** 0 to 40 °C
- **Storage temperature:** -30 to 70 °C
- **Relative humidity:** 5 to 93 % relative non-condensing
- **Ingress protection (IP) rating:** IP23
- **Vibration:**
 - **Frequency range:** 5 to 100 Hz
 - **Excitation level:** 0.7 g
- **Shock:**
 - **Peak acceleration:** 15 g
 - **Duration:** 11 ms
 - Half sine pulse
- **Referenced standards:**
 - IEC 60945:2002 and CORRIGENDUM 1:2008
 - IACS E10:2006

Receiver Unit

- **Operating temperature:** 0 to 50 °C

- **Storage temperature:** –30 to 70 °C
- **Relative humidity:** 5 to 93 % relative non-condensing
- **Ingress protection (IP) rating:** IP23
- **Vibration:**
 - **Frequency range:** 5 to 100 Hz
 - **Excitation level:** 0.7 g
- **Shock:**
 - **Peak acceleration:** 15 g
 - **Duration:** 11 ms
 - Half sine pulse
- **Referenced standards:**
 - IEC 60945:2002 and CORRIGENDUM 1:2008
 - IACS E10:2006

Hydrographic Work Station

- **Make and model:** Hewlett Packard MP5810
- **Operating temperature:** 0 to +50 °C
- **Storage temperature:** -20 to 70 °C
- **Relative humidity:** 5 to 95% relative, non-condensing
- **Certificates:**
 - IEC 60945
 - IACS E10
- **Ingress protection (IP) rating: IP22**

This IP rating is only applicable when the unit is mounted using the optional kit for 19-inch rack.

Display

- **Make and model:** IsicMD22/24/27 (DuraMON WS 22/24/27)
- **Manufacturer's website:** <http://www.isic-systems.com>
- **Operating temperature:** -15 to 55 °C
- **Storage temperature:** -25 to 70 °C
- **Relative humidity:** 8 to 95% relative non-condensing
- **Ingress protection (IP) rating**
 - Front: IP65
 - Rear: IP20

- **Certificates**
 - IEC 60945
 - IACS E10

Dimensional survey accuracy requirements

Minimum accuracy requirements are defined for the dimensional survey.

Note

The following accuracy requirements are minimum requirements. Higher accuracy will provide better results and should therefore always be aimed at.

Transducer

- **Position (x):** ± 0.05 m
- **Position (y):** ± 0.05 m
- **Position (z):** ± 0.02 m
- **Pitch:**
 - TX transducer array: ± 0.05 degrees
 - RX transducer array: ± 0.20 degrees
- **Roll:**
 - TX transducer array: ± 0.20 degrees
 - RX transducer array: ± 0.02 degrees
- **Heading:** ± 0.1 degrees
- **Relative heading between RX and TX transducer :** ± 0.1 degrees

Motion Reference Unit (MRU)

Note

These specifications are minimum requirements. Consult the installation manual for each sensor for how it is to be aligned and how accurately the location needs to be measured.

- **Position (x):** ± 0.05 m
- **Position (y):** ± 0.05 m
- **Position (z):** ± 0.05 m
- **Pitch:** ± 0.05 degrees
- **Roll:** ± 0.02 degrees
- **Heading:** ± 0.10 degrees

Heading sensor

Note _____

These specifications are minimum requirements. Consult the installation manual for each sensor for how it is to be aligned and how accurately the location needs to be measured.

- **Heading:** ± 0.10 degrees

Global positioning system (GPS) (Antenna)

Note _____

These specifications are minimum requirements. Consult the installation manual for each sensor for how it is to be aligned and how accurately the location needs to be measured.

- **Position (x):** ± 0.05 m
- **Position (y):** ± 0.05 m
- **Position (z):** ± 0.02 m

Waterline reference mark

- **Position (z):** ± 0.02 m

Alignment specifications

These alignment specifications summarize the alignment requirements of the EM 124 system.

Note

The following accuracy requirements are minimum requirements. Higher accuracy will provide better results and should therefore always be aimed at.

Transducer

- **Flatness:**
 - **Maximum deviation from ideal plane:** 1.6 mm
 - **Maximum gradient:** 0.1 %
The maximum allowed gradient between two adjacent mounting points on the frame is 0.1 % (1 mm/m).
- **Mounting angle between TX and RX transducer:** 90 degrees \pm 2 degrees

Cable layout and interconnections

Correct cabling is essential for EM 124 operation. Cabling principles, cable plans and drawings, as well as relevant procedures, are provided.

Topics

[Cable plans, page 184](#)

[List of EM 124 cables, page 200](#)

[Clock synchronization \(1PPS\), page 204](#)

[External synchronization, page 206](#)

[Cable drawings and specifications, page 209](#)

Cable plans

Topics

[Cable plan, Processing Unit, page 185](#)

[Cable plan - Transmitter Unit, page 186](#)

[Cable plan, Receiver Unit, 1 degree, page 194](#)


[Synchronization overview, 2 Transmitter Units 1 Receiver Unit, page 197](#)

[Remote on/off overview, 2 Transmitter Units 1 Receiver Unit, page 198](#)

[Cable plan, Hydrographic Work Station, page 199](#)

Cable plan, Processing Unit

The Processing Unit cables include those used to connect the EM 124 Processing Unit to AC mains power, and to the transmitter and receiver units. One Ethernet cable is used to connect the Processing Unit to the Hydrographic Work Station.



(CD020108_200_002)

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

A Processing Unit

Related topics


[List of EM 124 cables, page 200](#)

Cable plan - Transmitter Unit

The transmitter (TX) Unit cables include those used to connect the EM 124 TX Unit(s) to AC mains power, to the receiver (RX) Unit, to the Processing Unit and to the transducers. If there are more than one TX Unit they have to be connected to each other with a fibre optic cable.

The EM 124 system can have one or two Transmitter Units (TXUs), depending on the system configuration. A system with 0.5° transmitter array will need 96 Transmit Transducer modules and two Transmitter Units.

Transmitter Unit 1



(CD020109_201_001)

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

- A *Transmitter Unit 1*
- B *RIO-P board*
- C *TX RIO board 1*
- D *TX RIO board 12*
- E *Transmit transducer module number 1*
- F *Cables from Transmit Transducer 1 to 48 are connected to Transmitter Unit 1 according to the cable identification table*
- G *Cables from Transmit Transducer 49 to 96 are connected to Transmitter Unit 2 according to the cable identification table*

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

- A *Transmitter Unit 2*
- B *RIO-P board*
- C *TX RIO board 1*
- D *TX RIO board 12*
- E *Transmit transducer module number 1*
- F *Cables from Transmit Transducer 1 to 48 are connected to Transmitter Unit 1 according to the cable identification table*
- G *Transmit transducer module number 49*
- H *Cables from Transmit Transducer 49 to 96 are connected to Transmitter Unit 2 according to the cable identification table*

Marking of TX transducer cables

Each transducer module and its cable is identified with a serial number as follows:

TX<nnnn>

Where <nnnn> is a numerical value.

Each transducer module is also identified by its physical location in the array (frame). This location number must be recorded during the installation of the transducer modules, and written down in the table provided in this chapter.

The TX transducer array is physically positioned in the fore-and-aft direction under the hull.

TX transducer module number 1 is always the most forward module.

Connection of TX transducer cables

The 0.5 degree system consists of 96 TX modules/cables.

The 1 degree system consists of 48 TX modules/cables.

The 2 degree system consists of 24 TX modules/cables.

The 4 degree system consists of 12 TX modules/cables.

Note

It is essential to connect all TX cables successively to the TX RIO boards in the Transmitter Unit(s).

During the installation of the transducer array, you must fill in the serial number in the cable identification table.

Position	Transducer serial number (fill in)	Cable	Socket	TX RIO board	TX Unit	Size of system											
1	TX	TX 1	P1	1	TX Unit 1	4 deg											
2	TX	TX 2	P2														
3	TX	TX 3	P3														
4	TX	TX 4	P4														
5	TX	TX 5	P1	2		TX Unit 1	4 deg										
6	TX	TX 6	P2														
7	TX	TX 7	P3														
8	TX	TX 8	P4														
9	TX	TX 9	P1	3			TX Unit 1	4 deg									
10	TX	TX 10	P2														
11	TX	TX 11	P3														
12	TX	TX 12	P4														
13	TX	TX 13	P1	4				TX Unit 1	4 deg	2 deg							
14	TX	TX 14	P2														
15	TX	TX 15	P3														
16	TX	TX 16	P4														
17	TX	TX 17	P1	5					TX Unit 1	4 deg	2 deg	1 deg	0.5 deg				
18	TX	TX 18	P2														
19	TX	TX 19	P3														
20	TX	TX 20	P4														
21	TX	TX 21	P1	6						TX Unit 1	4 deg	2 deg	1 deg	0.5 deg			
22	TX	TX 22	P2														
23	TX	TX 23	P3														
24	TX	TX 24	P4														
25	TX	TX 25	P1	7							TX Unit 1	4 deg	2 deg	1 deg	0.5 deg		
25	TX	TX 26	P2														
27	TX	TX 27	P3														
28	TX	TX 28	P4														
29	TX	TX 29	P1	8								TX Unit 1	4 deg	2 deg	1 deg	0.5 deg	
30	TX	TX 30	P2														
31	TX	TX 31	P3														
32	TX	TX 32	P4														
33	TX	TX 33	P1	9									TX Unit 1	4 deg	2 deg	1 deg	0.5 deg
34	TX	TX 34	P2														
35	TX	TX 35	P3														
36	TX	TX 36	P4														

Position	Transducer serial number (fill in)	Cable	Socket	TX RIO board	TX Unit	Size of system			
37	TX	TX 37	P1	10	TX Unit 2				
38	TX	TX 38	P2						
39	TX	TX 39	P3						
40	TX	TX 40	P4						
41	TX	TX 41	P1	11					
42	TX	TX 42	P2						
43	TX	TX 43	P3						
44	TX	TX 44	P4						
45	TX	TX 45	P1	12					
46	TX	TX 46	P2						
47	TX	TX 47	P3						
48	TX	TX 48	P4						
49	TX	TX 49	P1	1					
50	TX	TX 50	P2						
51	TX	TX 51	P3						
52	TX	TX 52	P4						
53	TX	TX 53	P1	2					
54	TX	TX 54	P2						
55	TX	TX 55	P3						
56	TX	TX 56	P4						
57	TX	TX 57	P1	3					
58	TX	TX 58	P2						
59	TX	TX 59	P3						
60	TX	TX 60	P4						
61	TX	TX 61	P1	4					
62	TX	TX 62	P2						
63	TX	TX 63	P3						
64	TX	TX 64	P4						
65	TX	TX 65	P1	5					
66	TX	TX 66	P2						
67	TX	TX 67	P3						
68	TX	TX 68	P4						
69	TX	TX 69	P1	6					
70	TX	TX 70	P2						
71	TX	TX 71	P3						
72	TX	TX 72	P4						


Position	Transducer serial number (fill in)	Cable	Socket	TX RIO board	TX Unit	Size of system			
73	TX	TX 73	P1	7					
74	TX	TX 74	P2						
75	TX	TX 75	P3						
76	TX	TX 76	P4						
77	TX	TX 77	P1	8					
78	TX	TX 78	P2						
79	TX	TX 79	P3						
80	TX	TX 80	P4						
81	TX	TX 81	P1	9					
82	TX	TX 82	P2						
83	TX	TX 83	P3						
84	TX	TX 84	P4						
85	TX	TX 85	P1	10					
86	TX	TX 86	P2						
87	TX	TX 87	P3						
88	TX	TX 88	P4						
89	TX	TX 89	P1	11					
90	TX	TX 90	P2						
91	TX	TX 91	P3						
92	TX	TX 92	P4						
93	TX	TX 93	P1	12					
94	TX	TX 94	P2						
95	TX	TX 95	P3						
96	TX	TX 96	P4						

Related topics

[List of EM 124 cables, page 200](#)

Cable plan, Receiver Unit, 1 degree

The receiver (RX) Unit cables include those used to connect the EM 124 RX Unit(s) to AC mains power, to the transmitter (TX) Unit, to the Processing Unit and to the transducers.



(CD020109_202_001)

- A Receiver Unit (RXU)
- B Socket RX 1
- C Socket RX 16
- D Receive transducer 1
- E Receive transducer 16
- F Receive transducer 5 to 14 connects to Socket RX 5 to RX 14 on Receiver Unit

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

Marking of RX transducer cables

Each transducer module and its cable is identified with a number as follows:

Transducer: RX<nnn>

Where <nnn> is a numerical value.

Each transducer module is also identified by its physical location in the array (frame). This location number must be recorded during the installation of the transducer modules, and written down in the table provided in this chapter.

Transducer module number 1 is always the first on the port side.

Connection of RX transducer cables

The 1 degree system consists of 16 RX modules/cables.

The 2 degree system consists of 8 RX modules/cables.

The 4 degree system consists of 4 RX modules/cables.

Note

It is essential to connect all RX cables successively to the sockets in the Receiver Unit(s).

During the installation of the transducer array, you must fill in the serial number in the cable identification table.


Position	Transducer serial number (fill in)	Cable	Socket	Size of system		
1	RX	RX1	RX 1	4 deg	2 deg	1 deg
2	RX	RX2	RX 2			
3	RX	RX3	RX 3			
4	RX	RX4	RX 4			
5	RX	RX5	RX 5			
6	RX	RX6	RX 6			
7	RX	RX7	RX 7			
8	RX	RX8	RX 8			
9	RX	RX9	RX 9	1 deg		
10	RX	RX10	RX 10			
11	RX	RX11	RX 11			
12	RX	RX12	RX 12			
13	RX	RX13	RX 13			
14	RX	RX14	RX 14			
15	RX	RX15	RX 15			
16	RX	RX16	RX 16			

Related topics

[List of EM 124 cables, page 200](#)

Synchronization overview, 2 Transmitter Units 1 Receiver Unit

The transmitter and receiver unit(s) must be connected with a fibre optic synchronization signal.




- A *Transmitter Unit 1*
- B *Transmitter Unit 2*
- C *Receiver Unit (RXU)*

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.

Remote on/off overview, 2 Transmitter Units 1 Receiver Unit

The EM 124 system can be switched on/off via the Processin Unit.




(CD020199_030_002)

- A *Processing Unit*
- B *Transmitter Unit 1*
- C *Transmitter Unit 2*
- D *Receiver Unit (RXU)*

Cables identified with an asterisk (*) are system cables. These cables are supplied with the EM 124 delivery.

Cable plan, Hydrographic Work Station

The topside/bridge cables include those used to connect the EM 124 Hydrographic Work Station and the display to each other, to AC mains power, and to external devices.



A *Hydrographic Work Station*

B *Display*

The Hydrographic Work Station supports up to three displays.

C *Computer keyboard*

D *Computer mouse or trackball*

Cables identified with an asterisk (*) are system or commercial cables. These cables are supplied with the EM 124 delivery.

Related topics

[List of EM 124 cables, page 200](#)

List of EM 124 cables

A set of cables is required to connect the EM 124 units to each other, and to the relevant power source(s).

Cable	Type	From/To	Minimum requirements
C1	Video cable	From Hydrographic Work Station to display	
	This is a commercial cable. It is normally provided with the display. The Hydrographic Work Station supports up to three displays.		
C3	Computer cable	From Hydrographic Work Station to keyboard	
	This is a commercial cable. It is normally provided with the keyboard.		
C4	Computer cable	From Hydrographic Work Station to mouse (or another similar device)	
	This is a commercial cable. It is normally provided with the mouse.		
C5	AC power cable	From display to AC power outlet	
C7	AC power cable	From Hydrographic Work Station to AC power outlet	
C8	Ground cable	From Hydrographic Work Station to vessel ground	
C10	Ethernet cable	From Hydrographic Work Station to Processing Unit	CAT5-E STP (Shielded Twisted Pair)
	A 4.5 meter long Ethernet cable is provided with the Processing Unit. If a longer cable is required, this must be provided by the installation shipyard.		
C14	Serial cable	From Hydrographic Work Station to external device(s)	
C15	Serial cable	From Hydrographic Work Station to external device(s)	
C18	Ethernet cable	From Hydrographic Work Station to local area network (LAN)	CAT5-E STP (Shielded Twisted Pair)
C19	Ethernet cable	From Hydrographic Work Station to external device(s)	CAT5-E STP (Shielded Twisted Pair)
C25	AC power cable	From Processing Unit to AC power outlet	
C26	Ground cable	From Processing Unit to vessel ground	

Cable	Type	From/To	Minimum requirements
C27	Control cable	From Processing Unit to remote control device	
	Remote on/off switch If remote control is not used, a termination plug has to be inserted in the Remote control plug on the Processing Unit. This plug is a 9 pin D-SUB supplied with the Processing Unit. Remote control, page 214 Remote Control using K-Rem, page 215 Dummy plug for not using remote control, page 216		
C28	Control cable	From Processing Unit to synchronization device	
	External synchronization External synchronisation, page 213		
C29–C32	Serial cable	From Processing Unit to external device(s)	
	RS-232 serial line using three wires and RJ45 connector, page 210 RS-422 serial line using five wires and RJ45 connector, page 211		
C33	Ethernet cable	From Processing Unit to external device(s)	CAT5-E STP (Shielded Twisted Pair)
	Attitude Velocity sensor Attitude Velocity, Motion, Position and Time datagrams are supported via Ethernet.		
C34	Coax cable	From Processing Unit to the global positioning system (GPS)	
	The software clock can be synchronized to an external 1PPS (Pulse per second) signal. Clock synchronisation (1PPS) using a coax cable, page 212		
C36	Ethernet cable	Processing Unit internal connection	CAT5-E STP (Shielded Twisted Pair)
C40	Ethernet cable	From Processing Unit to Transmitter Unit 1	CAT5-E STP (Shielded Twisted Pair)
C41	Ethernet cable	From Processing Unit to Transmitter Unit 2	CAT5-E STP (Shielded Twisted Pair)
C42	Ethernet cable	From Processing Unit to Receiver Unit	CAT5-E STP (Shielded Twisted Pair)
C44	Fibre optic cable	From Transmitter Unit 1 to Transmitter Unit 2	
	The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.		
C45	Fibre optic cable	From Transmitter Unit 2 to Receiver Unit	
	The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.		
C50	Control cable	From Processing Unit to Transmitter Unit 1	
	Remote control of Transmitter Unit Remote control of Transmitter Unit, page 217		

Cable	Type	From/To	Minimum requirements
C51	Control cable	From Transmitter Unit 1 to Transmitter Unit 2	
	The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.		
C52	Control cable	From Transmitter Unit 2 to Receiver Unit	
	The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.		
C60	AC power cable	From Transmitter Unit to AC power outlet	
C61	Ground cable	From Transmitter Unit to vessel ground	
C62	AC power cable	From Transmitter Unit to AC power outlet	
C63	Ground cable	From Transmitter Unit to vessel ground	
C64	AC power cable	From Receiver Unit to AC power outlet	
C65	Ground cable	From Receiver Unit to vessel ground	
TX1-TX48	Transducer cable	From Transmitter Unit to transducer	
	The transducer cables are moulded to the transducer modules and connect in the other end to the Transmitter Unit (TXU) or Receiver Unit (RXU) with connectors. Transmit Transducer cable, page 223		
TX49-TX96	Transducer cable	From Transmitter Unit to transducer	
	The transducer cables are moulded to the transducer modules and connect in the other end to the Transmitter Unit (TXU) or Receiver Unit (RXU) with connectors. Transmit Transducer cable, page 223		
RX1-RX16	Transducer cable	From Receiver Unit to transducer	
	The transducer cables are moulded to the transducer modules and connect in the other end to the Transmitter Unit (TXU) or Receiver Unit (RXU) with connectors. Receive Transducer cable, page 224		

Comments

Note

It is very important that high-quality Ethernet cables are used. You must use CAT-5E STP (Shielded Twisted Pair) quality or better. If you use cables with lower bandwidth capacity you will reduce the EM 124 performance.

The EM 124 is often a part of a project delivery. For such deliveries, specific project cable drawings are established to show all the main cables, and how the various products

are connected. In such project cable drawings, the EM 124 cables may be identified as **EM 124/Cx**.

Related topics

[Cable plan, Processing Unit, page 185](#)


[Cable plan - Transmitter Unit, page 186](#)

[Cable plan, Receiver Unit, 1 degree, page 194](#)

[Cable plan, Hydrographic Work Station, page 199](#)

Clock synchronization (1PPS)

The Processing Unit has a 1PPS (one pulse per second) input for clock synchronization.



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

It can be selected in the operator software SIS whether the falling edge or the rising edge of the 1PPS signal is used by the Processing Unit to synchronize the internal clock. The 1PPS signal must be minimum 1 microsecond long.

The 1PPS signal is connected to the coax connector on the CBMF board. This connection is marked **1PPS**. If the Processing Unit has two CBMF boards the lower one must be used for **1PPS**.

The CBMF board is equipped with an optocoupler at this input. The input series resistor is tuned for a TTL signal (Low level < 0.6 V, High level > 3.2 V).


Optically isolated input signals

Note

The input signals must not be negative, that is no RS-232 signals can be used for these inputs.

A Input from external system

B Processing Unit input circuitry



The input current must be approximately 10 mA. Depending on your input signal additional resistance must be applied to achieve the required input current.

Two examples are shown to clarify.

•

$$I_F = \frac{4.5V - 1.2V(U_F)}{330\Omega} \approx 10\text{mA}$$

Using +4.5 V input signal the input current will be as required (~10 mA). No additional resistance required.

•


$$R_{\text{TOT}} = \frac{12V - 1.2V(U_F)}{10\text{mA}} = \frac{10.8}{0.010} = 1080\Omega$$

$$R_E = 1080 - 330 = 750\Omega$$

An added resistor of 750 Ω and minimum 0.1 W must be used.

External synchronization

The Processing Unit is has a connection for interface to an external synchronization system.



This is a generic photo. The CBMF board used by the EM 124 may look slightly different due to minor design changes on the protective lid and/or the front panel.

This connection is for interface to an external synchronization system, for example K-Sync. An external synchronization system is used when multiple echo sounders are employed on the same vessel.

The external synchronization connector is located on the CBMF board in the processing unit. If the Processing Unit has two CBMF boards the lower one must be used for synchronization.

This is an optically isolated connection that requires ~10mA current. Input power and resistor value must be adjusted accordingly. The connector is RJ45 type.

RJ45 connector pin layout

1	TRIG OUT +
2	TRIG OUT -
3	+ 5 VDC
4	TRIG IN +
5	TRIG IN -
6	+ 5 VDC
7	RTS OUT +
8	RTS OUT -

(CD0806_701_001)

Pin 3 and 6 are used by Kongsberg Maritime only.

External synchronization signal characteristics

Signal	Description	Type	Active
RTS	Ready To Send - Output from EM 124 when it is ready for the next trigger pulse	Open collector output from isolation unit	High
TRIG OUT	Trigger out - Output to external synchronization system, active while the EM 124 is transmitting	Open collector output from isolation unit	Low
TRIG IN	Trigger in - Input to EM 124 enabling it to transmit	Optical isolated input	High

Note

To avoid ground loops and damage of the electronics caused by external connections, all connections are optically isolated.


Optically isolated input signals

Note

The input signals must not be negative, that is no RS-232 signals can be used for these inputs.

A *Input from external system*

B *Processing Unit input circuitry*



The input current must be approximately 10 mA. Depending on your input signal additional resistance must be applied to achieve the required input current.

Two examples are shown to clarify.

•

$$I_F = \frac{4.5V - 1.2V(U_F)}{330\Omega} \approx 10mA$$

Using +4.5 V input signal the input current will be as required (~10 mA). No additional resistance required.

•

$$R_{TOT} = \frac{12V - 1.2V(U_F)}{10mA} = \frac{10.8}{0.010} = 1080\Omega$$

$$R_E = 1080 - 330 = 750\Omega$$

An added resistor of 750 Ω and minimum 0.1 W must be used.


Optically isolated output signals

A Processing Unit output circuitry

B External power

C Input to external system

The collector current must be approximately 10 mA. A resistor must be used to tune the collector current depending on your voltage.



Power	Resistor value	Minimum effect
5 V	0.38 k Ω	0.1 W
12 V	1.08 k Ω	0.15 W
24 V	2.28 k Ω	0.25 W

Cable drawings and specifications

Topics

[RS-232 serial line using three wires and RJ45 connector, page 210](#)

[RS-422 serial line using five wires and RJ45 connector, page 211](#)

[Clock synchronisation \(1PPS\) using a coax cable, page 212](#)

[External synchronisation, page 213](#)

[Remote control, page 214](#)

[Remote Control using K-Rem, page 215](#)

[Dummy plug for not using remote control, page 216](#)

[Remote control of Transmitter Unit, page 217](#)

[Remote control of Receiver Unit, page 219](#)


[Remote control overview, page 221](#)

[Transmit Transducer cable, page 223](#)


[Receive Transducer cable, page 224](#)

RS-232 serial line using three wires and RJ45 connector

An RS-232 serial line connection using three (3) wires is a common way to connect the EM 124 to external devices.




- A** *Local connection
RJ45 connector*
- B** *Connection on remote device*
- C** *Female 9-pin D-Subminiature connector*
- D** *Male 9-pin D-Subminiature connector*



Unless otherwise specified, this cable must be provided by the installation shipyard. Note that this cable does not support all the signals in the standard RS-232 specification.

(CD0804_001_004)




Minimum cable requirements

- **Conductors:** 2 x 2 x 0.2 mm²
- **Screen:** Overall braided
- **Voltage:** 30 V
- **Maximum outer diameter:** Defined by the plugs and/or the cable gland

We recommend using a shielded CAT-6A quality or better cable.

RS-422 serial line using five wires and RJ45 connector

An RS-422 serial line connection is a common way to connect the EM 124 to external devices. An RS-422 serial line connection can transmit data at rates as high as 10 million bits per second, and may be sent on cables as long as 1500 meters.




A *Local connection*

RJ45 connector

B *Connection on remote device*

Unless otherwise specified, this cable must be provided by the installation shipyard.



(CD0804_001_004)

Minimum cable requirements

- **Conductors:** 2 x 3 x 0.2 mm²
- **Screen:** Overall braided
- **Voltage:** 30 V
- **Maximum outer diameter:** Defined by the plugs and/or the cable gland

We recommend using a shielded CAT-6A quality or better cable.

Clock synchronisation (1PPS) using a coax cable

The Processing Unit is equipped with a 1PPS signal input for clock synchronisation.


- A *Male BNC connector*
- B *Ground*
- C *1PPS signal*

This cable must be provided by the installation shipyard.

The 1PPS (one pulse per second) signal is normally provided by a positioning system.

Related topics


[Clock synchronization \(1PPS\), page 204](#)



External synchronisation

The Processing Unit (PU) is equipped with a connection for interface to an external synchronisation system.

This connection is used for interface to an external synchronisation system (for example K-Sync) used when multiple echo sounders are employed on the same vessel. The external synchronisation connector is located on the CBMF board of the processing unit. The connector is RJ45 type.



A *Local connection* The connector is RJ45 type.

Note _____

Pin 3 and 6 is used by Kongsberg Maritime only.

B *Connection on remote device*

Unless otherwise specified, this cable must be provided by the installation shipyard.

Minimum cable requirements

- **Conductors:** 2 x 3 x 0.2 mm²
- **Screen:** Overall braided
- **Voltage:** 30 V
- **Maximum outer diameter:** Defined by the plugs and/or the cable gland

We recommend using a shielded CAT-6A quality or better cable.


Related topics

[External synchronization, page 206](#)

Remote control

The Processing Unit can be switched on/off with a remote switch. This switch is connected to a 9-pin D-connector on the Processing Unit.

- A** *Local connection, male 9-pin D-connector*
- B** *Connection to remote lamp and on/off switch*
- C** *Female 9-pin D-connector*
- D** *Male 9-pin D-connector*




(CD0806_701_010)

Minimum cable requirements


- **Conductors:** 3 x 0.5 mm²
- **Screen:** Overall braided
- **Voltage:** 60 V
- **Maximum outer diameter:** Defined by the plugs and/or the cable gland

This cable must be provided by the installation shipyard.




Remote Control using K-Rem

The Processing Unit can be switched on/off with a remote switch. This switch is connected to a 9-pin D-connector on the Processing Unit. A dedicated junction box with on/off switches and light indication has been designed for this purpose (K-Rem).



(CD0806_701_011)

- A *Local connection, male 9-pin D-connector*
- B *Connection at the terminal strip in Remote Control Unit (K-Rem)*
- C *Female 9-pin D-connector*
- D *Male 9-pin D-connector*




Minimum cable requirements

- **Conductors:** 3 x 0.5 mm²
- **Screen:** Overall braided
- **Voltage:** 60 V
- **Maximum outer diameter:** Defined by the plugs and/or the cable gland

This cable must be provided by the installation shipyard.


Dummy plug for not using remote control

The Processing Unit can be switched on/off with a remote switch. If remote control is not used, the enclosed remote control dummy plug has to be inserted in the **Remote Control** connector in the Processing Unit.



Note


*If remote control is not used, the enclosed remote control dummy plug has to be inserted in the **Remote Control** connector in the Processing Unit. The Processing Unit will not work without this dummy plug.*



Remote control of Transmitter Unit

Cable for switching on/off the Transmitter Unit from the Processing Unit.

This cable between the Transmitter Unit and the Processing Unit is required if you want to switch on and off the Transmitter Unit from the Processing Unit.



A Processing Unit end, male 4-pin Lemo connector.

Lemo part number: FGG.3B.304.CLAD62Z .


Kongsberg Maritime part number: 348015

B Transmitter Unit end, male 9-pin D-connector

Processing Unit end

Pin layout male 4-pin Lemo connector. Solder side view.


Connects to **48 VDC OUT** on the rear of the Processing Unit.



Transmitter Unit end

Pin layout male 9-pin D-connector.

Connects to **REMOTE ON/OFF IN** on the RIO-P board at the bottom of the Transmitter Unit.



Minimum cable requirements

- **Conductors:** 2 x 0.5 mm²
- **Screen:** Overall braided
- **Voltage:** 60 V
- **Maximum outer diameter:** Defined by the plugs


This cable must be provided by the installation shipyard.

Remote control of Receiver Unit

Cable for switching on/off the Receiver Unit from the Processing Unit.

This cable between the Transmitter Unit and the Receiver Unit is required if you want to switch on and off the Receiver Unit from the Processing Unit.

The fibre optic cable and the cable for remote control between the Transmitter Units and Receiver Units are delivered as a kit. The standard cable length is 10 metres.



A *Transmitter Unit end, male 9-pin D-connector*


Connects to **REMOTE ON/OFF OUT** at the bottom of the Transmitter Unit.

B *Receiver Unit end, male 9-pin D-connector*


Connects to **REMOTE ON/OFF IN** at the Receiver Unit.

Pin layout male 9-pin D-connector.

Connects to **REMOTE ON/OFF OUT** on the RIO-P board at the bottom of the Transmitter Unit.



Connects to **REMOTE ON/OFF IN** at the bottom of the Receiver Unit.



(CD020109_260_001)

Minimum cable requirements


- **Conductors:** 2 x 0.5 mm²
- **Screen:** Overall braided
- **Voltage:** 60 V
- **Maximum outer diameter:** Defined by the plugs

Remote control overview

The EM 124 system can be switched on/off with a central control switch.

An EM 124 system has several hardware units, and to make it easier to switch on/off the system it is prepared for remote control. There are several methods to do this:

- Using a remote switch to turn on/off the entire system. The remote switch can either be the K-Rem Remote Control Unit ordered from Kongsberg Maritime or a switch and lamp provided by the installation shipyard.
- Using the Processing Unit to switch on/off the entire system. The on/off switch on the Processing Unit can be used to switch on/off the Transmitter and Receiver Units in addition to the Processing Unit itself. In this case the enclosed remote control dummy plug has to be inserted in the Remote Control connector in the Processing Unit.



(CD0806_702_003)

- A Remote switch and lamp (optional)
- B Processing Unit, connector marked **REMOTE CONTROL**
- C Processing Unit, connector marked **48VDC OUT**
- D Transmitter Unit 1, connector marked **REMOTE ON/OFF IN**
- E Transmitter Unit 1, connector marked **REMOTE ON/OFF OUT**
- F Transmitter Unit 2, connector marked **REMOTE ON/OFF IN**
- G Transmitter Unit 2, connector marked **REMOTE ON/OFF OUT**
- H Receiver Unit 1, connector marked **REMOTE ON/OFF IN**
- I Receiver Unit 1, connector marked **REMOTE ON/OFF OUT**
- J Receiver Unit 2, connector marked **REMOTE ON/OFF IN**

K Receiver Unit 2, connector marked **REMOTE ON/OFF OUT**

Note _____

The number of Transmitter Units and Receiver Units depends upon the chosen system configuration.

The diagram shows the principle for a maximum possible solution, with two Transmitter Units and two Receiver Units.

Transmit Transducer cable

The transducer cables are moulded to the transducer modules and connect in the other end to the Transmitter Unit (TXU) with connectors.

The standard length of the transducer cables is 25 metres.

The length of the cables are fixed. The cables can not be extended or shortened during installation.

Extended cables can be delivered upon request. Cables are extended by splicing onto existing standard 25m length cables.

Cable specifications

- Cable length: 25 m
- Maximum outer diameter: 13 mm
- Minimum bending radius: 78 mm
- Connector: 25-pin D-Sub connector

Receive Transducer cable

The transducer cables are moulded to the transducer modules and connect in the other end to the Receiver Unit (RXU) with connectors.

The standard length of the transducer cables is 25 metres.

The length of the cables are fixed. The cables can not be extended or shortened during installation.

Extended cables can be delivered upon request. Cables are extended by splicing onto existing standard 25m length cables.

Cable specifications

- Cable length: 25 m
- Maximum outer diameter: 13 mm
- Minimum bending radius: 78 mm
- Connector: 25-pin D-Sub connector

Equipment handling

Observe these basic rules for transportation, storage and handling of units. In this context, a *unit* may be any large or small part of the system. It can be supplied as part of the initial delivery, or as a spare part. The phrase *box* is used to describe all kinds of cases, wooden or cardboard boxes etc used to hold the *unit*.

Topics

[Transporting Kongsberg Maritime equipment, page 226](#)

[Lifting units and transportation boxes, page 227](#)

[Inspection of units and transportation boxes after arrival, page 229](#)

[Specifications for storage prior to installation or use, page 230](#)

[Unpacking instructions, page 232](#)

[Specifications for storage after unpacking, page 237](#)

Transporting Kongsberg Maritime equipment

Unless otherwise stated in the accompanying documentation, electronic, electromechanical and mechanical units supplied by Kongsberg Maritime can be only transported using methods approved for delicate and fragile equipment.

Prerequisites

Transportation methods approved for delicate equipment includes transportation by road, rail, air or sea.

Context

The units are to be transported in accordance with general or specific instructions for the appropriate unit(s), using pallets, transport cases, wooden boxes, or carton boxes as appropriate.

Observe the packing instructions.

Note

Special local restrictions concerning air transportation may be applied to units containing certain types of batteries. These units must be checked properly, and the regulations must be investigated by the packer/shipper before the unit is dispatched.

Procedure

- 1 Ensure that all local transportation is done according to the same specifications as for the initial delivery.
- 2 Make sure that the box containing the unit is kept dry at all times, and sheltered from the weather.

It must not be subjected to shocks, excessive vibration or other rough handling. The box will normally be marked with text or symbols indicating which way it is to be placed. Follow the instructions provided, and make sure that the box is always placed with its “top” facing upwards.

- 3 Make sure that the box is not used for any purpose for which it was not intended (step, table, etc.).

In the absence of other information, no other boxes must be stacked on top of it.

- 4 Handle all boxes and units with care.

Note

Due to the nature of Kongsberg Maritime’s products, and the extensive use of delicate electronic parts, all units and boxes must be regarded and handled as fragile equipment.

Lifting units and transportation boxes

Some of the boxes used to hold equipment units may be heavy. Use caution when lifting.

Prerequisites

Units and boxes may be heavy. Make sure that you have the necessary equipment required for lifting heavy items. Persons using the lifting equipment must be skilled and have the relevant certificate(s).

Context

A heavy box will normally be marked with its weight. The weights of other boxes in the shipment will normally be entered on the packing list(s).

Heavy units may be equipped with dedicated lifting lugs for transportation by crane within the workshop or installation area.

Note

Observe the local rules and regulations related to the use of lifting equipment.

Procedure

- 1 Check the weight of the box or unit before you attempt to lift it.
- 2 Make sure that you have the relevant lifting apparatus required, and that this equipment is approved and certified for the load.
- 3 If you need to use a crane:
 - a Check the applicable weight certificate for the crane.
 - b Check the security of the lifting lugs.
 - c If the unit to be lifted is provided with dedicated lifting lugs, make sure that all available lugs are used.
 - d Make sure that the unit remains under full control during the lifting operation.
This is important to avoid damage to the unit, equipment or personnel.
- 4 If you need to use a forklift truck:
 - a Check the applicable weight certificate for the truck.
 - b Check the limitations for lifting height and angles.
 - c Pay special attention to the position of the unit's centre of gravity.
 - d Make sure that the unit is properly secured to the truck during the lifting and transportation operations.
- 5 Handle all units and boxes with care.

Note

Due to the nature of Kongsberg Maritime's products, and the extensive use of delicate electronic parts, all units and boxes must be regarded and handled as fragile equipment.

Inspection of units and transportation boxes after arrival

A visual inspection must be done immediately after the box(es) have arrived at their destination.

Prerequisites

If you suspect that the equipment has been damaged during the transport, request that a representative of the carrier is present during the inspection.

Procedure

- 1 Check all boxes (wooden or cardboard boxes, plastic bags and/or pallets) for physical damage.
Look for signs of dropping, immersion in water or other mishandling.
- 2 If external damage is detected, open the box to check its contents.
Request that a representative of the carrier to be present while the box is opened, so any transportation damage can be identified and documented.
- 3 If a unit has been damaged, prepare an inspection report stating the condition of the unit and actions taken.
Describe the damage, and collect photographic evidence if possible. Return the inspection report to Kongsberg Maritime as soon as possible.
- 4 If units are not damaged, check the humidity absorbing material.
If required, dry or replace the bags, then re-pack the unit(s) according to the packing instructions.

Specifications for storage prior to installation or use

When a system, a unit or a spare part has been delivered to the customer, it may be subject to long time storage prior to installation and use.

General specifications

During this storage period, certain specifications must be met. The equipment must be preserved and stored in such a way that it does not constitute any danger to health, environment or personal injury.

- 1 The equipment must be stored in its original transportation box.
- 2 Ensure that the units are clearly separated in the shelves and that each unit is easily identifiable.
- 3 The box must not be used for any purpose for which it was not intended (work platform, steps, table etc.).
- 4 Boxes must not be placed on top of each other, unless specific markings permit this.
- 5 Boxes must not be placed directly on a dirt floor.
- 6 Do not open a box for inspection unless special circumstances permit so.
“Special circumstances” may be suspected damage to the box and its content, or inspections by civil authorities.
 - a If a unit is damaged, prepare an inspection report stating the condition of the unit and the actions taken. Describe the damage and collect photographic evidence if possible. Re-preserve the equipment.
 - b If the unit is not damaged, check the humidity absorbing material. If required, dry or replace the bags, then re-pack the unit according to the packing instructions.
- 7 If a box has been opened, make sure that it is closed and sealed after the inspection. Use the original packing material as far as possible.
- 8 The storage room/area must be dry with a non-condensing atmosphere. It must be free from corrosive agents.
- 9 The storage room/area’s mean temperature must not be lower than -10°C , and not warmer than $+50^{\circ}\text{C}$. If other limitations apply, the crates will be marked accordingly.
- 10 Boxes must not be exposed to moisture from fluid leakages.
- 11 Boxes must not be exposed to direct sunlight or excessive warmth from heaters.
- 12 Boxes must not be subjected to excessive shock and vibration.
- 13 If the unit contained in a box holds normal batteries, these may have been disconnected/isolated before the unit was packed. These must only be reconnected before the installation starts. Units containing batteries are marked.

Caution

Units containing lithium or alkaline batteries must be handled separately and with care. Such units are marked accordingly. Do not attempt to recharge such batteries, open them, or dispose of them by incineration.

Refer to the applicable product data sheets or battery handling procedures for further details.

Temperature protection

Any units that requires protection against extreme temperatures are identified as such in the applicable documentation. The box used to transport and store such units are clearly marked, for example:

Must not be transported or stored in temperatures below -5 °C.

Other temperature limits may be used if applicable.

If a unit needs temperature protection, the box to be used for storage and transportation must be lined on all walls, base and lid, using minimum 5 cm thick polyurethane or polystyrene foam.

Most system units can normally be stored in temperatures between -30° C and +70° C. Refer to the relevant technical specifications for details.

Note

Unless otherwise specified, transducers and hydrophones must not be stored in temperatures below -10°C and above +50°C.

Unpacking instructions

Prior to installation or use, electronic, electromechanical and mechanical units must be unpacked from their transport boxes. It is important that this unpacking is done according to the relevant instructions, and without inflicting damage to the equipment.

Topics

[Unpacking standard parts and units, page 232](#)

[Unpacking mechanical units, page 233](#)

[Unpacking electronic and electromechanical units, page 234](#)

[Unpacking transducers, page 235](#)

Unpacking standard parts and units

Prior to installation or use, parts and units must be inspected, and then unpacked from their transport boxes. It is important that this unpacking is done without inflicting damage to the equipment.

Context

This procedure provides the basic tasks of unpacking units (main unit, spare parts etc) from boxes shipped from Kongsberg Maritime.

Note

If the unit in question is not unpacked for immediate use, you may consider storing it unopened in its original box. However, it may be useful to open the box to check its contents for damage and retrieve any accompanying documentation.

Do not use a knife to open cardboard boxes - the contents may be located close to the surface, and can then be damaged by the blade.

Procedure

- 1 Check the carton before opening it to ensure it shows no signs of dropping, immersion in water or other mishandling.
 - 1 If external damage is detected, open the box to check its contents.
 - 2 Request that a representative of the carrier to be present while the box is opened, so any transportation damage can be identified and documented.
 - 3 If a unit has been damaged, prepare an inspection report stating the condition of the unit and actions taken.

Describe the damage, and collect photographic evidence if possible. Return the inspection report to Kongsberg Maritime as soon as possible.

- 2 Place the box on a stable work bench or on the floor with the top of the box facing upwards.
- 3 In the absence of other instructions, always open the top of the carton first.
The contents of the box will normally have been lowered into the carton from above, so this will usually be the easiest route to follow. Be careful when you open the box, and make sure that the contents are not damaged. Do not use a knife to open cardboard boxes.
- 4 If the box has been closed using staples, remove the staples from the carton as you open it.
This will reduce the possibilities of scratch injury to yourself and damage to the contents.
- 5 If a wooden box has been closed using screws, always remove them using a screwdriver.
Do not attempt to force the lid open with a crowbar or similar tool.
- 6 Once the carton is open, carefully remove all loose packing and insulation material.
- 7 Check for user manuals and other documents that may have been added to the carton during packing.
- 8 Check also for special tools, door keys etc.

Unpacking mechanical units

Prior to installation or use, mechanical units must be unpacked from their transport boxes. It is important that this unpacking is done without inflicting damage to the equipment.

Prerequisites

Observe the procedure for unpacking of standard parts and units.

Context

Mechanical and electromechanical units may be heavy.

Procedure

- 1 Obtain the necessary lifting equipment, and make sure that the equipment is certified for the weight.
- 2 Lift the unit out of the transportation box.
- 3 Place it in a stable position on the floor/work bench.
- 4 Inspect the unit for visual damage.
- 5 Remove any packing material that may be inside the unit.
- 6 Collect and keep the relevant user manuals and/or documents provided with the unit.

Unpacking electronic and electromechanical units

Prior to installation or use, electronic and electromechanical units must be unpacked from their transport boxes. It is important that unpacking is done without inflicting damage to the equipment.

Context

Electronic and electromechanical units are normally wrapped in clear antistatic plastic bags.

Do not break the seal to open a printed circuit board, an electronic module or a unit before it shall be used. If the unit is returned with a broken seal we will assume that it has been used. You will then be billed accordingly.

Note

Beware of Electrostatic Discharge (ESD)!

When you handle electronic circuit boards and modules, you must beware of the dangers of electrostatic discharge (ESD), both to yourself and to the equipment. In order to ensure safe transport and storage, circuit boards and other electronic units will always be wrapped in a clear plastic protective bag, and the bag will be sealed.

Procedure

- 1 Lift the unit, in its protective bag, out of the transport box.

Note

You must never use the cables to lift or carry a unit.

- 2 Place it in a stable position on the floor or on the workbench.
- 3 Inspect the unit for damage.
 - a If a unit has been damaged, prepare an inspection report stating the condition of the unit and actions taken.
 - b Describe the damage, and collect photographic evidence if possible. Return the inspection report to Kongsberg Maritime as soon as possible.
- 4 Assuming all is well, open the bag and remove the unit.
- 5 Take out and keep the documentation.

You will need the documentation if the item shall be returned to us.
- 6 If applicable, open the unit and check inside.
- 7 Remove any packing and desiccant material that may be found inside the shipping container or bag.
- 8 Collect and keep the relevant user manuals and/or installation documents provided with the unit.

Unpacking transducers

Prior to installation or use, transducers, sonar heads and hydrophones must be unpacked from their transport boxes. It is important that this unpacking is done without inflicting damage to the equipment.

Prerequisites

Observe the procedure for unpacking of standard parts and units.

Context

Transducers may be supplied mounted to a hull unit (if any), or packed separately. Sonar heads and hydrophones are normally packed and shipped in separate boxes. Boxes are identified by the order number and the serial number of the unit inside.

Note

Once a transducer, sonar head or hydrophone is unpacked, make sure that the body and the cabling are not exposed to any mechanical stress. Protect the transducer face with a padded cover plate to prevent damage.

Transducers may be heavy.

A transducer must always be handled as a delicate instrument. Incorrect actions may damage the transducer beyond repair.

Observe these transducer handling rules:

- **Do not** activate the transducer when it is out of the water.
- **Do not** lift the transducer by the cable.
- **Do not** step on the transducer cable.
- **Do not** handle the transducer roughly and avoid impacts.
- **Do not** expose the transducer to direct sunlight or excessive heat.
- **Do not** use high-pressure water, sandblasting, metal tools or strong solvents to clean the transducer face.

Procedure

- 1 Obtain the necessary lifting equipment, and make sure that the equipment is certified for the weight.
- 2 Lift the transducer, sonar head or hydrophone out of the transportation box.
- 3 Place it in a stable position on the floor/work bench.
- 4 Inspect the unit for visual damage.
- 5 Make sure that the relevant protection is kept in place until the final stages of the installation.
- 6 Collect and keep the relevant user manuals and/or documents provided with the unit.

- 7 Observe the handling rules for transducers.

Specifications for storage after unpacking

The unit must whenever possible be stored in its original transportation crate until ready for installation.

General specifications

During storage, each box must not be used for any purpose for which it was not intended (work platform, table, steps etc.).

Once unpacked, all equipment must be kept in a dry, non condensing atmosphere, free from corrosive agents and isolated from sources of vibration.

Note

Do not break the seal to open a circuit board package before the board is to be used. If the board package is returned to Kongsberg Maritime with the seal broken, we will assumed that the unit has been used, and then you will be billed accordingly.

Each unit must be installed in its intended operating position as soon as possible after unpacking. If the unit contains normal batteries, these may have been disconnected/isolated before the unit was packed. These must then be reconnected during the installation procedure. Units containing batteries are marked.

Caution

Units containing lithium or alkaline batteries must be handled separately and with care. Such units are marked accordingly. Do not attempt to recharge such batteries, open them, or dispose of them by incineration.

Refer to the applicable product data sheets or battery handling procedures for further details.

Temperature protection

Any units that requires protection against extreme temperatures are identified as such in the applicable documentation. The box used to transport and store such units are clearly marked, for example:

Must not be transported or stored in temperatures below -5 °C.

Other temperature limits may be used if applicable.

If a unit needs temperature protection, the box to be used for storage and transportation must be lined on all walls, base and lid, using minimum 5 cm thick polyurethane or polystyrene foam.

Most system units can normally be stored in temperatures between -30° C and +70° C. Refer to the relevant technical specifications for details.

Note

Unless otherwise specified, transducers and hydrophones must not be stored in temperatures below -10°C and above $+50^{\circ}\text{C}$.

List of abbreviations

CPU	central processing unit
GNSS	global navigation satellite system
GPS	global positioning system
MRU	motion reference unit
NMEA	National Marine Electronics Association
PU	Processing Unit
RU or RXU	Receiver Unit
TXU	Transmitter Unit

Index

19-inch rack installation kit		
outline dimensions	157	
1PPS		
clock synchronisation	212	
connection	212	
385387		
fan unit	99	
A		
about		
document downloads	9	
EM 124	11	
online information	9	
purpose of this manual	9	
target audience	9	
transducer	14	
ac mains power		
requirements	175	
accuracy		
dimensional survey	180	
accuracy requirements		
dimensional survey measurements of global		
positioning system	181	
dimensional survey measurements of heading		
sensor	181	
dimensional survey measurements of motion		
reference unit	180	
dimensional survey measurements of		
transducer	180	
alignment		
specifications	182	
alignment specifications		
transducer	182	
waterline determination	181	
all		
datagram format	166	
anode		
inspecting	41	
replacing	41	
anti-fouling paints		
approved	42	
International Marine Coatings	42	
Jotun	42	
approved		
anti-fouling paints	42	
approved anti-fouling paints	42	
International Marine Coatings	42	
Jotun	42	
audience		
this manual	9	
B		
BIST		
CBMF test	26	
CBMF-CPU link	29	
CPU test	25	
RX channels	31	
RX noise level	33	
RX noise spectrum	34	
RX Unit test	27	
RX-CBMF link	30	
SW date and version	35	
System information	35	
TX channels	32	
TX Unit test	28	
BIST (Built-In Self Test)		
introduction	24	
BIST (Built-In Self test) dialog box		
description	20	
block		
diagram	13	
book		
purpose	9	
target audience	9	
bottom panel description		
Receiver Unit	128	
Transmitter Unit	120	
brief description		
transducer	14	
Built-In Self Test		
CBMF test	26	
CBMF-CPU link	29	
CPU test	25	
introduction	24	
RX channels	31	
RX noise level	33	
RX noise spectrum	34	
RX Unit test	27	
RX-CBMF link	30	
SW date and version	35	
System information	35	
TX channels	32	
TX Unit test	28	
C		
cable		
RX transducer	224	
TX transducer	223	
cable drawing		
1 pulse per second (1PPS)	212	
remote control Processing Unit	214	
remote control Receiver Unit	219	
remote control Transmitter Unit	217	
remote control using K-Rem	215	
RS-232 serial line	210	
RS-422 serial line	211	
cable plan		
Hydrographic Work Station	199	
Processing Unit	185	
Receiver Unit	194	
topside	199	
Transmitter Unit	186	
cables		
interconnections	183	
interfaces	183	
layout	183	
list of system interconnection cables	200	

-
- CBMF board
 - configuration 116
 - connectors 117
 - description 115
 - installing 59
 - links 116
 - overview 115
 - purpose 115
 - removing 58
 - replacing 57
 - spare part 97
 - switches 116
 - CBMF test
 - BIST theory 26
 - CBMF-CPU link
 - BIST theory 29
 - characteristics
 - performance 163
 - circuit boards
 - Processing Unit 109
 - clock synchronisation
 - 1 pulse per second (1PPS) 212
 - clock synchronization
 - connectors 204
 - signal characteristics 204
 - communication formats
 - motion information 167
 - position information 167
 - computer
 - introduction 16, 131
 - overview 16, 131
 - purpose 16, 131
 - Concurrent PP B12 CPU board
 - connectors 111
 - description 110
 - overview 110
 - purpose 110
 - spare part 98
 - Concurrent PP833 CPU board
 - connectors 112
 - description 111
 - overview 111
 - purpose 111
 - configuration
 - CBMF board 116
 - RIO-P board 125
 - connection
 - 1 pulse per second (1PPS) 212
 - remote control Processing Unit 214
 - remote control Receiver Unit 219
 - remote control Transmitter Unit 217
 - Remote Control Unit (K-Rem) 161
 - remote control using K-Rem 215
 - RS-232 serial cable 210
 - RS-422 serial cable 211
 - RX transducer cable 224
 - TX transducer cable 223
 - connectors
 - CBMF board 116–117
 - Concurrent PP B12 CPU board 111
 - Concurrent PP833 CPU board 112
 - VadaTech CP219 Ethernet switch 114
 - CPU board
 - description 110
 - installing 53
 - removing 52
 - replacing 51
 - CPU Concurrent PP B12
 - spare part 98
 - CPU test
 - BIST theory 25
 - D**
 - datagram format
 - all 166
 - KMall 166
 - datagram formats
 - motion information 167
 - position information 167
 - depth rating
 - transducer 177
 - description
 - BIST (Built-In Self test) dialog box 20
 - bottom panel Receiver Unit 128
 - bottom panel Transmitter Unit 120
 - CBMF board 115
 - Concurrent PP B12 CPU board 110
 - Concurrent PP833 CPU board 111
 - CPU board 110
 - front panel Processing Unit 107
 - Hydrographic Work Station 16, 131
 - Hydrographic Work Station front panel 131
 - Hydrographic Work Station rear panel 132
 - rear panel Processing Unit 108
 - Receiver Unit 15
 - system 11
 - top panel Transmitter Unit 122
 - transducer 14
 - Transmitter Unit 15
 - VadaTech CP219 Ethernet switch 113
 - details
 - technical 12
 - dialog box
 - BIST (Built-In Self test) dialog box
 - description 20
 - dimensional survey
 - accuracy 180
 - accuracy requirements for global positioning
 - system 181
 - accuracy requirements for heading sensor 181
 - accuracy requirements for motion reference
 - unit 180
 - accuracy requirements for transducer 180
 - dimensions
 - display 174
 - Hydrographic Work Station 156, 173
 - Processing Unit 173
 - Processing Unit outline dimensions
 - drawing 155
 - rack installation kit 157
 - Receiver Unit 173
 - RX Unit 173
 - technical specifications 172
 - transducer 172
 - Transmitter Unit 173
 - TX Unit 173
 - dip switch setting
 - Receiver Unit 129
 - RIO-P board 125

display	
environmental requirements	178
outline dimensions	174
power requirements	176
weight	174
documents	
download from website	9
download	
documents from website	9
drawing	
1 pulse per second (1PPS)	212
Hydrographic Work Station	156
remote control Processing Unit	214
remote control Receiver Unit	219
remote control Transmitter Unit	217
remote control using K-Rem	215
RS-232 serial line cable	210
RS-422 serial line cable	211
RX transducer cable	224
system diagram	13
TX transducer cable	223

E

electromechanical unit	
unpacking	234
electronic unit	
unpacking	234
environmental	
requirements	177
environmental requirements	
display	178
Hydrographic Work Station	178
transducer	177
equipment handling	
inspection	229
lifting units and transportation boxes	227
storage after unpacking	237
storage prior to installation	230
transportation	226
unpacking	232
unpacking a hydrophone	235
unpacking a mechanical unit	233
unpacking a sonar head	235
unpacking a transducer	235
unpacking an electronic or electromechanical unit	234
visual inspection	229
Ethernet switch	
installing PU	56
removing PU	55
replacing PU	54
Ethernet switch VadaTech CP218	
spare part	101
Excelsys power supply	
spare part	98
external synchronization	
connectors	206, 213
signal characteristics	206, 213

F

familiarization	
Processing Unit	106
Receiver Unit	127

Transmitter Unit	118
fan unit	
385387	99
installing PU	62
removing PU	61
replacing PU	60
replacing TXU	67
spare part	99, 101
fault location	
tools	19
file extension	
.all	166
.kmall	166
front panel description	
Hydrographic Work Station	131
Processing Unit	107
functional	
diagram	13
fuse	
Processing Unit	63

G

global positioning system	
accuracy requirements for dimensional survey	
measurements	181
GPS	
accuracy requirements for dimensional survey	
measurements	181
GPS information	
datagram formats	167

H

handling	
transducers	37
heading sensor	
accuracy requirements for dimensional survey	
measurements	181
help	
support offices	17
how to	
inspect anode	41
install CBMF board	59
install CPU board	53
install Ethernet switch PU	56
install fan unit PU	62
install fuse PU	65
install power supply TXU 12V	75
install power supply TXU HV	81
install power supplyRXU	92
install Processing Unit	50
install Receiver Unit	87
lift units and transportation boxes	227
remove CBMF board	58
remove CPU board	52
remove Ethernet switch PU	55
remove fan unit PU	61
remove fuse PU	64
remove power supply TXU 12V	73
remove power supply TXU HV	79
remove power supplyRXU	90
remove Processing Unit	49
remove Receiver Unit	85
replace anode	41

replace CBMF board	57
replace CPU board	51
replace Ethernet switch PU	54
replace fan unit PU	60
replace fan unit TXU	67
replace fuse PU	63
replace power supply RXU	89
replace power supply TXU 12V	72
replace power supply TXU HV	78
replace Processing Unit	48
replace Receiver Unit	84
transport Kongsberg Maritime equipment	226
unpack a hydrophone	235
unpack a mechanical unit	233
unpack a sonar head	235
unpack a transducer	235
unpack an electronic or electromechanical unit	234
unpack standard parts and units	232
visual inspection of units and transportation boxes after arrival	229
humidity requirements	177
HWS	
cable plan	199
front panel description	131
outline dimensions drawing	156
rear panel description	132
Hydrographic Work Station	
cable plan	199
description	16, 131
environmental requirements	178
front panel description	131
outline dimensions	173
outline dimensions drawing	156
overview	16, 131
power requirements	175
purpose	16, 131
rear panel description	132
weight	173
hydrophone anti-fouling paints	42
unpacking	235
I	
identification Receiver Unit	129
illustration system diagram	13
important transducer handling	37
information online	9
support	17
inspection transportation boxes	229
units	229
installation requirements environmental	177
humidity	177
temperature	177
installing CBMF board	59
CPU board	53
Ethernet switch PU	56
fan unit PU	62
fuse PU	65
power supply RXU	92
power supply TXU 12V	75
power supply TXU HV	81
Processing Unit	50
Receiver Unit	87
instructions unpacking	232
interconnection cables list	200
interconnections cables	183
interface cables	183
specifications	167
International Marine Coatings	
anti-fouling paints	42
introduction	
BIST (Built-In Self Test)	24
computer	16, 131
Processing Unit	15, 106
J	
Jotun	
anti-fouling paints	42
K	
K-Rem	
outline dimensions	160
wiring diagram	161
KMall	
datagram format	166
Kongsberg Maritime	
support	17
L	
LCD monitor	
environmental requirements	178
outline dimensions	174
power requirements	176
weight	174
lifting transportation boxes	227
unit	227
links CBMF board	116
list system interconnection cables	200
LPTX36 Transmitter board	
spare part	100
M	
mains power	
requirements	175
manual	
purpose	9
target audience	9

mechanical unit	
unpacking	233
modules	
Processing Unit	109
monitor	
environmental requirements	178
outline dimensions	174
power requirements	176
weight	174
motion information	
datagram formats	167
motion reference unit	
accuracy requirements for dimensional survey	
measurements	180
datagram formats	167
MRU	
accuracy requirements for dimensional survey	
measurements	180
datagram formats	167
N	
NMEA	
RS-232 serial line cable	210
RS-422 serial line cable	211
NMEA datagrams	
GPS information	167
motion information	167
position information	167
non-technical description	
Receiver Unit	15
Transmitter Unit	15
O	
offices	
support	17
online	
information	9
operating humidity	
Processing Unit	177
Receiver Unit	177
RX Unit	177
Transmitter Unit	177
TX Unit	177
operating temperature	
Processing Unit	177
Receiver Unit	177
RX Unit	177
transducer	177
Transmitter Unit	177
TX Unit	177
operating voltage	
display	176
Hydrographic Work Station	175
Processing Unit	175
Receiver Unit	175
RX Unit	175
Transmitter Unit	175
TX Unit	175
order number	
CBMF board	97
Concurrent PP B12 CPU board	98
Excelsys power supply	98
fan unit	99, 101

LPTX36 Transmitter board	100
PU power supply	98
Receiver Unit 1 degree	103
Receiver Unit 2 degrees	103–104
Roal power supply	104
RXU power supply	104
TX RIO board	100
TXU 12V power supply	101
TXU HV power supply	102
VadaTech CP218 Ethernet switch	101
ordering	
spare parts	96
outline dimensions	
display	174
Hydrographic Work Station	156, 173
rack installation kit	157
Receiver Unit	173
Remote Control Unit (K-Rem)	160
RX Unit	173
technical specifications	172
transducer	172
Transmitter Unit	173
TX Unit	173
outline dimensions drawing	
Processing Unit	155
overview	
CBMF board	115
computer	16, 131
Concurrent PP B12 CPU board	110
Concurrent PP833 CPU board	111
Hydrographic Work Station	16, 131
Processing Unit	15, 106
VadaTech CP219 Ethernet switch	113
P	
part number	
CBMF board	97
Concurrent PP B12 CPU board	98
Excelsys power supply	98
fan unit	99, 101
LPTX36 Transmitter board	100
PU power supply	98
Receiver Unit 1 degree	103
Receiver Unit 2 degrees	103–104
Roal power supply	104
RXU power supply	104
TX RIO board	100
TXU 12V power supply	101
TXU HV power supply	102
VadaTech CP218 Ethernet switch	101
PCBs	
Processing Unit	109
performance	
specifications	163
peripheral systems	
interface specifications	167
physical dimensions	
rack installation kit	157
Remote Control Unit (K-Rem)	160
plugs	
CBMF board	117
Concurrent PP B12 CPU board	111
Concurrent PP833 CPU board	112
VadaTech CP219 Ethernet switch	114

-
- position information
 - datagram formats 167
 - power
 - requirements 175
 - specifications 175
 - power consumption
 - Hydrographic Work Station 175
 - Processing Unit 175
 - Receiver Unit 175
 - RX Unit 175
 - Transmitter Unit 175
 - TX Unit 175
 - power requirements
 - display 176
 - Hydrographic Work Station 175
 - Receiver Unit 175
 - RX Unit 175
 - Transmitter Unit 175
 - TX Unit 175
 - power supply
 - installing RXU 92
 - installing TXU 12V 75
 - installing TXU HV 81
 - removing RXU 90
 - removing TXU 12V 73
 - removing TXU HV 79
 - replacing RXU 89
 - replacing TXU 12V 72
 - replacing TXU HV 78
 - power supply PU
 - spare part 98
 - power supply RXU
 - spare part 104
 - power supply TXU 12V
 - spare part 101
 - power supply TXU HV
 - spare part 102
 - procedure
 - inspecting anode 41
 - installing CBMF board 59
 - installing CPU board 53
 - installing Ethernet switch PU 56
 - installing fan unit PU 62
 - installing fuse PU 65
 - installing power supply RXU 92
 - installing power supply TXU 12V 75
 - installing power supply TXU HV 81
 - installing Processing Unit 50
 - installing Receiver Unit 87
 - lifting units and transportation boxes 227
 - removing CBMF board 58
 - removing CPU board 52
 - removing Ethernet switch PU 55
 - removing fan unit PU 61
 - removing fuse PU 64
 - removing power supply RXU 90
 - removing power supply TXU 12V 73
 - removing power supply TXU HV 79
 - removing Processing Unit 49
 - removing Receiver Unit 85
 - replacing anode 41
 - replacing CBMF board 57
 - replacing CPU board 51
 - replacing Ethernet switch PU 54
 - replacing fan unit PU 60
 - replacing fan unit TXU 67
 - replacing fuse PU 63
 - replacing power supply RXU 89
 - replacing power supply TXU 12V 72
 - replacing power supply TXU HV 78
 - replacing Processing Unit 48
 - replacing Receiver Unit 84
 - transporting Kongsberg Maritime
 - equipment 226
 - unpacking a hydrophone 235
 - unpacking a mechanical unit 233
 - unpacking a sonar head 235
 - unpacking a transducer 235
 - unpacking an electronic or electromechanical
 - unit 234
 - unpacking standard parts and units 232
 - visual inspection of units and transportation
 - boxes after arrival 229
 - procedures
 - unpacking 232
 - Processing Unit
 - cable plan 185
 - circuit boards and modules 109
 - dimensions 173
 - familiarization 106
 - front panel description 107
 - installing 50
 - introduction 15, 106
 - operating humidity 177
 - operating temperature 177
 - operating voltage 175
 - outline dimensions drawing 155
 - overview 15, 106
 - power consumption 175
 - purpose 15, 106
 - rear panel description 108
 - removing 49
 - replacing 48
 - spare part 97
 - storage temperature 177
 - weight 173
 - Processing Unit
 - installing fuse 65
 - removing fuse 64
 - replacing fuse 63
 - PU
 - front panel description 107
 - installing 50
 - installing fuse 65
 - rear panel description 108
 - removing 49
 - removing fuse 64
 - replacing 48
 - replacing fuse 63
 - spare part 97
 - PU power supply
 - spare part 98
 - publication
 - purpose 9
 - target audience 9
 - purpose
 - CBMF board 115
 - computer 16, 131
 - Concurrent PP B12 CPU board 110
 - Concurrent PP833 CPU board 111

Hydrographic Work Station	16, 131	Receiver Unit.....	85
Processing Unit	15, 106	replacing	
this manual.....	9	CBMF board.....	57
VadaTech CP219 Ethernet switch	113	CPU board	51
R		Ethernet switch PU	54
rack installation kit		fan unit PU	60
outline dimensions.....	157	fan unit TXU	67
raw file		fuse PU	63
datagram format.....	166	power supply RXU	89
reader		power supply TXU 12V	72
this manual.....	9	power supply TXU HV	78
rear panel description		Processing Unit	48
Hydrographic Work Station	132	Receiver Unit.....	84
Processing Unit	108	requirements	
Receiver Unit		ac mains power.....	175
bottom panel description.....	128	dimensional survey measurements of global	
brief description.....	15	positioning system	181
cable plan	194	dimensional survey measurements of heading	
dimensions	173	sensor	181
dip switch setting	129	dimensional survey measurements of motion	
environmental specifications	177	reference unit	180
familiarization	127	dimensional survey measurements of	
identification.....	129	transducer.....	180
installing	87	environmental	177
operating humidity.....	177	humidity.....	177
operating temperature	177	mains power	175
operating voltage.....	175	power	175
power consumption.....	175	supply power	175
power requirements.....	175	temperature	177
removing	85	RIO-P board	
replacing	84	configuration	125
shock.....	177	dip switch setting	125
storage temperature.....	177	Roal power supply	
vibration.....	177	spare part.....	104
weight	173	RS-232	
Receiver Unit 1 degree		serial line cable.....	210
spare part.....	103	RS-422	
Receiver Unit 2 degrees		serial line cable.....	211
spare part.....	103–104	rules	
remote control		transducer handling.....	37
connection overview	221	RX channels	
connection Processing Unit.....	214	BIST theory.....	31
connection Receiver Unit.....	219	RX noise level	
connection Transmitter Unit.....	217	BIST theory.....	33
dummy plug	216	RX noise spectrum	
not using	216	BIST theory.....	34
remote control overview		RX transducer cable	
connection of units.....	221	connection	224
Remote Control Unit		drawing.....	224
outline dimensions.....	160	specifications	224
wiring diagram	161	wiring.....	224
remote control using K-Rem		RX unit	
connection	215	cable plan	194
removing		RX Unit	
CBMF board.....	58	brief description.....	15
CPU board	52	dimensions	173
Ethernet switch PU	55	environmental specifications	177
fan unit PU.....	61	ID	129
fuse PU	64	installing	87
power supply RXU	90	operating humidity.....	177
power supply TXU 12V	73	operating temperature	177
power supply TXU HV	79	operating voltage.....	175
Processing Unit	49	power consumption.....	175
		power requirements.....	175
		shock.....	177

storage temperature.....	177
vibration.....	177
weight.....	173
RX Unit test	
BIST theory.....	27
RX-CBMF link	
BIST theory.....	30
RXU	
bottom panel description.....	128
familiarization.....	127
installing.....	87
removing.....	85
replacing.....	84
RXU power supply	
spare part.....	104
S	
sensors	
interface specifications.....	167
serial line	
RS-232 cable specifications.....	210
RS-422 cable specifications.....	211
shock	
Receiver Unit.....	177
RX Unit.....	177
Transmitter Unit.....	177
TX Unit.....	177
signal characteristics	
clock synchronization.....	204
external synchronization.....	206, 213
size	
display.....	174
Hydrographic Work Station.....	156, 173
rack installation kit.....	157
Remote Control Unit (K-Rem).....	160
technical specifications.....	172
transducer.....	172
sockets	
CBMF board.....	117
Concurrent PP B12 CPU board.....	111
Concurrent PP833 CPU board.....	112
VadaTech CP219 Ethernet switch.....	114
sonar head	
anti-fouling paints.....	42
unpacking.....	235
spare part	
CBMF board.....	97
Concurrent PP B12 CPU board.....	98
Excelsys power supply.....	98
fan unit.....	99, 101
LPTX36 Transmitter board.....	100
Processing Unit.....	97
PU power supply.....	98
Receiver Unit 1 degree.....	103
Receiver Unit 2 degrees.....	103–104
Roal power supply.....	104
RXU power supply.....	104
TX RIO board.....	100
TXU 12V power supply.....	101
TXU HV power supply.....	102
VadaTech CP218 Ethernet switch.....	101
spare parts	
ordering.....	96
specifications	
1 pulse per second (1PPS).....	212
alignment.....	182
interface capabilities.....	167
outline dimensions.....	172
performance.....	163
power.....	175
remote control Processing Unit.....	214
remote control Receiver Unit.....	219
remote control Transmitter Unit.....	217
remote control using K-Rem.....	215
RS-232 serial line cable.....	210
RS-422 serial line cable.....	211
RX transducer cable.....	224
storage after unpacking.....	237
storage prior to installation.....	230
TX transducer cable.....	223
weight.....	172
storage	
after unpacking.....	237
prior to installation.....	230
storage temperature	
Processing Unit.....	177
Receiver Unit.....	177
RX Unit.....	177
transducer.....	177
Transmitter Unit.....	177
TX Unit.....	177
supply power	
requirements.....	175
supply voltage	
display.....	176
Hydrographic Work Station.....	175
Processing Unit.....	175
Receiver Unit.....	175
RX Unit.....	175
Transmitter Unit.....	175
TX Unit.....	175
support information.....	17
survey	
dimensional survey accuracy.....	180
survey requirements	
accuracy requirements for dimensional	
survey measurements of global positioning	
system.....	181
accuracy requirements for dimensional survey	
measurements of heading sensor.....	181
accuracy requirements for dimensional survey	
measurements of motion reference unit.....	180
accuracy requirements for dimensional survey	
measurements of transducer.....	180
SW date and version	
BIST theory.....	35
switches	
CBMF board.....	116
sync	
clock synchronization.....	204
external synchronization.....	206, 213
system	
description.....	11
diagram.....	13
system cables	
list.....	200
System information	
BIST theory.....	35

T

target audience
 this manual 9

technical
 details 12

technical details 12

technical requirements
 ac mains power 175
 mains power 175
 power 175
 supply power 175

technical specifications
 interface specifications 167
 outline dimensions 172
 weight 172

technical support
 offices 17

temperature
 requirements 177

this manual
 purpose 9
 target audience 9

tools
 troubleshooting 19

top panel description
 Transmitter Unit 122

topside
 cable plan 199

transducer
 accuracy requirements for dimensional survey
 measurements 180
 alignment specifications 182
 anti-fouling paints 42
 brief description 14
 depth rating 177
 dimensions 172
 environmental requirements 177
 operating temperature 177
 storage temperature 177
 unpacking 235
 weight 172

transducer handling
 important rules 37

Transmitter board LPTX36
 spare part 100

Transmitter board TX RIO
 spare part 100

Transmitter Unit
 bottom panel description 120
 brief description 15
 cable plan 186
 dimensions 173
 environmental specifications 177
 familiarization 118
 operating humidity 177
 operating temperature 177
 operating voltage 175
 power consumption 175
 power requirements 175
 shock 177
 storage temperature 177
 top panel description 122
 vibration 177
 weight 173

transportation
 of delicate and fragile equipment 226

troubleshooting
 tools 19

TX channels
 BIST theory 32

TX RIO board
 spare part 100

TX transducer cable
 connection 223
 drawing 223
 specifications 223
 wiring 223

TX unit
 cable plan 186

TX Unit
 brief description 15
 dimensions 173
 environmental specifications 177
 operating humidity 177
 operating temperature 177
 operating voltage 175
 power consumption 175
 power requirements 175
 shock 177
 storage temperature 177
 vibration 177
 weight 173

TX Unit test
 BIST theory 28

TXU
 bottom panel description 120
 brief description 15
 familiarization 118
 top panel description 122

TXU power supply 12V
 spare part 101

TXU power supply HV
 spare part 102

U

unpacking
 a hydrophone 235
 a mechanical unit 233
 a sonar head 235
 a transducer 235
 an electronic or electromechanical unit 234
 instructions 232
 standard parts and units 232

V

VadaTech CP218 Ethernet switch
 spare part 101

VadaTech CP219 Ethernet switch
 connectors 114
 description 113
 overview 113
 purpose 113

vibration
 Receiver Unit 177
 RX Unit 177
 Transmitter Unit 177
 TX Unit 177

visual inspection	
transportation boxes	229
units	229

W

waterline	
alignment specifications	181
website	
download documents	9
weight	
display	174
Hydrographic Work Station	173
Processing Unit	173
Receiver Unit	173
RX Unit	173
technical specifications	172
transducer	172
Transmitter Unit	173
TX Unit	173
wiring	
information	183
list of system interconnection cables	200
RX transducer cable	224
TX transducer cable	223
wiring diagram	
Hydrographic Work Station	199
Processing Unit	185
Receiver Unit	194
Remote Control Unit (K-Rem)	161
topside	199
Transmitter Unit	186

©2020 Kongsberg Maritime