




KONGSBERG

Installation Manual

Seapath[®] 130-R series

Compact GNSS aided Inertial Navigation System

Kongsberg Maritime
ID: 110-0051867/C





KONGSBERG

Seapath 130-R series Compact GNSS aided Inertial Navigation System

Installation manual

Kongsberg Maritime
ID: 110-0051867/C

M340-64/3.0

May 2024 © Kongsberg Discovery AS

Document history

Document number: M340–64 / Revision 3.0		
Rev. 1.0	December 2018	First version.
Rev. 2.0	September 2023	Updated to correspond with Product sw version 2.01.00. Fugro Seastar DGNSS receiver connection diagrams included. Weight on Sensor Unit has been updated. Updated wiring schematic for DGNSS cable to PPU. Updated Sensor unit power specification. Included description of RS-232 and RS-422 connections.
Rev. 3.0	May 2024	Updated to correspond with Product sw version 2.02.00. Updated performance specifications.

Copyright

©Kongsberg Discovery AS

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or otherwise copied without prior permission from Kongsberg Discovery AS.

Note

The information contained in this document remains the sole property of Kongsberg Discovery AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Discovery AS.

Kongsberg Discovery AS endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.

Warning

The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. The user must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.

Kongsberg Discovery disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.

Comments

To assist us in making improvements to the product and to this manual, we welcome comments and constructive criticism.

e-mail: kd.seatex@kd.kongsberg.com

Table of contents

1	ABOUT THIS MANUAL	7
2	SEAPATH 130-R	8
2.1	Product description	8
2.2	System diagram	9
2.3	System units.....	11
2.3.1	Seapath 130 sensor unit description.....	11
2.3.2	MGC description	11
2.3.3	Spider cable description.....	12
2.4	Scope of supply	12
2.4.1	Standard parts provided.....	12
2.5	Product restrictions	12
2.5.1	Restrictions in export	12
2.5.2	Restrictions in guarantee	13
2.5.3	Restrictions in use.....	13
2.6	Seapath as NTP server.....	13
2.7	Network security	14
2.8	Support information.....	14
3	INSTALLATION	16
3.1	Preparing the installation.....	16
3.1.1	Necessary tools and equipment	16
3.1.2	Drawings.....	17
3.1.3	Radio frequency authorisation.....	17
3.1.4	Worker skills	17
3.1.5	Determining the location of system parts	17
3.2	Installation summary	18
3.3	Terminating the cable within the sensor unit (optional).....	19
3.4	Mounting the sensor unit.....	20
3.5	Mounting the MGC subsea bottle.....	22
3.5.1	Subsea bottle connectors and pin configuration	23
3.6	Powering the Seapath system	24
3.7	Installing the Seapath operator software	24
3.8	Uninstalling the Seapath operator software.....	25
4	CABLE LAYOUT AND INTERCONNECTIONS.....	26
4.1	Cable plan.....	26
4.1.1	Ethernet connections	29
4.1.2	PPS signal output description.....	29
4.1.3	Communication interfaces in the Seapath system	29
4.1.4	DGNSS correction from Fugro SeaStar	30

5	SURVEY OF SENSORS ON VESSELS	32
5.1	Vessel reference system definition.....	32
5.2	Determine the MGC mounting orientation.....	33
5.3	Surveying the MGC subsea bottle.....	34
5.4	Determining the sensor unit position and orientation.....	35
5.4.1	Surveying the sensor unit.....	36
5.5	Determining the distance vectors	37
5.6	Survey accuracy.....	38
6	SETTING TO WORK.....	39
6.1	Setting to work summary.....	39
6.2	Verifying that the Seapath is ready for operational use.....	40
6.3	Powering up the Seapath for the first time	40
6.4	Configuration management description.....	40
6.4.1	Entering the configuration management system.....	40
6.4.2	Operator software configuration description.....	40
6.4.3	NAV Engine Configuration.....	41
6.4.4	Changing the system mode	42
6.5	Required sensor unit configuration.....	43
6.5.1	Setting vessel dimensions and reference points	43
6.5.2	Entering sensor unit location parameters.....	46
6.5.3	Using Calibration Wizard to determine antenna parameters.....	48
6.5.4	Setting MGC location and mounting angles	51
6.5.5	Using Mounting Wizard to determine MGC mounting angles	53
6.5.6	Selecting heave filter options	56
6.5.7	Setting monitoring points	58
6.5.8	Communication interfaces description.....	61
6.5.9	Using the Serial interface.....	62
6.5.10	Using the Ethernet interface.....	63
6.5.11	Setting up the Telegram out interface.....	64
6.5.12	Setting up the DGNSS correction link parameters	67
6.5.13	Connecting to a network.....	68
6.6	Additional sensor unit configuration	70
6.6.1	Entering vessel identification parameters	70
6.6.2	Importing vessel shape from file	70
6.6.3	Selecting SBAS satellites	73
6.6.4	Enabling Fugro high precision services.....	74
6.6.5	Selecting heading input format from gyro compass	75
6.6.6	Setting up the MGC as an inertial navigation system (INS).....	76
6.7	Operator software configuration.....	77
6.7.1	Selecting the position of views in the display	77
6.7.2	Selecting the appearance of the Sky View	78
6.7.3	Adjusting the Integrity view	80

6.7.4	Adjusting the Compass view.....	81
6.7.5	Adjusting UTM presentation.....	82
6.7.6	Connecting the Seapath HMI software to the sensor unit	83
6.7.7	Selecting alarm message reception	85
6.8	Creating a backup of the configuration and software installation	86
6.9	Restoring the configuration backup.....	87
7	DRAWINGS.....	89
7.1	Sensor unit dimensions.....	90
7.2	MGC R2 and R3 SB50 dimensions.....	91
7.3	MGC R2 and R3 SB50 assembly drawing.....	92
7.4	MGC R2 and R3 SB50 sensor point location.....	93
7.5	Spider cable schematics, default version.....	94
7.6	Spider cable schematics, short version.....	95
8	TECHNICAL SPECIFICATIONS.....	96
8.1	Performance specifications.....	96
8.1.1	Roll, pitch and heading specifications.....	96
8.1.2	Heave specifications.....	96
8.1.3	Position and velocity specifications.....	96
8.1.4	Horizontal position drift specifications	97
8.2	Interface specifications.....	97
8.2.1	Sensor unit	97
8.3	Weight and outline dimensions.....	97
8.3.1	Sensor unit	98
8.3.2	MGC R2 and R3 SB50 unit	98
8.4	Power specifications.....	98
8.4.1	Sensor unit	98
8.4.2	MGC SB50 unit.....	98
8.5	Environmental specifications.....	99
8.5.1	Sensor unit	99
8.5.2	MGC R2 and R3 SB50 unit	99
8.6	Radio frequency specifications.....	99
8.6.1	GNSS antenna	100
8.7	Data output specifications.....	100
8.7.1	Sensor unit	100
8.8	Data input specifications.....	101
8.8.1	Sensor unit	101
8.9	Datum specifications	101
8.9.1	Sensor unit	101
8.10	Cable specifications	101
8.10.1	Sensor unit cable.....	101
8.10.2	MGC umbilical cable	102

8.11	Conformity declaration.....	102
9	EQUIPMENT HANDLING	104
9.1	Handling and storage.....	104
9.2	Disposal.....	104
A	OUTPUT PROTOCOLS	105
A.1	NMEA format.....	106
A.2	Binary format 3.....	112
A.3	Binary format 11.....	113
A.4	Seapath Binary 23.....	114
A.5	Seapath Binary 26.....	116
A.6	Simrad EM3000.....	118
A.7	KM binary format.....	118
A.8	Calibration format 7.....	121
A.9	Echo sounder format 9.....	122
A.10	Echo sounder format 18, TSS1.....	122
A.11	RDI ADCP.....	123
A.12	Lehmkuhl gyro repeater format 12.....	124
A.13	1PPS, NMEA ZDA format 13.....	124
A.14	1PPS, Trimble format 14.....	125
A.15	Atlas fansweep format 16.....	125
A.16	PFreeHeave.....	126
A.17	Cyclic redundancy check algorithm.....	127
A.18	RTCM format 80.....	128
B	NMEA TELEGRAMOUT OPTIONS	129
C	INSTALLATIONS WITH JUNCTION BOX	131
D	FREE OPEN SOURCE SOFTWARE	135
D.1	BSD license.....	135
D.2	f2c license.....	136
D.3	GCC license.....	136
D.4	GNU C library license.....	137
D.5	GNU general public license, version 2.....	140
D.6	GNU general public license, version 3.....	145
D.7	GNU lesser general public license, version 2.1.....	153
D.8	GNU lesser general public license, version 3.....	159
D.9	PHP license.....	161

1 About this manual

Observe the general information about the Seapath 130 series in this manual. This manual applies to the Seapath 130–R2 and 130–R3 products.

Purpose of manual

The purpose of this installation manual is to provide the descriptions and procedures required to install and set up the Seapath 130 series of products on a vessel.

Target audience

This installation manual is intended as a reference manual for the personnel installing the system and it contains the necessary information to install and set up the Seapath equipment on a vessel.

Maintenance purposes

This manual is also intended as reference material for the maintenance personnel. Keep this manual for later use.

License information

Export of the MGC R2, MGC R3 or MGC R4 component requires an export license.

Registered trademarks

Seapath® is a registered trademark of Kongsberg Discovery AS in Norway and the People's Republic of China.

2 Seapath 130–R

2.1 Product description

The Seapath 130 is developed specifically for hydrographic surveying where high precision heading, position, roll, pitch, heave and timing are critical measurements. The product combines state-of-the-art dual frequency GNSS receivers (GPS/GLO/GAL/BDS), inertial technology and processing algorithms in a compact and portable package.

The main component is the sensor unit with the motherboard, GNSS antennas and receivers. The sensor unit is to be mounted on top of the vessel mast or pole. On top of the transducer, the inertial sensor of type MGC R2 and R3 is mounted within a subsea bottle. The Seapath operator software is installed on a connected PC for configuration and monitoring. All the components are connected through a spider cable with MGC connection, three configurable serial lines, DGNSS (Differential GNSS) correction input, 1PPS output, network communication and power inlet.

The latest Seapath software includes Automatic Online Calibration (AOC) that significantly improves the roll and pitch accuracy. With the AOC functionality recalibration of the IMU is now longer required if the vessel is in motion with heading changes (not stationary vessels).


The Seapath 130–R series is delivered in the following and improved product range:

- **Seapath 130–R2** with MGC R2 to 0.008° roll and pitch accuracy
- **Seapath 130–R3** with MGC R3 to 0.007° roll and pitch accuracy

The advanced Seapath navigation algorithms integrate the RTK GNSS data with the inertial sensor data. This gives the Seapath 130 unique advantages compared to stand alone RTK products. The Seapath product's accurate roll, pitch and heading measurements allow the RTK antenna position to be referenced to any point on the vessel where accurate position and velocity are required. All the data from Seapath have the same time stamp and the output is in real-time. Subdecimetre position accuracy can be achieved through download of satellite orbit and clock data from internet and by post processing of satellite and IMU (Inertial Measurement Unit) data. The Seapath is robust against GNSS dropouts by using the inertial sensor for dead reckoning navigation in order to provide position, velocity and also heading measurements when GNSS is not available.

With latest Seapath software the typical position drift for MGC R2, MGC R3 and MGC R4 after GNSS dropout is shown in the plot below:

Figure 1 Typical position drift in meters after GNSS dropout in minutes




The product has three configurable RS-232/422 serial lines and Ethernet for output of motion data and NMEA messages to the multibeam and survey computer. Input of DGNSS corrections of various quality and sources are input on a configurable RS-232/422 serial line or Ethernet.

By utilising standard DGNSS, Fugro SeaSTAR XP2/G2/G4/G4+, VERIPOS Ultra/Ultra², C-NavC¹, C-NavC² and RTK corrections, this system is a unique solution for hydrographic surveying and dredging work which demand the most comprehensive, most accurate surveying data available.

2.2 System diagram

A system diagram for a Seapath setup.



Main units

- 1 Sensor unit with 1 meter cable with male connector
- 2 Mounting bracket
- 3 Seapath operator software installed on a PC (not part of the delivery)
- 4 MGC in subsea bottle

Cables

- A Cable to the sensor unit, part of the spider cable, 20 meter length with female connector
- B MGC umbilical cable with 8-pin SeaCon connector, 15 meter length
- C Ethernet cable to PC and other users, 5 meter length
- D Input/output serial line for GNSS corrections with 9-pin Dsub, 5 meter length
- E Output serial line for motion data to multibeam or survey computer with 9-pin Dsub, 5 meter length
- F Output serial line for NMEA data with 9-pin Dsub, 5 meter length
- G 1PPS output with 9-pin Dsub, 5 meter length
- H 24 VDC input, 5 meter length

2.3 System units


The Seapath product comprises the following main components.

2.3.1 Seapath 130 sensor unit description

The sensor unit runs the navigation software. This software combines the GNSS signal and the inertial measurements to determine accurate position, heading, attitude and heave signal. This software utilises Kongsberg Discovery AS advanced true multi-reference algorithms for real-time parallel processing of all available correction signals.


The sensor unit includes:

- Two GNSS receivers and antennas
- Motherboard
- Connector board for termination of the spider cable
- Cable of 1 meter with male connector
- Mounting bracket




2.3.2 MGC description

The MGC R2 and R3 SB50 mounted in subsea bottle. The MGC unit is a north-seeking gyro compass based on three Ring Laser Gyros (RLG) and three linear accelerometers.



2.3.3 Spider cable description

The product is delivered with a spider cable for sensor unit connection through the female connector, MGC connection through the 8-pin SeaCon connector, three configurable serial lines through 9-pin Dsubs, 1PPS output through 9-pin Dsub, network communication and power inlet.



Delivered in either 20 meter length or 8 meter length (short).

2.4 Scope of supply

2.4.1 Standard parts provided

Observe the basic items provided with a standard Seapath system delivery.

- 1 ea Seapath 130 sensor unit
Part number M340-03
- 1 ea Seapath 130 mounting bracket
Part number M340-05
- 1 ea MGC motion sensor and compass
Models MGC R2 SB50 or MGC R3 SB50
- 1 ea Seapath spider cable
Part number M340-20 (20 m length) or
Part number M340-25, short (8 m length)
- 1 ea user documentation

2.5 Product restrictions

2.5.1 Restrictions in export

Export of the MGC R1, R2, R3, R4 and R5 COMPASS component requires an export license.

Note

Notice to importer: The MGC product specified in this document is shipped from Norway in accordance with The Ministry of Foreign Affairs' Official Notification on Export Control and U.S. Export Administration Regulations (EAR). The MGC product will be subject to restrictions if re-exported from your country, including but not limited to a re-export license from the U.S. Government.

2.5.2 Restrictions in guarantee

Changes or modifications to the product not explicitly approved by Kongsberg Discovery AS will void the guarantee.

The liability of Kongsberg Discovery AS is limited to repair of this system only under the given terms and conditions stated in the sales documents. Consequential damages such as customer's loss of profit or damage to other systems traceable back to this system's malfunctions, are excluded. The warranty does not cover malfunctions of the system resulting from the following conditions:

- The Sensor Unit is not shipped in the original transport box.
- The Sensor Unit has been exposed to extreme shock and vibrations.
- The Sensor Unit housing has been opened by the customer in an attempt to carry out repair work.
- Incorrect power connection.

2.5.3 Restrictions in use

The Seapath function is based on GNSS signals and requires free sight to the sky, minimum four visible satellites, PDOP value less than 6 and otherwise normal conditions to operate. It is designed for use on board marine surface operated vehicles with linear acceleration less than $\pm 45 \text{ m/s}^2$ ($\pm 4.5g$) and an angular rate range less than $\pm 125^\circ/\text{s}$.

Specifications are valid without multipath, without shadowing of antenna and with vessel in motion.

This Seapath product is intended for use in maritime survey and navigation applications.

2.6 Seapath as NTP server

The Seapath can be used as an NTP server for clock synchronization of connected computer systems. An accuracy better than one millisecond can be achieved in local area networks under ideal conditions.

To use the Seapath as the NTP server, the NTP clients have to be configured with the Seapath IP address as the server. How this is done depends on the client software in use. Nothing in the Seapath has to be configured. The NTP server on the Seapath runs in standard mode with the PPS as reference.

2.7 Network security

Equipment manufactured by Kongsberg Discovery AS is frequently connected to local area networks (LAN). Connecting any computer to a network will always expose the data on that computer to all other computers connected to the same network. Several threats may immediately occur:

- Remote computers can read the data.
- Remote computers can change the data.
- Remote computers can change the behaviour of the computer, for example by installing unwanted software.

Usually, two parameters are used to define the threat level:

- 1 The likelihood that any remote connection will do any of the above.
- 2 The damage done if a remote connection succeeds doing this.

Because Kongsberg Discovery AS has no information regarding the complete system installation at a location, we can not estimate the threat level and the need for network security. For this reason, we can not accept responsibility for network security. Systems provided by Kongsberg Discovery AS are regarded as stand-alone offline systems, even though they may be connected to a network for sensor interfaces and/or data distribution.

Note

No network safety applications are installed on any Kongsberg Discovery computers. The computers are thus not protected against viruses, malware or unintentional access from external users.

Securing the system itself has no meaning unless there is a policy in place that secures all computers in the network. This policy must include physical access by trained and trusted users. The customer/end user of the system will always be in charge of defining and implementing a security policy, and providing the relevant network security applications.

Note

Kongsberg Discovery AS will not accept any responsibility for errors and/or damages caused by unauthorized use or access to the product.

2.8 Support information

- **Company name:** Kongsberg Discovery AS, Seatex
- **Address:** Havnegata 9, 7010 Trondheim, Norway
- **Duty phone:** +47 33 03 24 07 (24 hours)
- **Support e-mail address:** support.seatex@kd.kongsberg.com
- **Website:** <http://www.kongsberg.com/discovery>

KM-Support App

Support is also available from the KM Support App. This app is available for free in App Store and Google Play.

3 Installation

This chapter provides information necessary to plan the Seapath installation on a smaller hydrographic survey vessel. Correct installation is important for the system performance.

3.1 Preparing the installation

3.1.1 Necessary tools and equipment

We assume that you are equipped with a standard set of tools. This tool set must comprise the normal tools for electronic and electromechanical tasks, such as screwdrivers, pliers, spanners, a cable stripper etc. Each tool must be provided in various sizes. We recommend that all tools are demagnetized to protect your equipment.

Unless stated otherwise, all mounting equipment (such as bolts, nuts, washers, screws etc.) referred to within this document is to be supplied by the customer or the shipyard.

Survey equipment should be made available to determine the MGC mounting angles in roll, pitch and yaw and the distance vectors from the Origin to the sensor unit, the MGC and the monitoring points.

PC with Seapath operator software

An external PC (not part of the product delivery) is required for the installation of the Seapath operator software. The minimum requirements for the PC is Windows 10 or newer, 2 GHz CPU, 2 GB RAM and 1024 x 768 screen resolution.

Motion sensor and gyro compass (MGC)

The MGC is shipped in a specially designed transportation container. Keep the MGC within the container until everything is ready for installation.

Note

After the installation, please save the transportation container. The MGC must be shipped in this container for service or repair to maintain the warranty.

3.1.2 Drawings

General arrangement drawings of the vessel should be acquired to simplify determination of offsets between the sensor unit, the MGC, the Navigation Reference Point (NRP) and the different monitoring points. Locations for the various parts of the system must be decided.


3.1.3 Radio frequency authorisation

Ensure that the data link between the reference station and the mobile Seapath system is assigned to operate on the radio frequencies that will be used in the survey area. An assigned approval from the Authorities is required before use.

3.1.4 Worker skills

Trained mechanical and electrical workers.

3.1.5 Determining the location of system parts



- A Sensor unit mounted on pole
- B PC with operator software installed, indoors
- C MGC in subsea bottle mounted on transducer head

3.1.5.1 Sensor unit location

For the sensor unit, consider the following:

- The space above the sensor unit has to be free of obstructions of any kind.
- The sensor unit should be protected from direct illumination of radar beams and other transmitting antennas such as Inmarsat antennas. Seapath is more sensitive to blocking and reflections (multipath) of GNSS signals than GNSS sensors which only

use pseudo-range data. This is because Seapath also uses carrier phase measurements for heading determination, and both the internal GNSS antennas need to see at least four common satellites at the same time.

Caution

The sensor unit has to be mounted in such a way that blocking of the GNSS signal is avoided.

- In order to reduce problems due to multipath effects, the sensor unit has to be mounted above the nearest deck at a height which is equal to the width of this deck or higher.
- The sensor unit has to be mounted in such a way that torsion movement relative to the ship's hull is kept at an absolute minimum.

3.1.5.2 MGC location

If the MGC is mounted in a subsea bottle, the MGC is recommended mounted close to the user equipment of which it is supposed to measure the motion. This is to avoid errors in alignment with the user equipment.

Caution

Be aware of vibrations. *Direct mounting onto the main hull structure is preferable.*

Avoid mounting the sensor unit close to hydraulic pumps and valves where there are high frequency vibrations. The sensor unit has some sensitivity to vibrations around sequences of 100 Hz (100, 200, 300 Hz and so on). Such vibrations should not exceed 0.5 m/s² in any direction.

Caution

Be aware of resonance. *Care must be taken when mounting the sensor unit to the vessel's hull as to avoid self-resonance which in turn can amplify the dithering frequencies (around 600 Hz) of the gyroscopes. A properly mounted sensor unit will typically emit 58-64 dBA (1 meter) and improperly mounted the sound pressure level may increase to 85 dBA. It is recommended to mount it directly to solid and stable structure, like the steel deck.*

3.2 Installation summary

The installation consists of both mechanical and electrical installation.

Mechanical installation

The mechanical installation consists of:

- Installing a holder for the sensor unit and having it fastened in a suitable location in a mast or pole.
- Installing the sensor unit on a holder in the mast or pole.
- Installing the MGC with the subsea bottle near the user equipment for which attitude data is wanted, or close to the selected Navigation Reference Point (NRP).

Electrical installation

The electrical installation consists of:


- Connecting the cable from the sensor unit to the spider cable.
- Connecting the umbilical cable to the MGC subsea bottle.
- Connecting the Ethernet cable to the PC with Seapath operator software.
- Connecting cable with DGNSS RTK corrections to the sensor unit cable.
- Connecting sensor unit cable with output data to the survey computer.
- Connecting sensor unit cable with output data to the echo sounder.
- Connecting sensor unit cable with 1PPS output to the echo sounder.
- Supplying 24 V DC power to the sensor unit cable.

3.3 Terminating the cable within the sensor unit (optional)

The sensor unit cable must be terminated in the unit before mounting it on the mast or pole. Normally the sensor unit is delivered with the cable terminated.

Procedure

- 1 Open the connector board cover at the bottom of the sensor unit by unscrewing the four screws marked with a red circle on the figure.



- A** Connector board cover screws
- B** Sensor unit cable

- 2 Run the sensor unit cable through the gland and terminate the cable wires on the connector board according to the cable wiring table.

Pin	Signal	Pair	Wire colour	Pin	Signal	Pair	Wire colour
16	PWR+	1	White	10	1PPS TX-B	8	Red
1	PWR-	1	Blue	25	1PPS TX-A	8	Green
17	ETH RXD-	2	Green	9	1PPS GND	9	Red
2	ETH RXD+	2	White	26	Echo GND	9	Grey
18	ETH TXD-	3	Orange	11	Echo TX TX-B	10	Red
3	ETH TXD+	3	White	27	Echo RTS TX-A	10	Brown
19	GNSSCTS RX-A	4	White	12	MRU RX-A	11	Black
4	GNSS RX RX-B	4	Brown	29	MRU RX-B	11	Orange
20	GNSS RTS TX-A	5	White	14	MRU TX-A	12	Black
5	GNSS TX TX-B	5	Grey	28	MRU TX-B	12	Blue
21	GNSS GND	6	Red	13	MRU GND	13	Black
23	Survey GND	6	Blue	30	MRU 1PPS NTX-A	13	Green
8	Survey TX TX-B	7	Red		Not used	14	Black
24	Survey RTS TX-A	7	Orange		Not used	14	Brown

- 3 Fasten the cable gland to the sensor unit chassis.
- 4 Re-mount the connector board cover.

3.4 Mounting the sensor unit


The sensor unit is designed to be mounted horizontally on top of a mast or pole.

Prerequisites

A mounting arrangement for the sensor unit mounting bracket has been prepared by the customer.

Procedure

- 1 Make a holder for the sensor unit mounting bracket and fasten the holder properly to the mast or pole.
- 2 Separate the sensor unit from its mounting bracket by unscrewing the three screws on each side.




- A** Mounting bracket screws
- B** Mounting bracket
- C** Plastic insulation plate

- 3** Bring the sensor unit, its cable and mounting bracket as close as possible to the location of the sensor unit holder.


The normal orientation of the sensor unit is along ship with heading reference point no. 1 aft. It can, however, be mounted in any orientation, provided it is approximately horizontal.

- 4** Place the delivered insulation plate between the sensor unit mounting bracket and the holder, and ensure that the four bushings are placed in the mounting holes before the screws are entered (to ensure galvanic isolation of the sensor unit from the mast and to prevent corrosion). The nuts should be secured with washers or by using self-locking nuts.



- A** Mounting bracket
- B** Plastic washer
- C** Plastic insulation plate
- D** Holder

- 5** Place the mounting bracket in the preferred direction on the holder.



- 6** Lift the sensor unit on top of the mounting bracket. Insert the three screws on each side of the mounting bracket again and fasten them to the sensor unit.
- 7** Connect the cable from the sensor unit to the spider cable.

Figure 2 The two cable connectors



Figure 3 The two cables connected



3.5 Mounting the MGC subsea bottle

The MGC of model R2 or R3 is delivered mounted in a subsea bottle (SB50). The subsea bottle is mounted to the vessel or the transducer head.

Prerequisites

A mounting arrangement for the subsea bottle has been prepared by the customer.

Procedure

- 1 Find the location on the vessel, pole or transducer head to mount the bottle. If the orientation of the bottle can be freely selected, choose a subsea bottle orientation with the x arrow pointing in the bow direction.

The bottom plate has steering pins, four outer mounting holes and four inner holes which are equal to those on the MRU subsea bottle. The connector lid has an x arrow indication.

Figure 4 Bottom plate






Figure 5 Connector lid



- 2 When the mounting location on a structure has been identified, prepare fastening plate for the subsea bottle bottom plate screws.



- A Subsea bottle
- B Fastening plate
(provided by customer)
- C Mounting structure

- 3 Provide the necessary number of M6 screws of stainless steel (four for each lead) for fastening the subsea bottle to the structure.
- 4 Connect the MGC cable to **connector A** on the connector lid. Connect the provided dummy female connector to connector B since this is not used in the Seapath.
- 5 Fasten the MGC cable with clips to the structure to avoid the cable to vibrate when the vessel runs through the water.

3.5.1 Subsea bottle connectors and pin configuration

The bottle includes two 8-pin Seacon connectors. The part number for the Seacon connector is 5506-1508 (male). A Seacon pigtail for the customer's own application can be delivered as an option (part no MRU-E-PT8).

Connector A: Default pin configuration for Seapath

Pin	Signal (Seapath compatible)
1	POWER -
2	POWER +
3	COM1_IN_A-
4	COM1_IN_B+
5	COM1_OUT_B+
6	COM1_OUT_A-
7	CGND (ground ref for XIN)
8	XIN (Seapath 1PPS)

Connector B: Default pin configuration, Ethernet communication

Pin	Signal (Ethernet communication)
1	POWER -
2	POWER +
3	RD- (RJ_6)
4	RD+ (RJ_3)
5	TD- (RJ_2)
6	TD+ (RJ_1)
7	GGND
8	ALERT

3.6 Powering the Seapath system

There is no switch to power on/off the Seapath system. The system starts up when power is connected to it.

Procedure

- 1 When cables are connected to the sensor unit and the MGC, apply 24 V DC power. The power connection for the spider cable is according to the table.

Signal	Sensor unit (wire colours)	MGC (wire colours)
PWR+ (+24 V DC)	Brown	Green
PWR- (0 V DC)	White	Yellow

- 2 The system now gets up and running.

Powering off the Seapath system

Disconnect the power input to shutdown the system. The system can now be dismantled.

3.7 Installing the Seapath operator software

This software is used to set the configuration parameters for the sensor unit and to operate the Seapath system. You must install the operator software on the local PC (standard Windows procedure).

Procedure

- 1 Insert the USB flash drive with the software in the USB port on the local PC.
- 2 Open the Removable Disk drive to which the USB flash drive is connected.

- 3 Locate and run the installation file `SeapathHmiInstaller.exe`.
- 4 Follow the instructions on the screen in order to complete the installation of the **Seapath HMI** program.
- 5 When you reach the last step, clear the **Run the application** check box if you do not want to start the operator software immediately after installation.
- 6 Remove the USB flash drive from the local PC when the installation is finished.

3.8 Uninstalling the Seapath operator software

When you do not need the Seapath operator software anymore, you can remove it from your PC.


Procedure

- 1 Open the **Control panel** on your PC and select **Programs and Features** (the dialog box where you remove programs).
- 2 Locate the **Seapath 130 series** program in the list.
- 3 Click the **Uninstall** button to remove the program.
- 4 Follow the instructions on the screen.

4 Cable layout and interconnections

4.1 Cable plan

All the components are connected through the spider cable with MGC (Motion sensor and Gyro Compass) connection, three configurable serial lines, DGNSS (Differential GNSS) correction input, 1PPS output, network communication and power inlet.




Cables

- A** Cable to the sensor unit, part of the spider cable, 20 meter (default) or 8 meter (short) length with female connector
- B** MGC umbilical cable with 8-pin SeaCon connector, 15 meter length

- C** Ethernet cable to PC and other users, 5 meter length
- D** Input serial line for GNSS corrections with 9-pin Dsub, 5 meter length
- E** Output serial line to GNSS receiver with 9-pin Dsub, 5 meter length
- F** Output serial line for motion data to multibeam or survey computer with 9-pin Dsub, 5 meter length
- G** Output serial line for NMEA data with 9-pin Dsub, 5 meter length
- H** 1PPS output with 9-pin Dsub, 5 meter length
- I** 24 V DC input, 5 meter length

The pin-out for the different connectors is illustrated with a corresponding letter to the cables listed above.



The serial lines can be configured in the Seapath operator for either RS-232 or RS-422 communication. The signals between the two are shared as follows:

- RTS shares pin with TX-A
- TX shares pin with TX-B
- CTS shares pin with RX-A
- RX shares pin with RX-B

4.1.1 Ethernet connections

The system has the possibility to input and output data on individually configurable network ports. The format and update rate are configured for each port in the **NAV Engine Configuration** → **Network**. The network ports have 10/100 Mbps capacity. For direct connection to a PC you might need a crossover cable instead of a straight-through cable. The pin wiring for the different cable configurations is according to the table.

Straight-through			Crossover			
Signal	Pin no.		Signal	Pin no.	Pin no.	Signal
TX+	1		TX+	1	3	RX+
TX-	2		TX-	2	6	RX-
RX+	3		RX+	3	1	TX+
RX-	6		RX-	6	2	TX-

4.1.2 PPS signal output description

A 1 pulse-per-second (1PPS) signal synchronized with GNSS time is available from the 9-pin Dsub marked PPS output on the spider cable. The output has galvanic separation. This RS-422 1PPS signal originates from the GNSS receiver within the sensor unit. The 1PPS signal is buffered and fed to the Dsub at 120 Ohm. The 1PPS signal has a pulse width of 10 ms. The 1PPS is generated exactly once every second with its rising edge synchronised to GPS time.

Pin no. 8 (RxA) on the 9-pin Dsub has a rising edge and pin no. 2 (RxB) has a falling edge at the beginning of the pulse.

4.1.3 Communication interfaces in the Seapath system

The table below shows all available input/output ports available in the system. Only the DGNSS, ECHO, SURVEY and LAN1 are user configurable.

Table 1 Communication interfaces

I/O Properties	Type	Connected to
GNSS1	Serial, GNSS receiver no. 1	Internal GNSS antenna no. 1
GNSS2	Serial, GNSS receiver no. 2	Internal GNSS antenna no. 2
MGC	Bidirectional, RS-422	MRU 3, MRU H, MRU 5 or MRU 5+
DGNSS	Bidirectional, RS-232/422	GNSS corrections, user configurable
ECHO	Serial output, RS-232/422	Echo sounder, user configurable

Table 1 Communication interfaces (cont'd.)

I/O Properties	Type	Connected to
SURVEY	Serial output, RS-232/422	Survey computer, user configurable
1PPS	Serial output, RS-422	External equipment
LAN1	Ethernet port, 10/100 Mbit/s	User configurable

4.1.4 DGNSS correction from Fugro SeaStar

Connection diagrams for interfacing DGNSS correction signals from Fugro Seastar receiver are shown below.

Figure 6 Spider cable connection to Fugro Seastar 3610 receiver





Figure 7 Fugro Seastar 3610 or 3710 receiver connection to Seapath junction box



5 Survey of sensors on vessels

In order to achieve the specified accuracy of the system have to be surveyed. The MGC (Motion sensor and Gyro Compass) and the sensor unit have to be surveyed.

The reference systems in use are:

- The vessel reference system
- The MGC subsea bottle sensor point and axes system
- The sensor unit position and heading reference points

A survey has to be performed to determine the offsets in angle and position from the vessel reference system to the MRU and the sensor unit. These offsets are input in the **NAV Engine configuration** software and stored in the Seapath.


5.1 Vessel reference system definition

The following definitions are used:

- All vessels have a defined Cartesian coordinate system that all sensors can be referenced to. In this right hand system, the X-axis is positive forwards, which is parallel to the centre line of the vessel, the Y-axis, positive towards starboard, and the Z-axis, which is positive downward.
- The origin in the vessel reference system is typically frame 0 at keel level or the surveyed origin in a survey report, i.e. where X, Y and Z are all 0.
- The common reference point (CRP) is defined to be in the intersection between stern, centre line and keel. In case the keel is not parallel with the base line, the reference for CRP is where the keel crosses the vertical section amidships. The location of CRP vs the origin is configurable, and is typically set based on the survey report.
- The reference plane in this system must be well defined and described. This can be a Best Fit Plane on main deck, or a Best Fit Plane through the draught marks on the hull. This is particularly important on a floating vessel, as it is not possible to project the horizontal plane from land.

- The chosen convention must be made clear to all parties involved, both survey personnel performing the survey and the users of the survey results. Any deviation from the defined coordinate system, shown in the figure *Definition of Origin on vessel and positive X, Y and Z axes directions* on page 33, should be well described in both text and drawings to avoid common misunderstandings.

Figure 8 *Definition of Origin on vessel and positive X, Y and Z axes directions*



- | | |
|---------------------------------------|---------------------------|
| A Stern | F +Z axis |
| B Keel | G +X axis |
| C Main deck | H +Y axis |
| D CRP (common reference point) | I CL (centre line) |
| E Origin | J Amidships |

5.2 Determine the MGC mounting orientation


The default mounting orientation is defined with the top cover facing downward and the x-axis pointing forward. The illustration shows the mounting orientation with the MGC SB50 connector facing upward. This is the main orientation direction for this sensor. The sensor is then rotated 180 degrees round the x-axis. The body axes will then be:

- The R-axis (x arrow) points in the bow (forward) direction of the vehicle.
- The P-axis points horizontally and starboard.
- The Y-axis points in the downward direction.

Note

The x, y, z axes with the x arrow marked on the top cover is the axes orientation in the sensor frame. When mounting angles are input in the sensor configuration the sensor output axes is rotated from the sensor-frame to the body-frame (R, P, Y axes).

Figure 9 Top view of sensor unit with R direction indicated



Positive (+) output signals from the MGC include:


- Positive pitch means bow up, or a clockwise rotation about the P-axis.
- Positive roll means starboard (right) side facing downward, or a clockwise rotation about the R-axis.
- Positive yaw (heading, azimuth) means a turn to starboard (right), or a clockwise rotation about the Y-axis.

5.3 Surveying the MGC subsea bottle

To determine MGC mounting angles and position the following have to be surveyed:


- Position (X,Y,Z) of sensor point. The distance vector from the Origin to the MGC sensor point has to be measured up.
- Mounting angles in Roll, Pitch and Yaw (heading). The MGC misalignment angles in Roll, Pitch and Yaw with the vessel axes have to be measured up.

The illustration shows the sensor point and position (0, 0, 0) for the MGC subsea bottle.




5.4 Determining the sensor unit position and orientation

The illustration shows the reference points on the sensor unit. These points are used to determine the position and orientation of the sensor unit on the vessel it is mounted.




- A Heading reference point #2
- B Position reference point and centre of the internal GNSS antenna no. 1 and Heading reference point #1

Figure 10 Location of position reference point in Z direction, 92.8 mm above sensor unit holder



The location of the two heading reference points used for determining the mounting angle (heading offset). Angular offset between the line from heading reference point #1 to #2 and the vessel centre line (CL) have to be determined and input in the **NAV Engine configuration** as the heading offset.



- A Heading reference point #2
- B Heading reference point #1
- C Heading offset

Related topics

- *Entering sensor unit location parameters* on page 46

5.4.1 Surveying the sensor unit

For the sensor unit the following should be surveyed:

- Position reference point (X, Y, Z). The distance vector from the Origin to the position reference point has to be measured up.
- Mounting angle in heading. The angular offset between the vessel centre line (CL) and the line from heading reference point #1 to #2 and have to be determined and input as heading offset in the **NAV Engine configuration**.

Related topics

- *Entering sensor unit location parameters* on page 46

5.5 Determining the distance vectors

The MGC and the sensor unit both measure the motion for the location where they are located. These measurements must be transformed to be able to measure the motion in a common reference point, NRP (Navigation Reference Point). The NRP is the reference point for all measurements in this system.


The following distance vectors have to be determined and entered into the various dialog boxes in the **NAV Engine Configuration**:

- The distance vector from the Origin to the position reference point (GNSS antenna no. 1) (GNSS Geometry).
- The distance vector from the Origin to the MGC location (MGC Geometry).
- The distance vector from the Origin to the selected NRP location (Vessel Geometry).
- The distance vectors from the Origin to each of the monitoring points (maximum eight MPs) (Monitoring points Geometry).

All these distance vectors have to be measured or calculated based upon drawings or previously measured points. These vectors are to be measured within an accuracy described in on page . Positive vector orientation for these parameters is

- X - positive forwards
- Y - positive towards starboard
- Z - positive downwards with the Origin as the reference point.

The illustration shows distance vectors between the different components.



Related topics

- *Entering sensor unit location parameters* on page 46
- *Setting vessel dimensions and reference points* on page 43
- *Setting monitoring points* on page 58
- *Survey accuracy* on page 38

5.6 Survey accuracy

The Seapath product must be surveyed to the following accuracy level. If not, the performance of the product will be degraded.

- Distance vector from the Origin to the sensor unit position reference point (X, Y, Z): < 0.01 metre
- Distance vector from the Origin to the user defined monitoring points (X, Y, Z): < 0.01 metre
- MGC misalignment angles (Roll, Pitch) with the vessel axes: < 0.1°
- MGC heading misalignment angle with the vessel axes: < 0.1°

6 Setting to work

6.1 Setting to work summary

Once all the hardware units have been installed, and all the cables have been connected, the Seapath can be powered up for the first time, and set to work.

Prerequisites

- All hardware units have been installed according to the relevant instructions.
- All system cables have been installed.
- All connections have been made.
- All operating power is available.
- All external devices which shall communicate with the Seapath are available and operational.
- All relevant personnel and tools are available.

Procedure

- 1 Verify that the Seapath is ready for operational use.
 - a Verify that all hardware units have been installed correctly.
 - b Verify that all cables have been connected correctly.
 - c Verify that the Seapath operator software is installed on an external PC.
- 2 Power up the Seapath for the first time.
- 3 Configure the Seapath for operational use.
 - a Configure the location and heading offset of the sensor unit.
 - b Configure location and mounting angles for the MGC.
 - c Configure location of monitoring points.
 - d Configuration of communication interfaces.
- 4 Set up interfaces to external devices.

To provide correct information the system needs to communicate with external devices. All these interfaces must be set up in the system software.
- 5 Create a backup with the system configuration and software installation.

Once all system configuration and testing have been completed, it is recommended to make a backup of the configuration data and software installation

6.2 Verifying that the Seapath is ready for operational use

The Seapath system is ready for operational use when:

- All cables are properly connected. Verify that the MGC cable is connected to connector A on the subsea bottle.
- The power is correct. The system operates on 24 V DC power from the vessel's mains supply.
- The Seapath application has been installed on an external PC.

6.3 Powering up the Seapath for the first time

When you have verified that all hardware units and cables have been properly installed, and that the supply power is correct, you can power up the Seapath system for the first time. The Seapath starts up automatically when correct power is applied.

6.4 Configuration management description

6.4.1 Entering the configuration management system

The configuration parameters are available from:

- the **System** menu → **NAVEngine** → **Standard** for system configuration and
- the **System** menu → **Operator SW** for display views configuration.

To be able to make changes to the setup you must be in **Configuration** mode for standard configuration tasks or **Engineering** mode for advanced configuration and diagnostic tasks.

Note

Advanced NAVEngine configuration is for service personnel only.

6.4.2 Operator software configuration description

You can adjust the appearance of the display views through the **Operator software configuration** dialog box.

The dialog box contains tab pages for various presentation options and each page contains two confirmation buttons with different properties and a cancel button.

- **OK button:** selecting the **OK** button will save the changes and close the **Operator software configuration** dialog box.

- **Apply button:** selecting the **Apply** button will save the changes but the **Operator software configuration** dialog box will not close.
- **Cancel button:** selecting the **Cancel** button will close the dialog box and changes will not be saved.

Note

The position properties selected in the Operator software configuration dialog box are only for display purposes.

6.4.3 NAV Engine Configuration

You can configure the system parameters from the **NAV Engine Configuration** dialog box.

The dialog box consists of a list of configuration options, a parameter settings section, an exit button and three buttons which each has different properties with regard to configuration changes.

Apply


Select **Apply** to apply the configuration changes to the system. This button is disabled until you have made configuration changes. The button will be disabled when there are no configuration changes to apply.

Preview

Select the **Preview** button to see which parameters have changed since the configuration was loaded. Changed settings are highlighted in bold face. This button is disabled until you have made any configuration changes. Please note that monitoring point changes are displayed in the coordinate system in which they are actually stored by the configuration, i.e. related to the navigation reference point rather than origin.

Revert

Select the **Revert** button to reject all changes you made since the configuration was loaded. The button is disabled until changes have been made.



A Configuration options list

- B** Apply confirmation changes button
- C** Preview last configuration settings button
- D** Revert to previous settings button
- E** Exit NAV Engine Configuration
- F** Parameter settings section

6.4.4 Changing the system mode

The system has three modes: **Operation**, **Configuration**, **Engineering**. To be able to make changes to the setup you must be in **Configuration** or **Engineering** mode. You need a password to enter these modes. The password is **STX** and it is not case sensitive. The password is not possible to change.

Via the System menu

Procedure

- 1 Select the **System** menu → **Change system mode**.
- 2 Select either **Configuration** or **Engineering** to open the **Change system mode** dialog box.



- 3 Type the password **STX** and select **OK**. The password is not case sensitive. You are now able to carry out changes and/or set system parameters.

With keyboard commands directly from the display

Procedure

- 1 In the display, press
 - **CTRL+E** to enter Configuration mode
 - **CTRL+A** to enter Engineering modeObserve that the **Change system mode** dialog box appears.
- 2 Type the password **STX** and select **OK**. The password is not case sensitive. You are now able to carry out changes and/or set system parameters.

6.5 Required sensor unit configuration

6.5.1 Setting vessel dimensions and reference points

Prerequisites

The navigation reference points you enter in this dialog box must be measured or defined before you start the configuration process.

Context

This is information you need in order to specify correct location of various sensors, equipment and monitoring points on a vessel. The information you enter in this dialog box will help you later in the configuration process. The drawing is correctly scaled based on the vessel dimensions to ensure correct indication of the various points. The measurement unit of the entered coordinates is metres.

Shape type

Defines the shape of the vessel hosting the system. You can select between Ship, Rig, Jackup (3 leg) and Jackup (4 leg). These are all scaled according to the dimensions given in the **Shape dimension** section. The general shape outline can be overridden by an actual shape defined in a drawing file. Supported file extensions are **Vessel models (*.svm)**, **Vessel vector images (*.svi)** and **Old vessel images (*.txt)**. This file can be created or edited in a text editor. When a valid drawing file has been loaded, the dimensions are defined by the loaded shape and the **Shape dimension** parameters are locked.

Shape dimensions

Holds parameters for the overall length of the vessel from stern to bow, the overall width of the vessel and the overall height, which is the distance from the highest point of the vessel to the keel.


Origin location in drawing

All point locations in the configuration refer to the origin. The location of the origin is defined using distance from stern, center line and keel (often referred to as the CRP (common reference point) in survey reports). The distance from stern is the distance from the aft point of the ship to origin along the X axis. The distance from CL is the distance from the vessel's centre line, positive towards starboard. The distance from keel is the distance from the keel, positive downwards.

Navigation reference point (NRP)


The Navigation Reference Point location (NRP) is the reference point for all measurements in the system. The recommended NRP is near the Centre of Gravity (CG), but can be chosen freely. It is always defined related to the origin.

The illustration shows different vessel dimensions and location of origin. If a survey report is available the vessel origin should be located in the common reference point (CRP) used in the report.



- | | |
|---------------------------------------|---------------------------|
| A Stern | G +X axis |
| B Keel | H +Y axis |
| C Overall height | I CL (centre line) |
| D CRP (common reference point) | J Overall length |
| E Origin | K Overall width |

F +Z axis



Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Vessel** →**Geometry**.
- 3 Select the shape of your vessel from the **Shape type** list or select **Use vessel drawing** if you have a specific vessel shape file you want to use. Select **Browse** to search for the wanted file.
If you select **Use vessel drawing**, the Shape dimension parameters will be locked.
- 4 Type the overall length, width and height dimensions of your vessel.
- 5 Type the parameters for location of origin (survey origin).
- 6 Type the navigation reference point location, X, Y, Z.
- 7 Select **Show sensors** and/or **Show monitoring points** if you want to display these objects in the vessel illustration.
- 8 Select **Apply** to store the settings.

Related topics

- *Importing vessel shape from file* on page 70
- *Determining the distance vectors* on page 37
- *Survey accuracy* on page 38

6.5.2 Entering sensor unit location parameters

The antenna position, heading offset and height difference parameters have to be input correctly. If not, the performance of the system will be degraded. The antennas are included in the sensor unit.


Prerequisites

The sensor unit location parameters have been surveyed or measured:

- For **Antenna location**: The position reference point (X, Y, Z). The distance vector from the Origin to the position reference point.
- For **Antenna offset**: The mounting angle in heading. The angular offset between the vessel centre line (CL) and the line from heading reference point #1 to #2 called the heading offset.

Context


The reference points on the sensor unit are used to determine the position and orientation of the sensor unit on the vessel where it is mounted.



A Heading reference point #2

B Position reference point and centre of the internal GNSS antenna no. 1 **and** Heading reference point #1



The location of the two heading reference points is used to determine the mounting angle (heading offset). The angular offset between the line from heading reference point #1 to #2 and the vessel centre line (CL) have to be determined and entered into the **NAV Engine configuration** as the heading offset.



Example 1 Heading offset calculation

If the **Reference heading** measured by the reference system is found to be 32.1 degrees and the **GNSS heading** after the calibration is 15.3 degrees, the **Determined heading offset** will be (32.1 - 15.3). Observe that the heading offset is positive counterclockwise, and in the range [0,360] degrees.

Example 1 Heading offset calculation (cont'd.)



Procedure

- 1 Click the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Click the **Sensors** node →**GNSS** →**Geometry**.
- 3 Type the surveyed distance vector to the position reference point (antenna 1) in metres in the **Antenna location (from Origin)** table (X, Y and Z coordinates).
- 4 Type the surveyed **Heading offset** in degrees.
- 5 Type the **Height difference** in metres. For first time installation use the **Calibration Wizard** to calculate the correct height difference.
- 6 Observe that the sensor unit is located as expected in the vessel drawing. If not, check the signs and the location entered for the Antenna 1. Also, check the vessel dimensions and origin location in **Vessel geometry**.

Related topics

- *Determining the sensor unit position and orientation* on page 35

- *Surveying the sensor unit* on page 36
- *Determining the distance vectors* on page 37

6.5.3 Using Calibration Wizard to determine antenna parameters

Use the Calibration Wizard to determine the heading offset and the antenna height difference for the sensor unit.

Prerequisites

Readings of the vessel reference heading data on another PC or by manual readings have to be available before starting the wizard.

Context

Calibration the direction of the sensor unit against an external reference. Type of reference must be decided according to the required accuracy. The following calibration parameters have to be determined:

- **Heading offset.** The direction of the sensor unit relative to the vessel's longitudinal axis is measured in degrees.
- **Height difference.** The height difference between the two internal antennas within the sensor unit according to the vessel horizontal plane (the height to antenna #1 minus the height to antenna #2, compensated for vessel roll and pitch) is measured in metres..

It is of crucial importance to calibrate the heading offset correctly. During this calibration, several accurate reference measurements of the vessel heading must be read/logged simultaneously with the heading output from the Seapath. The data logging should continue for at least two hours under calm conditions alongside a quay. The best results are achieved if continuous logging of both the reference system and the Seapath measurements can be performed during the calibration period. If simultaneous logging of the two systems is not possible, one reading from both systems should be done at least every 30 seconds for a minimum of two full hours.

The long calibration time is necessary in order to eliminate errors in the Seapath measurements caused by multipath effects, which may be particularly pronounced in the static conditions of a harbour area.


Note

*Before entering the **Calibration wizard**, ensure that all configuration changes, including the correct MGC mounting angles, are applied by pressing the **Apply** button in the menu bar. Also, verify that roll, pitch and heading measurements are indicated as valid (green) before starting the wizard.*


Procedure

- 1 Click the **Calibration wizard** button to start the calibration. The system will indicate when calibration measurements are ready.


- 2 In the antenna Calibration Wizard Step 1 **Accuracy**, modify the baseline length and height difference accuracy values if needed. Clicking **Apply** will restart the calibration measurements.
- 3 If calibration measurements are unavailable, click **Cancel** and check that the prerequisites listed in the note above are all met. Then restart the Calibration Wizard.
- 4 The **Next** button will be enabled as soon as measurements are ready.
- 5 Click **Next** to continue to Calibration Wizard Step 2 **Period**.
- 6 Modify calibration period and message interval if needed. The default values are recommended.




- 7 Before clicking **Next** to start the calibration logging, it is recommended to start recording data of the vessel reference heading on another PC or by manual readings. When logging of the reference heading has started, click **Next** in order to proceed to page 3 **Processing**.
- 8 The progress of the logging is indicated on the screen with a graphical presentation of the measured data.



9 Click **Next** to proceed to Step 4 **Validation** for inspection of the logged data.



- 10 Delete possible wild points by selecting the corresponding row in the table, then click **Delete line**.
- 11 When the calibration result has been found acceptable, click **Next** to proceed to the last step, **Apply result**.
- 12 Enter the mean value for the vessel heading reference, then click **Update** in order to calculate the heading offset.



Click **Export log file** if the calibration data are wanted for post processing.

- 13 Click **Finish** to accept the result and exit the antenna Calibration Wizard.
- 14 The **Baseline length**, **Heading offset** and **Height difference** fields are automatically updated upon successful completion of the Calibration Wizard, according to the calibration result.
- 15 Click **Apply** in the menu bar to save the calibration information.

6.5.4 Setting MGC location and mounting angles

The physical location of the MGC relative to the origin and its mounting angles is required for the Seapath system to be able to calculate position, roll, pitch and heading correctly.

Prerequisites

For accurate location of the motion reference unit you will need detailed vessel drawings.

Context

The MGC measures the roll, pitch, yaw and heave motions of the vessel. In the **MGC Geometry** dialog box you must define the physical location of the MGC sensor related to the origin location you created in the **Vessel Geometry** dialog box.

In the **MGC Geometry** dialog box you enter the MGC location parameters, the X, Y and Z coordinates in meters and the MGC mounting angles, the roll, pitch and yaw parameters in degrees. Look at the vessel drawing to help you enter the correct signs for the coordinates and to check if the motion reference unit appears on the expected spot.

If something looks out of place, check the signs and X, Y, Z coordinates you typed for the sensor location and/or return to the **Vessel Geometry** dialog box and check the vessel shape dimensions, the origin location and the navigation reference point (NRP) location.


The MGC mounting angles can either be input manually or determined by use of the **Mounting wizard**. The Mounting Wizard is located in the **NAV Engine Configuration** → **Sensors** → **MGC** → **Geometry**.

Sensor location (from origin)

The position of the MGC in X, Y, Z coordinates in metres from Origin. The sensor unit location has to be measured or calculated based upon drawings or previously measured points. The default location of the sensor unit is in the vessel Origin.

Mounting angles

The mounting angles of the sensor unit in degrees for roll, pitch and yaw.



Procedure

- 1 Click the **System** menu, → **NAVEngine** → **Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Click the **Sensors** node → **MGC** → **Geometry**.
- 3 Type the X, Y and Z coordinates in metres from Origin to MGC location.
- 4 Type the mounting angles in degrees for roll, pitch and yaw.
If the mounting angle values are not known to you, use the Mounting Wizard to calculate these values.
- 5 Click **Apply** to store the settings.

Related topics

- *Determining the distance vectors* on page 37
- *Using Mounting Wizard to determine MGC mounting angles* on page 53

6.5.5 Using Mounting Wizard to determine MGC mounting angles

Use the Mounting Wizard to determine the roll, pitch and yaw mounting angles in degrees for the MGC sensor.

Prerequisites


The MGC offset angles have to be available from a survey report or through other methods with similar accuracy.

Context

The mounting bracket offset angles which have to be entered are roll, pitch and yaw.


Roll offset angle

The angle between the ship's Y-axis and the projection of the sensor z-axis in the ship's PY-plane. Positive roll offset angle if the bracket tilts to starboard.




Pitch offset angle

The angle between the ship's Y-axis and the projection of the sensor z-axis in the ship's RY-plane. Positive pitch offset angle if the bracket tilts to stern.



Yaw offset angle

The angle between the ship's R-axis and the projection of the sensor x-axis in the ship's RP-plane. Positive yaw offset angle if bracket is rotated clockwise.



Note

If the mounting bracket offset angles exceed 45 degrees, another main rotation should be selected.

Procedure


- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select the **Sensors** node →**MGC** →**Geometry**.
- 3 Select the **Mounting Wizard** button and use the wizard to calculate the roll, pitch and yaw mounting angles.

The red circle indicates Port and the green circle indicates Starboard. The arrow points in the bow direction.

- 4 In step 1, **Orientation**, select the < or > buttons to turn the motion reference unit around in 90-degree steps, axis by axis. Click until the correct mounting orientation of the motion reference unit has been found.

Observe that the parameters for roll, pitch and yaw in the Main rotation group are automatically updated with the actual main rotation of the motion sensor and gyro compass.


Alternatively, select the **Connector direction** or **+x arrow direction** option buttons to select the motion sensor and gyro compass orientation.



- 5 Select **Next** to continue to step 2, **Offset angles**.

Observe that the roll, pitch and yaw mounting angles are now indicated in the **Main rotation angles** group.

- 6 Type the surveyed sensor bracket offset angles in degrees for roll, pitch and yaw. The system calculates the mounting angles automatically and the values appear in the **Computed mounting angles** group.



- 7 Select **Finish** when you are ready to complete the offset angle setting.
This will exit the wizard and take you back to the initial MGC **Geometry** dialog box.
- 8 Select **Apply** to store the settings.

Related topics

- *Survey accuracy* on page 38

6.5.6 Selecting heave filter options

The heave configuration parameters allow you to tune the heave parameters to the vessel motion characteristics for the actual weather conditions. This is important when using real-time heave measurements in order to achieve optimum heave performance.

Context

Before a survey and/or during operation check the heave performance and tune the heave parameters until the best heave performance is achieved. An alternative is to select *Automatic* and let the system automatically choose the best settings.

Heave filter options

Hydrographic survey

To be selected when the heave phase and amplitude have to be output correctly in real time. This mode is typically selected when the heave output signal from

the system is to be used for heave compensation of echo sounders and offshore crane systems.

Automatic

To be selected when the vessel is operating in various sea states or when the average heave period is unknown. The *Automatic* filter mode estimates the average heave period and automatically sets the filter period in real time during operation. The *Automatic* filter mode uses the *Hydrographic survey* filter structure.

GNSS aided

To be selected when RTK DGNSS corrections are available or the GNSS velocity measurements are accurate. In this mode the heave and height measurements are determined by blending vertical acceleration and GNSS height measurements in a Kalman filter. This combination makes it possible to measure wave slopes and the tide in real time with high precision ideal for hydrographic work. The height measurements are provided with centimeter accuracy and independent of wave frequency. If RTK is not available the algorithm will use the GNSS velocity measurements for aiding the heave. If GNSS velocities are not available, the **Automatic** algorithm is used.

General purpose


Is selected when the heave phase is of no importance. This mode is typically selected when the system is to be used for measuring the heave height and period on oceanographic buoys.

Period

An expected average heave period has to be set to the heave filter unless the automatic mode is chosen. The settling time for the heave measurements from power-on or after a turn will be about 10 times the selected period, T_0 .

Roll/pitch dependent

Use the check box to enable whether the heave mean level should be dependent on the roll and pitch measurements or not. When enabled, the heave position in the monitoring points (MP) has now longer zero mean level, instead its value depends on the vessel tilt at any time. This option is useful especially in applications where the distance between the MP and the sea level is to be determined, like in echo sounder installations with depth changes due to changes in vessel trim and list. If not enabled, the heave will always have zero mean level. It is separate selections for the real time heave and the delayed heave (PFreeHeave).



Procedure

- 1 Click the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Click the **MGC** node →**Heave config**.
- 3 Select the heave filter mode you want to use from the **Options** list.
- 4 If you select **Hydrographic survey** or **General purpose**,
 - a Type the wanted filter period. Allowed value between 1 and 25 seconds.
- 5 Select the **Roll/Pitch dependent** box if you want the heave measurement dependent on the roll and pitch measurements. It is separate selections for the real time heave and the delayed heave (PFreeHeave).
- 6 Click **Apply** to store the settings.

6.5.7 Setting monitoring points

You must define the locations on the vessel for which you want the system to calculate the position.


Prerequisites

To get exact coordinates from Origin to each monitoring point, each monitoring point has to be measured or calculated based upon drawings or previously measured points.


Context


In this dialog box you can define points (monitoring points) on the vessel where you want the position measurements to be output. The monitoring points are given relative to Origin (positive forward, towards starboard and down). The position of a monitoring point relative to the Origin is indicated in the drawing when the cursor is over the monitoring point. As soon as a monitoring point has been defined, its location is indicated in the vessel drawing. If a monitoring point appears incorrect, check the signs and the coordinates input for each monitoring point and the vessel dimensions and the entered location of Origin in the **Vessel Geometry** dialog box.

The system supports up to eight user definable monitoring points.




Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Monitoring points** →**Geometry**.
- 3 Select **Add**  at the top of the page to add a monitoring point.
Observe that the cursor changes to two red lines which will help you to place the new monitoring point in the drawing.
- 4 Drag the cursor to the location on the **upper** vessel drawing where you want to add the **X** and **Z** coordinates for your monitoring point and click the mouse button.




- 5 Continue and drag the cursor to the location in the **lower** vessel drawing where you want to add the **Y** coordinate for your monitoring point and click the mouse button.

Observe that coordinates for the new monitoring point appear in the monitoring points table. These will also help you to get the wanted location for your monitoring point.



6 Select the **Name** column in the table and type an identifying name for your monitoring point. Press **Enter** to confirm.



7 Select the **X**, **Y** and **Z** columns and adjust the coordinates by typing the exact location of the monitoring point, if necessary. Press **Enter** to confirm.

8 Select **Apply** to store the settings.

Deleting a monitoring point

You can delete a monitoring point by selecting the wanted point in the table and clicking **Delete**

Related topics

- *Determining the distance vectors* on page 37
- *Survey accuracy* on page 38

6.5.8 Communication interfaces description

The communication interfaces are set in the **NAV Engine Configuration** dialog box under **Communication** → **Input/Output**. The **Input/Output list** shows all input and output ports which are available in the system.

When you select an **Interface** in the **Input/Output list**, the **Configuration details** part for that particular interface will appear in the lower part of the page. These details will change based on the interface type you have selected, Serial or Ethernet. You must select either Serial or Ethernet for all available interfaces before you select the specific parameters for a particular interface.


Select the arrow next to the group headings to show or hide the information.

To be able to get a properly working system you must set up these communication interfaces:

- MGC
- Telegram out
- DGNSS link

Note

You are not able to configure the GnssReceiver interface and the MRU interface.



- A Selected interface in Input/Output list
- B Type of interface selection: Serial or Ethernet
- C Specific configuration details for the selected interface

This procedure sums up the steps you have to go through to set up the communication interfaces for the system.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Communication interface** →**Input/Output**.
- 3 Select the interface you want to set up in the **Input/Output list**.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select which type of interface you want to use from the **Type** list: Serial or Ethernet.
- 5 Select the wanted I/O parameters. These will vary depending on the type of interface you selected.
- 6 Select the specific parameters you want for the interface you selected.
- 7 Select **Apply** to store the settings.

6.5.9 Using the Serial interface

The Serial interface allows you to decide how the sensor unit shall communicate and interface to other equipment.

Context

If you have decided to use a Serial interface, you must set up the port number, the baud rate and select RS-232 or RS-422 mode.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Communication interface** →**Input/Output**.
- 3 Select the interface you want to set up.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select **Serial** in the **Type** list.
- 5 Type an informative text about the interface in the **Description** box. This is optional.
- 6 Type a short identification text for the cables connected to the sensor unit in the **Cable ID** box. This is optional.
- 7 Select which port to use from the **Port** list.
The serial port number corresponds with the number on the sensor unit.
- 8 Select which baud rate you want to use from the **Baud rate** list. Maximum baud rate is 115200 bits/second.
- 9 Depending on which port you selected, select if you want to use RS-232 or RS-422 for the electrical interface.
- 10 Select the properties for the interface you selected in the **Input/Output list**.
 - MGC: **MGC** properties

- DGNSS link: **DGNSS link** properties
- Telegram out: **Telegram out** properties and **Telegram timing**

Result

You are now ready to set the specific parameters for the interface you have selected. See separate sections for selection details.

Related topics

- *Output protocols* on page 105

6.5.10 Using the Ethernet interface

The Ethernet interface allows you to decide how the sensor unit shall communicate via the internet protocol (IP) network.

Context

Broadcast

Broadcasting is a method of transferring a message to all recipients simultaneously.

The screenshot shows the 'I/O Properties' dialog box with the 'Broadcast' radio button selected. The 'Local interface' dropdown menu is set to 'LAN1 (157.237.85.158)'. The 'Port' field contains the value '2009'.

Unicast

Unicast transmission is the sending of messages to a single network destination identified by a unique address.

The screenshot shows the 'I/O Properties' dialog box with the 'Unicast' radio button selected. The 'Local interface' dropdown menu is set to 'Automatic'. The 'IP address' field contains '192.168.1.30'. The 'Local port' field contains '31099' and the 'Remote port' field also contains '31099'.

Multicast

Multicast (one-to-many or many-to-many distribution) is group communication where information is addressed to a group of destination computers simultaneously.

The screenshot shows the 'I/O Properties' dialog box with the 'Multicast' radio button selected. The 'Local interface' dropdown menu is set to 'LAN1 (157.237.87.30)'. The 'IP address' field contains '239.255.0.30'. The 'Remote port' field contains '31099'.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Communication interface** →**Input/Output**.
- 3 Select the interface you want to set up in the **Input/Output list**.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select **Ethernet** in the **Type** list.
- 5 Type a short identification text for the cables connected to the sensor unit in the **Cable ID** box. This is optional.
- 6 Select the wanted connection type: Broadcast, Unicast or Multicast.
 - **Local interface**: The LAN port on the sensor unit.
 - **Local port**: When receiving, this is the port on which the unit listens.
 - **Remote port**: When transmitting, this is the port to which the unit sends.
 - **IP address Unicast**: The target IP address, to which the unit is receiving or sending.
 - **IP address Multicast**: The multicast group address. Recommended range: 239.255.000.000 to 239.255.255.255.

Note

It is recommended to use the same port number for both Local and Remote ports.

- 7 Depending on the connection type you have selected, select which local interface you want to use from the **Local interface** list.
- 8 Select the properties for the interface you selected in the **Input/Output list**.
 - DGNSS link: **DGNSS link** properties
 - Telegram out: **Telegram out** properties and **Telegram timing**

Result

You are now ready to set the specific parameters for the interface you have selected. See separate sections for selection details.

Related topics

- *Output protocols* on page 105

6.5.11 Setting up the Telegram out interface

The Telegram out function allows you to enable and set up data messages transmitted to external equipment.

Context

Up to 16 serial and/or network interfaces can be configured.

Format

The format of the output telegrams.

Datum

The datum selection is only valid if the datum on the corrections input to the product are in WGS84 or no corrections are input. If the corrections input are in another datum than WGS84, you must select **WGS84** (which should actually have been labelled "No transformation" in this software). The datum of the output will then be on the same datum as the datum on the corrections input to the product. The other choices can only be used when the system navigates in WGS84 datum.

Monitoring point

A point on the vessel for which you want the position measurements to be output.

NMEA selection

The NMEA selection option is activated if the Format is selected as NMEA. Select between a number of NMEA telegrams.

Options

The contents of some of the available NMEA telegrams can be modified according to options listed in the **Options** list. This is for example useful when interfacing to older equipment.

NMEA talker ID

The talker ID of NMEA messages sent from this output. The default is IN.

Log to file

Logs the measurements to file internally in the system.

Time precision

Number of decimals in the time field in NMEA telegrams which supports Time precision.

Interval


The interval between each sample. Can be selected in the range 0.005 to 3000 seconds.

Event driven

The output of data is driven by receipt of MRU data to the Processing Unit. **Event driven** data is valid for the point in time the sensors within the MRU are sampled. Recommended used when transmission in real time is not required, typically for telegrams that include time information like Seapath binary 3, 11, 23 and 26.


Timer driven

By timer driven output the data will be output in real time (0 ms delay). **Timer driven** output is recommended used when the data is preferred in real-time and for instance when the system that receives the data time stamp it by receipt. Typically used when the EM3000 format is output.



Procedure


- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select the **Communication interface** node →**Input/Output**.
- 3 Select the **TelegramOut** interface you want to set up in the **Input/Output list**.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select either **Ethernet** or **Serial** in the **Type** list.
Enter the appropriate parameters for the selected interface type.
- 5 Continue to the **Telegram out properties** group.
- 6 Select the wanted output telegram format from the **Format** list.
Observe that if you select **NMEA** as telegram format, the **NMEA selection** list becomes active.



- 7 If **NMEA** is selected, select the wanted **NMEA** telegrams to use from the **NMEA** list.
- 8 Select the wanted datum format from the **Datum** list.
- 9 Select the wanted monitoring point from the **Monitoring point** list.
- 10 Type the talker ID of **NMEA** messages sent from this output in the **NMEA talker ID** box.

The default value is **IN**.

- 11 Select the **Log to file** box if you want to log the measurements to file internally in the system.
- 12 Select the wanted number of decimals in the time field in NMEA telegrams which supports Time precision from the **Time precision** box.
- 13 In the **Telegram timing** group, select the wanted output interval for the messages.
 - **Event driven**: Outputs data only when the data are calculated or when a change occurs. Output data are delayed.
 - **Timer driven**: The interval between each sample, type wanted interval in seconds in the **Interval** box. Range 0.01 to 3000 seconds.



- 14 Select **Apply** to store the settings.

Related topics

- *NMEA TelegramOut options* on page 129

6.5.12 Setting up the DGNSS correction link parameters

You can set up the system to receive various types of corrections which will improve the position accuracy.

Prerequisites

Check whether the reference station requires to know the position of your system to be able to send valid corrections back. If this is required, then enable **GGA Interval [s]** and set up how often the GGA message shall be sent to the reference station in the **DGNSS link properties**.

Context

Interface

Which external equipment you want to interface. Some configuration parameters are dependent on the interface selection.

Name

The name you want to give the DGNSS correction link.

Timeout

Age limit. If the age of the corrections exceeds this limit, the corrections are invalid.

Format

The format types which are supported by the system.

GGA interval

If selected, sends GGA messages to the DGNSS receiver at specified intervals in seconds.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Communication interface** →**Input/Output**.
- 3 Select the **DGNSSlink** interface you want to set up in the **Input/Output** list.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select either **Ethernet** or **Serial** in the **Type** list.
Enter the appropriate parameters for the selected interface type.
- 5 Continue to the **DGNSS link properties** group.

▼ DGNSS link properties

Interface: Generic | Name: RTCM | Timeout [s]: 60

Format: RTCM v3

Supplier: OTHER | GGA interval [s]: 1

- 6 Select the wanted interface from the **Interface** list.
The content of the **Format** list will depend on this selection.
- 7 Select the wanted format from the **Format** list.
- 8 Select the name of the correction link supplier from the **Supplier** list.
This selection depends on the parameter you selected in the **Interface** list.
- 9 Type the name of the DGNSS correction link.
This name will be displayed in the DGNSS link status bar at the bottom of View 1.



- 10 Type the correction Timeout age limit in seconds.
If the age of the correction exceeds this limit, the corrections are invalid.
- 11 Select the **GGA Interval** box if you want the system to send GGA messages to the DGNSS receiver. Type the wanted interval in seconds between the telegrams.
- 12 Select **Apply** to store the settings.

Related topics

- *Communication interfaces description* on page 61

6.5.13 Connecting to a network

Enter the Internet Protocol (IP) addresses for the sensor unit to be able to communicate on the local area network (LAN).

Context

The Interface settings group allows you to modify the IP address of the physical interface selected in the **Interface** list.

The sensor unit communicates with the operator software using multicast UDP/IP. Any client may join the configured multicast group provided that the network hardware between the sensor unit and the client supports multicast forwarding.


The default IP address for the sensor unit is: 192.168.1.10.

The default multicast address for the sensor unit is: 239.255.0.3.

The default subnet mask for the sensor unit is: 255.255.255.0.

The PC running Operator SW needs to be on the same subnet. Unless the IP address of the sensor unit is changed, the valid IP address for the PC would be 192.168.1.0-255 (excluding the address of the sensor unit itself).

Contact the network administrator for advice on IP address assignments.



Procedure


- 1 Click the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Click the **Network** node.
- 3 Select the interface for which you want to change the IP address.
- 4 Select the **DHCP** box if the IP address is given by a DHCP server.
- 5 Type the new IP address for the interface.
- 6 Type the subnet mask address for this interface.
- 7 Type the IP address for the default gateway.
- 8 Click the **Apply** button to confirm the changes.
- 9 Restart the sensor unit for these changes to take effect and for the new settings to be used by NAV Engine.
 - To restart, click the **System** menu →**Restart** →**Sensor Unit**.

If you click the **Restore** button you will return to the previous interface settings.

6.6 Additional sensor unit configuration

6.6.1 Entering vessel identification parameters

The vessel Description parameters allow you to enter information about the vessel which are needed for identification purposes.



Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Vessel** →**Description**.
- 3 Type the name of your vessel. This box cannot be empty. The default value is **VESSEL**.
- 4 Type the name of the vessel owner. This is optional information.
- 5 Type the country of origin for the vessel. This is optional information.
- 6 Type the MMSI number assigned to the vessel. Default value is 0.
- 7 Type the IMO number assigned to the vessel. Default value is 0.
- 8 Select **Apply** to store the settings.

6.6.2 Importing vessel shape from file

You can load a vessel model from file in order to get accurate dimensions for your vessel.

Context


The pre-defined scalable vessel shapes represent the actual vessel outline only in rare cases. In order to configure the accurate location of various sensors, equipment and monitoring points, it is recommended to load a separate vessel model from file.

The system supports two types of two dimensional outlines: side view (towards starboard) and top view. Three file types are available: **Vessel models (*.svm)**, **Vessel vector images (*.svi)** and **Old vessel images (*.txt)**.

The vessel image file must meet the following requirements:


- The vessel data have to be in an ASCII file generated by Excel, Notepad or similar tools.
- The file head includes Overall length (LOA), Overall width, Overall height and Stern to Origin data in metres.
- Profile (side view) data in X and Z coordinates in metres, related to the origin. Coordinates are specified clockwise from a point aft of the origin, and the last coordinate has to equal the first coordinate to form a closed polygon.
- The top view data in X and Y coordinates in metres. The first coordinate has to be aft of the origin along the centre line. Successive coordinates are specified clockwise, and the last coordinate has to equal the first to form a closed polygon.

Vessel image files can be created by Kongsberg Discovery AS upon customer request. GA drawings or similar are required to create vessel image files.



Example 2 Vessel shape from file

The illustration shows an example of a GA drawing of a multi-purpose vessel.



A user text file from Notepad may look like this.

Example 2 Vessel shape from file (cont'd.)

```


mpv.svi - Notepad
File Edit Format View Help
%Vessel Data [m]
%LOA = 120.70
%width = 23.00
%Height = 32.20
%Aft to AP = 7.00

%Profile coordinates in (X,Z) [m]
0.00,-3.55
2.44,-3.19
3.69,0.00
98.60,0.00
101.00,-0.14
105.20,-1.12
108.36,-2.70
110.09,-4.51
110.35,-5.20
110.40,-5.43
110.40,-5.69
.
.
.
63.10,-24.00
63.10,-21.00
59.62,-21.00
59.62,-15.13
57.87,-12.99
49.65,-10.50
4.25,-10.50
2.31,-12.00
-7.00,-12.00
-7.00,-8.00
-4.00,-4.11
0.00,-3.55

%Profile cutout
-23.20,-36.48
-23.20,-10.24
23.20,-10.24
23.20,-36.48
-23.20,-36.48

%Top view coordinates in (X,Y) [m]
-7.00,0.00
-7.00,11.50
90.30,11.50
.
.
.
113.60,0.57
113.70,0.00
    
```

The vessel shape in the NAV Engine Configuration looks like this.



Example 2 Vessel shape from file (cont'd.)

In the example, only the port side of the vessel top view is defined in the file. Symmetry is assumed, so this is sufficient to draw a symmetric vessel shape. If the vessel is *not* symmetric, use the section code `%Top view` coordinates in (X,Y) [m] Complete and give the coordinates along the complete shape, defined clockwise.

It is possible to define cutouts within the profile or top view polygons. For profile cutout, use `%Profile cutout n`, where *n* identifies the cutout.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Vessel** →**Geometry**.
- 3 Select **Use vessel drawing** and click **Browse** to search for the wanted image file.
If you select **Use vessel drawing**, the Shape dimension parameters will be locked.
- 4 Type the parameters for location of origin (survey origin).
- 5 Type the navigation reference point location, X, Y, Z.
- 6 Select **Apply** to store the settings.

6.6.3 Selecting SBAS satellites

The SBAS parameters allow you enable tracking of SBAS satellites and to set up automatic or manual tracking of these satellites.

Context

Enable


Select this box if you want your system to track SBAS satellites.

Automatic

The GNSS receiver selects which SBAS satellites to track. (This option is currently unavailable.)

Manual

The operator must select which SBAS satellites to use. If two SBAS satellites are selected, the system will automatically use data from the best satellite. If only one SBAS satellite is selected, only correction data from this satellite will be used in the computations.



If no specific SBAS satellite is selected, the system will select and use data from the best of the available satellites. If the selected SBAS satellite is not available, the system will not use the SBAS correction data in the computations. Maximum two SBAS satellites can be tracked by the GNSS receiver.

Enable SBAS test mode

The **Enable SBAS test mode** option is typically to be used for SBAS systems which have not reached full operation. An SBAS system in test mode does not provide full integrity.

Procedure


- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Sensors** →**DGNSS** →**SBAS**.
- 3 Select the **Enable** box to enable tracking of SBAS satellites.
- 4 If you want the system to select SBAS satellites automatically, select **Automatic**.
- 5 If you want to select which SBAS satellites to use, instead of automatic selection by the system, select **Manual**.
- 6 Select which SBAS satellites to use. You can select maximum two satellites.
- 7 Select **Apply** to store the settings.

6.6.4 Enabling Fugro high precision services

The XP/G2/G4 parameter allows you to use high precision services to improve the accuracy of the GNSS signals which results in a more accurate position.

Prerequisites

A Fugro demodulator has to be connected and activated.



Context

The use of high precision services must be enabled by the operator as the default setting is disabled.

Enable

Select this box if you want to enable the use of high precision services in the position solution.

Use Glonass

Select this box if you want to enable the use of GLONASS corrections in the position solution.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Sensors** →**DGNSS** →**XP/G2**.
- 3 Select the **Enable** box to enable the use of high precision services.
- 4 If you want the system to use GLONASS corrections, select **Use Glonass**.
- 5 Select **Apply** to store the settings.

6.6.5 Selecting heading input format from gyro compass

Heading input from a gyrocompass or similar can be input to the system as a backup to improve reliability.

Telegram in properties**Format**

The format of the telegram.

Timeout

Age limit. If the age of the heading message exceeds this limit, the heading message is invalid [s].

Interval

Expected interval in seconds between incoming telegrams. Can be configured.

Checksum required


Enables or disables NMEA checksum requirement. Default set to Enabled, which is the recommended setting.

GGA/VTG, interval

If selected, sends GGA and VTG messages to gyro at specified intervals in seconds.

Procedure

- 1 Select the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Select **Communication interface** →**Input/Output**.
- 3 Select the **Gyro** interface you want to set up in the **Input/Output list**.
Observe that the **Configuration details** parameters appear at the lower part of the page.
- 4 Select either **Ethernet** or **Serial** in the **Type** list.
Enter the appropriate parameters for the selected interface type.
- 5 Continue to the **Telegram in properties** group.
- 6 Select the wanted gyro telegram from the **Format** list.



- 7 Type the wanted **Timeout** age limit in seconds.
If the age of the gyro message exceeds this limit, the gyro message is invalid.
- 8 Type the wanted **Interval** for seconds between the incoming telegrams.
- 9 Select the **Checksum required** box if you want NMEA checksum to be required.
This selection is default selected. This is the recommended setting.
- 10 Select the **GGA/VTG** box if you want the system to send GGA and VTG messages to the gyro at specified intervals.
- 11 Select **Apply** to store the settings.

Related topics

- *Communication interfaces description* on page 61

6.6.6 Setting up the MGC as an inertial navigation system (INS)


You can set up the MGC to operate as an inertial navigation system.

Context

When the MGC shall operate as an INS (inertial navigation system) in addition to be an IMU (inertial measurement unit) for the Seapath, the MGC requires input of NMEA GGA, VTG and ZDA messages. For some installations it will be convenient to send these NMEA messages from the Processing Unit to the MGC instead of interfacing an external GNSS receiver to the MGC. However, be aware that if the MGC is installed as a type approved IMO gyro compass, these NMEA messages must be input from an IMO type approved GNSS receiver. Else the type approval will be voided.

Procedure

- 1 Click the **System** menu, →**NAVEngine** →**Standard** to open the **NAV Engine Configuration** dialog box.
- 2 Click the **Communication interface** node →**Input/Output**.
- 3 Select the interface **MGC** in the **Input/Output list**.
Observe that the **MGC properties** parameters appear at the lower part of the page.
- 4 Select **NMEA output interval** to enable output of NMEA GGA, VTG and ZDA messages to the MGC.



Note

Be aware that if the MGC is installed as a type approved IMO gyro compass these NMEA messages must be input from an IMO type approved GNSS receiver. Else the type approval will be voided.

- 5 The **Heading priority** should be set to **0**.
- 6 Click **Apply** to store the settings.

6.7 Operator software configuration

6.7.1 Selecting the position of views in the display

The **View** tab page allows you to select the contents of each view when the HMI (Human Machine Interface) application starts.

Context

The **View** tab page has the same layout as the views in the display. You can select which information shall appear in the various views.

Two views cannot have the same contents. When one view is selected as contents in **View 1**, other contents will automatically be selected for **View 2** or **View 3**.



Procedure

- 1 Select the **System** menu, →**Operator SW** to open the **Operator software configuration** dialog box.
- 2 Select the **View** tab.
- 3 Select which view you want for **View 1**, **View 2** and **View 3** from the drop-down lists.
- 4 Select **Apply** to store the settings.

6.7.2 Selecting the appearance of the Sky View

The **Sky View** tab page allows you to define the appearance of the Sky View.

Context

Display correction satellites

Display correction satellites allows you to show correction satellites such as Inmarsat and Spotbeam in the Sky View. The satellite positions are predefined. You must enable the satellites which you want to appear in the **Sky view** where they are shown as brown triangles. Spotbeam satellites are marked with an S while Inmarsat satellites are marked with an I. When you hover the cursor over a correction satellite in the Sky View, a tooltip with satellite name, azimuth, elevation and position will appear.

Signal strength

Signal strength allows you to display a signal bar under the satellites in the **Sky view**. The signal bar indicates the signal-to-noise ratio for the satellite, and the longer the bar, the stronger the signal.

Note

Signal strength L2 only available on dual frequency, single receiver systems.

Shadow sector


Shadow sector allows you to show the shadow sectors in the Sky View. You must add a shadow sector before you can display it in the Sky View. A shadow sector is just an indicator and does not influence the position solution in any way. The shadow sector refers to the vessel centre and will follow the vessel heading. Azimuth start describes the starting angle of the sector in degrees (0 to 360) related to North. Azimuth sweep describes the size in degrees. Elevation start describes the starting angle of the sector in degrees (0 to 90) where 0 degrees is the horizon and 90 degrees is straight above the antenna.

Satellite track plot length

Satellite track plot length assists in determining if a satellite is rising or falling in elevation. The Satellite track plot length defines how long the length of the track plot should be. When you select this option, the track plot starts to increase. Maximum length of the track plot is 720 minutes.

Display elevation mask

When you select **Display elevation mask**, the configured elevation mask is indicated in the lower left corner of the Sky view.



Procedure

- 1 Select the **System** menu, → **Operator SW** to open the **Operator software configuration** dialog box.
- 2 Select the **Sky View** tab.
- 3 Select **Display correction satellites**.
Observe that the **Select** button appears.
- 4 Select **Select**.
Observe that the **Select Correction Satellites** dialog box appears.

- 5 Select the satellites you want to appear in the Sky View and click **OK**.
- 6 Select **Signal strength** if you want to display the signal bar under the satellites in the Sky view.
- 7 Add shadow sectors to be able to display them in the Sky View.
 - a Place the cursor over the sky view area to the right in the Sky View tab page.
 - b Right-click and select **Add sector**.

Observe that the sector appears in the sky view area and in the table in the **Shadow Sector** group. The table shows your shadow sectors.
 - c Hover the cursor over the shadow sector.

Observe that the cursor changes to arrow symbols.
 - d Drag the arrows horizontally and vertically to create your shadow sector.


Observe the Azimuth and Elevation values in degrees.
- 8 Delete shadow sectors if they are no longer applicable.
 - a Select a sector in the sky view area to the right in the Sky View tab page.
 - b Right-click and select **Remove sector**.

Observe that the shadow sector disappears from the sky view area and from the table.
- 9 Select **Satellites track plot length** if you want to show this in the Sky View.

Observe that the Satellite track plot length list appears.
- 10 Select the wanted value for the satellite track plot length in minutes.
- 11 Select **Display the elevation mask value** if you want to display the elevation mask in degrees in the Sky View.
- 12 Select **Apply** to store the settings.

6.7.3 Adjusting the Integrity view

The **Position integrity** tab page allows you to adjust the scaling of the **Integrity** view.




Procedure

- 1 Click the **System** menu, →**Operator SW** to open the **Operator software configuration** dialog box.
- 2 Click the **Position Integrity** tab.
- 3 Enter the **Max ellipse EPE** in metres.
- 4 Enter the steps for **Ellipse diagram resolution**.
- 5 Click **Apply** to store the settings.

6.7.4 Adjusting the Compass view

The **Compass** tab page allows you to adjust the speed scaling of the **Compass** view.



Procedure

- 1 Click the **System** menu, →**Operator SW** to open the **Operator software configuration** dialog box.
- 2 Click the **Compass** tab.
- 3 Type the maximum vessel speed in knots to be displayed in the Compass View.
- 4 Type the number of circles to be displayed.
This is the resolution of the graphical presentation of the speed in the compass.
- 5 Type the lower speed limit in knots for when COG (Course Over Ground) and SOG (Speed Over Ground) shall be displayed in the Compass View.
- 6 Click **Apply** to store the settings.

6.7.5 Adjusting UTM presentation

The **UTM** tab page allows you to control how UTM positions are treated by the application. UTM is the Universal Transvers Mercator coordinate system.

Context

UTM options

When selecting **False Northing**, positions south of the equator will always be presented as positive in the **Position data** area in the display. A fixed offset of 10 000 000 m is added to the northing value to avoid negative coordinates in the southern hemisphere. When selecting **False Easting**, a fixed offset of 500 000 m is added to the true easting value to avoid negative coordinates. The UTM standard uses false northing and false easting, i.e. the coordinates are never negative. In case negative northing or easting is wanted, clear the **False Northing** check box.

Note


It is not possible to clear the False Easting check box.

Zone options

The UTM zone is automatically calculated by default. The **Auto extended** zone option is only applicable between 56 degrees to 64 degrees north and 3 degrees to 6 degrees east. The 32V zone is extended west to 3 degrees east, so when selecting the Auto extended zone in this area, zone 32V is used. When outside the current area and Auto extended zone is selected, the used zone is equal to the zone used when selecting **Auto** zone.

When selecting **Auto** zone, the system zone is automatically calculated in accordance with the inserted coordinates.

Selecting **Manual** zone makes it possible to define which Zone and Zone offset to use. The **Zone offset** option allows a fixed offset to be applied to the longitudinal degrees. The UTM zone can be offset up to ± 3 degrees. The zone offset is typically used where the maps used have an offset. The zone range is from 1 to 60.




Procedure

- 1 Select the **System** menu, →**Operator SW** to open the **Operator software configuration** dialog box.
- 2 Select the **UTM** tab.
- 3 Deselect the **False Northing** check box if you want positions south of the equator to be presented as negative values in the Position data when displaying position as UTM.
- 4 Select which zone option you want to use.
If you select **Manual**
 - a Type the value for the zone you want to use.
 - b Type the zone offset for this zone, range 1 to 60.
- 5 Select **Apply** to store the settings.

6.7.6 Connecting the Seapath HMI software to the sensor unit

The **Data Source** tab page allows you to select the available physical network interface. This defines the data source for the operator software (Seapath HMI).



Procedure

- 1 Click the **System** menu, → **Operator SW** to open the **Operator software configuration** dialog box.
- 2 Click the **Data source** tab.
- 3 Select the interface which represents the connection to the wanted sensor unit from the **Network interface** list.
- 4 Type the internet protocol (IP) address on which you want the operator software to receive data.

This is normally an address in the Multicast IP range.

- 5 Type the internet protocol (IP) port on which you want the operator software to receive data.


Important

The IP Address and IP Port must match the UDP address and UDP port entered in the **NAV Engine Configuration** in order to establish communication with the operator software.

- 6 Click the **List servers** button to show Seapath systems available through this physical interface. Information presented for each available sensor unit is its IP address, the product type and a description.
- 7 Click **Apply** to store the settings.

Important

Remember that the operator software has to be located on the same IP subnet as the sensor unit.



6.7.7 Selecting alarm message reception

The **Alarm** tab page allows you to define how to receive alarm messages.

Context


UDP Broadcast is the default (and recommended) setting. Defining a multicast address for alarm message distribution requires advanced network configuration skills.

UDP Multicast

If the operator software configuration which is performed, is not in the same network as the sensor unit, IP multicast is required. To enable multicast, select **UDP Multicast** and enter the multicast address to use for receiving alarms.

UDP Broadcast

Select this option if alarm messages are transmitted to all network units.



Procedure

- 1 Select the **System** menu, →**Operator SW** to open the **Operator software configuration** dialog box.
- 2 Select the **Alarms** tab.
- 3 Select the wanted connection type: UDP Multicast or UDP broadcast.
- 4 Select **Apply** to store the settings.

6.8 Creating a backup of the configuration and software installation

If you have a complex configuration setup in your system, it can be useful to make a copy of this configuration in case you should need it later.

Context


The **Copy Configuration** tool will copy the system configuration to a disk based archive file or to a USB flash drive.

Note

This procedure will only copy the configuration setup and not a full image of the installed system.

Procedure

- 1 Insert a USB flash drive into the USB port on the external PC with the Seapath application.
- 2 Select the **Tools** menu →**Copy Configuration** to open the **Configuration archiver** dialog box.



3 The configured vessel name is automatically entered into the **Vessel name** box but you can change this if you want.

4 Select **Start** to copy the configuration files to the USB flash drive.

The copied configuration will be stored as a compressed archive (ZIP file) under the `ConfigBackup` folder in the root of the USB flash drive.

Note

If a USB flash drive is not inserted, the archive will be stored in a temporary location on the local disk. In this case, the archive will only be available for restore until the next reboot.

Result

You can use the USB flash drive with the copied configuration to restore the system configuration at a later date.

6.9 Restoring the configuration backup

If you need to restore the configuration setup to your system, you can use the USB flash drive with a copy of your configuration which you created with the **Copy Configuration** tool.

Procedure


- 1 Insert a USB flash drive into the USB port on the external PC with the Seapath application.
- 2 Select the **System** menu → **Change system mode** to enter **Engineering** mode to open the **Change system mode** dialog box



3 Type the password **STX** and click **OK**. The password is not case sensitive.

You are now able to carry out changes and/or set system parameters.


- 4 Select the **Tools** menu → **Restore Configuration** to open the **Select configuration archive** dialog box with a list of available archive files..



- 5 Select the wanted archive and click **OK** to continue.

Observe that the **Configuration archiver** dialog box appears with information about the selected configuration.

Select at least one option in the **Information to restore** group. This will enable the **Restore** button.



- 6 Select **Restore** to restore the wanted configuration.


Note

*The **Restore Configuration** tool will stop NAV Engine before restoring the configuration. NAV Engine will be restarted automatically.*


7 Drawings

Outline drawing with mechanical dimensions for the Seapath 130 sensor unit, the MGC subsea bottle and system schematics.


7.1 Sensor unit dimensions




7.2 MGC R2 and R3 SB50 dimensions



7.3 MGC R2 and R3 SB50 assembly drawing



7.4 MGC R2 and R3 SB50 sensor point location



8 Technical specifications

8.1 Performance specifications

The performance specifications summarize the main functional and operational characteristics of the system.

8.1.1 Roll, pitch and heading specifications

Seapath 130–R2 Roll and pitch accuracy for $\pm 5^\circ$ amplitude 0.008° RMS^[1]

Seapath 130–R3 Roll and pitch accuracy for $\pm 5^\circ$ amplitude 0.007° RMS^[2]

Seapath 130–R2 heading accuracy 0.06° RMS

Seapath 130–R3 heading accuracy 0.05° RMS

8.1.2 Heave specifications

Heave accuracy (real-time output) 5 cm or 5 % whichever is highest

Heave motion periods (real-time output) 0 to 25 seconds

Heave accuracy (delayed signal, PFreeHeave[®]) 2 cm or 2 % whichever is highest

Heave motion periods (delayed signal, PFreeHeave[®]) 0 to 50 seconds

8.1.3 Position and velocity specifications

Position accuracy with DGNSS 0.5 m RMS or 1 m 95 % CEP

Position accuracy with SBAS 0.5 m RMS or 1 m 95 % CEP

1. With Automatic Online Calibration (AOC).
2. With Automatic Online Calibration (AOC).

Position accuracy with Fugro SeaSTAR XP2/G2/G2+/G4/G4+	0.05 m RMS or 0.1 m 95 % CEP
Position accuracy with VERIPOS Ultra/Ultra ²	0.05 m RMS or 0.1 m 95 % CEP
Position accuracy with C-NavC ¹ , C-NavC ²	0.05 m RMS or 0.1 m 95 % CEP
Position accuracy with RTK (x and y)	1 cm + 1 ppm RMS ^[3]
Position accuracy with RTK (z)	2 cm + 1 ppm RMS ⁽²⁾
Velocity accuracy	0.03 m/s RMS or 0.07 m/s 95 % CEP

8.1.4 Horizontal position drift specifications

Seapath 130-R2 typical position drift 1 minute after GNSS dropout (RTK)	0.6 m
Seapath 130-R3 typical position drift 1 minute after GNSS dropout (RTK)	0.2 m

8.2 Interface specifications

8.2.1 Sensor unit

Output serial ports	3 non-dedicated isolated ports, RS-232 or RS-422
Input serial ports	1 non-dedicated isolated ports, RS-232 or RS-422
Baud rate	Up to 115 200 bits/sec
LAN	1 Ethernet port
Data output rate	Up to 100 Hz
Timing accuracy	1 ms
Data delay	All data in real-time (0 ms) plus transmission delay

8.3 Weight and outline dimensions

The weights and outline dimension characteristics summarize the physical properties of the system.

3. The accuracy is dependent on GPS satellite geometry, environment, ionospheric conditions and distance to the reference station. Excessive multipath, GPS signal obstructions or interference may also reduce the performance.

Note

For more detailed information about the physical dimensions, see Drawings.

8.3.1 Sensor unit

Length	1210 mm
Width	210 mm
Height	94 mm
Weight (including 1 m cable)	7.7 kg

8.3.2 MGC R2 and R3 SB50 unit

Height	275 mm
Length	184 mm
Width	184 mm
Dry weight	10.5 kg
Submerged weight	5.5 kg
Colour	Titanium
Connectors	2, 8-pin Seacon, 5506–1508 (male)

8.4 Power specifications

The power specifications summarize the power supply requirements for the system.

8.4.1 Sensor unit

Voltage	10 to 36 V DC
Recommended voltage	24 V DC
Power consumption	Max. 10 W (typical 8 W)

8.4.2 MGC SB50 unit

Voltage input	24 V DC nominal (18 to 32 V DC)
Power consumption	Max. 12 W (typical 11 W)

8.5 Environmental specifications

The environmental specifications summarize the temperature and humidity requirements for the system.

8.5.1 Sensor unit

Enclosure material	Aluminium bottom part and polyurethane cover
Operating temperature range	-40 °C to +70 °C
Storage temperature range	-40 °C to +70 °C
Operating humidity (max)	Sealed, no limit
Storage humidity	Sealed, no limit
Ingress protection	IP 56
Electromagnetic compatibility (immunity/emission)	IEC 60945/EN 60945
Vibration	IEC 60945/EN 60945

8.5.2 MGC R2 and R3 SB50 unit

Enclosure material	Titanium
Enclosure protection	IP68. Depth rated to 50 metres
Operating temperature range	-15 °C to +55 °C
Storage temperature range	-25 °C to +70 °C
Storage humidity	Sealed, no limit
Electromagnetic compatibility (immunity/emission)	IEC 60945/EN 60945
Vibration	IEC 60945/EN 60945
Max. shock non-operational (10 ms peak)	1000 m/s ²
MTBF (computed)	50000 h
MTBF (service history based)	100000 h

8.6 Radio frequency specifications

The radio frequency characteristics summarize the frequency ranges for the system.

8.6.1 GNSS antenna

Type	NovAtel GPS-713-GGG-N
Upper band	1584 ± 27 MHz
Lower band	1210 ± 45 MHz
LNA gain	35 dB (typical)

8.7 Data output specifications

The system will interface with peripheral systems and sensors using standard and/or proprietary datagram formats.

8.7.1 Sensor unit

Output formats	<p>Simrad EM3000</p> <p>Seapath binary format 3, 11, 23, 26</p> <p>Calibration format</p> <p>Echo sounder format</p> <p>Echo sounder format 18, TSS1</p> <p>RD Instrument ADCP proprietary NMEA format, “PRDID”</p> <p>Lehmkuhl gyro repeater format</p> <p>1PPS time tag, NMEA ZDA message</p> <p>1PPS time tag, Trimble compatible messages</p> <p>Atlas Fansweep format</p> <p>RTCM v3, raw GNSS output</p> <p>PFreeHeave format</p> <p>IMU raw data output</p> <p>NMEA 0183 v. 3.0, Proprietary</p>
NMEA message types	<p>DTM, GBS, GGA, GLL, GNS, GRS, GSA, GST, GSV, THS, HDT, RMC, ROT, VBW, VTG, ZDA.</p> <p>NMEA proprietary: PSXN20, PSXN21, PSXN22, PSXN23, PSXN24, PSXN25, PSXN26, PSXN27.</p>

8.8 Data input specifications

8.8.1 Sensor unit

DGNSS corrections	Seastar XP, Seastar G2, Seastar G4/G4+, VERIPOS Ultra/Ultra ² , C-NavC ¹ , C-NavC ² , RTCM-SC104 v. 2.2, 2.3, 3.0 and 3.2, Trimble CMR
Gyro compass	NMEA 0183 HDT, HDM, HRC, PSXN10, PSXN23, Robertson LR22 BCD format and EM3000

8.9 Datum specifications

8.9.1 Sensor unit

Datum types. These datum types can only be selected if the corrections input to the product is in WGS84 or no corrections are input	NAD27, ED50, WGS84, MINNA, ARATU Bahia, ARATU Campos, ARATU ES, ARATU Santos, SIRGAS2000 and CAMACUPA.
---	--

8.10 Cable specifications

The cable characteristics summarize the cable specifications for the system.

8.10.1 Sensor unit cable

Type	Heavy duty screened, 14 x 2 x 0.25 mm ²
Length	20 m
Diameter	13.5 mm
Weight	0.27 kg/m
Flame retardation	IEC 60332-1
Insulation	PP (conductors) and PUR (outer cover)
Screen	Cu-braid
Bend radius	100 mm

8.10.2 MGC umbilical cable

Type	Umbilical cable, 4 x 2 x 0.75 mm ²
Length	15 or 30 m
Screen	Alum/braid
Diameter	12.6 mm
Bend radius static/dynamic	150 mm (minimum)
Weight in Air	241 Kg/Km
Weight in Sea	112 Kg/Km

8.11 Conformity declaration

The product is tested and is compliant with the relevant product standards.



KONGSBERG

EU DECLARATION OF CONFORMITY

Manufacturer's name: Kongsberg Discovery AS
 Manufacturer's address: Havnegata 9, N-7010 Trondheim, Norway

declares that the product:

Product name: Seapath 130 series
 Product items: Seapath 130-3, 130-H, 130-5, 130-5+, 130-R2, 130-R3

is in conformity with the Radio Equipment Directive, RED, 2014/53/EU and with reference to ETSI guide ETSI EG 203 367, using relevant sections of the following product standards:


Essential requirements	Standards
Health and Safety (Article 3.1(a))	EN 61010-1:2010/IEC 61010-1:2010
EMC (Article 3.1(b)) (GNSS receivers)	EN 301 489 V2.1.1 (2017-02), EN 301 489-19 (2017-03)
EMC (Article 3.1(b)) (Sensor Unit)	EN 60945:2002
Spectrum (GNSS receivers)	EN 303 413 V1.1.0

Test reference
 File: *Seapath 130 series TCF, SPH130S-2017-1*, issued by Kongsberg Seatex AS.

RoHS
 To the best of our knowledge, with reference to standard EN IEC 63000:2018, the product is compliant with Directive 2011/65/EU as amended by Commission Delegated Directive EU 2015/863.

Supplementary information
 The product was tested in its normal configuration.

Date and signature
 2023-11-21


 Erlend Vågsholm, Vice President R&D

Doc item: 110-0058853/A

9 Equipment handling

9.1 Handling and storage

Observe the following when handling the equipment:

- All units must be handled with care.
- The equipment must not be subjected to shocks, excessive vibration or other rough handling.
- The equipment must be preserved and stored in such a way that it does not constitute any danger to health, environment or personal injury.
- For operation and storage, see the respective environmental specifications.

Note

After the installation please save the MGC transportation container. To maintain warranty validity, the MGC must be shipped in this container for service or repair.


Related topics

- *Environmental specifications* on page 99

9.2 Disposal

All electrical and electronic components have to be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or local authorities. The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment. For more detailed information about disposal of your old appliance, please contact your local authorities or waste disposal service.

The equipment may be returned to Kongsberg Discovery AS if there is no local WEEE (Waste Electrical and Electronic Equipment) collection. The equipment is marked with this pictogram.



Appendix A

Output protocols

The following output data protocols are available from Seapath:

Name	Format no.	Description
NMEA	1	NMEA and proprietary messages
Seapath binary fmt3	3	Seapath binary format 3
Simrad EM3000/Hipap	6	Simrad EM3000, 300 and Hipap compatible
Calibration	7	Calibration format for GPS antennas
Echo Sounder fmt9	9	Echo sounder format
RDI ADCP	10	RDI ADCP format, PRDID
Seapath binary fmt11	11	Seapath binary format 11
Lehmkuhl gyro repeater	12	Lehmkuhl gyro repeater format
1PPS NMEA ZDA	13	1PPS time tag, NMEA ZDA message
1PPS Trimble	14	1PPS time tag, Trimble compatible message
Atlas Fansweep	16	Atlas Fansweep format
Echo Sounder fmt18	18	Echo sounder format, TSS1 compatible
Seapath binary fmt 22	22	Seapath output format for VMM 200 (not documented)
Seapath binary fmt 23	23	Seapath binary format 23
PFreeHeave format	24	Delayed heave format
Seapath binary fmt 25	25	Raw IMU output (not documented)
Seapath binary fmt 26	26	Seapath binary format 26
Seapath binary fmt 27	27	Seapath output format for VMM 200 version 2 (not documented)
KM binary	30	KM echo sounder compatible
RTCM version 3	80	Raw GNSS output
Post-processing 1	81	TerraPOS multiple telegrams in same stream (not documented)

A.1 NMEA format

The NMEA format is an ASCII text format using DTM, ZDA, GGA, GLL, VTG, HDT, RMC, VBW, ROT, VER, GST, GSA and GRS messages, the proprietary PBFG and the proprietary PSXN 20, 21, 22, 23, 24, 25, 26 and 27 messages conforming to the same specification.

Format:

\$INDTM,dcode,scode,latoff,{N|S},longoff,{E|W},altoff,rcode*csum term

\$INZDA,time,day,month,year,,*csum term

\$INGGA,time,lat,{N|S},long,{E|W},gga-qual,nsat,hdop,height,M,geoidal,M,age,stn*csum term

\$INGLL,lat,{N|S},long,{E|W},time,gll-qual,mode*csum term

\$INVTG,course,T,,M,speed,N,,K,mode*csum term

\$INHDT,head,T*csum term

\$INHRC,head,rate*csum term

\$INRMC,utc,status,lat,{N|S},long,{E|W},speed,course,date,magvar,{E|W},mode*csum term

\$INTHS,head,a*csum term

\$INVBW,lwspeed,twspeed,Aw,lgspeed,tgspeed,Ag,stwspeed,At,stgspeed,As*csum term

\$INROT,rate,Arate*csum term

\$INVER,total-no,sentence-no,dev-type,vendor,,serial-no,model-code,sw-rev,hw-rev,seq-id*csum term

\$INGBS,utc-fix,err-lat,err-long,err-alt,id-failed,missed,bias,sd-bias*csum term

\$INGNS,time,lat,{N|S},long,{E|W},gns-mode,nsat,hdop,alt-msl,geo-sep,age,stn*csum term

\$INGSV,tno,no,nsat-view,id,elev,azi,snr,,,,,,,,,id,elev,azi,snr*csum term

\$INGST,time,,semi-maj,semi-min,ell-orient,sd-lat,sd-long,sd-height*csum term

\$INGSA,gsa-mode,gsa-status,id,id,id,id,id,id,id,id,id,id,id,pdop,hdop,vdop*csum term

\$INGRS,time,1,res,res,res,res,res,res,res,res,res,res,res*csum term

\$PBFG,vers,time,ro,pi,hd,hv,ro-rate,pi-rate,ya-rate,x-vel,y-vel,z-vel,sts-att,sts-hd,sts-hv,sts-vel*csum term

\$PSXN,20,horiz-qual,hgt-qual,head-qual,rp-qual*csum term

\$PSXN,21,event*csum term

\$PSXN,22,gyro-calib,gyro-offs*csum term

\$PSXN,23,roll,pitch,head,heave*csum term

\$PSXN,24,roll-rate,pitch-rate,yaw-rate,vertical-vel*csum term

\$SPSXN,25,gnss-rec,ant-forw,ant-stb,ant-down,ant-code,rec-code*csum term

\$SPSXN,26,mp-no,mp-forw,mp-stb,mp-down,mp-name*csum term

\$SPSXN,27,mru-forw,mru-stb,mru-down,angle-ro,angle-pi,angle-yaw*csum term

Explanation:

dcode	Local datum code (null field) on format ccc.
scode	Local datum subdivision code on format a.
latoff	Latitude offset in minutes N/S on format x.x.
longoff	Longitude offset in minutes E/W on format x.x.
altoff	Altitude offset in metres (+/-) on format x.x.
rcode	Reference datum code (WGS84 = W84) on format ccc.
time	UTC time on format hhmmss.ss where hh is hours (00 - 23), mm is minutes (00 - 59) and ss.ss is seconds (00.00 - 59.99).
day	Day of month (01 - 31).
month	Month of year (01 - 12).
year	Year on format yyyy.
lat	Latitude on format ddmm.mmmmmm where dd is degrees (00 - 90) and mm.mmmmmm is minutes (00.000000 - 59.999999).
long	Longitude on format dddmm.mmmmmm where ddd is degrees (000 - 180) and mm.mmmmmm is minutes (00.000000 - 59.999999).
gga-qual	GPS quality indicator: 0 = invalid position, 1 = GPS SPS used, 2 = DGPS used, 3 = GPS PPS used, 4 = GPS RTK used, 5 = GPS float RTK used, 6 = dead reckoning.
nsat	Number of satellites in use (00 - 99).
hdop	HDOP on format x.x.
height	Height above ellipsoid in metres on format m.mm.
geoidal	Geoidal separation in metres on format m.mm.
age	Age of DGPS corrections in seconds on format s.s.
stn	DGPS reference station ID (0000 - 1023).
gll-qual	Geographic position quality: A = valid, (D)GPS used (normal or reduced performance), V = dead reckoning or invalid position.
mode	Positioning mode: A = GPS used, D = DGPS used, E = dead reckoning, N = invalid position/velocity.
course	Course over ground, degrees true on format d.dd (0.00 - 359.99).
speed	Speed over ground, knots on format k.k.
head	Heading, degrees true on format d.dd (0.00 - 359.99).

a	Mode indicator: A = Autonomous, V = Data not valid.
utc	UTC of position fix on format hhmmss.ss.
status	Status: A = Data valid, V = Navigation receiver warning.
date	Date: day, month, year on format xxxxxx.
magvar	Magnetic variation in degrees on format x.x.
lwspeed	Longitudinal water speed in knots on format x.x. Longitudinal speed: "-" = astern
twspeed	Transverse water speed in knots on format x.x. Transverse speed: "-" = port
Aw	Status: Water speed, A = valid data on format A
lgspeed	Longitudinal ground speed in knots on format x.x. Longitudinal speed: "-" = astern
tgspeed	Transverse ground speed in knots on format x.x. Transverse speed: "-" = port
Ag	Status: Ground speed, A = valid data on format A.
stwspeed	Stern transverse water speed in knots on format x.x. Transverse speed: "-" = port
At	Status: Stern water speed, A = valid data on format A.
stgspeed	Stern transverse ground speed in knots on format x.x. Transverse speed: "-" = port
As	Status: Stern ground speed, A = valid data on format A.
rate	Rate of turn (degrees/minute on format x.x. "--" = bow turns to port
Arate	Status: A = Data valid, V = Data invalid, on format A
total-no	Total number of sentences needed (1-9) on format x.
sentence-no	Sentence number (1-9) on format x.
dev-type	The manufactured purpose of the device (GNSS).
vendor	Vendor name (KSX).
serial-no	The unique serial number for the device.
model-code	A code describing the type of model.
sw-rev	The product's software revision.
hw-rev	The product's hardware revision.
seq-id	Sequence message identifier (0-9) on format x.
utc-fix	UTC of the GGA or GNS fix associated with this sentence (hours, minutes, seconds) on format hhmmss.ss.
err-lat	Expected error in latitude on format x.x.
err-long	Expected error in longitude on format x.x.
err-alt	Expected error in altitude on format x.x.

id-failed	ID number of most likely failed satellite, GPS: 1-32 , WAAS: 33-64, GLONASS: 65-96 on format xx.
missed	Probability of missed detection for most likely failed satellite on format x.x.
bias	Estimate of bias in metres on most likely failed satellite on format x.x.
sd-bias	Standard deviation of bias estimate on format x.x.
gns-mode	Mode indicator on format c-c. The first character indicates the use of GPS/GLONASS satellites. N = No fix, A = Autonomous mode, D = Differential mode.
alt-msl	Antenna altitude, metres, reference: mean-sea-level (geoide) on format x.x.
geo-sep	Geoidal separation, metres: the difference between the earth ellipsoid and mean-sea-level on format x.x.
tno	Total number of messages (1-9) on format x.
no	Message number (1-9) on format x.
nsat-view	Total number of satellites in view on format x.x.
elev	Elevation in degrees, 90° maximum on format xx.
azi	Azimuth in degrees (000-359) on format xxx.
snr	SNR 00-99 dB-Hz, 0 when not tracked on format xx.
semi-maj	Standard deviation of the semi-major axis of the position error ellipse in metres on format m.mm.
semi-min	Standard deviation of the semi-minor axis of the position error ellipse in metres on format m.mm.
ell-orient	Orientation of the semi-major axis of the position error ellipse in degrees (0 - 180).
sd-lat	Standard deviation of latitude error in metres on format m.mm.
sd-long	Standard deviation of longitude error in metres on format m.mm.
sd-height	Standard deviation of height error in metres on format m.mm.
gsa-mode	GPS position mode setting: A = height aiding enabled, M = 3D only.
gsa-status	GPS position mode used: 1 = no GPS position, 2 = height aided (3 satellites), 3 = 3D.
id	Satellite ID number, GPS (01 – 32), WAAS: 33-64, GLONASS: 65-96.
pdop	PDOP on format x.x
vdop	VDOP on format x.x.
res	GPS range residual in metres on format m.m (no fraction if the value is greater than 99.9 metres).

vers	Version number (1-9) on format x.
ro	Roll in degrees on format d.ddd. Positive with starboard side down.
pi	Pitch in degrees on format d.ddd. Positive with bow up.
hd	Heading in degrees on format d.ddd.
hv	Heave in metres on format d.ddd. Positive down.
ro-rate	Roll rate in degrees per second on format d.ddd. Positive with starboard side down.
pi-rate	Pitch rate in degrees per second on format d.ddd. Positive with bow up.
ya-rate	Yaw rate in degrees per second on format d.ddd. Positive clockwise.
x-vel	Velocity in North direction on format d.ddd.
y-vel	Velocity in East direction on format d.ddd.
z-vel	Velocity in Down direction on format d.ddd. Positive down.
sts-att	Status on roll and pitch angle and rate: 0 = Invalid, 1 = Reduced, 2 = Normal.
sts-hd	Status on heading and yaw rate: 0 = Invalid, 1 = Reduced, 2 = Normal.
sts-hv	Status on heave and velocity in Z-direction: 0 = Invalid, 1 = Reduced, 2 = Normal.
sts-vel	Status on velocity in X- and Y-direction: 0 = Invalid, 1 = Reduced, 2 = Normal..
horiz-qual	Horizontal position and velocity quality: 0 = normal, 1 = reduced performance, 2 = invalid data.
hgt-qual	Height and vertical velocity quality: 0 = normal, 1 = reduced performance, 2 = invalid data.
head-qual	Heading quality: 0 = normal, 1 = reduced performance, 2 = invalid data.
rp-qual	Roll and pitch quality: 0 = normal, 1 = reduced performance, 2 = invalid data.
gyro-calib	Gyro calibration value since system start-up in degrees on format d.dd.
gyro-offs	Short-term gyro offset in degrees on format d.dd.
roll	Roll in degrees on format d.dd. Positive with port side up.
pitch	Pitch in degrees on format d.dd. Positive with bow up.
heave	Heave in metres on format d.dd. Positive down.
roll-rate	Roll rate in degrees per second on format d.dd. Positive when port side is moving upwards.

pitch-rate	Pitch rate in degrees per second on format d.dd. Positive when bow is moving upwards.
yaw-rate	Yaw rate in degrees per second on format d.dd. Positive when bow is moving towards starboard.
vertical-vel	Vertical velocity in metres per second on format d.dd. Positive when moving downwards.
gnss-no	GNSS receiver number [1..n].
ant-forw	Arm from Origin to GNSS antenna in forward direction [m].
ant-stb	Arm from Origin to GNSS antenna in starboard direction [m].
ant-down	Arm from Origin to GNSS antenna in down direction [m].
ant-code	IGS GNSS antenna code (20 characters).
rec-code	IGS GNSS receiver code (20 characters).
mp-no	Monitoring point number [0..n]. If mp-no = 0, then arm from Origin to NRP is input.
mp-forw	Arm from Origin to MP/NRP in forward direction [m].
mp-stb	Arm from Origin to MP/NRP in starboard direction [m].
mp-down	Arm from Origin to MP/NRP in down direction [m].
mp-name	Monitoring point name. If mp-no =0, then mp-name =NRP.
mru-forw	Arm from Origin to MRU in forward direction [m].
mru-stb	Arm from Origin to MRU in starboard direction [m].
mru-down	Arm from Origin to MRU in down direction [m].
angle-ro	MRU mounting angle roll [-180.000 to 179.999 deg].
angle-pi	MRU mounting angle pitch [-89.999 to 89.999 deg].
angle-yaw	MRU mounting angle yaw [-180.000 to 179.999 deg].
event	Event code: 1 = system restart.
csum	Checksum (exclusive or) of all characters between, but not including, the preceding \$ and *, hexadecimal (00 - FF).
term	CR-LF (2 bytes, values 13 and 10).

The ZDA, GGA, GLL, VTG, HDT, GST, GSA, GRS, PSXN 20, 21, 22, 23 and 24 messages are output regularly at an adjustable rate. If gyro calibration data are not being calculated, the PSXN, 22 message is not output. The PSXN, 21 message is output once when an event occurs.

A sub set of the available NMEA messages can be configured individually for each serial line.

A.2 Binary format 3

This binary format consists of a fixed-length message using single-byte unsigned, 4-byte two-complement integer and 4-byte IEEE floating point data elements. For the multi-byte elements, the most significant byte is transmitted first.

Format:

Element	Scaling	Format	Bytes	Value
Header		ASCII	1	ASCII "q"
Length		Unsigned	1	49
Token		Unsigned	1	0 - 255
Time	nanoseconds	Integer	4	0 - 999999999
Latitude	$2^{30} = 90$ degrees	Integer	4	$-2^{30} - 2^{30}$
Longitude	$2^{30} = 90$ degrees	Integer	4	$-2^{31} - 2^{31}$
Height	metres	Float	4	
Heave	metres	Float	4	
North velocity	metres/second	Float	4	
East velocity	metres/second	Float	4	
Down velocity	metres/second	Float	4	
Roll	radians	Float	4	
Pitch	radians	Float	4	
Heading	radians	Float	4	0 - 2 pi
Status word	radians	Bit-fields	4	
Checksum		Unsigned	1	0 - 255

Length is number of bytes between, but not including, the Length and Checksum fields. Checksum is calculated modulo 256 of all bytes between, but not including, the Length and Checksum fields. The contents of the Token field is adjustable. Latitude is positive north of the Equator. Longitude is positive east of Greenwich. Height is above the ellipsoid. Heave is positive down. Roll is positive with port side up. Pitch is positive with bow up.

The status word consists of 32 single bit flags numbered from 0 to 31, where 0 is the least significant bit.

A 1 value (true) means:

Bit no.	Interpretation
0	Reduced horizontal position and velocity performance.
1	Invalid horizontal position and velocity data.

Bit no.	Interpretation
2	Reduced heave and vertical velocity performance.
3	Invalid heave and vertical velocity data.
4	Reduced roll and pitch performance.
5	Invalid roll and pitch data.
6	Reduced heading performance.
7	Invalid heading data.

The remaining bits in the status word are reserved for future expansion.

A.3 Binary format 11

This binary format consists of a fixed-length message using 1, 2 and 4-byte signal and unsigned integers. The signed integers are represented as two-complement numbers. For the multi-byte elements, the most significant byte is transmitted first. The total number of bytes is 42.

Format:

Element	Scaling	Format	Bytes	Value
Header		ASCII	1	ASCII "q"
Time, seconds	seconds	Integer	4	
Time, fraction of second	0.01 second	Unsigned	1	0 - 99
Latitude	$2^{30} = 90$ degrees	Integer	4	$-2^{30} - 2^{30}$
Longitude	$2^{30} = 90$ degrees	Integer	4	$-2^{31} - 2^{31}$
Height	centimetres	Integer	4	
Heave	centimetres	Integer	2	
North velocity	centimetres/second	Integer	2	
East velocity	centimetres/second	Integer	2	
Down velocity	centimetres/second	Integer	2	
Roll	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$
Pitch	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$
Heading	$2^{14} = 90$ degrees	Unsigned	2	$-0 - 2^{16}$
Roll rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Pitch rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$

Element	Scaling	Format	Bytes	Value
Yaw rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Status word		Bit-fields	2	
Checksum		Unsigned	2	

Checksum is calculated as a 16-bit Block Cyclic Redundancy Check of all bytes between, but not including the Header and Checksum fields. The CRC algorithm is described in a separate section. Time is divided in an integer seconds part and a fractional second part. The integer seconds part of time is counted from 1970-01-01 UTC time, ignoring leap seconds.

Latitude is positive north of the Equator. Longitude is positive east of Greenwich. Height is above the ellipsoid. Heave is positive down. Roll is positive with port side up. Pitch is positive with bow up.

The status word consists of 16 single bit flags numbered from 0 to 15, where 0 is the least significant bit.

A 1 value (true) means:

Bit no.	Interpretation
0	Reduced horizontal position and velocity performance.
1	Invalid horizontal position and velocity data.
2	Reduced heave and vertical velocity performance.
3	Invalid heave and vertical velocity data.
4	Reduced roll and pitch performance.
5	Invalid roll and pitch data.
6	Reduced heading performance.
7	Invalid heading data.

The remaining bits in the status word are reserved for future expansion.

A.4 Seapath Binary 23

This binary format consists of a fixed-length message using 1, 2 and 4-byte signal and unsigned integers. The signed integers are represented as two-complement numbers. For the multi-byte elements, the most significant byte is transmitted first. The total number of bytes is 44.

Format

Element	Scaling	Format	Bytes	Value
Header		Unsigned	1	AA Hex
Header		Unsigned	1	51 Hex
Time, seconds	seconds	Integer	4	
Time, fraction of second	0.0001 second	Unsigned	2	0 to 9999
Latitude	$2^{30} = 90$ degrees	Integer	4	$-2^{30} - 2^{30}$
Longitude	$2^{30} = 90$ degrees	Integer	4	$-2^{31} - 2^{31}$
Height	centimetres	Integer	4	
Heave	centimetres	Integer	2	
North velocity	centimetres/second	Integer	2	
East velocity	centimetres/second	Integer	2	
Down velocity	centimetres/second	Integer	2	
Roll	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$
Pitch	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$
Heading	$2^{14} = 90$ degrees	Unsigned	2	$0 - 2^{16}$
Roll rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Pitch rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Yaw rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Status word		Bit-fields	2	
Checksum		Unsigned	2	

Checksum is calculated as a 16-bit Block Cyclic Redundancy Check of all bytes between, but not including the Header and Checksum fields. The CRC algorithm is described in a separate section. Time is divided in an integer seconds part and a fractional second part. The integer seconds part of time is counted from 1970-01-01 UTC time, ignoring leap seconds.

Latitude is positive north of the Equator. Longitude is positive east of Greenwich. Height is above the ellipsoid. Heave is positive down. Roll is positive with port side up. Pitch is positive with bow up.

The status word consists of 16 single bit flags numbered from 0 to 15, where 0 is the least significant bit.

A 1 value (true) means:

Bit no.	Interpretation
0	Reduced horizontal position and velocity performance.
1	Invalid horizontal position and velocity data.
2	Reduced heave and vertical velocity performance.
3	Invalid heave and vertical velocity data.
4	Reduced roll and pitch performance.
5	Invalid roll and pitch data.
6	Reduced heading performance.
7	Invalid heading data.

The remaining bits in the status word are reserved for future expansion.

A.5 Seapath Binary 26

This binary format consists of a fixed-length message using 1, 2 and 4-byte signal and unsigned integers. The signed integers are represented as two-complement numbers. For the multi-byte elements, the most significant byte is transmitted first. The total number of bytes is 52.

Format

Element	Scaling	Format	Bytes	Value
Header		Unsigned	1	AA Hex
Header		Unsigned	1	53 Hex
Time, seconds	seconds	Integer	4	
Time, fraction of second	0.0001 second	Unsigned	2	0 to 9999
Latitude	$2^{30} = 90$ degrees	Integer	4	$-2^{30} - 2^{30}$
Longitude	$2^{30} = 90$ degrees	Integer	4	$-2^{31} - 2^{31}$
Height	centimeters	Integer	4	
Heave, real-time	centimeters	Integer	2	
North velocity	centimeters/second	Integer	2	
East velocity	centimeters/second	Integer	2	
Down velocity	centimeters/second	Integer	2	
Roll	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$
Pitch	$2^{14} = 90$ degrees	Integer	2	$-2^{15} - 2^{15}$

Element	Scaling	Format	Bytes	Value
Heading	$2^{14} = 90$ degrees	Unsigned	2	$0 - 2^{16}$
Roll rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Pitch rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Yaw rate	$2^{14} = 90$ degrees/second	Integer	2	$-2^{15} - 2^{15}$
Delayed heave time, seconds	seconds	Integer	4	
Delayed heave time, fraction of second	0.0001 second	Unsigned	2	0 to 9999
Heave, delayed	centimeters	Integer	2	
Status word		Bit-fields	2	
Checksum		Unsigned	2	

Checksum is calculated as a 16-bit Block Cyclic Redundancy Check of all bytes between, but not including the Header and Checksum fields. The CRC algorithm is described in a separate section. Time is divided in an integer seconds part and a fractional second part. The integer seconds part of time is counted from 1970-01-01 UTC time, ignoring leap seconds.

Latitude is positive north of the Equator. Longitude is positive east of Greenwich. Height is above the ellipsoid. Heave is positive down. Roll is positive with port side up. Pitch is positive with bow up.

The status word consists of 16 single bit flags numbered from 0 to 15, where 0 is the least significant bit.

A 1 value (true) means:

Bit no.	Interpretation
0	Reduced horizontal position and velocity performance.
1	Invalid horizontal position and velocity data.
2	Reduced heave and vertical velocity performance.
3	Invalid heave and vertical velocity data.
4	Reduced roll and pitch performance.
5	Invalid roll and pitch data.
6	Reduced heading performance.
7	Invalid heading data.
8	Invalid delayed heave data

The remaining bits in the status word are reserved for future expansion.

A.6 Simrad EM3000

The Simrad EM3000 format consists of a fixed-length message using single-byte unsigned, 2-byte unsigned and 2-byte two-complement integer data elements. For the 2-byte elements, the least significant byte is transmitted first.

Format

Element	Scaling	Format	Bytes	Value
Status byte		Unsigned	1	
Header		Unsigned	1	90 Hex
Roll	0.01 degrees	Integer	2	-17999 to 17999
Pitch	0.01 degrees	Integer	2	-17999 to 17999
Heave	1 cm	Integer	2	-999 to 999
Heading	0.01 degrees	Unsigned	2	0 to 35999

Roll is positive with port side up. Pitch is positive with bow up. Heave is positive up.

The status byte can have the following values:

Value	Interpretation
90 Hex	Normal
91 Hex	Reduced performance
A0 Hex	Invalid data

Invalid data are also indicated by values outside the specified ranges. When the status is A0, the values which are within specified ranges can be assumed to have valid, but reduced quality.

A.7 KM binary format

The KM binary protocol is a proprietary binary format used when connection to multibeam echo sounders and other systems. Length 132 bytes.

Format

		Format	# of bytes
Start id	#KMB	char	4U
Dgm length		uint16	2U
Dgm version (=1)		uint16	2U
UTC seconds	s	uint32	4U
UTC nanoseconds	ns	uint32	4U

		Format	# of bytes
Status		uint32	4U
Latitude	deg	double	8F
Longitude	deg	double	8F
Ellipsoid height	m	float	4F
Roll	deg	float	4F
Pitch	deg	float	4F
Heading	deg	float	4F
Heave	m	float	4F
Roll rate	deg/s	float	4F
Pitch rate	deg/s	float	4F
Yaw rate	deg/s	float	4F
North velocity	m/s	float	4F
East velocity	m/s	float	4F
Down velocity	m/s	float	4F
Latitude error	m	float	4F
Longitude error	m	float	4F
Height error	m	float	4F
Roll error	deg	float	4F
Pitch error	deg	float	4F
Heading error	deg	float	4F
Heave error	m	float	4F
North acceleration	m/s ²	float	4F
East acceleration	m/s ²	float	4F
Down acceleration	m/s ²	float	4F
Delayed heave:			
UTC seconds	s	uint32	4U
UTC nanoseconds	ns	uint32	4U
Delayed heave	m	float	4F

This format include the necessary information for calculation of the Doppler effect at the transducer locations (needed in FM chirp mode). The update rate should then be minimum 100 Hz.

Definitions

Data format

Little endian (the least significant byte is transmitted first). Float is according to IEEE - 754.

Dgm length

The total number of bytes in the datagram.

Dgm version

The version is incremented if the datagram format is changed.

Timestamp format

Epoch 1970-01-01 UTC time, ignoring leap seconds.

Position and height

At user defined sensor reference point. Position in decimal degrees.

- Latitude: Negative on Southern hemisphere.
- Longitude: Negative on Western hemisphere.
- Height: Positive above ellipsoid.

Positive roll

Port side up.

Positive pitch

Bow up.

Positive heave

Downwards, at user defined sensor reference point.

Heading

True North.

Error fields

Sensor data quality: RMS

-1= not implemented

Status word

One bit per status info, 1= active

Bit #	
	Invalid data:
0	Horizontal position and velocity
1	Roll and pitch
2	Heading

Bit #	
3	Heave and vertical velocity
4	Acceleration
5	Delayed heave
	Reduced performance:
16	Horizontal position and velocity
17	Roll and pitch
18	Heading
19	Heave and vertical velocity
20	Acceleration
21	Delayed heave

A.8 Calibration format 7

The calibration format is a columnar ASCII text format for use when calibrating the GNSS antenna installation.

Format:

Element	Columns	Scaling	Decimals	Value
Time	1 - 7	seconds	1	0.0 - 86399.9
Heading	10 - 15	degrees	2	0.00 - 359.99
Gyro heading	18 - 23	degrees	2	0.00 - 359.99
Baseline	26 - 31	metres	3	
Height	34 - 38	metres	2	
Term	39 - 40			CR-LF

Each record consists of numbers on ASCII format separated by spaces and terminated by carriage return and linefeed (values 10 and 13). Leading spaces are used, so the numbers are separated by two or more spaces, and spaces may occur before the first number on the record.

Time is counted since last midnight UTC time. Heading is true heading from the GNSS phase measurement, which is not the same as the heading output on the other formats. Gyro heading is from an external gyro, 0.00 if no gyro is connected. Baseline is the slant range between the antenna centres from the GNSS phase measurement. Height is the height difference between the antennas from the GNSS phase measurement. Height is positive if antenna 1 is above antenna 2.

The data are intended for calibration of the antenna installation, so no data are output unless the GNSS phase measurements are valid.

A.9 Echo sounder format 9

This echo sounder format is a proprietary ASCII text format with fixed-length records used when connecting Simrad EA500 and other echo sounders.

Format:

Element	Columns	Scaling	Format
Header	1 - 7		:000000
Heave	9 - 13	1 cm	sdddd
Warning	14		space or “?”
Roll	15 - 19	0.01 degree	sdddd
Pitch	21 – 25	0.01 degree	sdddd
Term	26 – 27		CR-LF

Heave is positive up. Roll is positive with port side up. Pitch is positive with bow up.

The zeroes in the header occupy the columns used for acceleration when this format is output from other systems. Seapath does not output acceleration.

“s” is the sign character, space if positive and “-“ if negative. “dddd” is a decimal number with leading zeroes where appropriate.

The warning character is space if data are normal, “?” if data are invalid or of reduced quality.

Columns between elements are filled with spaces.

The definition of the attitude angles in this format is different from the Euler angles definition used elsewhere. The difference appears in the roll angle, where:

$$roll_{echo-sounder} = \arcsin[\sin(roll_{Euler}) \cdot \cos(pitch_{Euler})]$$

A.10 Echo sounder format 18, TSS1

This echo sounder format is a proprietary ASCII text format with fixed-length records used when connecting Seapath to Seabeam and other echo sounders.

Format:

Element	Columns	Scaling	Format
Header	1 - 7		:000000
Heave	9 - 13	1 cm	sdddd
Warning	14		"F" or "f"
Roll	15 - 19	0.01 degree	sdddd
Pitch	21 - 25	0.01 degree	sdddd
Term	26 - 27		CR-LF

Heave is positive up. Roll is positive with port side up. Pitch is positive with bow up.

The zeroes in the header occupy the columns used for acceleration when this format is output from other systems. Seapath does not output acceleration.

“s” is the sign character, space if positive and “-“ if negative. “dddd” is a decimal number with leading zeroes where appropriate.

The warning character is “F” if data are normal, “f” if data are invalid or of reduced quality.

Columns between elements are filled with spaces.

The definition of the attitude angles in this format is different from the Euler angles definition used elsewhere. The difference appears in the roll angle, where:

$$roll_{echo-sounder} = \arcsin[\sin(roll_{Euler}) \cdot \cos(pitch_{Euler})]$$

A.11 RDI ADCP

The RDI format is a proprietary ASCII text format used when connecting RDI ADCP equipment.

Format:

\$PRDID,pitch,roll,head term

Explanation:

- pitch** Pitch, degrees on format sddd.dd. s is the sign character, "+" or "-". ddd.dd is a decimal number with leading zeroes where appropriate. Positive with bow up.
- roll** Roll, degrees on format sddd.dd. s is the sign character, "+" or "-". ddd.dd is a decimal number with leading zeroes where appropriate. Positive with port side up.

- head** Heading, degrees true on format ddd.dd, with leading zeroes where appropriate.
- term** CR-LF (2 bytes, values 13 and 10).

A.12 Lehmkuhl gyro repeater format 12

This Lehmkuhl gyro repeater format is used when outputting heading from Seapath to Lehmkuhl gyro repeaters. The message is similar to the HDT message output in the standard NMEA format from Seapath. The main differences are lower resolution and no checksum.

When heading is output to devices that are compliant to the NMEA specification, it is recommended to use the standard NMEA format and not the Lehmkuhl format.

A.13 1PPS, NMEA ZDA format 13

This 1PPS time tag message is output once per second, approximately 0.5 seconds before the time pulse. The message format is ASCII text using the ZDA message. The message contains the UTC time when the message is output. The next time pulse appears at the first integer second after the time in the message.

Format:

`$INZDA,time,day,month,year,*,*csum term`

Explanation:

- time** UTC time on format hhmmss.ss where hh is hours (00 - 23), mm is minutes (00 - 59) and ss.ss is seconds (00.00 - 59.99).
- day** Day of month (01 - 31).
- month** Month of year (01 - 12).
- year** Year on format yyyy.
- csum** Checksum (exclusive or) of all characters between, but not including, the preceding \$ and *, hexadecimal (00 - FF).
- term** CR-LF (two bytes, values 13 and 10).

This format is recommended used together with 1PPS signal output on the 1PPS cable in the sensor unit spider cable. This since the message is output synchronised with the 1PPS signal and is easier/faster to decode than the standard NMEA output with a number of NMEA messages included.

A.14 1PPS, Trimble format 14

This 1PPS time tag message is output once per second, approximately 0.5 seconds before the time pulse. The message format is fixed length ASCII text. The message contains the UTC time of the next time pulse.

Format:

Element	Columns	Format
Header	1 - 3	UTC
Date	5 - 12	yy.mo.da
Time	14 - 21	hh:mm:ss
Fix type	23	digit or '?'
No. of satellites	24	digit or '?'
Term	25 - 26	CR-LF

“yy.mo.da” is year (00 - 99), month of year (01 - 12) and day of month (01 - 31). “hh:mm:ss” is hours (00 - 23), minutes (00 - 59) and seconds (00 - 59). Fix type is “5” for 3D fix with accurate time, “?” for no fix (time from receiver clock). No. of satellites is “1” – “8” for 1 - 8 satellites tracked, “9” for 9 or more satellites tracked, “?” for no fix (time from receiver clock).

Columns between elements are filled with spaces.

A.15 Atlas fansweep format 16

This Atlas format is a proprietary binary format used for outputting data to Atlas Fansweep echo sounders. It consists of a fixed-length message using single-byte and 2-byte two-complement integer data elements. For the 2-byte elements, most significant byte is transmitted first.

Format:

Element	Scaling	Format	Bytes	Value
Start byte		Integer	1	10 Hex
Roll	$2^{14} = 90$ degrees	Integer	2	
Pitch	$2^{14} = 90$ degrees	Integer	2	
Heave	millimetres	Integer	2	
Status byte		Integer	1	
Stop byte		Integer	1	10 Hex

Roll is positive with port side up. Pitch is positive with bow up. Heave is positive up.

The definition of the attitude angles in this format is different from the Euler angles definition used elsewhere. The difference appears in the roll angle, where:

$$roll_{echo-sounder} = \arcsin[\sin(roll_{Euler}) \cdot \cos(pitch_{Euler})]$$

The status byte can have the following values:

Value	Interpretation
6	Normal
7	Reduced performance or invalid data

A.16 PFreeHeave

This PFreeHeave® format consists of a fixed-length message using 1-, 2- and 4-byte signed and unsigned integers. The signed integers are represented as two-complement numbers. For the multi-byte elements, the most significant byte is transmitted first. The total number of bytes is 13.

The PFreeHeave output is delayed by a few minutes due to processing. The time fields contain time of validity for the data.

Format

Element	Scaling	Format	Bytes	Value
Header		Unsigned	1	AA Hex
Header		Unsigned	1	52 Hex
Time, seconds	Seconds	Integer	4	
Time, fraction of second	0.0001 second		2	0 to 9999
Heave	Centimetres	Integer	2	
Status word		Bit-fields	1	
Checksum		Unsigned	2	

Checksum is calculated as a 16-bit Block Cyclic Redundancy Check of all bytes between, but not including the Header and Checksum fields. The CRC algorithm is described in a separate section. Time is divided in an integer seconds part and a fractional second part. The integer seconds part of time is counted from 1970-01-01 UTC time, ignoring leap seconds.

Heave is positive down. The status field is zero if heave is valid, non-zero if heave is invalid.

A.17 Cyclic redundancy check algorithm

The 16-bit Block Cyclic Redundancy Check algorithm used to calculate the checksum in some formats is described in C and Fortran source code below.

C code

```
#define POLY 0x8408
unsigned short blkcrc(
    unsigned char *bufptr,      /* message buffer */
    unsigned long len          /* number of bytes */
)
{
    unsigned char i;
    unsigned short data;
    unsigned short crc = 0xffff;

    if (len == 0L) {
        return ~crc;
    }

    do {
        for (i=0, data = (unsigned short) (0xff & *bufptr++);
            i < 8;
            i++, data >>= 1) {
            if ((crc & 0x0001) ^ (data & 0x0001)) {
                crc = (crc >> 1) ^ POLY;
            } else {
                crc >>= 1;
            }
        }
    } while (--len);

    crc = ~crc;
    data = crc;
    crc = (crc << 8) | ((data >> 8) & 0xff);

    return crc;
}
```

Fortran code

```

SUBROUTINE blkcrc(inbuffer, len, crc)

INTEGER*2 len, i , bit
INTEGER*4 crc, data, poly
CHARACTER inbuffer*(*)

poly = 16#8408
crc = 16#FFFF
data = 0

IF (len.EQ.0) THEN
    crc = 0
    RETURN
END IF

DO i = 1, len
    data = ICHAR(inbuffer(i:i))
    DO bit = 1, 8
        data = IAND(data,16#FF)
        IF (IAND(crc,16#01).EQ.(IAND(data,16#01))) THEN
            crc = ISHL(crc,-1)
        ELSE
            crc = ISHL(crc,-1)
            crc = IEOR(crc, poly)
        END IF
        data = ISHL(data,-1)
    END DO
END DO

data = IEOR(crc,16#FFFF)
crc = IOR(ISHL(data,8),IAND(ISHL(data,-8),16#FF))

END

```

A.18 RTCM format 80

This protocol is based on the RTCM Standard 10403.2, *Differential GNSS services*, version 3 with Amendments 1 and 2. See this standard for a description of the output properties.

This output protocol is used for outputting raw GNSS data for post processing of the position. All data are output in the GNSS antenna only and applies for both antennas.

Appendix B

NMEA TelegramOut options

The contents of some of the available NMEA telegrams may be modified according to options listed in the configuration. This is for example useful when interfacing to older equipment.

This table holds a description of the various options.


Telegram out option	Description
Output residuals on Ashtech RRE format (GRS)	Use this option if you have enabled the GRS sentence and want the residuals output on the Ashtech RRE format instead.
Send VHW message after VTG using ground speed from VTG	Use this option when a VHW sentence is needed, and vessel heading and vessel speed relative to the water are not available. When this option is enabled, an NMEA VHW sentence is output, using SOG as Speed, and COG as heading. The VHW sentence is output immediately after the VTG sentence.
Output empty fields in NMEA HDT and NMEA THS messages also for reduced accuracy	Use this option when you want to set invalid heading (empty HDT/THS field) when heading status is reduced (low accuracy).
Use inertial roll, pitch and heave only	Use this option if you want the output of roll, pitch and heave to be calculated from IMU measurements only (no GNSS).
Use time from dataset in NMEA ZDA message	GNSS systems: Use this option if you want the timestamp in the NMEA ZDA message to be equal to timestamp of the GNSS data set and the GGA message.
Disable additional GNS messages when difcorr is used for both GPS and GLONASS	Use this option if you do not want additional NMEA messages if differential corrections are used for both GPS and GLONASS.
Limit correction age to 9.9 sec in GGA	Use this option if your system does not handle correction ages above 9.9 seconds in the GGA sentence. If this option is enabled, the correction age will increase and stop at 9.9 seconds even if the correct correction age is more than 9.9 seconds.

Telegram out option	Description
Use GNSS solution only	For Integrated systems only: Use this option if you want to output position based on GNSS only (no IMU).
Set GGA quality indicator to 5 if converged high precision	Use this option if you want the Quality Indicator in the NMEA GGA sentence set to 5, when position solution is converged clock orbit or float filter (XP, G2, Ultra, Apex etc).
Freeze NMEA position if invalid	Use this option if you want the position output to use the last known valid position when the current position becomes invalid.
Use current GNSS info if only integrated position is valid	Integrated systems only: Use this option if you want to output current HDOP, number of satellites and corrections age in the GGA message though the GNSS position is invalid and the integrated position is valid.
Allow more than 12 satellites in GGA message	The NMEA standard limits the number of satellites in the GGA sentence to 12. Use this option if you want the GGA sentence to use the actual number of satellites.
Use modified quality indicator in GGA message	Use this option if you want the quality Indicator in the NMEA GGA sentence to be replaced by GQI.
Use external attitude for lever arm compensation	Use this option if you want to use external attitude for lever arm compensation and velocity decomposition.
Use DQI(0-9) as GGA quality indicator	DP only: Use this option if you want to use talker DP and output DQI instead of NMEA Quality Indicator for GGA.
Send each NMEA telegram in separate UDP datagram	Use this option if TelegramOut is configured to send on UDP, and you want each NMEA telegram to be sent in a separate UDP telegram.
Use 2 decimals instead of 1 for velocity in NMEA VTG and RMC	Use this option if you want the velocity field in NMEA VTG and NMEA RMC to contain 2 decimals instead of the default 1.
Stop GGA, GLL, GNS and RMC output if invalid position	Use this option if you want the output of the position telegrams to stop if the position is invalid.

Appendix C Installations with junction box

For more permanent installations the Seapath 130 can be installed by use of junction box as an alternative to the spider cable. In the below figures is described some alternatives with part numbers on the necessary cables and junction boxes.

Figure 11 Installation by use of junction box and MGC in subsea bottle



The connections within the Seapath 130 junction box is described in the below figures.

Figure 12 Connections for user side terminals P2 to P9

M340-22 Seapath 130 Junction Box

P2 - MRU			
Pin	Signal RS-422	Description	
1	0 V	Powerground	
2	24 V	Power+	
3	RXA	Signal sent to MRU	
4	RXB	Signal sent to MRU	
5	TXB	Signal sent from MRU	
6	TXA	Signal sent from MRU	
7	LGND	Logical ground	
8	XIN	1PPS input to MRU	

P3 - ECHO			
Pin	Signal RS-232	Signal RS-422	Description
1	GND	GND	Ground
2	RTS	TXA	Output from Seapath
3	TX	TXB	Output from Seapath

P4 - PPS		
Pin	Signal RS-422	Description
1	GND	Ground
2	TXA	Output from Seapath
3	TXB	Output from Seapath

P5 - SURVEY			
Pin	Signal RS-232	Signal RS-422	Description
1	GND	GND	Ground
2	RTS	TXA	Output from Seapath
3	TX	TXB	Output from Seapath

P6 – GNSS OUT			
Pin	Signal RS-232	Signal RS-422	Description
1	GND	GND	Ground
2	RTS	TXA	Output from Seapath
3	TX	TXB	Output from Seapath


P7 – GNSS IN			
Pin	Signal RS-232	Signal RS-422	Description
1	GND	GND	Ground
2	CTS	RXA	Input to Seapath
3	RX	RXB	Input to Seapath

P8 – 24 VOLT		
Pin	Signal	Description
1	0 V	Power ground
2	24 V	Power+

P9 – ETHERNET		
Pin	Signal	Description
1	RJ1_TXD+	TD+, Ethernet
2	RJ2_TXD-	TD-, Ethernet
3	RJ3_RXD+	RD+, Ethernet
4	RJ6_RXD-	RD-, Ethernet

Note:
 Plug the unused cable glands and tighten properly to ensure that they are watertight. This to fulfil the enclosure protection specification.

Figure 13 Connections for user side terminal P1 of the Sensor Unit cable, M340-21



Rev. 2

Figure 14 Cable wiring schematics for M340–21

Souriau 26 pin Signal	Conn.	Signal Description	Conductor	
			Pair No.	Color
PWR+	R	Power supply (+24 V)	1a	White
PWR-	B	Power supply (0 V)	1b	Blue
ETH RXD-	C	RD-, Ethernet	2a	White
ETH RXD+	T	RD+, Ethernet	2b	Orange
ETH TXD-	S	TD-, Ethernet	3a	White
ETH TXD+	P	TD+, Ethernet	3b	Green
GNSS CTS RX-A	G	RS422A- or RS232 input signal from GNSS rec.	4a	White
GNSS RX RX-B	H	RS422B+ or RS232 input signal from GNSS rec.	4b	Brown
GNSS RTS TX-A	X	RS422A- or RS232 output signal to GNSS rec.	5a	White
GNSS TX TX-B	A	RS422B+ or RS232 output signal to GNSS rec.	5b	Grey
GNSS GND	J	GND GNSS receiver	6a	Red
Survey GND	K	GND survey computer	6b	Blue
Survey TX TX-B	c	RS422B+ or RS232 output signal to survey comp	7a	Red
Survey RTS TX-A	M	RS422A- or RS232 output signal to survey comp.	7b	Orange
1PPS TX-B	E	RS422B+ output 1PPS signal	8a	Red
1PPS TX-A	Y	RS422A- output 1PPS signal	8b	Green
1PPS GND	a	GND for 1PPS signal	9a	Red
Echo GND	U	GND for echo sounder	9b	Grey
Echo TX TX-B	V	RS422B+ or RS232 output signal to echo sound.	10a	Red
Echo RTS TX-A	L	RS422A- or RS232 output signal to echo sounder	10b	Brown
MRU RX-A	Z	RS422A- input signal from MRU	11a	Black
MRU RX-B	W	RS422B+ input signal from MRU	11b	Orange
MRU TX-A	b	RS422A- output signal to MRU	12a	Black
MRU TX-B	F	RS422B+ output signal to MRU	12b	Blue
MRU GND	D	GND for MRU	13a	Black
MRU 1PPS P TX-B	N	1PPS signal to MRU (XIN)	13b	Green
		Not connected	14a	Black
		Not connected	14b	Brown

Appendix D

Free open source software

Some of the software components in this product are free and open source software released under the licenses shown below.

Source code for the relevant software components is available from:

Kongsberg Discovery AS

Attn.: Customer support

Pirsenteret

N-7462 Trondheim

Norway

E-mail: support.seatex@kd.kongsberg.com

The application software is proprietary, and no source code is available for it.

D.1 BSD license

Copyright (c) 1983, 1988, 1989, 1990, 1993 The Regents of the University of California.

Copyright (c) 1996, 1997, 1998, 1999, 2003 Theodore Ts'o.

Copyright (c) 1997, 1998, 2001 Kungliga Tekniska Högskolan.

Copyright (c) 1991, 1992 Paul Kranenburg <pk@cs.few.eur.nl>

Copyright (c) 1993 Branko Lankester <branko@hacktic.nl>

Copyright (c) 1993 Ulrich Pegelow <pegelow@moorea.uni-muenster.de>

Copyright (c) 1995, 1996 Michael Elizabeth Chastain <mec@duracef.shout.net>

Copyright (c) 1993, 1994, 1995, 1996 Rick Sladkey <jrs@world.std.com>

Copyright (c) 1998-2001 Wichert Akkerman <wakkerma@deephackmode.org>

Copyright (c) 1995 Nick Simicich (<njs@scifi.emi.net>

Copyright (c) 2000-2001 Gunnar Ritter.

Copyright (c) 2004, Jan Kneschke, incremental

Copyright (c) 1997-2010 University of Cambridge

Copyright (c) 2007-2010, Google Inc.

All Rights Reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

D.2 f2c license

Copyright 1990 - 1997 by AT&T, Lucent Technologies and Bellcore.

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that the copyright notice and this permission notice and warranty disclaimer appear in supporting documentation, and that the names of AT&T, Bell Laboratories, Lucent or Bellcore or any of their entities not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

AT&T, Lucent and Bellcore disclaim all warranties with regard to this software, including all implied warranties of merchantability and fitness. In no event shall AT&T, Lucent or Bellcore be liable for any special, indirect or consequential damages or any damages whatsoever resulting from loss of use, data or profits, whether in an action of contract, negligence or other tortious action, arising out of or in connection with the use or performance of this software.

D.3 GCC license

GCC is released under the license shown below in addition to GPL and LGPL.

GCC RUNTIME LIBRARY EXCEPTION

Version 3.1, 31 March 2009

Copyright (C) 2009 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. This GCC Runtime Library Exception ("Exception") is an additional permission under section 7 of the GNU General Public License, version 3 ("GPLv3"). It applies to a given file (the "Runtime Library") that bears a notice placed by the copyright holder of the file stating that the file is governed by GPLv3 along with this Exception. When you use GCC to compile a program, GCC may combine portions of certain GCC header files and runtime libraries with the compiled program. The purpose of this Exception is to allow compilation of non-GPL (including proprietary) programs to use, in this way, the header files and runtime libraries covered by this Exception.

0. Definitions.

A file is an "Independent Module" if it either requires the Runtime Library for execution after a Compilation Process, or makes use of an interface provided by the Runtime Library, but is not otherwise based on the Runtime Library. "GCC" means a version of the GNU Compiler Collection, with or without modifications, governed by version 3 (or a specified later version) of the GNU General Public License (GPL) with the option of using any subsequent versions published by the FSF. "GPL-compatible Software" is software whose conditions of propagation, modification and use would permit combination with GCC in accord with the license of GCC. "Target Code" refers to output from any compiler for a real or virtual target processor architecture, in executable form or suitable for input to an assembler, loader, linker and/or execution phase. Notwithstanding that, Target Code does not include data in any format that is used as a compiler intermediate representation, or used for producing a compiler intermediate representation. The "Compilation Process" transforms code entirely represented in non-intermediate languages designed for human-written code, and/or in Java Virtual Machine byte code, into Target Code. Thus, for example, use of source code generators and preprocessors need not be considered part of the Compilation Process, since the Compilation Process can be understood as starting with the output of the generators or preprocessors. A Compilation Process is "Eligible" if it is done using GCC, alone or with other GPL-compatible software, or if it is done without using any work based on GCC. For example, using non-GPL-compatible Software to optimize any GCC intermediate representations would not qualify as an Eligible Compilation Process.

1. Grant of Additional Permission.

You have permission to propagate a work of Target Code formed by combining the Runtime Library with Independent Modules, even if such propagation would otherwise violate the terms of GPLv3, provided that all Target Code was generated by Eligible Compilation Processes. You may then convey such a combination under terms of your choice, consistent with the licensing of the Independent Modules.

2. No Weakening of GCC Copyleft.

The availability of this Exception does not imply any general presumption that third-party software is unaffected by the copyleft requirements of the license of GCC.

D.4 GNU C library license

The GNU C library is released under the licenses shown below in addition to GPL and LGPL.

This file contains the copying permission notices for various files in the GNU C Library distribution that have copyright owners other than the Free Software Foundation. These notices all require that a copy of the notice be included in the accompanying documentation and be distributed with binary distributions of the code, so be sure to include this file along with any binary distributions derived from the GNU C Library.

All code incorporated from 4.4 BSD is distributed under the following license:

Copyright (C) 1991 Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. [This condition was removed.] 4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The DNS resolver code, taken from BIND 4.9.5, is copyrighted both by UC Berkeley and by Digital Equipment Corporation. The DEC portions are under the following license: Portions Copyright (C) 1993 by Digital Equipment Corporation. Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software without specific, written prior permission.

THE SOFTWARE IS PROVIDED ``AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

The Sun RPC support (from rpsrc-4.0) is covered by the following license: Copyright (C) 1984, Sun Microsystems, Inc. Sun RPC is a product of Sun Microsystems, Inc. and is provided for unrestricted use provided that this legend is included on all tape media and as a part of the software program in whole or part. Users may copy or modify Sun RPC without charge, but are not authorized to license or distribute it to anyone else except as part of a product or program developed by the user.

SUN RPC IS PROVIDED AS IS WITH NO WARRANTIES OF ANY KIND INCLUDING THE WARRANTIES OF DESIGN, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE.

Sun RPC is provided with no support and without any obligation on the part of Sun Microsystems, Inc. to assist in its use, correction, modification or enhancement.

SUN MICROSYSTEMS, INC. SHALL HAVE NO LIABILITY WITH RESPECT TO THE INFRINGEMENT OF COPYRIGHTS, TRADE SECRETS OR ANY PATENTS BY SUN RPC OR ANY PART THEREOF.

In no event will Sun Microsystems, Inc. be liable for any lost revenue or profits or other special, indirect and consequential damages, even if Sun has been advised of the possibility of such damages. The following CMU license covers some of the support code for Mach, derived from Mach 3.0: Mach Operating System Copyright (C) 1991,1990,1989 Carnegie Mellon University All Rights Reserved. Permission to use, copy, modify and distribute this software and its documentation is hereby granted, provided that both the copyright notice and this permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS ``AS IS" CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Carnegie Mellon requests users of this software to return to: Software Distribution Coordinator School of Computer Science Carnegie Mellon University Pittsburgh PA 15213-3890 or Software. Distribution@CS.CMU.EDU any improvements or extensions that they make and grant Carnegie Mellon the rights to redistribute these changes.

The file if_ppp.h is under the following CMU license: Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY CARNEGIE MELLON UNIVERSITY AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE UNIVERSITY OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The following license covers the files from Intel's "Highly Optimized Mathematical Functions for Itanium" collection: Intel License Agreement Copyright (c) 2000, Intel Corporation All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * The name of Intel Corporation may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL INTEL OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The files inet/getnameinfo.c and sysdeps/posix/getaddrinfo.c are copyright (C) by Craig Metz and are distributed under the following license: /* The Inner Net License, Version 2.00 The author(s) grant permission for redistribution and use in source and binary forms, with or without modification, of the software and documentation provided that the following conditions are met: 0. If you receive a version of the software that is specifically labelled as not being for redistribution (check the version message and/or README), you are not permitted to redistribute that version of the software in any way or form. 1. All terms of the all other applicable copyrights and licenses must be followed. 2. Redistributions of source code must retain the authors' copyright notice(s), this list of conditions, and the following disclaimer. 3. Redistributions in binary form must reproduce the authors' copyright notice(s), this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution. 4. [The copyright holder has authorized the removal of this clause.] 5. Neither the name(s) of the author(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ITS AUTHORS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

If these license terms cause you a real problem, contact the author. */

D.5 GNU general public license, version 2

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it. Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or, Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. If distribution of executable or object code is made

by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and an idea of what it does>

Copyright ©<year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

```
Gnomovision version 69, Copyright (C) year name of author
```

```
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.
```

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

```
Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.
```

```
<signature of TyCoon> 1 April 1989 Ty Coon, President of Vice
```

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

D.6 GNU general public license, version 3

GNU GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright (C) 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The GNU General Public License is a free, copyleft license for software and other kinds of works.

The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program—to make sure it remains free software for all its users. We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors. You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things. To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others. For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or

can get the source code. And you must show them these terms so they know their rights. Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it. For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions. Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users. Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special danger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL assures that patents cannot be used to render the program non-free. The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS

0. Definitions.

"This License" refers to version 3 of the GNU General Public License. "Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks. "The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations. To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work. A "covered work" means either the unmodified Program or a work based on the Program. To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy. Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well. To "convey" a work means any kind of propagation that enables other parties to make or receive copies. Mere interaction with a user through a computer network, with no transfer of a copy, is not conveying. An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion.

1. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work. A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language. The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it. The "Corresponding Source" for a work in object

code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities. However, it does not include the work's System Libraries, or general-purpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work. The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source. The Corresponding Source for a work in source code form is that same work.

2. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are irrevocable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law. You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you. Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary.

3. Protecting Users' Legal Rights From Anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures. When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures.

4. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program. You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee.

5. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions: a) The work must carry prominent notices stating that you modified it, and giving a relevant date. b) The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to "keep intact all notices". c) You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7

additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it. d) If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so. A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, in or on a volume of a storage or distribution medium, is called an "aggregate" if the compilation and its resulting copyright are not used to limit the access or legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate.

6. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways: a) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange. b) Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge. c) Convey individual copies of the object code with a copy of the written offer to provide the Corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b. d) Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain obligated to ensure that it is available for as long as needed to satisfy these requirements. e) Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d. A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work. A "User Product" is either (1) a "consumer product", which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, "normally used" refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial or non-consumer uses, unless such uses represent the only significant mode of use of the product. "Installation Information" for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made. If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of

the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM). The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network. Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying.

7. Additional Terms.

"Additional permissions" are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions. When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission. Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms: a) Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or b) Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or c) Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or d) Limiting the use for publicity purposes of names of licensors or authors of the material; or e) Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or f) Requiring indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors. All other non-permissive additional terms are considered "further restrictions" within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying. If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms. Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way.

8. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11). However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the

copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation. Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice. Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10.

9. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program. Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so.

10. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License. An "entity transaction" is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest, if the predecessor has it or can get it with reasonable efforts. You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it.

11. Patents.

A "contributor" is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's "contributor version". A contributor's "essential patent claims" are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the contributor version. For purposes of this definition, "control" includes the right to grant patent sublicenses in a manner consistent with the requirements of this License. Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version. In the following three paragraphs, a "patent license" is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To "grant" such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party. If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with

the requirements of this License, to extend the patent license to downstream recipients. "Knowingly relying" means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid. If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you grant is automatically extended to all recipients of the covered work and works based on it. A patent license is "discriminatory" if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on the non-exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license (a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or (b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007. Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law.

12. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program.

13. Use with the GNU Affero General Public License.

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such.

14. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation. If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program. Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version.

15. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

17. Interpretation of Sections 15 and 16.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal effect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively state the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found. <one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author> This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program. If not, see <<http://www.gnu.org/licenses/>>. Also add information on how to contact you by electronic and paper mail. If the program does terminal interaction, make it output a short notice like this when it starts in an interactive mode: <program> Copyright (C) <year> <name of author> This program comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details. The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, your program's commands might be different; for a GUI interface, you would use an "about box". You should also get your employer (if you work as a programmer) or school, if any, to sign a "copyright disclaimer" for the program, if necessary. For more information on this, and how to apply and follow the GNU GPL, see <<http://www.gnu.org/licenses/>>. The GNU General Public License does not permit incorporating your

program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License. But first, please read <<http://www.gnu.org/philosophy/why-not-lgpl.html>>.

D.7 GNU lesser general public license, version 2.1

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages—typically libraries—of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it. For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".) "Source

code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

The modified work must itself be a software library.

You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence

you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW.

EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED

INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and an idea of what it does>

Copyright ©<year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail. You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary.

Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library. `Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon> 1 April 1990 Ty Coon, President of Vice

That's all there is to it!

D.8 GNU lesser general public license, version 3

GNU LESSER GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright (C) 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

This version of the GNU Lesser General Public License incorporates the terms and conditions of version 3 of the GNU General Public License, supplemented by the additional permissions listed below.

0. Additional Definitions.

As used herein, "this License" refers to version 3 of the GNU Lesser General Public License, and the "GNU GPL" refers to version 3 of the GNU General Public License. "The Library" refers to a covered work governed by this License, other than an Application or a Combined Work as defined below. An "Application" is any work that makes use of an interface provided by the Library, but which is not otherwise based on the Library. Defining a subclass of a class defined by the Library is deemed a mode of using an interface provided by the Library. A "Combined Work" is a work produced by combining or linking an Application with the Library. The particular version of the Library with which the Combined Work was made is also called the "Linked Version". The "Minimal Corresponding Source" for a Combined Work means the Corresponding Source for the Combined Work, excluding any source code for portions of the Combined Work that, considered in isolation, are based on the Application, and not on the Linked Version. The "Corresponding Application Code" for a Combined Work means the object code and/or source code for the Application, including any data and utility programs needed for reproducing the Combined Work from the Application, but excluding the System Libraries of the Combined Work.

1. Exception to Section 3 of the GNU GPL. You may convey a covered work under sections 3 and 4 of this License without being bound by section 3 of the GNU GPL.

2. Conveying Modified Versions.

If you modify a copy of the Library, and, in your modifications, a facility refers to a function or data to be supplied by an Application that uses the facility (other than as an argument passed when the facility is invoked), then you may convey a copy of the modified version: a) under this License, provided that you make a good faith effort to ensure that, in the event an Application does not supply the function or data, the facility still operates, and performs whatever part of its purpose remains meaningful, or b) under the GNU GPL, with none of the additional permissions of this License applicable to that copy.

3. Object Code Incorporating Material from Library Header Files.

The object code form of an Application may incorporate material from a header file that is part of the Library. You may convey such object code under terms of your choice, provided that, if the incorporated material is not limited to numerical parameters, data structure layouts and accessors, or small macros, inline functions and templates (ten or fewer lines in length), you do both of the following: a) Give prominent notice with each copy of the object code that the Library is used in it and that the Library and its use are covered by this License. b) Accompany the object code with a copy of the GNU GPL and this license document.

4. Combined Works.

You may convey a Combined Work under terms of your choice that, taken together, effectively do not restrict modification of the portions of the Library contained in the Combined Work and reverse engineering for debugging such modifications, if you also do each of the following: a) Give prominent notice with each copy of the Combined Work that the Library is used in it and that the Library and its use are covered by this License. b) Accompany the Combined Work with a copy of the GNU GPL and this license document. c) For a Combined Work that displays copyright notices during execution, include the copyright notice for the Library among these notices, as well as a reference directing the user to the copies of the GNU GPL and this license document. d) Do one of the following: 0) Convey the Minimal Corresponding Source under the terms of this License, and the Corresponding Application Code in a form suitable for, and under terms that permit, the user to recombine or relink the Application with a modified version of the Linked Version to produce a modified Combined Work, in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source. 1) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (a) uses at run time a copy of the Library already present on the user's computer system, and (b) will operate properly with a modified version of the Library that is interface-compatible

with the Linked Version. e) Provide Installation Information, but only if you would otherwise be required to provide such information under section 6 of the GNU GPL, and only to the extent that such information is necessary to install and execute a modified version of the Combined Work produced by recombining or relinking the Application with a modified version of the Linked Version. (If you use option 4d0, the Installation Information must accompany the Minimal Corresponding Source and Corresponding Application Code. If you use option 4d1, you must provide the Installation Information in the manner specified by section 6 of the GNU GPL for conveying Corresponding Source.)

5. Combined Libraries.

You may place library facilities that are a work based on the Library side by side in a single library together with other library facilities that are not Applications and are not covered by this License, and convey such a combined library under terms of your choice, if you do both of the following: a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities, conveyed under the terms of this License. b) Give prominent notice with the combined library that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

6. Revised Versions of the GNU Lesser General Public License.

The Free Software Foundation may publish revised and/or new versions of the GNU Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Library as you received it specifies that a certain numbered version of the GNU Lesser General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that published version or of any later version published by the Free Software Foundation. If the Library as you received it does not specify a version number of the GNU Lesser General Public License, you may choose any version of the GNU Lesser General Public License ever published by the Free Software Foundation. If the Library as you received it specifies that a proxy can decide whether future versions of the GNU Lesser General Public License shall apply, that proxy's public statement of acceptance of any version is permanent authorization for you to choose that version for the Library.

D.9 PHP license

The PHP License, version 3.01

Copyright (c) 1999 - 2010 The PHP Group.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, is permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

The name "PHP" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact group@php.net.

Products derived from this software may not be called "PHP", nor may "PHP" appear in their name, without prior written permission from group@php.net. You may indicate that your software works in conjunction with PHP by saying "Foo for PHP" instead of calling it "PHP Foo" or "phpfoo".

The PHP Group may publish revised and/or new versions of the license from time to time. Each version will be given a distinguishing version number. Once covered code has been published under a particular version of the license, you may always continue to use it under the terms of that version. You may also choose to use such covered code under the terms of any subsequent version of the license published by the PHP Group. No one other than the PHP Group has the right to modify the terms applicable to covered code created under this License.

Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes PHP software, freely available from <http://www.php.net/software/>".

THIS SOFTWARE IS PROVIDED BY THE PHP DEVELOPMENT TEAM ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PHP DEVELOPMENT TEAM OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software consists of voluntary contributions made by many individuals on behalf of the PHP Group.

The PHP Group can be contacted via Email at group@php.net.

For more information on the PHP Group and the PHP project, please see <http://www.php.net/>.

PHP includes the Zend Engine, freely available at <http://www.zend.com/>.

A

accuracy, survey, 38
 adjusting heave
 parameters, 56
 alarm message reception,
 how to select, 85
 antenna location
 parameters, how to enter, 46
 antenna offset, 46
 antenna parameters, 48
 assembly, sensor unit, 92
 authorisation, radio
 frequency, 17

B

backup of software
 configuration, 86
 Binary format 23, 114
 Binary format 26, 116
 broadcast, 63

C

cable specifications, 101
 Calibration Wizard, sensor
 unit antenna parameters, 48
 centre of gravity (CG), 43
 changing system mode, 42
 clock synchronization, 13
 common reference point,
 CRP, 32
 communication interface,
 description, 61
 communication interface,
 how to set up, 62
 communication interfaces, 61
 Compass view appearance,
 how to select, 81
 configuration backup, how
 to create, 86
 configuration backup, how
 to restore, 87
 configuration management
 system, how to enter, 40
 configuration via NAV
 Engine, 43
 configuration via operator
 software, 77
 configuring operator
 software for operational
 use, 77
 configuring sensor unit for
 operational use, 43
 connecting operator
 software to sensor unit, 83
 connecting to a network, 68
 connectors, subsea bottle, 23

contact details, 14
 correction satellite, 78
 creating configuration
 backup, 86
 CRP, common reference
 point, 32
 cyclic redundancy check, 127

D

data input, sensor unit, 101
 datum, 65
 datum specifications,
 sensor unit, 101
 definition, vessel reference
 system, 32
 deleting monitoring points, 60
 description, mgc, 11
 description, operator
 software configuration, 40
 description, sensor unit, 11
 description, spider cable, 12
 description, system, 8
 determining MGC
 mounting angles, 53
 determining, distance
 vectors, 37
 determining, sensor unit
 mounting orientation, 35
 DGNS correction link,
 how to set up, 67
 dimension specifications, 97
 dimensions, 89
 dimensions, sensor unit,
 90–91, 98
 disposal of electrical
 components, 104
 distance vectors, how to
 determine, 37
 drawings, 17, 89

E

elevation mask, 79
 enabling high precision
 services, 74
 entering antenna location
 parameters, 46
 entering sensor unit
 location parameters,
 46
 entering the configuration
 management system, 40
 entering vessel
 identification parameters, 70
 environmental
 specifications, 99

environmental
 specifications, sensor
 unit, 99
 equipment handling, 104
 Ethernet interface, how to
 use, 63
 export license, 7
 export restrictions, 12

F

free and open source
 software, 135
 frequencies, GNSS
 antenna, 100
 Fugro high precision
 services, how to enable, 74

G

gateway, 68
 GNSS antenna,
 frequencies, 100
 guarantee, restrictions, 13
 gyro interface, how to set
 up, 75

H

handling, equipment, 104
 heading input from gyro
 compass, how to select, 75
 heading offset, 46
 heave filter options, 56
 heave parameters, how to
 adjust, 56
 heave period, 57
 heave, Automatic mode, 57
 heave, General purpose
 mode, 57
 heave, GNSS aided mode, 57
 heave, Hydrographic
 survey mode, 56
 high precision services,
 how to enable, 74
 how to mount, sensor unit, 20
 how to, adjust heave
 parameters, 56
 how to, change system
 mode, 42
 how to, configure operator
 software for operational
 use, 77
 how to, configure sensor
 unit for operational use, 43
 how to, connect the
 operator software to
 the sensor unit, 83

- how to, connect to a network, 68
- how to, create configuration backup, 86
- how to, delete monitoring points, 60
- how to, determine distance vectors, 37
- how to, determine sensor unit mounting orientation, 35
- how to, dispose of electrical components, 104
- how to, enable high precision services, 74
- how to, enter antenna location parameters, 46
- how to, enter sensor unit location parameters, 46
- how to, enter the configuration management system, 40
- how to, enter vessel identification parameters, 70
- how to, import vessel shape from file, 70
- how to, install MGC subsea bottle, 22
- how to, install Seapath operator software, 24
- how to, power on/off the sensor unit, 24
- how to, restore configuration backup, 87
- how to, select alarm message reception, 85
- how to, select appearance of Compass view, 81
- how to, select appearance of Integrity view, 80
- how to, select appearance of Sky View, 78
- how to, select heading input from gyro compass, 75
- how to, select presentation of view in display, 77
- how to, select SBAS satellites, 73
- how to, select UTM presentation, 82
- how to, set MGC location, 51
- how to, set MGC mounting angles, 51
- how to, set monitoring points, 58

- how to, set up a communication interface, 62
- how to, set up DGNSS correction link, 67
- how to, set up gyro interface, 75
- how to, set up MGC to be inertial navigation system, 76
- how to, set up telegram out interface, 64
- how to, set vessel dimensions, 43
- how to, set vessel reference points, 43
- how to, survey MGC subsea bottle, 34
- how to, survey sensor unit, 36
- how to, terminate sensor unit cable, 19
- how to, uninstall Seapath operator software, 25
- how to, use calibration wizard to determine sensor unit antenna parameters, 48
- how to, use the Ethernet interface, 63
- how to, use the serial interface, 62
- how to, use wizard to determine MGC mounting angles, 53
- how to, verify Seapath for operational use, 40

I

- importing vessel shape from file, 70
- inertial navigation system, how to set up MGC, 76
- installation summary, 18
- installation, sensor unit, 20
- installing MGC subsea bottle, 22
- installing Seapath operator software, 24
- Integrity view appearance, how to select, 80
- interface specifications, sensor unit, 97
- IP address, 13, 68
- IP address, default sensor unit IP address, 69

K

- KM binary format, 118

L

- license information, 7
- license, export, 7
- local area network (LAN), 14
- location MGC, how to set, 51
- location, sensor point, 93
- location, sensor unit, 17
- location, system parts, 17

M

- maintenance, 7
- manual, purpose, 7
- mechanical dimensions, 89
- mechanical installation, 20
- MGC location, how to set, 51
- MGC mounting angle , how to set, 51
- MGC mounting angles, how to determine with wizard, 53
- MGC transportation container, 16
- MGC unit, power specifications, 98
- mgc, description, 11
- mode, system modes, 42
- monitoring points, how to delete, 60
- monitoring points, how to set, 58
- mounting angles MGC, how to determine with wizard, 53
- mounting anglesMGC, how to set, 51
- mounting the sensor unit, 20
- Mounting Wizard, MGC mounting angles, 53
- multicast, 63

N

- NAV Engine configuration, 43
- NAV Engine configuration, Advanced, 40
- NAV Engine configuration, Standard, 40
- navigation reference point (NRP), 43
- network security, 14
- network, how to connect to, 68
- NMEA telegram, 65
- NTP server, 13

O

operational use, how
to configure operator
software, 77

operational use, how to
configure sensor unit, 43

operational use, how to
verify that Seapath is
ready, 40

operator software
configuration, 40, 77

operator software
configuration description, 40

operator software, how to
connect to sensor unit, 83

operator software, how to
install, 24

operator software, how to
uninstall, 25

origin, 38

origin location in drawing, 43

output protocols, 105

output protocols, sensor
unit, 100

P

parts, location, 17

password, 42

performance
specifications, 96

PFreeHeave format, 126

pin configuration, subsea
bottle, 23

pitch, 53

power specifications, 98

power specifications, MGC
unit, 98

power specifications,
sensor unit, 98

power wiring, sensor unit, 24

powering the sensor unit
on/off, 24

pre-installation, 16

preparations, 16

purpose of manual, 7

R

radio frequency,
authorisation, 17

radio frequency,
specifications, 99

RDI ADCP format, 123

restore of software
configuration, 87

restoring configuration
backup, 87

restrictions, 12

restrictions, guarantee, 13

roll, 53

roll/pitch dependent, 57

S

satellite track plot length, 79

SBAS satellites, how to
select, 73

scope of supply, 12

selecting alarm message
reception, 85

selecting Compass view
appearance, 81

selecting heading input
from gyro compass, 75

selecting Integrity view
appearance, 80

selecting presentation view
in display, 77

selecting SBAS satellites, 73

selecting Sky View
appearance, 78

selecting UTM
presentation, 82

sensor point location, 93

sensor unit antenna
parameters, 48

sensor unit cable, how to
terminate, 19

sensor unit cable,
specifications, 101

sensor unit installation, 20

sensor unit location, 17

sensor unit location
parameters, how to enter, 46

sensor unit mounting
orientation, how to
determine, 35

sensor unit, assembly, 92

sensor unit, cable
termination, 19

sensor unit, data input, 101

sensor unit, datum
specifications, 101

sensor unit, default IP
address, 69

sensor unit, description, 11

sensor unit, dimensions,
90–91, 98

sensor unit, environmental
specifications, 99

sensor unit, how to mount, 20

sensor unit, how to power
on/off, 24

sensor unit, how to survey, 36

sensor unit, interface
specifications, 97

sensor unit, output
protocols, 100

sensor unit, power
specifications, 98

sensor unit, power wiring, 24

serial interface, how to use, 62

setting MGC location, 51

setting MGC mounting
angles, 51

setting monitoring points, 58

setting to work, summary, 39

setting up a communication
interface, 62

setting up DGNSS
correction link, 67

setting up the gyro
interface, 75

setting up the MGC as an
INS, 76

setting up the telegram out
interface, 64

setting vessel dimensions, 43

setting vessel reference
points, 43

shadow sector, 79

shape dimensions, 43

shape type, 43

signal strength, 78

Simrad EM3000 format, 118

skills, workers, 17

Sky View appearance, how
to select, 78

software configuration
backup, 86

software configuration
restore, 87

specifications, 96

specifications, cable, 101

specifications, dimensions, 97

specifications,
environmental, 99

specifications, power, 98

specifications, radio
frequency, 99

specifications, sensor unit
cable, 101

specifications, system
performance, 96

specifications, umbilical
cable, 102

spider cable schematics, 94–95

spider cable, description, 12

standard NAV Engine
configuration, 40

standard parts, 12

storage, equipment, 104

- subnet mask, 68
- subsea bottle, connectors, 23
- subsea bottle, how to install, 22
- subsea bottle, pin configuration, 23
- summary of installation, 18
- support information, 14
- survey accuracy, 38
- survey, sensor unit, 36
- system description, 8
- system diagram, 9
- system mode, how to change, 42
- system modes, 42
- system modes, how to change, 42
- system parts, location, 17
- system units, 11

T

- target audience, 7
- technical specifications, 96
- telegram out interface, how to set up, 64
- telegram out options, 129
- terminating sensor unit cable, 19
- tools and equipment, 16
- transportation container for MGC, 16

U

- UDP Broadcast, 85
- UDP Multicast, 85
- umbilical cable, specifications, 102
- unicast, 63
- uninstalling Seapath operator software, 25
- use, restrictions, 13
- using the Ethernet interface, 63
- using the serial interface, 62
- UTM options, 82
- UTM presentation, how to select, 82

V

- verifying that Seapath is ready for operational use, 40
- vessel dimensions, how to set, 43
- vessel identification parameters, how to enter, 70

- vessel reference points, how to set, 43
- vessel reference system, definition, 32
- vessel shape from file, how to import, 70
- view placement in display, how to select, 77

W

- wiring, sensor unit power, 24
- worker skills, 17

X

- XP/G2/G4, 74

Y

- yaw, 53

Z

- zone options, UTM, 82

©2024 Kongsberg Discovery