




KONGSBERG

# Instruction Manual

## HPR 400P series

### Portable Acoustic Positioning System





# **HPR 400P series**

## Portable Acoustic Positioning System

Instruction Manual

### **Note**

Kongsberg Maritime AS makes every effort to ensure that the information contained within this document is correct. However, our equipment is continuously being improved and updated, so we cannot assume liability for any errors which may occur.

### **Warning**

The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment or injury to personnel. The user must be familiar with the contents of the appropriate manuals before attempting to install, operate or maintain the equipment.

Kongsberg Maritime AS disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.

### **Copyright**

© 2004 Kongsberg Maritime AS

The information contained within this document remains the sole property of Kongsberg Maritime AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within is not to be communicated to a third party, without the prior written consent of Kongsberg Maritime AS.

### **Contact information**

**Support:** ui@kongsberg.com

**Sales:** subsea@kongsberg.com

#### **Kongsberg Maritime AS**

Strandpromenaden 50  
P.O.Box 111  
N-3191 Horten,  
Norway

Telephone: +47 33 02 38 00  
Telefax: +47 33 04 47 53  
**www.kongsberg.com**  
E-mail: subsea@kongsberg.com



**KONGSBERG**

## Sections

This manual describes the maintenance and set-up of the HPR 400P Hydroacoustic Positioning Reference system. The maintenance philosophy is based on the system's built-in test equipment (BITE) for self diagnostics. The maintenance technician is only expected to replace modules and units.

### **1 Introduction**

*Introduction to the manual.*

### **2 HPR 400P System description**

*This section describes the HPR 400P system.*

### **3 System set-up**

*This section includes the general procedure for connecting and setting-up the system.*

### **4 Maintenance**

*This section describes the maintenance which the operator is expected to be able to perform. Detailed mechanical and electrical maintenance should be performed by a specialist engineer.*

### **5 HPR 400 Transceiver Unit**

*This section gives a technical description of the HPR 400 Transceiver Unit, using text and block diagrams. The section includes disassembly and reassembly instructions.*

### **6 Technical specifications**

*This section presents the technical specifications for the complete system.*

### **7 Spare parts**

*This section contains a list of the spare parts available for the HPR 400 Portable system.*

### **8 Drawings**

*This section contains drawings of the system and transducers.*

### **9 Index**

*Index.*

## Additional manuals

### **Operator station (HSC 400) - Compact PC manual**

*Manual supplied with the Compact PC. This is not a Kongsberg Maritime document.*

### **WhiteHEAD / USB manual**

*Manual supplied with the unit. This is not a Kongsberg Maritime document.*

## Remarks

### References

Further information about the HPR 400P system may be found in the following manuals:

- APOS Instruction manual

### The reader

This maintenance manual is intended to be used by a trained maintenance technician or engineer, with experience of electronic and digital circuitry, computers and electromechanical design. The level of information is based on Kongsberg Maritime's maintenance philosophy: The onboard technical personnel shall, with the help of the documentation and the system's built-in test functions, be able to identify malfunctions, locate the fault, and replace major parts, modules and components on the "Line Replaceable Unit (LRU)" level. He/she will however not attempt to repair the LRUs.

# Contents

<b>INTRODUCTION</b> .....	<b>1</b>
Overview .....	1
List of abbreviations .....	1
<b>SYSTEM DESCRIPTION</b> .....	<b>2</b>
Overview .....	2
Description .....	2
HPR 400 portable systems .....	3
HPR 410P - SSBL .....	4
HPR 418P - combined LBL and SSBL .....	5
HPR 408P- LBL surface system .....	6
HPR 408P subsea system .....	7
HPR 400P cabinet .....	8
HPR 400 Transceiver Unit .....	9
Operator station - HSC 400 .....	9
Transducers .....	9
Overview .....	9
PMT 301 Portable Mini Transducer .....	9
Dunking transducer .....	9
Standard transducer (wide/medium) .....	10
Narrow beam transducer (wide/narrow) .....	10
Transponders .....	10
External sensors (options) .....	10
Vertical Reference Unit (VRU) .....	10
Gyro .....	10
<b>SYSTEM SET-UP</b> .....	<b>11</b>
Overview .....	11
System set-up .....	12
Transceiver unit connections .....	14
Cable connections .....	14
Transducers .....	15
Getting started .....	15
Modes .....	16
Cables and connectors .....	17
General .....	17
Internal cables .....	17
External cables .....	18
Connections .....	19
Transceiver unit .....	19
Operator station - HSC 400 .....	21

Cables .....	22
Standard cables .....	22
Serial line cables .....	22
Transceiver unit - responder cables J .....	23
Transceiver unit pin allocations .....	24
Introduction .....	24
Serial 1 .....	24
Serial 2 .....	24
Serial 3 .....	24
Serial 4 .....	25
Serial 5 .....	25
Serial 6 .....	25
Parallel .....	25
Analogue I/O .....	26
Gyro/syncro .....	26
Responder 1 - 4 .....	27
Transducers 1 and 2 .....	27
Transducers 3 and 4 .....	27
Operator station pin allocations .....	28
Com 1, 2 and 3 .....	28
LPT 1 .....	28
VGA .....	29
WhiteHEAT/USB .....	29
<b>MAINTENANCE .....</b>	<b>30</b>
General .....	30
Maintenance philosophy .....	30
Preventive maintenance .....	30
Corrective maintenance .....	31
Tools .....	31
Transceiver unit .....	31
WhiteHEAT/USB .....	31
Operator station .....	31
Alarm and event messages .....	31
Winch unit .....	32
General .....	32
Cable drum .....	32
Transducer .....	33
General .....	33
Cleaning the transducers .....	33
Replacement of the transducer .....	33
Replacement of transceiver unit parts .....	34
Overview .....	34



Replacement of circuit boards and software .....	34
How to remove a circuit board .....	34
Software .....	35
How to remove the backplane .....	36
Replacement of the backplane .....	37
Replacement of circuit boards .....	37
Fuses .....	38
Location .....	38
Replacement .....	38
<b>HPR 400 TRANSCEIVER UNIT .....</b>	<b>40</b>
Design .....	40
External connections .....	40
Power supply .....	40
Maintenance .....	40
Theory of operation .....	41
Introduction .....	41
Navigation .....	41
Telemetry .....	41
Circuit board identification and main functions .....	42
Internal layout .....	44
Backplane .....	46
InputM .....	61
Analogue digital converter (ADCM) .....	63
Board description .....	63
Digital signal processor (DSPM 50) .....	64
Transmitter (TXM) .....	66
“Powerbox” AC power supply .....	68
Control Processor Unit (CPUEx) .....	70
Input/output board (IO/M) .....	72
Responder controller (RPC) board (option) .....	74
DC power supply (DC - PWR) .....	76
<b>TECHNICAL SPECIFICATIONS .....</b>	<b>78</b>
SSBL Accuracy .....	78
LBL accuracy .....	78
Range capabilities .....	80
HPR 400 portable unit .....	81
HPR 400 Transceiver Unit .....	82
Operator station - HSC 400 .....	83

Multi-port Serial Adapter for USB (WhiteHEAT-4/USB) .....	84
Transducers .....	85
General .....	85
PMT 301 - Portable Mini Transducer .....	85
Standard MF (wide/medium beam) transducer .....	86
MF (wide/narrow beam) transducer .....	86
LF (wide beam) transducer .....	86
Dunking transducers .....	87
RTD 333 - ROV Transducer .....	87
<b>SPARE PARTS .....</b>	<b>88</b>
Overview .....	88
HPR 400 Transceiver unit .....	89
Fuses .....	89
Operator station - HSC 400 .....	90
WhiteHEAT/USB .....	90
Standard transducers .....	90
Dunking transducers .....	90
RTD 333 - ROV Transducer .....	90
<b>DRAWINGS .....</b>	<b>91</b>
Overview .....	91
Cables and interconnections .....	91
Standard transducers .....	91
Dunking transducers .....	91
Miscellaneous .....	91
<b>INDEX .....</b>	<b>106</b>

## Document logistics

Rev	Date	Written	Checked	Approved
A	06.12.00	GM	RA	JEF
B	15.02.02	GM	EB	JEF
C	06.03.03	GM	EB	JEF
D	05.05.04	GM	THG	JEF
E				
F				
G				

(The original signatures are recorded in the company's logistic database.)

Rev	Comments
A	Original issue.
B	Technical data updated. Reduced PCBs information. Contents reorganised. New layout.
C	Implemented portable system with HPR 400 Subsea unit and technical specifications for the Inclinator. Updated and reorganised technical specifications. Minor corrections in the text. Ref. EM 857-164388C.
D	Implemented new operator station - Compact PC with USB. Updated various illustrations. Ref. EM 857-164388D.

**Blank page**

# INTRODUCTION

## Overview

This document describes the Kongsberg Maritime HPR 400 Portable Underwater Positioning and Navigation Systems using the following operating modes:

- Super Short Base Line (SSBL)
- Long Base Line (LBL)
- Combined Long and Super Short Base Line (LSSBL)

## List of abbreviations

APOS	Acoustic Positioning Operator Station
DGPS	Differential Global Positioning System
HiPAP	High Precision Acoustic Positioning
HPR	Hydroacoustic Position Reference
HPR 400S	Hydroacoustic Positioning Reference Subsea System
LBL	Long Base Line
LF	Low Frequency
MF	Medium Frequency
MPT	Multifunction Positioning Transponder
N/A	Not Applicable
ROV	Remotely Operated Vehicle
SSBL	Super Short Base Line
TP	TransPonder
TU	Transceiver Unit

## SYSTEM DESCRIPTION

### Overview

This section gives a short description of the HPR 400P system.

### Description

A **HPR 400P unit** is assembled in a rugged, splash-proof, shock resistant and "all in one" portable cabinet.

The portable cabinet is equipped with strong carrying handles and has detachable covers in front and rear.



*Figure 1 Portable cabinet*

Together with applicable software and a selection of transducers, the systems are easy to move by simply interfacing the applicable transducer to the back-plane of the HPR portable unit.

The transducer may be deployed from any vessel or platform.

All HPR 400 P systems are based around the same portable electronic cabinet, but software and transducer interfaces will vary.

All the HPR 400P systems can be directly interfaced to a Differential Global Positioning System (DGPS) receiver, making it possible to give transponder position, Super Short Base Line (SSBL) or vessel position, Long Base Line (LBL) in UTM coordinates.

**A complete HPR portable system comprises:**

- HPR 400 Portable unit, including;
  - HPR 400 transceiver Unit
  - Operator station (Compact PC)
  - Multi-port serial adapter for USB
- Transducer with cable
- Transponder(s)

## **HPR 400 portable systems**

The HPR 400 portable systems available are:

- **HPR 410P** - Portable SSBL system, with portable transducer.
- **HPR 408P:**
  - Portable LBL system with dunking transducer.
  - Portable LBL system with subsea transceiver (HPR 400S).
- **HPR 418P** - Portable combined LBL/SSBL system with Portable Mini Transducer.

## HPR 410P - SSBL

The HPR 410P system is normally delivered with a **transducer** and cable.




Figure 2 HPR 410 / 418 Portable system

The **HPR 410P** - is the SSBL system. Together with dedicated SSBL software and the Portable Mini Transducer (PMT 301), a single compact transducer unit, it is applicable as a stand-alone underwater navigation system.

- The calculation of position is based on range, vertical and horizontal angle measurements, giving three-dimensional transponder positions relative to the system's transducer.
- The beam-pattern of the PMT 301 transducer is omni-directional and will cover the whole 160° hemisphere below the vessel. This means that the system has high sensitivity in all planes, both for transponder signals and for noise coming in. The system will therefore be more sensitive to noise from the vessels propellers than systems with more directive beam pattern. This is why we do not recommend this transducer for critical operations like for instance being a reference to a DP system. For such operations, optional beam-forming transducers are available.



- The transducer is supplied with an underwater connector and a handy mounting bracket, which allows a very easy installation to any pole or shaft over the side of a vessel. The transducer and the bracket comes in a robust carrying case.
- A built-in roll and pitch sensor, designed around highly accurate electronic inclinometers is in the transducer, and enables the system to automatically compensate for any vertical misalignment of the transducer/transducer-pole, as well as compensation of roll and pitch movements.

### **HPR 418P - combined LBL and SSBL**

The 418P system is normally delivered with a **transducer** and cable (as for the HPR 410 system).

→ *See figure on page 4.*

The **HPR 418P** - is a powerful portable underwater positioning system. It is capable of solving most underwater positioning applications. The system is a combination of the HPR 408P and HPR 410P, and can work in a combined mode using a SSBL transducer.

For details, see the HPR 408P and HPR 410P information.

- *For more information on the HPR 400S system, refer to the HPR 400S Instruction manual.*
- *For APOS start-up, refer to the APOS Instruction manual.*
- *For APOS operation, refer to the APOS on-line help.*

### HPR 408P- LBL surface system

This HPR 408P system is normally delivered with a **transducer** and a cable with cable drum.




Figure 3 HPR 408 Portable system

The **HPR 408P** - is a stand-alone portable LBL system. By using LBL software and dedicated over-the-side (Dunking Transducer), the system becomes a surface system for any LBL or telemetry application.

The HPR 408P system can also be delivered with a subsea transceiver (HPR 408S) connected to the Portable unit, and this will be suitable for Remotely Operated Vehicle (ROV) LBL positioning, as well as for any other subsea module positioning requiring LBL accuracy's.

→ See figure on page 7.

Both systems will then be operated from the same Operator station.

With their comprehensive manuals and self-explanatory operating menu, the LBL systems are considered to be very user friendly.

### HPR 408P subsea system

This HPR 408P system, is delivered with a subsea transceiver and transducer.

Note

*The Subsea Transceiver Unit and dedicated transducer are described in the HPR 400S Instruction manual.*




Figure 4 HPR 408Portable system

## HPR 400P cabinet

The HPR 400P cabinet includes the transceiver unit and the operator station. The Transceiver unit is placed at the top, and the operator station at the bottom. This is shown in the figure below, where the front cover is removed.



*Figure 5 HPR 400P cabinet - front*

As shown on the figure below, the connectors for all interfaces are made easily available from the rear, and the power cable is placed in the rear cover.



*Figure 6 HPR 400P cabinet -rear*

## **HPR 400 Transceiver Unit**

The Transceiver is the acoustic signal processor with transmitter and receiver electronics and software. It processes the acoustic signals, calculates the transponder position(s) and the acoustic telemetry data, and sends the information to the portable PC where it is presented on the display.

- The transceiver has interfaces for the transducer(s), a gyro and a pitch / roll sensor.
- It can operate up to four transducers with up to 56 + 14 transponders simultaneously.
- The acoustic telemetry functions are also controlled from this unit, using the same transducers.

## **Operator station - HSC 400**

The operator station, the HTC 400 is a portable computer, and it contains the APOS (system) software.

→ *For more information about the Portable PC, refer to separate manual.*

## **Transducers**

### **Overview**

Several SSBL and LBL transducer types are available, and can be supplied with the system.

A standard transducer mounted on a hull unit may also be used if required. This would enable the portable system to be used as an emergency system if the standard system should develop a fault. These are not described in this manual.

### **PMT 301 Portable Mini Transducer**

The HPR 410P is normally delivered with the PMT 301 Portable Mini Transducer. This transducer can be used for SSBL and LBL operation.

### **Dunking transducer**

Several types of dunking transducers are available. These are used for LBL or telemetry operation.

A portable transducer is connected onto a 70 m transducer cable which is held on a cable drum. The transducer must be lowered to a depth well below the lowest point of the vessel's hull. The "free end" of the cable must be connected to the transceiver unit.

### **Standard transducer (wide/medium)**

This transducer can be used for LBL and SSBL operations. The HPR 400 system then requires an external VRU.

### **Narrow beam transducer (wide/narrow)**

This transducer can be used for LBL and SSBL operations. The HPR system then requires an external VRU.

## **Transponders**

→ *Refer to separate transponder manuals.*

## **External sensors (options)**

### **Vertical Reference Unit (VRU)**

A Vertical Reference Unit (VRU) can be interfaced to the HPR 400P transceiver if required. The system can thereby automatically compensate for the vessel's roll and pitch movements. The HPR 400 system can use the same VRU as the Dynamic Positioning (DP) system (if one is fitted).

The MPT 301 transducer contains a built-in roll / pitch sensor (Shaevitz).

### **Gyro**

A number of different gyro types can be interfaced to the HPR 400P transceiver if required (syncro or serial).

## **SYSTEM SET-UP**

### **Overview**

This section describes the set-up and getting started procedures for the HPR 400P system. A description of the cables and the interconnections between the units is also included.

## System set-up

Place the HPR 400P unit on a reasonably level and stable surface, and proceed as follows:

- 1 Remove the front and rear covers of the cabinet.
  - You now have access to the operator station (HSC 400) and the transceiver unit.




Figure 7 Getting ready

- 2 Extract the operator station drawer. (A).
- 3 Undo the transportation straps (B).



- 4 Lift the operator station out of the drawer (C).
  - Ensure the operator station cable is connected.
- 5 Place the operator station on a desktop or a suitable workbench (D).
- 6 At storage and transportation, you are advised to strap the cable together with the operator station as illustrated on the figure below.



*Figure 8 Operator station and cable*

## Transceiver unit connections




Figure 9 HPR 400 Transceiver Unit - rear side, showing connections for a MPT 301 transducer

- A** Securing nuts for capacitors located inside of the transceiver unit rear panel.
- B** Cable between the transceiver unit and the operator unit via USB.
- C** Cable between the operator unit and the transceiver unit via USB.
- D** USB
- E** Transducer cable
- F** HPR 400P power

### Cable connections

- 1** Check the portable unit internal connections.
- 2** Connect the required transceiver unit interface cables
  - **Standard cables**
    - \* Transducer cable(s)
    - \* 230 Vac supply
  - **Options**
    - \* Gyro compass
    - \* Vertical reference sensor (VRU)  
(Included in the PMT 301 transducer cable)
    - \* Serial line to external computer

- \* Responder(s)  
(requires an optional responder board)
- \* External VGA monitor
- \* Printer
- \* Depth

Note

*Only the standard cables are described in this document.*

→ *Refer to section on page 18.*

## Transducers

### PMT 301 Portable Mini Transducer

The portable unit must be placed close to the ships' railing to ensure correct use of the transducer.

- 1 Lower the transducer into the sea.
- 2 When lowered into position, the cable must be securely fastened to the ship railing.
- 3 Ensure no sharp edges can cut the cable.

### Dunking transducer

The portable unit must be placed close to the ships' railing to ensure correct use of the dunking transducer.

- 1 Lower dunking transducer is lowered into the sea.
  - Two persons should participate. One person lowering the cable by hand, the other loosening the cable from the cable drum.
  - The hand crank on the drum is only for helping the cable on/off, as the transducer is too heavy for crank handling only.
- 2 When fully lowered, tightened the drum locking pin. In addition:
  - The cable must be securely fastened to the ship railing.
  - Ensure no sharp edges can cut the cable.

## Getting started

To switch on the HPR 400P, perform the procedure below:

- 1 Switch on the transceiver unit using the switch on the front panel.
- 2 Switch on the computer using the *Power on* switch.
- 3 Wait for the system to run up and boot. Once the **Positioning** picture is displayed on the screen, the system is ready for use.

→ *Refer to the APOS Instruction manual / APOS on-line help operation.*

## Modes

### Standby mode

The **Standby** mode is a condition in which the PC reduces its power usage by switching off most of its components when it has not been used for a set period of time. This condition is practical if you should leave the PC running unattended for short periods.

The mode can be initiated by pressing the **Standby** mode button. When you exit the mode (by pressing the button again) the information will be brought back to the display. With a fully charged battery, the PC can remain in the **Standby** mode for up to 120 hours.

### Dormant mode

The **Dormant** mode is a condition in which the computer stores all the information in the system memory, on the hard disk.

When you switch power on to the PC, all the information is returned to the system memory, such that the computer returns to the point in the program/document at which the dormant mode was initiated. The computer can remain in the **Dormant** mode for an unlimited period, as long as the battery is not discharged.

## Cables and connectors

### General

All standard cables delivered with the system are indicated in the figure below.




Figure 10 Standard cables for a HPR 400 Portable system

### Internal cables

#### Cable A

#### Standard RS-232 Serial line cable

- Included with the delivery.
- $3 \times 2 / 0.5 \text{ mm}^2$ , overall braided screen, 60 V.
- RFI screen must be connected to the plug housing.

**Cable B**                      **Standard USB cable**

- Included with the delivery.

**Cable X**                      **Braided grounding cable to connect the unit to EMC ground**

- Included with the delivery (Kongsberg Simrad part no.649-096720).
- 2 x 7 mm.
- Maximum length: 1 m.

**External cables**

**Cable C**                      **230 Vac power supply to the Compact PC**

- Included with the delivery.
- 3 x 1 / 1.5 mm<sup>2</sup> with ground as separate conductor, 750 V.
- Maximum length: No practical limits.

**Cable H**                      **230 Vac power supply to the transceiver unit**

- Included with the delivery.
- 3 x 1 / 1.5 mm<sup>2</sup> with ground as separate conductor, 750 V.
- Maximum length: No practical limits.

**Cable K**                      **Transducer cable from the transceiver unit to the transducer**

- Included with the delivery.
- System specified.

## Connections

Both the HPR 400 Transceiver Unit and the computer have a number of rear-mounted connectors. These can be used to connect a variety of different units and systems into the HPR 400P.

### Transceiver unit

All connections to and from the HPR 400 Transceiver Unit are made on the connection panel on the rear of the unit. All connectors are male except where stated female.




Figure 11 Connectors on the HPR Transceiver Unit's rear panel

The transceiver unit holds the following connectors and fuses used with a HPR 400 P system (top to bottom, left to right when looking at the rear panel):

- 1 Standard 3-pin, 230 Vac, 50/60 Hz mains power in.
- 2 Fuse, 230 Vac, 2 A.
- 3 Fuse, 230 Vac, 2 A.
- 4 9-pin D-connector for Serial line 1.
  - This connector is used to communicate with the PC.
- 5 9-pin D-connector for Serial line 2.
  - This connector is not used with the HPR 400 P.
- 6 9-pin D-connector for Serial line 3.
  - This connector is used to connect a serial line gyro, or any of the following Vertical Reference Unit types: MRU or Seapath.
- 7 9-pin (Seatex) D-connector for Serial line 4.
  - This connector is not used with the HPR 400 P.
- 8 9-pin D-connector for Serial line 5.
  - This connector is not used with the HPR 400 P.

- 9** 9-pin D-connector for Serial line 6.
  - This connector is not used with the HPR 400 P.
- 10** 25-pin D-connector for Parallel input.
  - This connector is not used with the HPR 400 P.
- 11** 25-pin D-connector for Analogue input/output.
  - Piro  $40 \pm 15^\circ$
  - Piro  $40 \pm 90^\circ$
  - PMT Accustar  $\pm 60^\circ$
  - Shaevitz  $\pm 4.5^\circ$
  - MRU  $\pm 20^\circ$
- 12** 15-pin D-connector for Gyro input (syncro)
- 13** 3-pin Amphenol connector for Responder 1. (Optional)
- 14** 3-pin Amphenol connector for Responder 2.
- 15** 3-pin Amphenol connector for Responder 3.
- 16** 3-pin Amphenol connector for Responder 4.
- 17** 3-pin Amphenol connector for Transducer 3.
  - This transducer connector is used with dunking transducers.
- 18** 3-pin Amphenol connector for Transducer 4.
  - This transducer connector is used with dunking transducers.
- 19** 35-pin Amphenol connector for Transducer 1.
  - This transducer connector is used with PMT 301, SSBL MF medium, SSBL MF narrow and SSBL LF medium transducers.
- 20** 35-pin Amphenol connector for Transducer 2.
  - This transducer connector is used with PMT 301, SSBL MF medium, SSBL MF narrow and SSBL LF medium transducers.

All connectors are marked with labels as indicated on the previous drawing.



## **Operator station - HSC 400**

The portable computer has rear-mounted connectors.

Note

*Different portable computers may be used on the HPR 400P system. The physical location of the connectors may therefore differ from type to type.*

→ *Refer to separate documentation.*

## Cables

### Standard cables

The following cables are regarded as *standard*, and are connected into the appropriate sockets on the rear of the Compact computer:

**C** 230 Vac to the Compact PC

Different connector types are used on the various cables to ensure the correct connections.

The following cables are included with the Portable unit.

**H** 230 Vac to the Transceiver Unit

**K** Transducer cable

### Serial line cables

#### Standard configuration

The standard configuration is a 4 ports PCMCIA board can be supplied, giving a total of 5 serial ports. (Com 1 on the Compact PC, and Com3-6 on the PCMCIA board.)

#### Cable A

Note

*RS-232 is standard.*

The connections used are recorded in the system software.

## Transceiver unit - responder cables J

The Responder function requires an optional responder PCB.

One separate cable is required for each responder to be connected to the transceiver. The transceiver end connects to one of the 4-pin amphenol connectors on the rear of the transceiver unit.

**Note**

*Links LK1 and LK2 located on the rear of the transceiver unit must be in place to power the Responder Controller Board (RPC) with +48 Vdc. This voltage is converted to +24 Vdc on the RPC board to supply the 24 V responder trigger pulse. It is this +24 V that is available at pin 3 on the Responder 4-pin special connector. This power can be, but is normally not used to supply the responder with power. Normally the responder is supplied from an external source, either a separate power supply unit or the ROV etc.*




Figure 12 Responder connections

## Transceiver unit pin allocations

### Introduction

The connectors on the rear of the HPR 400 Transceiver Unit have the pin allocations as follows (as seen from outside, looking at the rear of the unit).

The connectors not listed here are not used with the HPR 400P Series.

### Serial 1

The “Serial 1” socket is a 9-pin delta connector. It is located on the rear panel of the HPR 400 Transceiver Unit, and is identified with the label “SERIAL 1”.


It is used for communication with the computer. The inputs and outputs are optically isolated.

It is used for communication with the APC 10 C computer. The inputs and outputs are optically isolated.

The pins are allocated as follows:

- 1 422+ input
- 2 232 input
- 3 232 output
- 4 422- input
- 5 Ground
- 6 422- output
- 9 422+ output

Pins 7 and 8 are not used.



*Figure 13 9-pin Delta connector, seen from the outside, looking at the rear of the unit*

### Serial 2

Not in use.

### Serial 3

The “Serial 3” socket is a 9-pin delta connector. It is located on the rear panel of the HPR 400 Transceiver Unit, and is identified with the label “SERIAL 3”.

This serial line is used to connect a serial line gyro or Vertical Reference Unit.

The pins are allocated as follows:

- 1** 422+ input
- 4** 422- input
- 5** Ground
- 6** 422- output
- 9** 422+ output

The remaining pins are not used.

→ *Refer to figure 13.*

### **Serial 4**

The “Serial 4” socket is a 9-pin delta connector. It is located on the rear panel of the HPR 400 Transceiver Unit, and is identified with the label “SERIAL 4”.

The serial line is used for synchronization.

The pins are allocated as follows:

- 1/4** Sync 1 in
- 7/8** Sync 2 in
- 9/6** Sync 1 out
- 3/2** Sync 2 out
- 5** Ground

→ *Refer to figure 13.*

### **Serial 5**

Not in use.

### **Serial 6**

Not in use.

### **Parallel**


Not in use.

### Analogue I/O

The “Analogue” socket is a 25-pin delta connector. It is located on the rear panel of the HPR 400 Transceiver Unit, and is identified with the label “ANALOG IO/”. The pins are allocated as follows:

- 10** Analogue ground
- 11** Roll
- 12** Pitch
- 22** +15 Vdc
- 23** -15 Vdc
- 24** Common

The remaining pins are not used.




*Figure 14 25-pin Delta connector, seen from the outside, looking at the rear of the unit*

### Gyro/synchro

The “Gyro / synchro” socket is a 15-pin delta connector. It is located on the rear panel of the HPR 400 Transceiver Unit, and is identified with the label “GYRO”. The pins are allocated as follows:


- 1** S<sub>1</sub>
- 2** S<sub>2</sub>
- 3** S<sub>3</sub>
- 9** R<sub>H</sub>
- 10** R<sub>L</sub>



*Figure 15 15-pin Delta connector, seen from the outside, looking at the rear of the unit*

## Responder 1 - 4

The Responder 1 to 4 connectors are 4-pin AMP sockets. They are located on the rear panel of the HPR 400 Transceiver Unit, and are identified with the label “TRANSPONDER 1-4”.



*Figure 16 Responder connector, seen from the outside, looking at the rear of the unit*

The pins for all four connectors are allocated as follows:

- A** + 24 V
- B** Trigger
- C** Reference
- D** Screen


## Transducers 1 and 2

These are the transducer connectors for Standard, LF and Narrow beam transducers.

## Transducers 3 and 4

The “TRANSDUCER 3” and “TRANSDUCER 4” connectors are 3-pin amp. connectors. The pins are allocated as follows:

- A** Signal
- B** Ground
- C** Signal



*Figure 17 Transducer 3/4 connector, seen from the outside, looking at the rear of the unit*

Note

*Transducer 2/4 can only be used when 2 Transmit PCBs and 2 Rx PCBs are fitted.*


## Operator station pin allocations

The connectors on the rear of the portable computer has the pin allocations as follows (as seen from outside, looking at the rear of the unit).

### Com 1, 2 and 3

Com 1, 2 and 3 are 9-pin Delta connectors. The pins are allocated as follows:

<b>1</b>	Carrier detect
<b>2</b>	Receive data
<b>3</b>	Transmit data
<b>4</b>	Data terminal ready
<b>5</b>	Ground
<b>6</b>	Data set ready
<b>7</b>	Ready to send
<b>8</b>	Clear to send
<b>9</b>	Ring indicator



*Figure 18 9-pin Delta connector, seen from the outside, looking at the rear of the unit*

### LPT 1

LPT 1 is a 25-pin Delta connector. The pins: are allocated as follows:

<b>1</b>	Strobe (*)
<b>2</b>	Data bit 0
<b>3</b>	Data bit 1
<b>4</b>	Data bit 2
<b>5</b>	Data bit 3
<b>6</b>	Data bit 4
<b>7</b>	Data bit 5
<b>8</b>	Data bit 6
<b>9</b>	Data bit 7
<b>10</b>	Acknowledge (*)
<b>11</b>	Busy
<b>12</b>	Paper out
<b>13</b>	Select
<b>14</b>	Auto linefeed (*)
<b>15</b>	Error (*)
<b>16</b>	Initialize printer (*)
<b>17</b>	Select in (*)
<b>18-25</b>	Ground

(\*) = active low






Figure 19 25-pin Delta connector, seen from the outside, looking at the rear of the unit

## VGA

VGA is a 15-pin Delta connector. The pins are allocated as follows:

<b>1</b>	Red analogue
<b>2</b>	Green analogue
<b>3</b>	Blue analogue
<b>4</b>	Not connected
<b>5</b>	Ground
<b>6 / 7 / 8</b>	Ground analogue
<b>9</b>	Not connected
<b>10</b>	Ground
<b>11 / 12</b>	Not connected
<b>13</b>	Horizontal synchronization
<b>14</b>	Vertical synchronization
<b>15</b>	Not connected




Figure 20 VGA connector, seen from the outside, looking at the rear of the unit

→ For more information, refer to separate documentation.

## WhiteHEAT/USB

→ Refer to separate documentation or Manufacturer; <http://www.connecttech.com>

## MAINTENANCE

### General

This section describes general maintenance of the HPR 400P system.

The HPR 400P system is designed as a modular system. This means that that corrective maintenance is normally performed by replacing modules and circuit boards.

Note

*This document may include information regarding equipment not included in your system.*

### Maintenance philosophy

This technical description is meant to assist the maintenance engineer with intermediate level maintenance operations. This means that the maintenance technician or engineer is expected to replace faulty Line Replaceable Units (LRU) (circuit boards or modules), but not to perform circuit board repairs.

In order to find the faulty component, it is further expected that the maintenance personnel have access to standard electronic instruments, such as oscilloscopes and multimeters.

The personnel designated to perform maintenance on this unit (and the rest of the system) should be well qualified technical personnel, with experience of computer-based electronic circuitry. It is also strongly recommended that the personnel are familiar with the basic principles of hydroacoustic technology, and in particular, positioning systems.

Training courses are available from Kongsberg Maritime AS.

### Preventive maintenance

The basic preventative maintenance tasks such as system checks and cleaning, which can be carried out by the operator prior to and on completion of an operation are included.

#### **Transceiver unit**

If the transceiver unit is installed within a cabinet, then the fan filter must be checked and vacuum-cleaned every three months or whenever it appears to be necessary. Switch off power before removing the fan covers.

*Caution*

*Maintenance beyond preventive precautions, must be carried out by a qualified service engineer.*

## Corrective maintenance

### Caution

*Electronic devices can be destroyed by static electricity. It is essential therefore that full protection against static is practised by service engineers. Although the unit is resistant to mechanical vibration and shock, every effort must be made to avoid careless handling when the unit is in use or being transported.*

A number of error messages are available for use by the system operator. These are not described in this document.

The corrective maintenance on the transceiver unit is limited to operational checks and circuit board replacements. An extension board will be required if the maintenance engineer wishes to perform measurements on the boards during system operation. This is delivered with the standard spare parts kit for the transceiver unit.

→ *For more maintenance information, refer to section HPR 400 Transceiver Unit.*

## Tools

No special tools are required.

## Transceiver unit

→ *Replacement of transceiver unit parts, refer to page 34.*

## WhiteHEAT/USB

No special maintenance is required.

→ *For information about the unit refer to separate documentation or Manufacturer; <http://www.connecttech.com>*

## Operator station

→ *For information about the Portable PC, refer to separate documentation.*

## Alarm and event messages

Alarm and events messages are presented in a separate window on the screen, on request. The Alarm and event messages system is described in the APOS on-line help.

## Winch unit

### General

- 1 After use, wash the winch unit and cable with fresh water to remove any salt and dirt.

#### *Caution*

*A high-pressure hose must not be used - the transducer can be damaged.*

- 2 Check the transducer. Ensure the face is clean and free from defects.
- 3 Check that the retaining strap is in good condition.
  - This will prevent the transducer falling out of its holder during transportation.
- 4 Check the connector on the “topside end” of the cable. Ensure the rubber seal is fitted and is in good condition.

### Cable drum

#### **When the unit is not in use:**

- 1 Ensure the protective cap is attached to the drum, and is fitted to the topside connector when the unit is not in use.
  - This will prevent the ingress of water into the connector, and will prevent damage to the connector pins.
- 2 A few drops of oil on the drum and roller bearings, around the winding handle and on the break screw thread will help to prevent corrosion and ensure trouble-free operation when the unit is required.
- 3 Check the lifting strop and look for cuts, frays and other damage.

## Transducer

### General

Preventive maintenance is limited to keeping the unit clean.

Any marine growth on the transducers will degrade the system's operational capabilities. The transducers should therefore be kept clean.

- The transducers must be handled with care. If the black rubber coating on a transducer is damaged, the transducer will have to be replaced.
- Before any connectors are disconnected, ensure the surrounding areas are dry.
- Inspect the unit for damage at regular intervals. Pay particular attention to the transducer surface. This is manufactured of a synthetic rubber material, and can be damaged easily.

### Cleaning the transducers

#### *Caution*

*Do not use metal tools, solvents, or high-pressure hose.*

- 1 Using a plastic-bristled brush, cloths and fresh water, remove all traces of salt, debris, mud and weed from the transducer.
- 2 Remove stubborn crustacean growth using a rounded wooden or plastic scraper. Be very careful not to damage the rubber coating on the transducer.

### Replacement of the transducer

The transducer is a sealed unit and can not be opened. If the unit is not working, the whole unit must be replaced.

## Replacement of transceiver unit parts

### Overview

The following circuit boards contained in the transceiver unit are defined as Line Replaceable Units (LRUs):

- Backplane
- Input M - A/B
- A/D Converter (ACM)
- Digital Signal Processor (DSPM)
- Control Processing Unit (CPUM)
- Input/Output (IOM)
- Responder (RPC)
- Transmitter (TxM - A/B)
- DC Power supply (DC - PWR)
- AC Power supply (AC - PWR)

The removal and replacement of these parts is described in the following paragraphs.

→ *Description of each of the boards, see page 44.*

Note

*The maintenance engineer must wear a grounding bracelet which is securely connected to the vessel's ground at all times when performing maintenance on the transceiver unit.*

## Replacement of circuit boards and software

The circuit boards are all plug-in modules and are easy to replace.

- A small screw-driver may be required to open the front panel.
- A special extraction tool (wire hooks) will simplify the removal of a board.
- All the boards and power units are replaced using the same procedure.

### How to remove a circuit board

To remove a board, perform the following procedure:

- 1 Switch off all power to the HPR system, and other systems connected to the HPR system (DPS, vertical reference unit etc.).
- 2 Remove the system fuses if possible.
- 3 Label the fuse panel with a tag stating that maintenance is being carried out on the system.

- 4 Us a small screw-driver if necessary, to open the transceiver unit front panel.
  - This is done by slackening the two captive screws in the upper corners and hinging the panel downwards.
  - The panel must be allowed to swing below the horizontal if circuit boards are to be removed, so the unit may need to be supported on blocks.
- 5 Identify the unit / board to be removed, and write down the location of pin 1.
- 6 Use a small screwdriver or a special extraction tool, and remove the device carefully from its socket on the source circuit board.
  - Lift the unit / board as vertically as possible to prevent damage to the pins.
- 7 Locate the desired circuit board and carefully remove any connectors which may be attached to the front of the board.
- 8 Locate the extraction tool hooks into the holes in the upper and lower corners of the board's front edge and carefully pull the circuit board straight out from the transceiver unit rack.

**Note**

*Most of the circuit boards hold software in EPROMS, PROMs and PALs. If a board is to be replaced, the software will have to be moved over to the new board. Also, several links and switches must be set correctly to ensure proper operation. When replacing a circuit board, ensure that the new links and switches match the old.*

**Software**

To replace the software, or load it to a new board, is a delicate job and must be handled with extreme care. The following precautions must be taken:

- 1 The replacement must be performed on a clean and stable workbench or table.
- 2 The table must be covered with an anti-static mat connected to the ship's ground.
- 3 The maintenance engineer **MUST** wear a grounding bracelet connected to the ship's ground.

- 4 Each software device is identified with a white label. This label holds the following information:
- Circuit board ..... DSPM
  - Device number ..... U15
  - Software version ..... V1.1
  - Date ..... 99.09.15
  - Check sum (in hexadecimal) ..... 05A3

### How to remove the backplane

The backplane is located behind the circuit boards, and is accessible through the back of the unit. All the circuit boards and power units must be removed through the front of the unit before the backplane can be removed. All connections to the backplane are made using plugs.

To remove the backplane, follow the procedure below:

Note

*If the transceiver unit is installed in a console or a rack, the unit will need to be extracted and taken to a work-bench before proceeding with the backplane removal procedure.*

- 1 Switch off all power to the HPR system, and other systems connected to the HPR system (DPS, vertical reference unit etc.).
- 2 Remove the system fuses if possible.
- 3 Label the fuse panel with a tag stating that maintenance is being carried out on the system.
- 4 Label all the cables connected into the back of the transceiver unit, and disconnect them.
- 5 Remove all the circuit boards and power units.
  - Ensure the boards are placed in a safe place.
- 6 Use a small screw-driver and remove the 12 screws securing the transceiver unit rear panel in position.
  - The panel is now attached to the unit only by the cables.
- 7 Use a suitable insulated tool or wire link, and discharge the two large capacitors located towards the left side of the rear panel.
- 8 Remove all the connectors attached to the backplane.
  - The backplane should now be readily accessible.
- 9 Slacken and remove the 18 screws securing the backplane into the transceiver unit.
  - The backplane should now be loose, and the engineer can remove it carefully through the back of the unit.



If the backplane is going to be out of the transceiver unit for some time, it is recommended to replace the circuit boards into the front of the unit and close the unit to protect the boards.

## Replacement of the backplane

Replacing the backplane is the reverse of removal.

→ Refer to the procedure on page 36.

Care should be taken to ensure that parts fit together correctly before securing screws are tightened. Do not attempt to apply force to any of the parts. Do not over tighten the securing screws.

## Replacement of circuit boards

When replacing a board into the rack, care must be taken to ensure that the board is correctly positioned in the rails before any pressure is applied to the board. If the rear mounted connector pins are damaged, a replacement board will be required.

- 1 Switch off all power to the HPR system, and other systems connected to the HPR system (DPS, vertical reference unit etc.).
- 2 Remove the system fuses if possible.
- 3 Label the fuse panel with a tag stating that maintenance is being carried out on the system.
- 4 Locate the correct slot for the board in question.

### Note

*The slots are identified by the board's initials, and the boards are identified by text written onto the component side. In all cases, the board must be located such that the components are to the right of the board.*

- 5 Locate the board in the slots and carefully slide the board into the unit.
  - Ensure that the board does not interfere with and cables as it is pushed in.
  - If necessary, hold any cables which may be obstructing the board out from the unit.
- 6 When the connectors on the back of the board begin to mate with the connectors on the back plane, (approximately 5 mm before the board is fully home) check that the board is correctly located then apply even pressure over the front of the board and push it firmly home.

- 7 When the front of the board is fully home, the black plastic board retention clip will latch over the upper edge of the board to keep it in position.
- 8 Carefully replace the front connector (if applicable), ensuring it is pressed fully into the socket.
- 9 Once all the boards are in position, close the front of the transceiver unit.
  - Ensure that the power cable towards the right side of the unit is not crimped as the panel is closed.
- 10 Secure the panel closed using the two screws in the upper corners.

## Fuses

### Location

The transceiver unit holds two mains input fuses. These are located in fuse holders located towards the left side of the rear panel (when seen from the rear).

Four fuses are located on the Responder board (This board is optional and may not be included in the transceiver unit) and the AC power supply holds one.

- **On the rear panel**

- *Location, refer to figure on page 19.*

- For 115/230 Vac supply - 5 mm x 30 mm, 2 A, slow-blow.
- For 115/230 Vac supply - 5 mm x 30 mm, 2 A, slow-blow.

- **On the Responder Controller board (RPC)**

- *Location, refer to figure on page 74.*

- 5 mm x 20 mm, 0.1 A, 24 Vdc, slow-blow.

- **On the AC power supply**

The fuse is contained in a holder located on the rear of the unit.

- *Location refer to figure on page 68.*

- 5 mm x 20 mm, 250 V, 2.5 A, slow-blow.

### Caution

*Never attempt to use any other size of fuses than those stated.*

### Replacement

- 1 Switch off the entire HPR system, including external units which are connected to the HPR system.
- 2 If the suspect fuse is located on a circuit board, remove the board from the transceiver unit.
  - *Refer to the procedure on page 37.*

- 3 Replace the blown fuse(s) with the correct size and type of fuse.

*Caution*

*NEVER attempt to use anything except the correct size and type of fuse in the fuse holders. Irreparable damage may be caused to the transceiver unit if the wrong fuses (or anything else) are used.*

- 4 Switch on the HPR system.

- 5 Switch on the other external units.

*Caution*

*If, when a fuse is replaced, it blows again when power is switched on to the system, a more serious fault exists. Do not replace the fuses a second time till the fault has been located and corrected.*

## HPR 400 TRANSCEIVER UNIT

### Design

The transceiver unit is constructed of aluminium panels and extruded strip. One of several different cover panel designs may be used depending on the type of installation (console, desk-top, rack, or portable). The dismantling procedures described in this manual refer to the unit as used in the console or 19" rack.

The majority of the circuit boards contained in the unit are standard single-Europe cards, accessible by opening the front of the unit.

Holes (3 mm) are drilled in the upper and lower front corners of each board. These are to attach the wire handle used to extract the board from the unit.

### External connections

All external connections to the transceiver unit are made via plugs located on the rear of the unit.

### Power supply

The transceiver unit can be powered from a 115 Vac or a 230 Vac supply. Links must be set inside the unit to adapt the unit to the voltage supply. A mains power switch is located on the front panel, together with a *Power on* indicator lamp.

### Maintenance

→ *Refer to page 30.*

## Theory of operation

### Introduction

The HPR 400 Transceiver Unit is the central part of the HPR system. It contains the following:

- Electronic circuitry for transmission of acoustic pulses
- Amplifiers and filters for reception of acoustic signals
- Interfaces to external sensors
- Serial line for communication with the Beam Control Unit (for tracking systems)
- Serial line for communication with the System Controller (an Ethernet link will be available shortly).

The Transceiver Unit's main navigation function is to interrogate transponders and measure the range and bearing to them. The main telemetry function is to transmit and receive acoustic signals.

→ *The operating modes are described on page 4.*

### Navigation

The operator selects the active mode of operation. The system can then switch automatically between the selected mode and the other available mode(s). This means that the system can make use of several different types of transponder in the same operation.

### Telemetry

The operator may select this mode to send and receive telemetry messages, for example to read the battery status of a transponder. When the transceiver reads the telemetry message from the System Controller, it will convert the message into acoustic signals. This acoustic message contains bursts and pulses with different frequencies and fixed intervals. The transceiver transmits the message(s), and will await the telemetry reply.




Figure 21 HPR 400 Transceiver unit - functional block diagram

## Circuit board identification and main functions

- **Central Processing Unit (CPUEX)**
  - Position calculation
  - Loads and controls the DSPM 50 program
  - Serial line to CDU
  - Controls Tx/Rx hardware
- **Digital Signal Processor (DSPM 50)**
  - Reads data from ADCM
  - Performs pulse detection
  - Performs digital filtering (Fast Fourier Transformations)
- **Analog Digital Converter (ADCM)**
  - Samples the data from INPUTM
  - Converts to binary format
- **Input (INPUTM)**
  - 8-channel receiver
  - Amplifies
  - Bandpass filtering
  - Sample/hold circuitry
- **Transmitter (TXM)**
  - Transmitter
  - Frequency generator for Rx and Tx frequency

- **Input & Output (IOM)**
  - Interface to vertical reference unit (analogue)
  - Interface to gyro (synchro and serial line)
  - TVG initialization
  - Clock for phase locked loop on INPUTM
- **Ethernet (ENET-M)**
  - Ethernet interface
- **Motherboard**
  - Connects all the individual circuit boards together

## Internal layout

This section provides a short description of each of the circuit boards contained within the HPR 400 Transceiver Unit.

The transceiver unit holds the following circuit boards and power units.

**From left to right:**

- A/D Converter (ADCM)
- Digital Signal Processor (DSPM)
- Control Processing Unit (CPUM)
- Input/Output (IOM)
- Transmitter (TXM - A/B)
- DC Power supply (DC - PWR)
- AC Power supply (AC - PWR)

The backplane is located behind the circuit boards, and is accessible through the rear of the transceiver unit. All the circuit boards and power units must be removed through the front of the unit before the backplane can be removed. All connections to the backplane are made using plugs.






Figure 22 HPR 400 Transceiver Unit - internal layout

## Backplane

The backplane is located in the back of the Transceiver Unit. It is the interconnection circuit board, carrying connectors and wiring tracks to interconnect the other circuit boards in the Transceiver Unit. All the other circuit boards plug into the backplane.

### Main components

The board holds the following three ICs:

- U01 . . . 74HC240 Buffer, inverted on outputs
- U02 . . . PAL 20V8 Address decoder. (For TX-PCBs only)
- U03 . . . 74HC123F Retriggerable monostable multivibrator

### Socket mounted components

The board holds only one socket-mounted component:

- U02PAL 20V8 Address decoder. (For TX-PCBs only)

### Connections

There are 37 connectors on the circuit board, mounted on both sides. Connectors J1 to J12 are 96-pin Europa connectors for the single Euro-card circuit boards in the unit. For the pin configurations, refer to the following drawing:

*HPR 400 Backplane . . . . . 824-108544 (SH-067)*

J1	InputM-B
J2	InputM-A
J3	ADCM
J4	DSPM 50
J5	CPUEX
J6	Ethernet
J7	Spare
J8	IO-M
J9	RPC
J10	TXM-B
J11	TXM-A

J12	POWERM
P14	8-pin Phoenix plug, male
P15	50-pin 3M, male, flat ribbon cable connector
P16	18-pin Molex, male
P17	8-pin Phoenix plug, male
P18	2-pin Phoenix plug, male
P19	2-pin Phoenix plug, male
P20	2-pin Phoenix plug, male
P21	34-pin 3M, male, flat ribbon cable connector
P22	50-pin 3M, male, flat ribbon cable connector
P23	50-pin 3M, male, flat ribbon cable connector
P24	2-pin Phoenix plug, male
P25	2-pin Phoenix plug, male
P26	9-pin Molex, male
P27	3-pin Molex, male
P28	9-pin Molex, male
P29	3-pin Molex, male
P30	6-pin Molex, male
P31	9-pin Molex, male
P32	3-pin Molex, male
P33	9-pin Molex, male
P34	3-pin Molex, male
P35	6-pin Molex, male
P36	3-pin Molex, male

P37	3-pin Molex, male
P38	3-pin Molex, male

### Pin assignments

P14 pin assignments		
Pin	Signal	Description
1	TD 2, Tx+ .....	Transducer 2, transmission +
2	TD 2, Tx- .....	Transducer 2, transmission -
3	TD 4, Tx+ .....	Transducer 4, transmission +
4	TD 4, Tx- .....	Transducer 4, transmission -
5	+15 Vdc	
6	-15 Vdc	
7	AGND .....	Analogue ground
8	DGND .....	Digital ground

P15 pin assignments			
Pin	Signal	Description	Ext.
1	RS422_Rx1	RS422+ serial line. To CPU .....	Input 1
2	RS422_Tx1-	RS422- serial line. From CPU .....	Output 6
3	RS232_Rx	RS232 serial line. To CPU .....	Input 2
4			7
5	RS232_Tx	RS232 serial line. From CPU .....	Output 3
6			8
7	RS422_Rx1-	RS422- serial line. To CPU .....	Input 4
8	RS422_Tx1	RS422+ serial line. From CPU .....	Output 9
9	GND1	Galvanically isolated ground	5
10	RS422_Rx2	RS422+ serial line 2 .....	Input 1
11	RS422_Tx2-	RS422- serial line 2 .....	Output 6
12			2
13			7
14			3
15			8
16	RS422_Rx2-	RS422- serial line 2 .....	Input 4
17	RS422_Tx2	RS422+ serial line 2 .....	Output 9
18	GND	Ground	5

<b>P15 pin assignments</b>			
<b>Pin</b>	<b>Signal</b>	<b>Description</b>	<b>Ext.</b>
19	RS422_Rx3	RS422+ serial line 3 ..... Input	1
20	RS422_Tx3-	RS422- serial line 3 ..... Output	6
21			2
22			7
23			3
24			8
25	RS422_Rx3-	RS422- serial line 3 ..... Input	4
26	RS422_Tx3	RS422+ serial line 3 ..... Output	9
27	GND	Ground	5
28	SY1_in	External sync1+ ..... Input	1
29	SY1_out-	External sync1- ..... Output	6
30	SY2_out-	External sync2- ..... Output	2
31	SY2_in	External sync2+ ..... Input	7
32	SY2_out	External sync2+ ..... Output	3
33	SY2_in-	External sync2- ..... Input	8
34	SY1_in-	External sync1- ..... Input	4
35	SY1_out	External sync1+ ..... Output	9
36	GND	Ground	5
37	ANA_1	Analogue 1 ..... Input	14
38	AGND	Analogue ground	2
39	ANA_2	Analogue 2 ..... Input	15
40	AGND	Analogue ground	3
41			16
42			4
43			17
44			5
45	S1	Synchro gyro S1 ..... Input	1
46	R.Hi	Reference high R.Hi ..... Input	9
47	S2	Synchro gyro S2 ..... Input	2
48	R.L	Reference low R.L ..... Input	10
49	S3	Synchro gyro S3 ..... Input	3
50			11

Abbreviations: SY = Synch, ANA = Analogue

P16 pin assignment	
Pin	Description
1	+24 volt, responder 1
2	Trigger, responder 1
3	Digital ground
4	Analogue ground
5	+24 volt, responder 2
6	Trigger, responder 2
7	Digital ground
8	Analogue ground
9	+24 volt, responder 3
10	Trigger, responder 3
11	Digital ground
12	Analogue ground
13	+24 volt, responder 4
14	Trigger, responder 4
15	Digital ground
16	Analogue ground
17	-
18	-

P17 pin assignment		
Pin	Signal	Description
1	TD 1, Tx+ .....	Transducer 1, transmission +
2	TD 1, Tx- .....	Transducer 1, transmission -
3	TD 3, Tx+ .....	Transducer 3, transmission +
4	TD 3, Tx- .....	Transducer 3, transmission -
5	+15 Vdc	
6	-15 Vdc	
7	AGND .....	Analogue ground
8	DGND .....	Digital ground

P18 pin assignment		
Pin	Signal	Description
1	TxA CAP + .....	Capacitor A ..... +48 Vdc
2	TxA CAP - .....	Capacitor A ..... 0 V

<b>P19 pin assignment</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	TxB CAP + .....	Capacitor B ..... +48 Vdc
2	TxB CAP - .....	Capacitor B ..... 0 V

<b>P20 pin assignment</b>	
<b>Pin</b>	<b>Description</b>
1	+48 Vdc from AC power supply
2	Analogue ground

<b>P21 pin assignments</b>			
<b>Pin</b>	<b>Signal</b>	<b>Description</b>	<b>Ext.</b>
1	RXAI	RS422+ serial line A ..... Input	1
2	TXA/	RS422- serial line A ..... Output	6
3	RXA	RS232 serial line A ..... Input	2
4	RXCB	RX clock TTL ..... Input	7
5	TXA	RS232 serial line A ..... Output	3
6	CTSA/	Clear to send A TTL ..... Input	8
7	RXA/	RS422- serial line A ..... Input	4
8	TXA0	RS422+ serial line A ..... Output	9
9	GND	Ground reference A	5
10	RXBI	RS422+ serial line B ..... Input	1
11	TXB/	RS422- serial line B ..... Output	6
12	RXB	RS232 serial line B ..... Input	2
13	TXCB	RX clock TTL ..... Input	7
14	TXB	RS232 serial line B ..... Output	3
15	CTSB/	Clear to send B TTL ..... Input	8
16	RXB/	RS422- serial line B ..... Input	4
17	TXB0	RS422+ serial line B ..... Output	9
18	GND	Ground reference B	5
19	IO1	Digital input/output ..... Input/Output	1
20	IO2	Digital input/output ..... Input/Output	2
21	IO3	Digital input/output ..... Input/Output	3
22	IO4	Digital input/output ..... Input/Output	4
23	IO5	Digital input/output ..... Input/Output	5
24	IO6	Digital input/output ..... Input/Output	6
25	IO7	Digital input/output ..... Input/Output	7
26	IO8	Digital input/output ..... Input/Output	8
27	RXCB	RX clock TTL ..... Input	9
28	TXCB	TX clock TTL ..... Input	10
29	CTSB/	Clear to send B TTL ..... Input	11
30	CTSA/	Clear to send A TTL ..... Input	12
31	GND	Power ground	13
32	GND	Power ground	14
33	+5 Vdc	+5 Vdc power supply ..... Output	15
34	+5 Vdc	+5 Vdc power supply ..... Output	16



<b>P22 pin assignments</b>			
<b>Pin</b>	<b>Signal</b>	<b>Description</b>	<b>Ext.</b>
1	RS422_Rx1	RS422+ serial line. To CPU ..... Input	1
2	RS422_Tx1-	RS422- serial line. From CPU ..... Output	6
3	RS232_Rx	RS232 serial line. To CPU ..... Input	2
4			7
5	RS232_Tx	RS232 serial line. From CPU ..... Output	3
6			8
7	RS422_Rx1-	RS422- serial line. To CPU ..... Input	4
8	RS422_Tx1	RS422+ serial line. From CPU ..... Output	9
9	GND1	Galvanically isolated ground	5
10	RS422_Rx2	RS422+ serial line 2 ..... Input	1
11	RS422_Tx2-	RS422- serial line 2 ..... Output	6
12			2
13			7
14			3
15			8
16	RS422_Rx2-	RS422- serial line 2 ..... Input	4
17	RS422_Tx2	RS422+ serial line 2 ..... Output	9
18	GND	Ground	5
19	RS422_Rx3	RS422+ serial line 3 ..... Input	1
20	RS422_Tx3-	RS422- serial line 3 ..... Output	6
21			2
22			7
23			3
24			8
25	RS422_Rx3-	RS422- serial line 3 ..... Input	4
26	RS422_Tx3	RS422+ serial line 3 ..... Output	9
27	GND	Ground	5
28	SY1_in	External sync1+ ..... Input	1
29	SY1_out-	External sync1- ..... Output	6
30	SY2_out-	External sync2- ..... Output	2
31	SY2_in	External sync2+ ..... Input	7
32	SY2_out	External sync2+ ..... Output	3
33	SY2_in-	External sync2- ..... Input	8
34	SY1_in-	External sync1- ..... Input	4
35	SY1_out	External sync1+ ..... Output	9
36	GND	Ground	5

P22 pin assignments			
Pin	Signal	Description	Ext.
37	RXBI	RS422+ serial line B ..... Input	1
38	TXB/	RS422- serial line B ..... Output	6
39	RXB	RS232 serial line B ..... Input	2
40	TXCB	RX clock TTL ..... Input	7
41	TXB	RS232 serial line B ..... Output	3
42	CTSB/	Clear to send B TTL ..... Input	8
43	RXB/	RS422- serial line B ..... Input	4
44	TXB0	RS422+ serial line B ..... Output	9
45	GND	Ground reference B	5
46			
47			
48			
49			
50			

**Pins 1 through 9** will connect to the external plug Serial I, on backplane (from IOM, P2 pins 1→9 P15 pins 1→9).

**Pins 10 through 18** will connect to the external plug Serial II, on backplane (from IOM, P2 pins 10→18 P15 pins 10→18).

**Pins 19 through 27** will connect to the external plug Serial III, on backplane (from IOM, P2 pins 19→27 P15 pins 19→27).

**Pins 28 through 36** will connect to the external plug Serial IV, on backplane (from IOM, P2 pins 28→36 P15 pins 28→36).

**Pins 37 through 45** will connect to the external plug Serial V, on backplane (from CPU, P2 pins 10→19 P21 pins 10→19).

**Pins 46 through 50** will connect to the external plug Serial VI (Debug), on backplane (from CPU, P2).

<b>P23 pin assignments</b>			
<b>Pin</b>	<b>Description</b>	<b>Pin</b>	<b>Description</b>
1	IO5, Digital input/output	26	GND
2	IO6, Digital input/output	27	PC0 (Analogue 1)
3	IO7, Digital input/output	28	PC1 (Ground)
4	IO8, Digital input/output	29	PC2 (Analogue 2)
5	CLK 0	30	PC3 (Ground)
6	GATE 1	31	PC4 (Analogue 3)
7	T0 out	32	PC5 (Ground)
8	T1 out	33	PC6 (Analogue 4)
9	GND	34	PC7 (Ground)
10	PB7	35	GND
11	PB6	36	DIFF 1- (S1, synchro)
12	PB5	37	DIFF 1 (Rh, ref. high)
13	PB4	38	DIFF 2- (S2, synchro)
14	PB3	39	DIFF 2 (Rl, ref. low)
15	PB2	40	DIFF 3- (S3 synchro)
16	PB1	41	DIFF 3
17	PB0	42	GND
18	PA7	43	AN_IN 8 (VRU +15 V)
19	PA6	44	AN_IN 7 (Analogue ground)
20	PA5	45	AN_IN 6 (VRU -15 V)
21	PA4	46	AN_IN 5 (Roll)
22	PA3	47	AN_IN 4 (Common)
23	PA2	48	AN_IN 3 (Pitch)
24	PA1	49	AN_IN 2 (Analogue ground)
25	PA0	50	AN_IN 1

<b>Signal descriptions for P23</b>				
<b>Signal</b>	<b>From</b>	<b>Via</b>	<b>Via</b>	<b>To</b>
Analogue 1	IO/M P2 37	P15 pin 37	P23 pin 27	ANALOGUE I/O pin 14
GND	IO/M P2 38	P15 pin 38	P23 pin 28	ANALOGUE I/O pin 2
Analogue 2	IO/M P2 39	P15 pin 39	P23 pin 29	ANALOGUE I/O pin 15
GND	IO/M P2 40	P15 pin 40	P23 pin30	ANALOGUE I/O pin 3
S1	IO/M P2 45	P15 pin 45	P23 pin36	GYRO pin 1
Rh	IO/M P2 46	P15 pin 46	P23 pin37	GYRO pin 9
S1	IO/M P2 47	P15 pin 47	P23 pin38	GYRO pin 2
R1	IO/M P2 48	P15 pin 48	P23 pin39	GYRO pin 10
S3	IO/M P2 49	P15 pin 49	P23 pin40	GYRO pin 3
VRU +15 Vdc	IO/M P1 c23	P23 pin 43		ANALOGUE I/O pin 22
GND	IO/M P1 b2	P23 pin 44		ANALOGUE I/O pin 10
VRU -15 Vdc	IO/M P1 a2	P23 pin 45		ANALOGUE I/O pin 23
Roll	IO/M P1 c22	P23 pin 46		ANALOGUE I/O pin 11
Common	IO/M P1 b2	P23 pin 47		ANALOGUE I/O pin 24
Pitch	IO/M P1 a2	P23 pin 48		ANALOGUE I/O pin 12
Analogue ground	IO/M P1 c21	P23 pin 49		ANALOGUE I/O pin 25

<b>P24 pin assignment (DC input)</b>	
<b>Pin</b>	<b>Description</b>
1	+48 Vdc backup
2	Analogue ground

<b>P25 pin assignment (External responder power)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	Ext. pwr RSP .....	Responder power
2	AGND	Analogue ground

<b>P26 pin assignment (To Input-A pcb, channels 1 - 3)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	A INA_1 .....	Input A, channel 1 IN +
2	A INBA_1 .....	Input A, channel 1 IN -
3	AGND	Analogue ground
4	A INA_2 .....	Input A, channel 2 IN +
5	A INB_2 .....	Input A, channel 2 IN -
6	AGND	Analogue ground
7	A INA_3 .....	Input A, channel 3 IN +
8	A INB_3 .....	Input A, channel 3 IN -
9	AGND	Analogue ground

<b>P27 pin assignment (To Input-A pcb, channel 4)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	A INA_4 .....	Input A, channel 4 IN +
2	A INB_4 .....	Input A, channel 4 IN -
3	AGND	Analogue ground

<b>P28 pin assignment (To Input-A pcb, channels 5 - 7)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	A INA_5 .....	Input A, channel 5 IN +
2	A INB_5 .....	Input A, channel 5 IN -
3	AGND	Analogue ground
4	A INA_6 .....	Input A, channel 6 IN +
5	A INB_6 .....	Input A, channel 6 IN -
6	AGND	Analogue ground
7	A INA_7 .....	Input A, channel 7 IN +
8	A INB_7 .....	Input A, channel 7 IN -
9	AGND	Analogue ground

<b>P29 pin assignment (To Input-A pcb, channel 8)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	A INA_8 .....	Input A, channel 8 IN +
2	A INB_8 .....	Input A, channel 8 IN -
3	AGND	Analogue ground

<b>P30 pin assignment (For transducer 1)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	ST 24, VC_B .....	Voltage control B, Td 1
2	DGND .....	Digital ground
3	AGND .....	Analogue ground
4	N/W-signal .....	Narrow/Wide Td 1
5	AGND .....	Analogue ground
6	Screen .....	

<b>P31 pin assignment (To Input-B pcb, channels 1 - 3)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	B INA_1 .....	Input B, channel 1 IN +
2	B INBA_1 .....	Input B, channel 1 IN -
3	AGND	Analogue ground
4	B INA_2 .....	Input B, channel 2 IN +
5	B INB_2 .....	Input B, channel 2 IN -
6	AGND	Analogue ground
7	B INA_3 .....	Input B, channel 3 IN +
8	B INB_3 .....	Input B, channel 3 IN -
9	AGND	Analogue ground

<b>P32 pin assignment (To Input-B pcb, channel 4)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	B INA_4 .....	Input B, channel 4 IN +
2	B INB_4 .....	Input B, channel 4 IN -
3	AGND	Analogue ground

<b>P33 pin assignment (To Input-B pcb, channels 5 - 7)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	B INA_5 .....	Input B, channel 5 IN +
2	B INB_5 .....	Input B, channel 5 IN -
3	AGND	Analogue ground
4	B INA_6 .....	Input B, channel 6 IN +
5	B INB_6 .....	Input B, channel 6 IN -
6	AGND	Analogue ground
7	B INA_7 .....	Input B, channel 7 IN +
8	B INB_7 .....	Input B, channel 7 IN -
9	AGND	Analogue ground

<b>P34 pin assignment (To Input-A pcb, channel 8)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	B INA_8 .....	Input B, channel 8 IN +
2	B INB_8 .....	Input B, channel 8 IN -
3	AGND	Analogue ground

<b>P35 pin assignment (For transducer 2)</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	ST 25, VC_D .....	Voltage control D, Td 2
2	DGND .....	Digital ground
3	AGND .....	Analogue ground
4	N/W-signal .....	Narrow/Wide Td 2
5	AGND .....	Analogue ground
6	Screen .....	

<b>P36 pin assignment (For transducer 3)</b>		
<b>Note ! External cable from P36 to Input-A pcb, channel 8</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	ALNK_A1 .....	Telemetry (+) TxMB to input A
2	ALNK_A2 .....	Telemetry (-) TxMB to input A
3	AGND .....	Analogue ground

<b>P37 pin assignment (For transducer 4)</b>		
<b>Note ! External cable from P36 to Input-B pcb, channel 8</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	ALNK_B1 .....	Telemetry (+) TxMB to input B
2	ALNK_B2 .....	Telemetry (-) TxMB to input B
3	AGND .....	Analogue ground

<b>P38 pin assignment</b>		
<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	“ON”, (diode) .....	Power ON
2	GND .....	Ground
3	“CPU” (diode) .....	Not connected

**Links**

LK 1	0 V for responder power. Link <b>IN</b> means internal power
LK 2	+48 V for responder power. Link <b>IN</b> means internal power
ST 1	Link 1-2 for VC_B to Input-A P1 c7
ST 1	Link 2-3 for VC_A to Input-A P1 c7 (Normally closed) Seen from rear: ._. .
ST 2	Link 1-2 for VC_D to Input-B P1 c7
ST 2	Link 2-3 for VC_C to Input-B P1 c7 (Normally closed) Seen from rear: ._. .
ST 7	EXRDY- Normally out
ST24	VC_B, (TVG), TD1. Normally in
ST25	VC_D, (TVG), TD2. Normally in
ST26	Link 1-2 for VEE(-5 V) to Input A/B P1 abc 28
ST26	Link 2-3 for VCC(+5 V) to Input-A/B P1 abc 28 (Normally closed) Seen from rear: ._. .



## InputM

### Purpose

The HPR 400 Transceiver Unit holds two InputM boards, B and A. The purpose of the InputM circuit board is to amplify transducer signals, perform demodulation and narrow band filtering, and present the output signals via Sample and hold circuitry.

The InputM board is a single Euro-card circuit board.

The InputM circuit board is designed for eight individual channels, using identical analogue channel hybrid circuits. However, only five are fitted. The first four (grouped) are used for the SSBL system, the fifth (set apart from the others) is for the LBL system. The board is also equipped with digital circuitry common to all the analogue channels.

The InputM circuit board carries one connector. This is a 96-pin Europe connector mounted on the rear edge of the board, used to link the board into the backplane.

TP 1	Transducer signal channel 1
TP 2	Transducer signal channel 2
TP 3	Transducer signal channel 3
TP 4	Transducer signal channel 4
TP 5	Not fitted
TP 6	Not fitted
TP 7	Not fitted
TP 8	Not fitted

- The de-modulator frequency should be present at “Demfil” pins 1 and 2. The frequency should be two times the actual listening frequency. Note that the frequency will shift by the transmitter pulse after the reply is received. (50 Hz off).
- The bandwidth clock should be present on “Demfil” pin 14, and should be 50 times the actual bandwidth.
- The Sample/Hold clock should be present on U13 pin 13, and then go to pin 15 on all the “Demfil” packages.

The signal reply pulses (5 to 7 Vp-p) should be present on the test points in front of the “Demfils”. (TPs 1, 2, 3, 4 and 8).

- The signal pulse envelope should be present on “Demfil” pins 27 and 28. Maximum amplitude should be 4 V p-p.
- LK1

Link 1-2	Not used
Link 2-3	2 x mod. freq. telemetry normally closed

- LK2

Link 1-2	Not used
Link 2-3	Not used

- LK3

Link 1-2	Not used
Link 2-3	Not used

- LK4 / LK5

Link 1-2	LK 4 pin 2 is linked to LK 5 pin 2 to set bandwidth for wide and telemetry
----------	--

## Analogue digital converter (ADCM)

### Purpose

The purpose of the ADCM is to perform analogue to digital conversion. It offers conversion of 32 analogue input channels and temporary storage of data in dual port RAM. Up to eight conversion sequences can be programmed into an EPROM. Data sets are stored alternately in two banks of RAM.

### Board description

The ADCM is designed to the single Euro-card circuit board standard, with four layers. Two layers are used for the signals, two layers are used for the power supply. The board is equipped with two connectors, one located at each end. A 50-pin connector (P2) is the only front mounted device visible when the board is in position in the HPR 400 Transceiver Unit.

The ADCM circuit board provides 32 multiplexed analogue input channels. Dual 16-bit multiplexers are used to select analogue input signals obtained from the sample-and-hold outputs of the Input-M circuit board. Each output from the Input-M provides a real and imaginary analogue signal between  $\pm 2.5$  Vdc.

### Connections

The board carries two connectors, one located at each end of the board. **P1** is a 96-pin, male, right-angled connector. It connects the ADCM into the motherboard. **P2** is a 50-pin, male, right-angled connector with ejector/latch. It is located on the front edge of the board.

TP 1	ADC, IC4 input (real signal)
TP 2	ADC, IC4 BUSY~
TP 3	ADC, IC8 input (imaginary signal)
TP 4	ADC, IC8 BUSY~
TP 5	START_SEQ
TP 6	CLK~
TP 7	IC21 CK (multiplexer address latch)
TP 8	S_H
TP 9	+5 Vdc digital
TP 10	DGND
TP 11	+12 Vdc analogue
TP 12	Analogue ground
TP 13	-12 Vdc analogue

## Digital signal processor (DSPM 50)

### Location and purpose

The Digital Signal Processor (DSPM 50) board is located fourth from the left in the HPR 400 Transceiver Unit rack. It is designed as a general purpose single board computer, and its main task is to perform digital signal processing.

### Board description

The DSPM 50 is a single Euro-card circuit board, constructed of eight layers. It holds two LEDs and one 50-pin connector, P2, on its front edge.

The DSPM 50 is a general purpose digital signal processor board. It utilizes the TMS 320C50 Digital Signal Processor manufactured by Texas Instruments. The DSPM 50 operates on a 50 MHz clock frequency, and holds a total of 128 Kb memory for program and data storage. The program memory is loaded from a main control processor unit (the Central Processing Unit (CPUEX)) through a general bus interface in the 96-pin Europa connector P1.




Figure 23 Digital Signal Processor (DSPM 50) - block diagram

The board requires +5 Vdc, and consumes approximately 250 mA.

### Connections

The MUNAV Digital Signal Processor (DSPM 50) holds two connectors (with place for two more which are not used in the HPR 400 system):

P1	96-pin, male, right-angled Europa connector placed at the back edge of the circuit board
P2	50-pin, male, low-profile flat ribbon cable connector placed at the front edge of the circuit board
P3	Serial line connector - not used
P4	Emulator connector - not used

### Test points

TP1	FIFO Empty flag
-----	-----------------

The user may check basic functions by using an oscilloscope and measure on the following points:

- The HOLD/ signal on U2 pin-2 and RS/ on U2 pin-5. These must both be low when loading the program memory.
- The signal STRB/ on U16 pin-4. A pulse train will be observed when the signal processor is running.

### Links

Lk 1	Normally on - enables D1
Lk 2	Normally on - connects HOLD/ to TMS320C50
Lk 3	Normally on - enables D2
Lk 4	Normally on - connects RS/ from U2
Lk 5	Normally open - selects clock option
Lk 6	Normally open - selects clock option
Lk 7	Used for test, Normally on - connects clock to TMS320C50
Lk 8	Normally open - selects MP or MC mode of TMS320C50
Lk 9	GND
Lk 10	+5 V
Lk 11	Normally A. A selects A14, B selects A15 to program ram P3

### LEDs

LED D1	On when FIFO is empty
LED D2	On when board is running

## Transmitter (TXM)

### Purpose

Two Transmitter (TXM) boards are used in the HPR 400 Transceiver Unit. These are TXM-A and TXM-B. The Transmitter board (TXM) is a general purpose transmitter.

### Board description

The TXM is designed to the single Euro-card standard, and comprises four layers, and contains its own frequency generator, power control and power supply circuits (the board feeds both the Rx and CPU circuit boards when in the Mutran mode).

The two boards used in the system are identical in all respects.

The transmitter board holds two MAX663 voltage regulators which provide the voltages used in the transmitter. It also has a crystal oscillator which is used as the Tx frequency source and a direct numerical synthesizer for generating the correct Tx frequency.




Figure 24 Transmitter circuit board - block diagram

### Front mounted devices

The TXM board holds two test points and two factory-set links on its front edge.

### Socket-mounted components

U5 (PAL)	Programmable I/O controller
----------	-----------------------------

### Connections

The board has one 96-pin, male, right-angled connector (P1) located on the rear edge of the board to link the board into the backplane.

### Test points

The following oscilloscope test points are available to assist the maintenance engineer:

TP1	FTx, 50% duty cycle
TP2	Transmitter pulse, 10 ms, voltage depending on power
TP3	+10 V when POWERON is ON, ( <b>Mutran</b> ). +15 V for <b>Munav</b>
TP4	10 ms burst to Tx driver, duty cycle dep. on power control. +5 V when POWERON is ON
TP5	180° out of phase with TP4"
TP6	+5 V, 10 ms pulse from CPUM
TP7	GND

### Links

The TXM board holds the following links:

LK1	Link 1-2 if U5(Pal) is in use. Normally closed Link 2-3 for external frequency burst
LK2	Link 1-2 if U5(Pal) is in use. Normally closed Link 2-3 for external frequency burst

### Switches

The TXM board holds no switches.

## “Powerbox” AC power supply

This power supply is a sealed unit. In the event of malfunction, replace the unit.

### Purpose

The **POWERBOX ESA-K104U/SS** AC power supply enables the HPR 400 system to be powered from a 230 Vac or 115 Vac supply.

### Board description

The unit is purchased from an external supplier. It is based on a commercially available power supply, though has been altered to Simrad’s specifications. The unit is open to allow cooling air around the components, but is designated “Repair by replacement”. It is designed to be installed in a standard 19 rack.

### Specifications

Operating temperature	0°C to 80°C
Storage temperature	-25°C to +85°C
Efficiency	80% typical
Isolation and safety	To EN 60 950
EMI/RFI standards	To EN 55 022B (VDE 0871 B)

### Electrical characteristics

Note

*To switch between 115 Vac and 230 Vac, use the straps inside the unit.*

### Socket-mounted components

None - this power supply is a sealed unit and must not be “adjusted” by the system maintainer.

### Connections

The power supply unit is plugged into the backplane by a connector comprising fifteen 5 mm spade terminals. The terminals are allocated as follows:



P1 pin allocation 15-pin connection block	
Pin	Signal description
4	+ Vo1
6	+ Vo1
8	+ Vo1
10	+ S
12	- S
14	- Vo1
16	- Vo1
18	- Vo1
20	
22	
24	
26	
28	230 Vac in (L)
30	230 Vac in (N)
32	GND

### Fuses

The unit holds an input fuse, located in the rear of the unit. The fuse is:

- 5 mm x 20 mm, 250 V, 2.5 A, slow-blow

*Caution*

*Other fuses must not be used.*

## Control Processor Unit (CPUEx)

### Purpose

The CPUEx is a single-board computer utilizing the 80386EX microprocessor. The purpose of the board is to control the operation of the transceiver unit.

### Board description

The CPUEx is a standard eight-layer single-Europa board. One edge connector connects to the motherboard. The front edge holds a 34-pin connector, four LEDs, two test points and link Lk7.

The CPUEx is designed as a Control Processor Unit using the 80386EX microprocessor from Intel. The board has sockets for an 80387SL numeric processor and flash memory. The board also holds RAM memory for program and data storage, serial lines, interrupt inputs, general I/O lines and a general bus interface (96-pin Europa connector).

The board contains 6 TTL inputs (ID1 to ID6), 12 TTL outputs (ID9 to ID16 and OUT1 to OUT4), nine external interrupt inputs and six 16-bit timers.

Two separate serial lines with separate programmable baud-rate control are available. Selection between RS-232 and RS-422 is made by links on the inputs. Both serial lines supply RS-232 and RS-422 as outputs at the same time.

### Connections

There are two connectors; one placed at each end of the circuit board.

P1	96-pin, male, right-angled Europa connector
P2	34-pin, male, flat ribbon cable connector

### Test points

TP 1	GND
TP 2	+5 V

### Links

LK 01	Link 1-2 for RS 422 input serial line A Link 2-3 for RS 232 input serial line A
LK 02	Link 1-2 for RS 422 input serial line B Link 2-3 for RS 232 input serial line B
LK 03	Normally closed, software control

LK 04	Ram dependent
LK 05	On = enables D1 - D4
LK 06	On = WD enable
LK 07	Reset connector

**LEDs**

D1 -D4	Software-controlled, front mounted
--------	------------------------------------

**Oscilloscope check points**

The maintenance engineer can check the basic functions by using an oscilloscope and measuring on the following points:

- The signal ADS/ on U16 Pin 3, observe the pulses when the board is (should be) running. Check for one positive pulse to start every instruction cycle.

## Input/output board (IO/M)

### Purpose

The Input/Output board (IO/M) is designed to the single Euro-card circuit board standard. It is designed to interface the most common SSBL and LBL inputs and outputs, such as a vertical reference unit, course gyro, external synchronization and serial lines.

### Board description

The vertical reference unit, gyro and serial line 1 (to the system controller) are galvanically isolated. Serial lines 2 and 3 are dedicated to tracking interface. These serial lines are galvanically isolated on the Serial Interface board, SIF.

Serial line 1 is available with a programmable baud-rate control, coming from the CPU board. Selection between RS-232 and RS-422 is made using links on the inputs. The serial line may also be inverted by links on the board. The serial line may supply RS-232 and RS-422 as outputs simultaneously.

Serial lines 2 and 3 are RS 422 only, controlled by U3, 82530.

U13 is the address buffer for the system bus. It contains two address bits. The bus is available on P1. U5 and U6 are the bidirectional data transceivers. The data bus is also available on P1.

The 82530 (U3) Serial Communication Controller contains two serial lines identified as 2 and 3".

Four analogue inputs are supported, made switchable by means of the U10 multiplexer. Two of the inputs are dedicated for Roll and Pitch inputs from an external vertical reference unit (VRU).

Four analogue outputs are provided. These are originally designated as TVG outputs (Time Varied Gain) to preamplifier boards and/or transducers. The analogue outputs are generated by the D/A converter U20.

One synchro input intended for a course gyro input, and two differential inputs, are provided.

### Front mounted devices

A 50-pin connector, P2, is the only device mounted on the front edge of the board.

### Connections

There are two connectors; one at each end of the circuit board.

P1	96-pin, male, right-angled connector
P2	50-pin, male, flat ribbon cable connector

**Test points**

TP 01	GND
TP 02	Analogue inputs, between multiplexer and AD
TP 03	Pitch
TP 04	Roll
TP 05	VCC
TP 06	VCC1
TP 07	GND1
TP 08	Pitch input
TP 09	VRU common
TP 10	Roll input

LK 01	Link 1-2 for direct Analog_1 input Link 2-3 for Analog_1 input via amplifier.
LK 02	Link 1-2 for direct Analog_2 input Link 2-3 for Analog_2 input via amplifier.
LK 03	Link between analogue and digital ground Normally closed.
LK 04	Digital ground to D/A converter. Normally closed.
LK 05	-5 Vdc to D/A converter.
LK 06	A/D converter 20 V input. Normally closed.
LK 07	A/D converter 10 V input.
LK 08	Link 1-2 for inverted Serial line 1, Tx. Link 2-3 for non-inverted Serial line 1, Tx. Normally closed.
LK 09	Link 1-2 for inverted Serial line 1, Rx. Link 2-3 for non-inverted Serial line 1, Rx. Normally closed.
LK 10	Link 1-2 for RS422 input serial line 1 Normally closed. Link 2-3 for RS232 input serial line 1.
LK 11	Analogue ground to D/A converter.
LK 12	200 Hz reference frequency.
LK 13	100 Hz reference frequency. Normally closed.

R 13	Adjustment of bipolar offset, A/D converter.
R 14	Adjustment of reference voltage A/D converter.

The IO/M board holds no switches.

## Responder controller (RPC) board (option)

### Purpose

The purpose of the responder controller (RPC) board is to provide responder trigger pulses as requested from the Operator Station.

### Board description

The RPC board is located behind the main control panel. It is designed to the single Euro-card standard. The board holds four identical opto-isolated responder trigger circuits, and communicates with the TMC board in the PC via a flat cable.




Figure 25 RPC board

The RPC board's address is set by means of the DIL switch U2.

### Switches

Dil switch U2	Address switch block
---------------	----------------------

- Switches 5 and 6 must be set to **OFF**.
- All other switches in the block must be set to **ON**.

### Front mounted devices

The RPC board carries four fuses and a diode mounted on its front edge.

### Socket-mounted components

The board carries no socket-mounted components.

### Connections

The board holds one connector, P1, located on the back edge of the board. This connects the board into the transceiver unit backplane.

P1	64-pin, male, right-angled connector
----	--------------------------------------

**Test points**

The RPC has no specific test points for use by the maintenance engineer.

**Links**

LK1	Connected only when 24 V is supplied and U16 is not mounted
LK2	Always connected

**LED**

D2	Lights when board is transmitting
----	-----------------------------------

**Fuses**

The board carries four 0.1 A, slow-blow fuses, on the +24 Vdc lines.

## DC power supply (DC - PWR)

The DC-PWR is located second from the right in the rack. The board is designed by Simrad, though the power converter units mounted on the board are bought from an external source.

### Purpose

The purpose of the MUNAV Power Supply (POWERM) is to supply the electronic circuitry with low level DC voltages. The unit can provide several different voltages, in this system 15 Vdc is used.

### Board description

This DC supply is based on EriPower DC-DC converters, which produce the following voltages:

- +5 Vdc
- +15 Vdc
- -15 Vdc

The  $\pm 15$  Vdc is converted to  $\pm 5$  Vdc used for analogue circuitry by means of serial regulators.

Two converters are used, one mounted directly onto the board, the other mounted piggy-back fashion on the solder side of the board. The front of the board comprises a black aluminium heat sink. The 48 Vdc input power to the board can be supplied to two different input lines: DC-IN1 and DC-IN2. The board also holds a 2 A constant current output.

When a TTL level signal is applied to either POWER-ON or POWER-UP, the gate on Q1 will be forced to a low level by Q2. This will set the Q2 to a ON condition, and thus pass this power, supplied to input DC-IN1 or DC-IN2.

### Note

*There is a start-up delay of approximately 40 ms between the arrival of a Power On pulse and a settled +5 Vdc output.*

The constant current block is based on a three-terminal voltage regulator (U1) LM317HV and a serial resistor (R1). The output current will increase until the voltage across R1 is equal to  $V_{REF}$  (1.2 Vdc). A 1  $\Omega$  resistor gives a current of approximately 1.2 A.

The DC-DC converter used is a 25W EriPower PKA4000 series, requiring an input voltage between 39 Vdc and 64 Vdc.



The output data is as follows:

**+5 Vdc output:**

Nominal / maximum load	3.1 A / 5 A
------------------------	-------------

**± 15 Vdc output:**

Nominal / maximum load	0.31 A / 0.8 A
------------------------	----------------

**Warning**

***The total load must never exceed 25 W for each EriPower unit, i.e. 50 W in total.***

To generate the  $\pm 5$  Vdc analogue voltage (AVCC / AVEE) the  $\pm 15$  Vdc outputs from the DC-DC converter are fed to U2 and U3.

**Socket-mounted components**

The board holds no socket mounted components.

**Connections**

The board carries one 96-pin Europa connector to link it into the Transceiver Unit's backplane.

**Test points**

TP1	+ 5 V digital
TP2	Digital ground
TP3	+ 48 V analogue input
TP4	Analogue ground input
TP5	Analogue ground output
TP6	- 15 V analogue output
TP7	+ 5 V analogue output
TP8	+ 15 V analogue output

**Links**

The board has a link field (LKI) comprising four links S1, S2, S3 and S4. These links are used to swap polarity on the DC-DC converted input pins.

A 48 volt supply requires S1 and S3 to be closed.

**Switches**

The board holds no switches.

## TECHNICAL SPECIFICATIONS

### SSBL Accuracy

Transducer type	Accuracy	The specification is based on:
HPR 400 PMT 301, 20-32 kHz: - Wide beam $\pm 80^\circ$	$\leq 2\%$ of slant range	<ul style="list-style-type: none"> <li>• Free line of sight from transducer to transponder.</li> <li>• No influence from ray-bending.</li> <li>• Signal-to-Noise ratio in the receiver beam <math>\geq 20</math> dB. rel. <math>1\mu\text{Pa}</math>.</li> <li>• No error from heading and roll/pitch sensors.</li> </ul>
HPR 400 Standard 20-32 kHz: - Wide beam $\pm 80^\circ$ - Medium beam $\pm 55^\circ$	$\leq 5\%$ of slant range $\leq 2\%$ of slant range	
HPR 400 Narrow beam 20-32 kHz: - Wide beam $\pm 80^\circ$ - Narrow beam $\pm 22.5^\circ$	$\leq 5\%$ of slant range $\leq 1\%$ of slant range	
HPR 400, LF 10-15 kHz: Wide beam $\pm 80^\circ$ Medium beam $\pm 55^\circ$	$\leq 5\%$ of slant range $\leq 2\%$ of slant range	


### LBL accuracy

Transducer type	Accuracy	* The position accuracy for LBL operation depends on:
Dunking, MF 20-32 kHz: - Narrow beam $\pm 50^\circ$	*	<ul style="list-style-type: none"> <li>• Transponder array geometry.</li> <li>• Sound velocity errors.</li> <li>• Signal-to-Noise ratio.</li> </ul> <p>However, the accuracy can be shown by simulations. Range accuracy's down to a few centimetres can be obtained, while ROV and vessel positions can be calculated to within a few decimetres.</p>
Dunking, MF 20-32 kHz: - Wide beam approx $\pm 50^\circ$	*	
Dunking, LF 10-15 kHz: - Beam approx $\pm 50^\circ$	*	
RTD 333, MF 20-32 kHz: - "Doughnut" shape	*	

The following "one sigma" error contribution to the range measurements are assumed (20-30 kHz system):

- Range reception with 20 dB S/N: 0.15 m
- Range reception in the transponder: 0.15 m
- Range error due to TP movement: 0.10 m
- Range error due to rig movement: 0.20 m

The random errors are added as Gaussian noise to the measurements.



(Cd5534)

Figure 26 Error in the horizontal position

The figure shows the error in the horizontal position when the Rig moves within the transponder array. The simulations are done with the following parameters:

- Four LBL transponders placed on the seabed in a circle with radius 636 m.
- The water depth is 1200 m.

The error is showed as a function of the East coordinate. The north coordinate is retained at zero, and the East coordinate zero is consequently the centre of the array. We have assumed that the wide beam of the transducer is used, and that the S/N when receiving the transponder replies is 20 dB. The effect of a systematic error in the Sound velocity of 1 m/s is also showed. When being in the centre of the array, that error causes no position error. When being in the outer parts of the array, that error causes a significant systematic error in the position.

## Range capabilities

The range capabilities depends on:

- Vessels noise level
- Attenuation of the transponder signal level
- Transponder type
- Ray-bending effects may also reduce the operating range.

The figures in the table below are based on 20-32 kHz systems and are approximate values for guidance.

- The HiPAP system will in most cases have longer range capabilities than specified below, due to its narrow receiving beam.

<b>Transponder type/ range capabilities</b>	<b>Operating range</b>	<b>The specification is based on:.</b>
Standard transponder / w/ 188 dB rel.1mPa ref.1m	Typical 1000 m - 1500 m	<ul style="list-style-type: none"> <li>• Free line of sight from transducer to transponder.</li> <li>• No influence from ray-bending.</li> </ul>
High power transponder / w/ 195 dB rel.1mPa ref.1m	Typical 1500 m - 2000 m	<ul style="list-style-type: none"> <li>• Signal-to-Noise ratio in the receiver beam <math>\geq 20</math> dB. rel. 1<math>\mu</math>Pa.</li> </ul>
High power transponder / w/ 206 dB rel.1mPa ref.1m	Typical 2500 m - 4000 m	<ul style="list-style-type: none"> <li>• No error from heading and roll/pitch sensors.</li> </ul>

## HPR 400 portable unit

The HPR 400 Portable unit is a 19 inch wide and 6U high transport housing. This housing has an internal support frame with anti-vibration mounts, where the HPR 400 is mounted.

### Dimensions:

Dimension: W x H x D	530 x 360 x 565 mm
Weight	approx 33 kg

### Frequencies:

Medium Frequency (MF)	21,000 Hz - 32,500 Hz
Low Frequency (LF)	9,500 Hz - 15,750 Hz
Mains supply	230 Vac (110 Vac on request)

### Temperatures:

Operating temperature	-10° to +55°C
Storage temperature	-40° to +70°C

## HPR 400 Transceiver Unit

This is a 3U high, 19 inch rack electronic unit for acoustic signal transmitting and receiving processing.

### Power supply:

Voltage	185 – 264 Vac
Frequency	50-60 Hz
Consumption max.	55 W

### Temperature:

Storage	-20 to +60 °C
Operating	0 to +55 °C

### Humidity:

Storage / operating	90% relative 80% relative
---------------------	---------------------------

### Weight:

19inch/3u rack module	approx. 9 kg
-----------------------	--------------

### Heading reference:

- Synchronous
- Serial RS-422 SKR format
- Serial RS-422 STL format
- Serial RS-422 NMEA format
- Serial RS-422 Seatex MRU or Seapath
- Serial RS -422 DGR format (Tokimec DGR 11)

### Roll and pitch reference:

- Analogue Sine  $\pm 90^\circ \pm 10V$
- Analogue Sine  $\pm 15^\circ \pm 10V$
- Analogue linear  $\pm 60^\circ \pm 10V$
- Analogue Seatex MRU  $\pm 20^\circ \pm 10V$
- Serial RS-422 Seatex MRU or Seapath

**Transducer frequency combinations:**

- 2 SSBL MF and 2 LBL/Telemetry MF
- 2 SSBL LF and 2 LBL/Telemetry LF
- 1 SSBL & 1 LBL/Telemetry MF and/or 1 SSBL & 1 LBL/Telemetry LF

Responder drives	max. 4
Transponders in use	max. 56 (HPR 400) + 14 (HPR 300)
Transponder channels	56 for HPR 400 14 for HPR 300

**Operator station - HSC 400**

→ *Refer to separate manual.*

## Multi-port Serial Adapter for USB (WhiteHEAT-4/USB)

Manufacturer; <http://www.connecttech.com>



Figure 27 Multi-port Serial Adapter

### General:

Dimension: W x H x D	1796 x 381 x 1349 mm
Weight	0.34 kg
Number of ports	4
Interfaces	RS-232
Connectors	four DB-9 male / serial ports one USB type B / host connection
Power requirements	100mA

### Temperatures:

Operating temperature	0° to +70°C
Storage temperature	-65° to +150°C

### Humidity:

Operating temperature	95 % non-condensing
-----------------------	---------------------



## Transducers

### General

This section presents the technical specification for the following transducers:

- PMT 301 - Portable Mini Transducer
- Standard MF (wide/medium beam) Transducer
- MF (wide/narrow beam) Transducer
- LF (wide beam) Transducer
- **Dunking transducers:**
  - MF narrow beam
  - MF wide beam
  - LF narrow beam
- RTD 333 - MF ROV Transducer

### PMT 301 - Portable Mini Transducer

→ *Outline dimensions, refer to page 96.*

Maximum depth rating	50 m
Housing material	Bronze
Weight in air / water	8.6 kg / 6.1 kg
Transducer-cable	Normally delivered with 30 m Optional, specified length
Connector 19-pin female	SOURIAU
Transmission response	173 dB rel 1µPa/W rel 1m at 23 kHz

### Sensor performance

Total range	± 60°
Linear range	± 45°
Threshold	0.001°
<b>linearity:</b>	
- Null to 10°	± 0.1°
- 10° to 45°	± 1%
- 45° to 60°	Monotonic
Null repeatability	0.05°
Cross axis error	0.3 sec
Frequency response (-3dB)	0.5 Hz

RF susceptibility	$< \pm 2^\circ$
Accuracy inclinometer	$0.2^\circ$

- Transducer and transducer-cable are with Souriau underwater connector.
- Delivered with a handy mounting bracket for easy installation onto a pole.
- Inclinometers incorporated for automatic compensation of Roll and Pitch movements. No vertical alignment necessary from the same inclinometers. Can be tilted up to 20 degrees.

### Standard MF (wide/medium beam) transducer

→ *Outline dimensions, refer to page 97.*

Maximum depth rating	50 m
Housing material	Bronze
Weight in air / water	47 kg / 33.2 kg
Transducer cable	Normally delivered with 30 meter Optional, specified length
Connector 19- pin	SOURIAU
Transmission response	180 dB rel 1 $\mu$ Pa/W rel 1m at 23 kHz

### MF (wide/narrow beam) transducer

→ *Outline dimensions, refer to page 98.*

Maximum depth rating	50 m
Housing material	Bronze
Weight in air / water	63 kg / 44.6 kg
Transducer cable	Normally delivered with 30 meter Optional, specified length
Connector 19- pin	SOURIAU
Transmission response	178 dB rel 1 $\mu$ Pa/W rel 1m at 23 kHz

### LF (wide beam) transducer

Same as for the MF (wide/narrow beam) transducer described above.

## Dunking transducers

### MF narrow beam transducer

→ *Outline dimensions, refer to page 99.*

Maximum depth rating	100 m
Housing material	Bronze
Weight in air / water	5 kg / 3 kg
Operating frequency	30 kHz
Beam width	approx. 100° at -6dB
Transmission response	172 dB rel 1 $\mu$ Pa/W rel 1m at 23 kHz
Reception response	-190 dB rel 1V/ $\mu$ Pa

### MF wide beam transducer

→ *Outline dimensions, refer to page 100.*

Maximum depth rating	100 m
Housing material	Bronze
Weight in air / water	3.5 kg / 2.5 kg
Operating frequency	30 kHz
Beam width	approx. 200° at -3dB
Transmission response	172 dB rel 1 $\mu$ Pa/W rel 1m at 23 kHz
Reception response	-190 dB rel 1V/ $\mu$ Pa

### LF transducer

Maximum depth rating	100 m
Housing material	Bronze
Height	355 mm
Diameter (max)	128 mm
Weight in air / water	5 kg / 3.5 kg
Operating frequency	12 kHz
Beamwidth	approx. 100° at -6dB
Transmission response	172 dB rel 1 $\mu$ Pa/W rel 1m at 23 kHz
Reception response	-190 dB rel 1V/ $\mu$ Pa

### RTD 333 - ROV Transducer

→ *Refer to the HPR 400S Instruction manual.*

## SPARE PARTS

### Overview

This document contains the spare part for the HPR 400 Portable units. All parts may be ordered directly from Kongsberg Maritime AS or our appointed dealer.

#### Note

*The lists contain only those items that are most likely to be required; other items may be available on request. Note also that several items may be purchased locally; these items are marked accordingly in the lists.*

## HPR 400 Transceiver unit

Extender board	382-057634
Backplane	382-101504
Input MF	382-088903
Input LF	382-089475
A/D converter (ADCM)	382-083755
Digital Signal Processor (DSPM 50)	382-110358
Control Processor Unit (CPU EX)	382-112510
Input/Output (IO-M)	382-088886
Responder Controller (RPC) (Option)	382-089372
Transmitter (TXM) MF	382-088912
Transmitter (TXM) LF	382-089556
DC power supply (DC-PWR)	382-088945
AC power supply (AC-PWR)	382-086646

### Fuses

Local supply of fuses is recommended. All fuses are “slow-blow”.

Transceiver unit rear panel	6 mm $\varnothing$ x 30 mm, 3.15 A
Transceiver unit rear panel	6 mm $\varnothing$ x 30 mm, 2 A
Responder PCB	5 mm $\varnothing$ x 20 mm, 0.1 A
AC Power supply	5 mm $\varnothing$ x 20 mm, 2.5 A

## Operator station - HSC 400

→ *Refer to the separate manual.*

## WhiteHEAT/USB

Part number	WH4A01
-------------	--------

Manufacturer; <http://www.connecttech.com>

## Standard transducers

Transducer	Type
PMT 301 - Portable Mini Transducer	PMT-089962
Standard MF (wide/medium beam) transducer	TDS-067538
MF (wide/narrow beam) transducer	TDN-081633
LF (wide beam) transducer	TDL-083420

## Dunking transducers

Transducer	Type
MF narrow beam transducer	100-080377
MF wide beam transducer	100-082260
LF transducer	100-102880

## RTD 333 - ROV Transducer

→ *Refer to the HPR 400S Instruction manual.*

## DRAWINGS

### Overview

This section contains some illustrations referred to in various sections in this manual. The illustrations are based on the original system drawings and wiring diagrams.

- All measurements are in mm.
- The illustrations are not in scale.
- The original drawings are available in electronic format (AutoCAD) upon request.

The following drawings are included:

### Cables and interconnections

- HPR 400 Transceiver Unit - internal connections (two pages), page 92.
- Portable transducer cable (without VRU), page 94.
- PMT 301 portable transducer cable, page 95.

### Standard transducers


- Transducer PMT 301 - outline dimensions, page 96.
- Standard MF (Wide/medium beam) transducer - dimensions, page 97.
- MF (wide/narrow beam) transducer - dimensions, page 98.
- LF (wide beam) transducer, - dimensions, page 98.

### Dunking transducers


- MF narrow beam dunking transducer - dimensions, page 99.
- MF wide beam dunking transducer - dimensions, page 100.
- RTD 333 transducer, page 103.

### Miscellaneous


- Proposal of mounting an PMT 301, page 101.
- Proposal of installing an PMT 301, page 102.
- Bracket for HPR mini TD, page 104.
- Brackets for tilt of PMT 300 / 301, page 105.

























*Figure 28 MF narrow beam dunking transducer - dimensions*

(CD3966)





Weight: 3.5 kg (2.5 kg in water)





*Figure 29 MF wide beam dunking transducer - dimensions*














## **INDEX**

The next pages presents the index of this manual.

## Numbers

230 Vac power supply, 18

### A

A/D Converter, 34

AC, 44

AC Power supply, 34

AC power supply, 38, 68

Board description, 68

Connections, 68

Electrical characteristics, 68

Fuses, 69

Purpose, 68

Socket-mounted components, 68

ADCM, 42, 44, 63

Alarm messages, 31

Analog Digital Converter, 42

Analogue digital converter, 63

Board description, 63

Connections, 63

Location and purpose, 63

Analogue I/O, 26

Analogue input/output, 20

APC 10 C computer, 24

APC 10 C computer, 19

APOS, 1, 9, 31

### B

Backplane, 34

Block diagrams:

Digital Signal Processor (DSPM 50), 64

Transmitter circuit board, 66

Braided grounding cable, 18

### C

Cable A, 22

Cable connections, 14

Cable drum, 32

Cables, 17, 22

Cables J, 23

Central Processing Unit, 42

Cleaning the transducers, 33

Com 1, 28

Com 2, 28

Com 3, 28

Computer pin allocations, 28

LPT 1, 28

Connections, 19

Connectors, 17

Control Processing Unit, 34

Control processor unit

Board description, 70

Connections, 70

Test points, 70

Corrective maintenance, 31

CPUEX, 42, 70

CPUEX board, 71

LEDs, 71

Links, 70

Purpose, 70

CPUM, 44

### D

DC, 44

DC Power supply, 34

DC power supply, 76

DC-DC, 76

Design, 40

DGPS, 3

Digital Signal Processor, 34, 42

Digital signal processor board, 64

Board description, 64

Connections, 64

LEDs, 65

Links, 65

Location, 64

Purpose, 64

Test points, 65

Dormant mode, 16

Drawings, 91

Cables and interconnections, 91

Dunking transducers, 91

Miscellaneous, 91

Standard transducers, 91  
 DSPM, 44  
 DSPM 50, 42, 64  
 Dunking transducer, 9, 15  
 Dunking transducers, 87, 90

## E

EMC, 18  
 ENET–M, 43  
 Ethernet, 43  
 Event messages, 31  
 External connections, 40  
 External sensors, 10

## F

Fuses, 19, 38, 89  
 Location, 38  
 Replacement, 38

## G

Getting started, 15  
 Gyro, 10, 26  
 Gyro compass, 14  
 Gyro input, 20

## H

H, 22  
 Heading reference, 82  
 HiPAP, 1  
 How to remove the backplane, 36  
 HPR, 1  
 HPR 400 Narrow beam transducer, 78  
 HPR 400 PMT 301, 78  
 HPR 400 portable systems, 3  
 HPR 400 portable unit, 81  
 HPR 400 Standard transducer, 78  
 HPR 400 Transceiver unit, 89

HPR 400 transceiver Unit, 3  
 HPR 400 transceiver unit, 40  
 HPR 400P cabinet, 8  
 HPR 400P unit, 2  
 HPR 400S, 1  
 HPR 408P, 3, 6, 7  
 HPR 410P, 3, 4  
 HPR 418P, 3, 5  
 HSC 400, 83, 90

## I

I/O, 72  
 Illustrations:  
 15–pin Delta connector, 26  
 25–pin Delta connector, 26, 29  
 9–pin Delta connector, 24, 28  
 Connectors on the Transceiver Unit's rear panel, 19  
 Error in the horizontal position, 79  
 HPR 400 Transceiver Unit – rear side, 14  
 HPR 400 Transceiver unit – functional block diagram, 42  
 HPR 400 Transceiver Unit – internal layout, 45  
 HPR 400P cabinet – rear, 8  
 HPR 408 Portable system, 6, 7  
 HPR 410 / 418 Portable system, 4  
 Multi–port Serial Adapter, 84  
 Operator station and cable, 13  
 Portable cabinet, 2  
 Responder connections, 23  
 Responder connector, 27  
 RPC board, 74  
 Standard cables for a HPR 400 Portable system, 17  
 Transducer 3/4 connector, 27  
 VGA connector, 29  
 Input, 42  
 Input & Output, 43  
 Input M, 34  
 Input/Output, 34  
 Input/output board, 72  
 50–pin connector, 72  
 Board description, 72  
 Connections, 72  
 Front mounted devices, 72  
 Purpose, 72  
 INPUTM, 42



InputM, 61  
Purpose, 61

Interface cables, 14

Internal layout, 44

IOM, 43, 44

## K

K, 22

## L

LBL, 1, 3

LBL accuracy, 78

LF, 1, 90

LF (wide beam), 90

LF transducer, 86, 87

Line Replaceable Units, 34

List of abbreviations, 1

LRUs, 34

LSSBL, 1

## M

Maintenance, 30

Maintenance philosophy, 30

MF, 1

MF (wide/narrow beam), 90

MF narrow beam, 90

MF narrow beam transducer, 87

MF transducer, 86

MF wide beam transducer, 87, 90

Modes, 16

Motherboard, 43

MPT, 1

Multi-port serial adapter , 3

Multi-port Serial Adapter for USB, 84

## N

N/A, 1

Narrow beam transducer, 10

Navigation, 41

## O

Operation, 5

Operator Station, 12

Operator station, 3, 9, 31, 83, 90

## P

Parallel, 25

Parallel input, 20

PMT 301, 9

PMT 301 , 90

PMT 301 – Portable Mini Transducer, 85

PMT 301 Portable Mini Transducer, 15

PMT–301 portable transducer cable, 91

Portable transducer cable, 91

Power supply, 40

POWERM, 76

Preventive maintenance, 30

procedure.□□How to remove a circuit board, 34

PWR, 76

## R

Range capabilities, 80

Rear panel, 19, 38

Replacement of circuit boards, 34, 37

Replacement of the backplane, 37

Replacement of the transducer, 33

Replacement oftransceiver unit parts, 34

Responder, 15

Responder 1, 20

Responder 1 – 4, 27

Responder 2, 20

Responder 3, 20

Responder 4, 20

Responder Controller board, 38

Responder controller board, 74  
  Board description, 74  
  Connections, 74  
  Front mounted devices, 74  
  Fuses, 75  
  LED, 75  
  Links, 75  
  Socket–mounted components, 74  
  Switches, 74  
  Test points, 75  
Responder trigger pulses, 74  
Roll and pitch reference, 82  
ROV, 1  
RPC, 74  
RPC board, 74  
RS 422 Serial line cable, 17  
RTD 333, 90  
RTD 333 – ROV Transducer, 87

## S

Serial 1, 24  
Serial 2, 24  
Serial 3, 24  
Serial 4, 25  
Serial 5, 25  
Serial 6, 25  
Serial line 1, 19  
Serial line 2, 19  
Serial line 3, 19  
Serial line 4, 19  
Serial line 5, 19  
Serial line 6, 20  
Serial line cables, 22  
Serial line to external computer, 14  
Set–up, 12  
Software, 34, 35  
Spare parts, 88  
Specifications, 68  
SSBL, 1, 3  
SSBL Accuracy, 78  
Standard cables, 22

Standard MF, 90  
Standard MF transducer, 86  
Standard transducer, 10  
Standard transducers, 90  
Standby mode, 16  
Startup, 5  
Static electricity, 31  
Syncro, 26  
System description, 2  
System set–up, 11, 12

## T

Technical specifications, 78  
Telemetry, 41  
Test points, 73  
Theory of operation, 41  
Tools, 31  
TP, 1  
Transceiver Uni, 44  
Transceiver Unit, 9, 12, 19, 24, 34, 82  
Transceiver unit, 19, 30, 31  
Transceiver Unit – internal connections, 91  
Transceiver unit connections, 14  
Transceiver Unit pin allocations, 24  
Transducer, 33  
Transducer 1, 20  
Transducer 2, 20  
Transducer 3, 20  
Transducer 4, 20  
Transducer frequency combinations, 83  
Transducers, 9, 15, 85  
Transducers 1 and 2, 27  
Transducers 3 and 4, 27  
Transmitter, 34, 42  
Transmitter board, 66  
  Board description, 66  
  Connections, 67  
  Front mounted devices, 66  
  Links, 67  
  Purpose, 66

Socket–mounted components, 66  
Switches, 67  
Test points, 67  
Transponders, 10  
TU, 1  
TXM, 42, 44, 66

## **U**

USB, 3

## **V**

Vertical reference sensor, 14  
Vertical Reference Unit, 10  
VGA, 29  
VRU, 10, 14

## **W**

WhiteHEAT/USB, 29, 90  
Winch unit, 32

**Blank page**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

**HPR 400P Instruction Manual**

