
Kongsberg EA600 and EA400



KONGSBERG

Information Letter

Input power for GPT

The user manual for EA 600 and EA 400 will not be updated, and any further corrections will be released as information letters.



The input power for the General Purpose Transceiver must be kept between 110 and 250 VAC.

When installing or moving a GPT, make sure the input power is kept between 110 and 250 VAC.